


EN

The Rider 30



- 1 Power / Back**
 - Press and hold to turn the Rider 30 on or off.
 - Press to return to the previous page or cancel an operation.
- 2 Start / Stop**
 - In menu mode, press to enter or confirm a selection.
 - In free cycling mode, press to start recording. Press again to stop recording.
- 3 Mode / Up**
 - Press to switch modes: Meter, Find & Go, Altitude Chart and My Buddy.
 - In menu mode, press to move up to scroll through menu options.

- 4 Lap / Down**
 - In menu mode, press to move down to scroll through menu options.
 - While recording, press to start to record a lap.

Reset the Rider 30

To reset the Rider 30, press and release both and at the same time.

Accessories

The Rider comes with the following accessories:

- USB cable
- Bike mount

Optional items:

- Speed/Cadence sensor
- Power adapter
- Heart rate belt
- Plug(s)

Status Icons


icon	Description
Bike in used	
	Bike 1
	Bike 2
GPS Signal Status	
	No signal (not fixed)
	Weak signal
	Strong signal

Power Status	
	Full battery
	Half battery
	Low battery
	Heart Rate Sensor Active
	Cadence Sensor Active
	Training Plan in Progress
	Log Record in Progress

NOTE: Training Plan and Log Record are displayed only when they are in progress.

Charging the Battery


To charge the battery, connect your Rider 30 to your computer by using USB cable.



Turn on the Rider 30

Press and hold the Power button to turn on the Rider 30 on.

Power button



Acquire Satellite Signals

Once the Rider 30 is turned on, it will automatically search for satellite signals. It may take 30 to 60 seconds to acquire signals.

Initial Setup

When turning the Rider 30 on for the first time, the setup wizard appears on screen. Follow the instructions to complete setup.

1. Select the display language.
2. Select the unit of measurement.
3. Enter your "user profile".

(It is recommended to input the data. The data accuracy will highly affect your training analysis.)

4. Read and accept the Safety Agreement.

NOTE: If you want to change the language on the device, change the setting via Bryton Bridge -> My Rider 30 -> Device Language.

Ride your Bike with Rider 30!

1. Just ride with free cycling mode or set up a training program through Menu options.
2. Press the Mode button to switch modes.
3. Select from the available different modes: Meter, Find & Go, Altitude Chart and My Buddy.
4. In free cycling, press to start recording log, and press again to stop recording.






Manage Rider 30 Data via Your Computer

1. Connect your Rider 30 to your computer by using USB cable.
2. Install the Bryton Bridge application. You can download the application at <http://corp.brytonsport.com/supportSDownload.html> or the bundled CD that includes in the package.
3. Follow the on-screen instructions to transfer data to your computer.


Share Your Experience With Other Bikers

To share your experiences and training result with other bikers around the world, please visit <http://Brytonsport.com>.

Switching Modes



Mount the Rider 30 to the Bike

FR
DE

FR

DE


IT

ES


NL

IT
ES
NL


1




2




3




4



5



6



7

