

**SAFETY**

- Only adults should replace the batteries.
- Do not mix battery types or old and new batteries together.
- Remove exhausted batteries from walkie talkies.
- The supply terminals are not to be short circuited.
- Packaging should be kept as it may contain important information.
- All packaging to be removed before giving to child.

**NOTE:** The working range for these walkie talkies are 2 miles. They work best in open areas however the weather and environment can also effect the range.

**WARNING:**  
**CHOKING HAZARD** -Small parts.  
 Not suitable for children under 3 years.

Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

For body worn operation, this handset has been tested and meets the FCC RF exposure guidelines when used with the accessories supplied or designated for this product. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

Front-of-face : 0.032W/kg

Body-worn : 0.072W/kg

Manufactured and  
Imported by



BROOKLYN, NY 11205  
 www.nesstoy.com  
 © 2018 NESSTOY

**ARMOGEAR**

For Ages  
**5+**

# 2 Mile Range Voice Changer Walkie Talkie

*Owner's Manual*

Item # KL-2106




FCC ID: 2AE67-2106-2907

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
 (1) This device may not cause harmful interference, and  
 (2) This device must accept any interference received, including interference that may cause undesired operation.

**OPERATION**

To power on press the On/Off Button. The Walkie Talkies switch on automatically when the batteries are installed. The walkie talkie will beep and the display will show the current channel number. Press and hold the Voice Changer button to ring other walkie talkies. Press the Voice Changer button to disguise your voice, press it again to make your voice go back to normal. To speak press the Talk Button. Hold the walkie talkie approximately 1.5 - 2 inches from your mouth and speak at a normal volume. Speaking too loud will cause distortion. Release Talk Button after speaking. To change channels press the Channel Selector Button for 2 - 3 seconds. The Channel Indicator will display the selected channel.

**BATTERIES**

To install the batteries release the belt clip locking clip and slide the belt clip vertically off the back of the walkie talkie body. Remove the battery compartment screw and lift the battery door off. Insert (3) AAA batteries as shown in illustration. Replace battery door and secure with screw. Replace belt clip and ensure it's secure.

**TROUBLESHOOTING**

**If you are not receiving a message:** make sure both walkie talkies are switched on and you're not holding the Talk Button while waiting for a message to be heard. If this doesn't work check the batteries. They must be properly installed and in good working order.

**If a message is fading or you hear interference:** make sure the antenna is pointing up. Don't get too close to buildings or large structures. Power lines can also cause interference. Move closer if you're out of range. Keep the walkie talkie 1.5 - 2 inches from your mouth and speak at a normal volume.