



motorola **T325**

Quick Start Guide

D
R
A
F
T

congratulations

The Motorola T325 Portable Bluetooth® Handsfree Car Kit Speaker gives you the freedom to make and receive phone calls in your vehicle while safely keeping your hands on the steering wheel using:


- caller name identification
- automatic power on and off when you enter or leave your vehicle
- direct access to the favorite contacts you use most frequently while in your vehicle.

Caution: Please read the important **Legal & Safety** information at the back of this guide.

Note: Using a mobile device while driving may cause distraction. End a call if you can't concentrate on driving. Also, using a mobile device or accessory may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.


your speaker

Take a moment to familiarize yourself with your new T325 speaker.



charge it

You'll need to charge your speaker before using it.



The indicator light is red while the battery is charging. When the battery is fully charged, the indicator light turns blue.

Note: Speaker is functional while charging.

Note: Your battery is designed to last the life of your product. It should only be removed by a recycling facility. Any attempt to remove or replace your battery will damage your speaker.

connect wirelessly

pair & connect

Let's get your speaker paired and connected to your Bluetooth-enabled phone.

- ➊ Turn off any Bluetooth devices previously paired (linked) with your speaker.
- ➋ Turn on the Bluetooth feature on your phone.
- ➌ Turn on your speaker (see page 8).

The indicator light becomes steadily lit in blue.

- ➍ Set your phone to search for Bluetooth devices.
- ➎ Select **Motorola T325** from the search results on your phone.
- ➏ Select **Ok** or **Yes** to pair your speaker with your phone.

Note: When prompted for the passkey, enter **0000**.

When your speaker successfully pairs and connects with your phone, you hear "*connected to <phone name>*" and you see the indicator light rapidly flash in blue and purple.

connect wirelessly

download phone contacts

Once paired, your speaker automatically downloads contact names and numbers from your phone so that it can announce the name of your incoming caller.

Your phone may first request permission to accept information access. Go ahead and accept so downloading can begin. Once downloading begins, you hear *"downloading caller ID information"*.

The indicator light flashes in purple while downloading. When your downloading is complete (less than 2 minutes), you hear *"download complete"*.

If the download is interrupted, for example by an incoming call, it resumes on the next phone connection.

Note: Your phone must support Bluetooth Phone Book Access Profile (PBAP) for this feature to work.

reconnect

After initially pairing and connecting your phone and speaker, you don't need to do it again.

connect wirelessly

For daily use, make sure your speaker is turned on, and your phone's Bluetooth feature is on. Your speaker and phone will connect automatically!


test your connection

- 1 Slide the speaker onto your visor (see page 7).
- 2 On the phone, dial the number and press the **Call/Send** key.

If your phone and speaker are successfully connected, you hear ringing on the speaker.

install in car

Slide the visor clip onto your sun visor as shown




turn it on & off

You can manually turn your speaker on and off or use the automatic on/off option. The speaker may take up to 4 seconds to power on.

manual on/off

Slide and hold the Power switch to **ⓘ** until you hear a tone, then release.



To turn off your speaker, slide the Power switch to **Ⓛ**. You hear an audio tone when turned off.


turn it on & off

automatic on/off

This feature automatically disconnects the speaker and turns it off when your phone is more than 20 feet away for more than 20 seconds (actual distance is network/phone dependent). When you return, the speaker turns on and connects.

Note: Pressing a button or moving the speaker also turns it on.

To **enable automatic on/off**, just turn your speaker on and leave the Power switch in the center position.



When your speaker turns on or off, you hear an audio tone.

calls

To...	
answer call	Press the Call button.
reject call	Press the Volume Down button.
make a voice dial call	Press the Call button and you hear an audio tone.
make a favorite contact call	Press the Mute/Phonebook button, then press Volume buttons to scroll through your favorite contact list. When you hear the name to call, press the Call button. Note: While your speaker stores up to 1,500 phone contacts, direct access is provided to your top 10 (or 25) favorite contacts.
redial last call	Press and hold the Call button until you hear an audio tone.
mute or unmute a call	Press the Mute/Phonebook button.
end a call	Press the Call button.

calls

To...

transfer call between phone and speaker	Press and hold Mute/Phonebook button until you hear an audio tone.
---	--

Note: Your speaker supports both Handsfree and Headset Profiles. Accessing call functions depends upon which profile your phone supports. See the instructions that came with your phone.

Note: Some call features are phone/network dependent.

status indicator light

with charger plugged in

speaker indicator	speaker status
red	charging
blue	charging complete

with charger not plugged in

speaker indicator	speaker status
off	power off
three blue flashes	powering on/off
steady blue	pairing/connect mode
rapid blue/ purple flashes	connection successful
quick blue flash	incoming/outgoing call
slow blue pulse	connected (on a call)
slow blue flash	standby (connected to phone)

status indicator light

speaker indicator	speaker status
red flash	idle (not connected to a phone)
slow purple pulse	connected call muted
slow purple flash	downloading contacts from phone
steady red	low battery (up to 1.5 hours)

Note: After 15 minutes of inactivity, the light stops flashing to conserve power, but the speaker remains on.

download contacts

phonebook download

You can manually download up to 1,500 phonebook contacts from your phone to your speaker so it can announce the name of your incoming caller.

To do this, press both Call and Mute/Phonebook buttons at the same time until you hear *“downloading caller ID information”* or see your phone requesting for permission to accept information access from your phone.

When download is complete, you hear *“download complete”*.

Note: Your phone must support Bluetooth Phone Book Access Profile (PBAP) for this feature to work.

v-card download

If your phone does not support the Bluetooth PBAP profile, you can manually send up to 50 phonebook contacts from your phone to your speaker.

- 1 Press and hold the Mute/Phonebook button until you hear a tone or *“connection to <phone name> has been dropped, ready to receive V-card”*.

download contacts

- 2 Select your phonebook contacts on your phone and send it to your speaker via Bluetooth (see your phone's user guide for detailed instructions). The indicator light flashes in purple during this step.

When the download is complete, you hear "*connected to <phone name>*" as speaker connects back to the phone. If you have reached the maximum allowable downloaded contacts, you hear "*maximum v-card entries has been reached, connected to <phone name>*".

Note: Your speaker automatically exits phonebook mode after 30 seconds of inactivity (no button presses).

battery check

Press and hold both Volume buttons while not on a call.

voice prompt	available talk time
<i>"battery level is very low. Please recharge now"</i>	up to 1.5 hours
<i>"battery level is low"</i>	up to 6 hours
<i>"battery level is medium"</i>	up to 13 hours
<i>"battery level is high"</i>	over 16 hours

personalize

You can change settings on your speaker. To do this, turn off your speaker, then press and hold the Call button and move the Power switch to the **ⓘ** position until you hear *"welcome to setup."*

Follow the voice prompts to change settings for:

- Language
- Enable/disable voice prompts
- Enable/disable Name/Number Caller ID feature
- Size of favorite contact list (10 or 25)

restore to factory settings

Caution: This action erases all pairing information stored in your speaker.

To restore your speaker to original factory settings:

- 1 Turn off your speaker.
- 2 Press and hold both the Mute/Phonebook and one of the volume buttons.
- 3 Slide and hold the Power switch in the ① position.

When complete, you hear a tone or *“restored to default settings.”*

battery saving

To conserve battery power, your speaker turns off when not connected to your phone for more than 30 minutes.

problems?

My speaker will not enter pairing mode.

Make sure that any devices previously paired with the speaker are turned off. If the indicator light is not steadily blue, turn off the other device. Press and hold the Mute/Phonebook and Volume Up buttons until you hear “*pairing mode*.” The indicator light changes to steady blue indicating the speaker is now in pairing mode.

My phone does not find my speaker.

Make sure the indicator light on your speaker is on (lit in blue) and steady when your phone is searching for devices (see “pair & connect” on page 4).

My speaker worked with my phone before but now they are not working.

Make sure your phone is on and the Bluetooth feature is turned on in your phone. If the Bluetooth feature was turned off or was turned on only temporarily, you may need to repeat steps on page 4 to start the Bluetooth feature and pair your phone and speaker again.

After downloading my phonebook contacts, I am unable to access all the phonebook contacts in my speaker in phonebook mode.

For your convenience, your speaker supports accessing and dialing your favorite contacts (with your choice of 10

problems?

or 25 entries) instead of needing to scroll through all 1,500 possible contacts.

My speaker will not download phonebook contacts.

Some phones may not support phonebook downloading. In that case, you can download selected phonebook contacts (see page 14).

European Union Directives Conformance Statement



Hereby, Motorola declares that this product is in compliance with:

- The essential requirements and other relevant provisions of Directive 1999/5/EC
- All other relevant EU Directives

IMEI: 350034/40/394721/9



Type: MC2-41H14

Product
Approval
Number

The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at www.motorola.com/rtte. To find your DoC, enter the Product Approval Number from your product's label in the "Search" bar on the Web site.

Software Copyright Notice

Motorola products may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Safety & General Information



IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION. READ THIS INFORMATION BEFORE USING YOUR DEVICE.

Approved Accessories

Use of accessories not approved by Motorola, including but not limited to batteries, antennas, and convertible covers, may cause your mobile device to exceed RF energy exposure guidelines and may void your mobile device's warranty. For a list of approved Motorola accessories, visit our Web site at: www.motorola.com

Batteries & Chargers

Your battery, charger, or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not let your battery, charger, or mobile device get wet.

Use & Safety for Battery-Powered Accessories

- Do not store or use your battery-powered accessory (such as a Bluetooth® headset or other device) in temperatures below -10°C (14°F) or above 60°C (140°F).
- Do not recharge your accessory in temperatures below 0°C (32°F) or above 45°C (113°F).
- Conditions inside a parked car can exceed this range. Do not store your accessory in a parked car.
- Do not store your accessory in direct sunlight.
- Storing your fully charged accessory in high-temperature conditions may permanently reduce the life of the internal battery.
- Battery life may temporarily shorten in low-temperature conditions.

Caution About High Volume Usage

Warning: Exposure to loud noise from any source for extended periods of time may temporarily or permanently affect your hearing. The louder the volume sound level, the less time is required before your hearing could be affected. Hearing damage from loud noise is sometimes undetectable at first and can have a cumulative effect. To protect your hearing:

- Start your volume control at a low setting and use as low a volume as possible.
- Limit the amount of time you use headsets or headphones at high volume.
- Where possible, use your headset in a quiet environment with low background noise.
- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can't hear people speaking near you.

If you experience hearing discomfort, including the sensation of pressure or fullness in your ears, ringing in your ears, or muffled speech, you should stop listening to the device through your headset or headphones and have your hearing checked by your doctor.

Smart Practices While Driving

Using a mobile device while driving may cause distraction. End a call if you can't concentrate on driving. Also, using a mobile device or accessory may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Responsible driving practices can be found at www.motorola.com/callsmart (in English only).

Industry Canada Notice to Users

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device. See RSS-GEN 7.1.5.

FCC Notice to Users

The following statement applies to all products that have received FCC approval. Applicable products bear the FCC logo, and/or an FCC ID in the format FCC-ID:xxxxxx on the product label.

Motorola has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Motorola Limited Warranty for the United States and Canada

What Does This Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

Products and Accessories

Products Covered	Length of Coverage
Products and Accessories as defined above, unless otherwise provided for below.	One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.
Decorative Accessories and Cases. Decorative covers, bezels, PhoneWrap™ covers and cases.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Monaural Headsets. Ear buds and boom headsets that transmit mono sound through a wired connection.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Consumer and Professional Two-way Radio Accessories.	Ninety (90) days from the date of purchase by the first consumer purchaser of the product.

Products Covered	Length of Coverage
Products and Accessories that are Repaired or Replaced.	The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.

Exclusions (Products and Accessories)

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

Use of Non-Motorola Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

Software

Products Covered	Length of Coverage
Software. Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	Ninety (90) days from the date of purchase.

Exclusions (Software)

Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

Software NOT Embodied in Physical Media. Software that is not embodied in physical media (e.g. software that is downloaded from the Internet), is provided "as is" and without warranty.

Who is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information

USA	Phones: 1-800-331-6456 Pagers: 1-800-548-9954 Two-Way Radios and Messaging Devices: 1-800-353-2729
------------	--

Canada	All Products: 1-800-461-4575
TTY	1-888-390-6456
For Accessories and Software , please call the telephone number designated above for the product with which they are used.	

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly, (e) your address and telephone number.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Product Registration

Online Product Registration:

www.motorola.com/us/productregistration

Product registration is an important step toward enjoying your new Motorola product. Registering permits us to contact you for product or software updates and allows you to subscribe to updates on new products or special promotions. Registration is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Caring for the Environment by Recycling

This symbol on a Motorola product means the product should not be disposed of with household waste.



Disposal of your Mobile Device & Accessories

Please do not dispose of mobile devices or electrical accessories (such as chargers, headsets, or batteries) with your household waste. Do not dispose of your battery or mobile device in a fire. These items should be disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any Motorola Approved Service Center in your region.



Details of Motorola approved national recycling schemes, and further information on Motorola recycling activities can be found at: www.motorola.com/recycling

Disposal of your Mobile Device Packaging & Product Guide

Product packaging and product guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

DRAFT

Motorola, Inc.
Consumer Advocacy Office
600 N. US Hwy 45
Libertyville, IL 60048

www.motorola.com

Note: Do not ship your accessory product to the above address. If you need to return your product for repairs, replacement, or warranty service, please contact the Motorola Customer Support Center at:

1-877-MOTOBLU (Motorola Bluetooth Support)

1-800-331-6456 (United States)

1-888-390-6456 (TTY/TDD United States for hearing impaired)

1-800-461-4575 (Canada)

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. All other product and service names are the property of their respective owners.

© 2009 Motorola, Inc. All rights reserved.

Bluetooth QD ID: B015177

Manual Number: 68000201109-A

www.motorola.com

