

Microsoft RADIUS support

This feature allows to configure Microsoft RADIUS (Network Policy and Access Services a.k.a NPS) as Authentication server for SM and User authentication.

- For SM Authentication, SM will use PEAP-MSCHAPv2 since NPS doesn't support TTLS protocol.
- For User Authentication, the Canopy software will use EAP-MD5 but the user has to do certain configuration in order to enable EAP-MD5 on NPS.



Note

All this configuration has been tested on Windows Server 2012 R2 version.


This feature is not supported on hardware board type P9 or lower platforms.

SM Authentication Configuration

There are no new configuration on AP. However SM has to be configured for PEAP authentication protocol.

1. Go to Configuration > Security page
2. Select "**eappeap**" for Phase 1 attribute under tab AAA Authentication Settings.

Figure 139 EAPPEAP settings



The Phase 2 will change automatically to MSCHAPv2 on select of Phase 1 attribute as EAP-PEAP. Other parameters of Phase 2 protocols like PAP/CHAP will be disabled.

Windows Server Configuration

Import Certificate

The SM certificate has to be imported to Windows Server for certificate authentication.


1. Copy the certificate which is configured in SM under **Configuration > Security -> Certificate1** to Windows Server machine.
2. Right click and select 'Install Certificate'. This will install the certificate and it's ready for use. This certificate will be used while configuring PEAP-MSCHAPv2 in NPS.

NPS Configuration (<https://technet.microsoft.com/en-us/network/bb545879.aspx>)

Following **items** should be configured in NPS Console:

- RADIUS Client
 - <https://technet.microsoft.com/en-us/library/cc732929>
- Connection Request Policies
 - <https://technet.microsoft.com/en-us/library/cc730866>
 - Choose 'Wireless-Other' in NAS-Port-Type
- Network Policy
 - <https://technet.microsoft.com/en-us/library/cc755309>
 - Choose 'Wireless-Other' in NAS-Port-Type.
 - While configuring PEAP, select the above imported certificate.

Figure 140 Importing certificate in NPS




User Authentication Configuration

Enabling EAP-MD5

As mentioned earlier, Microsoft has deprecated the support for MD5 from versions of Windows. To enable MD5, the following steps to be followed:

1. Follow the instructions:
 - <https://support.microsoft.com/en-us/kb/922574/en-us?wa=wsignin1.0>
 - Optionally, the [registry file](#) can be downloaded. It can be installed by double-click it in Windows Registry.
2. From NPS Console **Network Policy** > <Policy Name> > **Properties** > **Constraints** > **Authentication Method** and click Add. Select MD5 and click OK.

Figure 141 Selecting MD5 from NPS console




User Configuration in Active Directory

Next open 'Active Directory Users and Computers' and create user.

Make sure user property is configured as shown below.

Figure 142 User configuration



RADIUS VSA Configuration


Before using VSA, the **Cambium-Canopy-UserLevel(50)** VSA must be configured with some access level say ADMIN(3),

Follow below link for configuring VSA:

<https://technet.microsoft.com/en-us/library/cc731611>

The Cambium's vendor code is 161.

Figure 143 RADIUS VSA configuration



Accounting

User can enable accounting in NPS under **NPS Console > Accounting > Configure Accounting**.

For more details refer <https://technet.microsoft.com/library/dd197475>

Cisco ACS RADIUS Server Support

This briefly explains how to configure Cisco ACS RADIUS server for PEAP-MSCHAPv2 authentication.

The configuration had been tested on **CISCO ACS Version : 5.7.0.15**


Adding RADIUS client

Figure 144 Adding RADIUS client




Creating Users

Figure 145 Creating users




Creating RADIUS instance

Figure 146 Creating RADIUS instance



RADIUS protocols

Figure 147 RADIUS protocols




Service selection

Figure 148 Service selection



Adding Trusted CA

Figure 149 Adding Trusted CA




Note that certificate has to be in DER form, so if you have in PEM format convert using openssl.

```
openssl.exe x509 -in <path-to>/cacert aaasvr.pem -outform DER -out <path-to>/cacert aaasvr.der
```

Installing Server Certificate

After installing trusted CA, you need to add a server certificate which will be used for TLS tunnel. Generally you have to install same certificate which is installed in your AP, so that AP can trust the radius server.

Figure 150 Installing Server Certificate



Monitoring Logs

Figure 151 Monitoring logs



Configuring VSA

Before using VSA , user has to add Cambium Vendor Specific Attribute

Navigate to System Administration > Configuration > Dictionaries > Protocols > RADIUS > RADIUS VSA > Motorola

If Motorola is not present you can create Vendor with ID 161

Add all the VSA one by one


Figure 152 VSA list

<input type="checkbox"/>	Attribute	ID	Type	Direction	Multiple Allowed
<input type="checkbox"/>	Cambium-Canopy-BCASTMIR	24	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-DLBLE	9	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-DLBR	8	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-DLMB	27	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-Gateway	25	IP Address	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-HPDLCIR	4	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-HPENABLE	5	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-HPULCIR	3	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-LPDLCIR	2	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-LPULCIR	1	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-ULBLE	7	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-ULBR	6	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-ULMB	26	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-UserLevel	50	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-UserMode	51	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-VLAGETO	20	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-VLFRAMES	15	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-VLIDSET	16	Unsigned Integer 32	BOTH	true
<input type="checkbox"/>	Cambium-Canopy-VLIGVID	21	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-VLLEARNEN	14	Unsigned Integer 32	BOTH	false
<input type="checkbox"/>	Cambium-Canopy-VLMGVID	22	Unsigned Integer 32	BOTH	true
<input type="checkbox"/>	Cambium-Canopy-VLSMMGPASS	23	Unsigned Integer 32	BOTH	false


Using VSA for users

Navigate to Access Policies > Access Services > Cambium ACS > Authorization


1. Change condition to User name



2. Next click Create and then click Select see diagram below





3. Click Create from the screen you get following screen




Chose some name and then move to RADIUS Attributes tab

4. Fill attribute which all you want for that particular user



Important: Click Add for each attribute and when done click Submit.

- Now you are ready to use this Authorization profile for the use
Select and Press OK



- Finally press Save Changes and you are ready to use it.

Chapter 8: Tools

The AP and SM GUIs provide several tools to analyze the operating environment, system performance and networking, including:

- [Using Spectrum Analyzer tool](#) on page 8-2
- [Using the Alignment Tool](#) on page 8-15
- [Using the Link Capacity Test tool](#) on page 8-21
- [Using AP Evaluation tool](#) on page 8-27
- [Using BHM Evaluation tool](#) on page 8-31
- [Using the OFDM Frame Calculator tool](#) on page 8-35
- [Using the Subscriber Configuration tool](#) on page 8-39
- [Using the Link Status tool](#) on page 8-40
- [Using BER Results tool](#) on page 8-45
- [Using the Sessions tool](#) on page 8-46

Using Spectrum Analyzer tool

The integrated spectrum analyzer can be very useful as a tool for troubleshooting and RF planning, but is not intended to replicate the accuracy and programmability of a high-end spectrum analyzer, which sometime can be used for other purposes.

The AP/BHM and SM/BHS perform spectrum analysis together in the Sector Spectrum Analyzer tool.



Caution

On start of the Spectrum Analyzer on a module, it enters a scan mode and drops any RF connection it may have had. When choosing **Start Timed Spectrum Analysis**, the scan is run for the amount of time specified in the **Duration** configuration parameter. When choosing **Start Continuous Spectrum Analysis**, the scan is run continuously for 24 hours, or until stopped manually (using the **Stop Spectrum Analysis** button).

Any module can be used to see the frequency and power level of any detectable signal that is within, just above, or just below the frequency band range of the module.



Note

Vary the days and times when you analyze the spectrum in an area. The RF environment can change throughout the day or throughout the week.

Mapping RF Neighbor Frequencies

The neighbor frequencies can be analyzed using Spectrum Analyzer tool. Following modules allow user to:

- Use a BHS or BHM for PTP and SM or AP for PMP as a Spectrum Analyzer.
 - View a graphical display that shows power level in RSSI and dBm at 5 MHz increments throughout the frequency band range, regardless of limited selections in the **Custom Radio Frequency Scan Selection List** parameter of the SM/BHS.
 - Select an AP/BHM channel that minimizes interference from other RF equipment.
-



Caution

The following procedure causes the SM/BHS to drop any active RF link. If a link is dropped when the spectrum analysis begins, the link can be re-established when either a 15 minute interval has elapsed or the spectrum analyzer feature is disabled.

Temporarily deploy a SM/BHS for *each* frequency band range that need to monitor and access the Spectrum Analyzer tab in the Tools web page of the module.

- Using Spectrum Analyzer tool
- Using the Remote Spectrum Analyzer tool

Spectrum Analyzer tool


Analyzing the spectrum

To use the built-in spectrum analyzer functionality of the AP/SM/BH, proceed as follows:

Procedure 29 Analyzing the spectrum

- 1 Predetermine a power source and interface that works for the AP/SM/BH in the area to be analyzed.
- 2 Take the AP/SM/BH, power source and interface device to the area.
- 3 Access the **Tools** web page of the AP/SM/BH.
- 4 Enter **Duration** in Timed Spectrum Analyzer Tab. Default value is 10 Seconds
- 5 Click **Start Timed Sector Spectrum Analysis**
- 6 The results are displayed:

Figure 153 Spectrum analysis - Results



Note

AP/SM/BH scans for extra 40 seconds in addition to configured **Duration**

- 7 Travel to another location in the area to BHS.
- 8 Click **Start Timed Spectrum Analysis**

- 9 Repeat Steps 4 and 6 until the area has been adequately scanned and logged.

As with any other data that pertains to your business, a decision today to put the data into a retrievable database may grow in value to you over time.

**Note**

Whenever the operator find the measured noise level is greater than the sensitivity of the radio that is plan to deploy, use the noise level (rather than the link budget) for your link feasibility calculations.

The AP/SM/BH perform spectrum analysis together in the Sector Spectrum Analyzer feature.

Graphical spectrum analyzer display

The AP/SM/BH display the graphical spectrum analyzer. An example of the **Spectrum Analyzer** page is shown in [Figure 153](#).

The navigation feature includes:

- Results may be panned left and right through the scanned spectrum by clicking and dragging the graph left and right
- Results may be zoomed in and out using mouse

When the mouse is positioned over a bar, the receive power level, frequency, maximum and mean receive power levels are displayed above the graph

To keep the displayed data current, either set "Auto Refresh" on the module's **Configuration > General**.

Spectrum Analyzer page of AP

The Spectrum Analyzer page of AP is explained in [Table 166](#).

Table 166 Spectrum Analyzer page attributes - AP

Results	
Spectrum Analysis not performed. Receiver Channel Bandwidth: 10.0 MHz System time at start of analysis: Site Name: Site Name Location: Site Location Contact: Site Contact	
Display Data Path :	Both ▼
Data :	File does not exist.
Display :	<input type="radio"/> Instantaneous <input checked="" type="radio"/> Averaging <input type="button" value="Stop Spectrum Analysis"/>
Min And Max Frequencies	
Min and Max Frequencies in KHz :	5470000 5900000 (Valid Range in KHz: 4900000 - 5925000)
<input type="button" value="Set Min And Max To Full Scan"/> <input type="button" value="Set Min And Max To Center Scan +/-40MHz"/>	
Access Point Stats	
Registered SM Count :	0 (0 Data VCs)
Maximum Count of Registered SMs :	0
Spectrum Analyzer Options	
SM Scanning Bandwidth :	5.0 MHz ▼
Note: Only SM changing channel bandwidth is currently supported. AP will scan at current channel bandwidth	
Timed Spectrum Analyzer	
Duration :	10 Seconds (10—1000)
<input type="button" value="Start Timed Sector Spectrum Analysis"/>	
Note: AP scans for extra 40 seconds	
Continuous Spectrum Analyzer	
<input type="button" value="Start Continuous Spectrum Analysis"/>	
Note: Continuous Spectrum Analysis has a max of 24 hours and afterwards will automatically resume transmitting.	

Attribute	Meaning
Display Data Path	Both means that the vertical and horizontal paths are displayed or an individual path may be selected to display only a single-path reading.
Data	For ease of parsing data and to facilitate automation, the spectrum analyzer results may be saved as an XML file. To save the results in an XML formatted file, right-click the "SpectrumAnalysis.xml" link and save the file.
Display	<p>Instantaneous means that each reading (vertical bar) is displayed with two horizontal lines above it representing the max power level received (top horizontal line) and the average power level received (lower horizontal line) at that frequency.</p> <p>Averaging means that each reading (vertical bar) is displayed with an associated horizontal line above it representing the max power level received at that frequency.</p>
Registered SM Count	This field displays the MAC address and Site Name of the registered SM.
Maximum Count of Registered SMs	This field displays the maximum number of registered SMs.

Duration	This field allows operators to configure a specified time for which the spectrum is scanned. If the entire spectrum is scanned prior to the end of the configured duration, the analyzer will restart at the beginning of the spectrum.
Continuous Spectrum Analyzer	Start Continuous Spectrum Analysis button ensures that when the SM is powered on, it automatically scans the spectrum for 10 seconds. These results may then be accessed via the Tools > Spectrum Analyzer GUI page.

Spectrum Analyzer page of SM


The Spectrum Analyzer page of SM is explained in [Table 167](#).

Table 167 Spectrum Analyzer page attributes - SM

Results

Timed Spectrum Analysis complete for 10 seconds.
 Receiver Channel Bandwidth: 5.0 MHz
 System time at start of analysis: 20:22:03 08/24/2015 IST
 Site Name: Site Name Location: Site Location Contact: Site Contact

Spectrum Summary



Display Data Path : Both

Data : [SpectrumAnalysis.xml](#)

Display : Instantaneous Averaging

Min And Max Frequencies

Min and Max Frequencies in KHz : (Valid Range in KHz: 4900000 - 5925000)

Subscriber Module Stats

Session Status : REGISTERED VC 18 Rate 8X/8X MIMO-B
 Registered AP : [0a-00-3e-bb-00-fb](#) Site Name

Spectrum Analyzer Options

Scanning Bandwidth : 5.0 MHz

Timed Spectrum Analyzer

Duration : Seconds (10—1000)

Perform Spectrum Analysis on Boot Up for One Scan : Enable Disable

Continuous Spectrum Analyzer


Note: Continuous Spectrum Analysis has a max of 24 hours and afterwards will automatically resume scanning for APs.

Attribute	Meaning
Display Data Path	Refer Table 166 on page 8-5
Data	Refer Table 166 on page 8-5
Display	Refer Table 166 on page 8-5
Min and Max Frequencies in KHz	To scan min to max range of frequencies, enter min and max frequencies in KHz and press Set Min and Max to Full Scan button. To scan +/- 40 MHz from center frequency, enter center frequency in KHz and press Set Min And Max To Center Scan +/- 40KHz button.
Registered SM Count	Refer Table 166 on page 8-5
Maximum Count to Registered SMs	Refer Table 166 on page 8-5
Duration	Refer Table 166 on page 8-5

Spectrum Analyzer page of BHM

The Spectrum Analyzer page of BHM is explained in [Table 168](#).

Table 168 Spectrum Analyzer page attributes - BHM



Attribute	Meaning
Data	Refer Table 166 on page 8-5
Display	Refer Table 166 on page 8-5
Duration	Refer Table 166 on page 8-5
Continuous Spectrum Analyzer	Refer Table 166 on page 8-5

Spectrum Analyzer page of BHS

The Spectrum Analyzer page of BHS is explained in [Table 169](#).

Table 169 Spectrum Analyzer page attributes - BHS

Results

Sector Spectrum Analysis complete for 10 seconds.
 Receiver Channel Bandwidth: 5.0 MHz
 System time at start of analysis: 18:24:51 08/25/2015 IST
 Site Name: No Site Name Location: No Site Location Contact: No Site Contact

Spectrum Summary

Display Data Path : Both ▼

Data : [SpectrumAnalysis.xml](#)

Display :
 Instantaneous
 Averaging

Min And Max Frequencies

Min and Max Frequencies in KHz : (Valid Range in KHz: 4900000 - 5925000)

Backhaul Stats

Timing Slave Status : Connected

Timing Slave Stats

Session Status : REGISTERED VC 18 Rate 8X/1X MIMO-A VC 255 Rate 8X/1X MIMO-B

Registered Backhaul : [0a-00-3e-bb-00-fb](#) No Site Name

Spectrum Analyzer Options

Scanning Bandwidth : 5.0 MHz ▼

Timed Spectrum Analyzer

Duration : Seconds (10—1000)

Perform Spectrum Analysis on Boot Up for One Scan :
 Enable
 Disable

Continuous Spectrum Analyzer


Note: Continuous Spectrum Analysis has a max of 24 hours and afterwards will automatically resume scanning for BHM's.

Attribute	Meaning
Data	Refer Table 166 on page 8-5
Display	Refer Table 166 on page 8-5
Session Status	This field displays current session status and rates. The session states can be Scanning, Syncing, Registering or Registered.
Registered Backhaul	This field displays MAC address of BHM and PTP model number
Duration	Refer Table 166 on page 8-5

Perform Spectrum Analysis on Boot Up for one scan	This field allows to Enable or Disable to start Spectrum Analysis on boot up of module for one scan.
Continuous Spectrum Analyzer	Refer Table 166 on page 8-5

Spectrum Analyzer page result of PMP 450 SM

Figure 154 Spectrum Analyzer page result – PMP 450 SM



Remote Spectrum Analyzer tool

The Remote Spectrum Analyzer tool in the AP/BHM provides additional flexibility in the use of the spectrum analyzer in the SM/BHS. Set the duration of 10 to 1000 seconds, then click the **Start Remote Spectrum Analysis** button to launch the analysis from that SM/BHS.

In PMP configuration, a SM has to be selected from the drop-down list before launching **Start Remote Spectrum Analysis**.

Analyzing the spectrum remotely

Procedure 30 Remote Spectrum Analyzer procedure

- 1 The AP/BHM de-registers the target SM/BHS.
- 2 The SM/BHS scans (for the duration set in the AP/BHM tool) to collect data for the bar graph.
- 3 The SM/BHS re-registers to the AP/BHM.
- 4 The AP/BHM displays the bar graph.

The bar graph is an HTML file, but can be changed to an XML file, which is then easy to analyze through the use of scripts that you may write for parsing the data. To transform the file to XML, click the "SpectrumAnalysis.xml" link below the spectrum results. Although the resulting display appears mostly unchanged, the bar graph is now coded in XML. You can now right-click on the bar graph for a **Save Target As** option to save the `Spectrum Analysis.xml` file.

Remote Spectrum Analyzer page of AP

The Remote Spectrum Analyzer page of AP is explained in [Table 170](#).

Table 170 Remote Spectrum Analyzer attributes - AP

Access Point Stats

Registered SM Count :	1 (1 Data VCs)
Maximum Count of Registered SMs :	1

Configuration

Current Subscriber Module :	Site Name [0a003ebb0104]Luid: 2 ▼
Duration :	10 Seconds (10—1000)
Scanning Bandwidth :	5.0 MHz ▼
<input type="button" value="Start Remote Spectrum Analysis"/>	

Remote Results

Timed Spectrum Analysis complete for 10 seconds.
 Receiver Channel Bandwidth: 5.0 MHz
 System time at start of analysis: 20:22:03 08/24/2015 IST
 Site Name: Site Name Location: Site Location Contact: Site Contact

Spectrum Summary


Display Data Path :	Both ▼
Data :	SpectrumAnalysis.xml
Display :	<input type="radio"/> Instantaneous <input checked="" type="radio"/> Averaging

Attribute	Meaning
Registered SM Count	This field displays the number of SMs that were registered to the AP before the SA was started. This helps the user know all the SMs re-registered after performing a SA.
Maximum Count of Registered SMs	This field displays the largest number of SMs that have been simultaneously registered in the AP since it was last rebooted. This count can provide some insight into sector history and provide comparison between current and maximum SM counts at a glance.
Current Subscriber Module	The SM with which the Link Capacity Test is run.
Duration	This field allows operators to configure a specified time for which the spectrum is scanned. If the entire spectrum is scanned prior to the end of the configured duration, the analyzer will restart at the beginning of the spectrum.
Scanning Bandwidth	This parameter defines the size of the channel scanned when running the analyzer.

Remote Spectrum Analyzer page of BHM

The Remote Spectrum Analyzer page of BHM is explained in [Table 171](#).

Table 171 Remote Spectrum Analyzer attributes - BHM



Attribute	Meaning
Duration	Refer Table 166 on page 8-5

Using the Alignment Tool

The SM's or BHS's Alignment Tool may be used to maximize Receive Power Level, Signal Strength Ratio and Signal to Noise Ratio to ensure a stable link. The Tool provides color coded readings to facilitate in judging link quality.



Note

To get best performance of the link, the user has to ensure the maximum Receive Power Level during alignment by pointing correctly. The proper alignment is important to prevent interference in other cells. The achieving Receive Power Level green (> -70 dBm) is not sufficient for the link.

Figure 155 Alignment Tool tab of SM – Receive Power Level > -70 dBm




Figure 156 Alignment Tool tab of SM – Receive Power Level between -70 to -80 dBm





Figure 157 Alignment Tool tab of SM – Receive Power Level < -80 dBm



Aiming page and Diagnostic LED – SM/BHS

The SM's/BHS's Alignment Tool (located in GUI **Tools** -> **Aiming**) may be used to configure the SM's/BHS's LED panel to indicate received signal strength and to display decoded beacon information/power levels. The SM/BHS LEDs provide different status based on the mode of the SM/BHS. A SM/BHS in "operating" mode will register and pass traffic normally. A SM/BHS in "aiming" mode will not register or pass traffic, but will display (via LED panel) the strength of received radio signals (based on radio channel selected via **Tools** ->**Aiming**).. See [SM/BHS LEDs](#) on page 2-13.



Note

In order for accurate power level readings to be displayed, traffic must be present on the radio link.

Refer [Table 19 SM/BHS LED descriptions](#) on page 2-14 for SM/BHS LED details.

Aiming page of SM

The Aiming page is similar to Spectrum Analyzer where it scans the spectrum but it does not establish any session with any Aps. It has two modes – Single Frequency Only and Normal Frequency Scan List.

The Aiming page of SM is explained in [Table 172](#).

Table 172 Aiming page attributes – SM

Tools → Aiming	
5.4/5.7GHz MIMO OFDM - Subscriber Module - 0a-00-3e-a0-a0-66	
Alignment mode	
<div style="border: 1px solid black; padding: 5px;"> <p>Aiming Configuration</p> <p>Aiming Mode : <input type="radio"/> Single Frequency Only <input checked="" type="radio"/> Normal Frequency Scan List <small>Note: No beacon information is decoded for 'Single Frequency Only' mode</small></p> <p>Single Frequency : <input type="text" value="None"/> <input type="button" value="Enable Aiming Mode"/> <input type="button" value="Disable Aiming Mode"/></p> <p style="text-align: center;">Aiming Mode will be enabled for 15 minutes or until disabled.</p> </div>	
<div style="border: 1px solid black; padding: 5px;"> <p>Aiming Status</p> <p>Current Status : SM is in Alignment Mode for selected frequencies</p> </div>	
<div style="border: 1px solid black; padding: 5px;"> <p>Aiming Results</p> <p>Current entry: Frequency: 5745.000 MHz Power: -31.9 (-50.0 V / -32.0 H) dBm Users: 1 ESN: 0a-00-3e-a1-35-75 Color Code: 0 Multipoint</p> <hr/> <p>Other entries: Frequency: 5680.000 MHz Power: -36.5 (-42.0 V / -38.0 H) dBm ESN: 0a-00-3e-a0-aa-9a Color Code: 5 Backhaul</p> <hr/> <p>Frequency: 5740.000 MHz Power: -77.8 (-91.0 V / -78.0 H) dBm Users: 2 ESN: 0a-00-3e-a0-08-08 Color Code: 0 Multipoint</p> </div>	
Attribute	Meaning
Aiming Mode	<p>Single Frequency Only: scans only selected single frequency.</p> <p>Normal Frequency Scan List: scans: scans all frequency of scan list.</p>
Single Frequency	Select a particular frequency from drop down menu for scanning.
Scan Radio Frequency Only Mode	<p>Enabled: the radio is configured to “aiming” or “alignment” mode, wherein the LED panel displays an indication of receive power level. See Table 19 SM/BHS LED descriptions on page 2-14.</p> <p>Disabled: the radio is configured to “operating” mode, wherein the SM registers and passes traffic normally.</p>
Aiming Results	<p>The Aiming Results are displayed in two sections – Current entry and Other entries.</p> <p>Frequency: this field indicates the frequency of the AP which is transmitting the beacon information.</p>

Power: This field indicates the current receive power level (vertical channel) for the frequency configured in parameter **Radio Frequency**.

Users: This field indicates the number of SMs currently registered to the AP which is transmitting the beacon information.

ESN: This field indicates the MAC, or hardware address of the AP/BHM which is transmitting the beacon information.

Color Code: This field displays a value from 0 to 254 indicating the AP's configured color code. For registration to occur, the color code of the SM and the AP *must* match. Color code is not a security feature. Instead, color code is a management feature, typically for assigning each sector a different color code.

Color code allows you to force a SM to register to only a specific AP, even where the SM can communicate with multiple APs. The default setting for the color code value is 0. This value matches only the color code of 0 (*not* all 255 color codes).

Multipoint or Backhaul: this field indicates type of configuration - point-Multipoint(PMP) or Backhaul(PTP).

Aiming page of BHS

The Alignment page of BHS is explained in [Table 173](#).

Table 173 Aiming page attributes - BHS

Alignment mode

Aiming Configuration

Aiming Mode : Single Frequency Only
 Normal Frequency Scan List
 Note: No beacon information is decoded for 'Single Frequency Only' mode

Single Frequency :

Aiming Mode will be enabled for 15 minutes or until disabled.

Aiming Status

Current Status : BHS is in Alignment Mode for selected frequencies

Aiming Results


No Backhauls available and visible which match current configuration.
 Other entries:
Frequency: 5680.000 MHz
Power: -27.0 (-30.0 V / -30.0 H) dBm
Users: 0
ESN: 0a-00-3e-a0-aa-9a
Color Code: 5
Backhaul

Attribute	Meaning
Refer Table 161 for Atributes details.	

Alignment Tone

For coarse alignment of the SM/BHS, use the Alignment Tool located at **Tools -> Alignment Tool**. Optionally, connect a headset alignment tone kit to the AUX/SYNC port of the SM/BHS and listen to the alignment tone, which indicates greater SM/BHS receive signal power by pitch. By adjusting the SM's/BHS's position until the highest frequency pitch is obtained operators and installers can be confident that the SM/BHS is properly positioned. For information on device GUI tools available for alignment, see sections [Aiming page and Diagnostic LED – SM/BHS](#) on page 8-16, [Using the Link Capacity Test tool](#) on page 8-21 and [Using AP Evaluation tool](#) on page 8-27.

Figure 158 PMP/PTP 450i link alignment tone



Note

The Alignment Tone cable for a 450i uses an RJ-45 to headset cable where the 450 alignment tone cable uses an RJ-12 to headset cable.

Using the Link Capacity Test tool

The **Link Capacity Test** tab allows you to measure the throughput and efficiency of the RF link between two modules. Many factors, including packet length, affect throughput.

The Link Capacity Test tool has following modes:

- **RF Link Test:** Fully tests radio-to-radio communication, but does not bridge traffic.
- **Link Test with Bridge:** Bridges traffic to “simulated” Ethernet ports, providing a status of the bridged link.
- **Link Test with Bridge and MIR:** Bridges the traffic during test and also adheres to any MIR (Maximum Information Rate) settings for the link.
- **Extrapolated Link Test:** Estimates the link capacity by sending few packets and measuring link quality.

The **Link Capacity Test** tab contains the settable parameter **Packet Length** with a range of 64 to 1714 bytes. This allows you to compare throughput levels that result from various packet sizes.

The **Current Results Status** also displayed date and time of last performed Link Capacity Test. If there is any change in time zone, the date and time will be adjusted accordingly.

Figure 159 Link Capacity Test - AP

The screenshot displays two configuration panels for the Link Capacity Test tool. The top panel, titled "Link Test Configurations", includes a dropdown menu for "Link Test Mode" set to "RF Link Test", radio buttons for "Signal to Noise Ratio Calculation during Link Test" (with "Enabled" selected), and radio buttons for "Link Test VC Priority" (with "High and Low Priority VCs" selected). A note below states: "Note: High and Low Priority VCs option requires that the SM already has high priority channel enabled." The bottom panel, titled "Link Test Settings", includes a dropdown for "Current Subscriber Module" set to "No Site Name [0a003ea0a066] Luid: 2", a text input for "Duration" set to "1" with the unit "Seconds (2 — 10)", a dropdown for "Direction" set to "Bi-directional", a text input for "Number of Packets" set to "64" with the note "(0 — 64) Zero will flood the link for duration of test", and a text input for "Packet Length" set to "1714" with the unit "Bytes (64 — 1714 bytes)". A "Start Test" button is located at the bottom of this panel.



Note

The Extrapolated Link Test can be run by Read-Only login also..

Performing “RF Link Test”, “Link Test with Bridge” or “Link Test with Bridge and MIR”

To run a simple link capacity test, perform the following procedure:

Procedure 31 Performing a simple Link Capacity Test

- 1 Access the Link Capacity Test tab in the Tools web page of the module.
- 2 Select Link Test Mode **RF Link Test**, **Link Test with Bridge** or **Link Test with Bridge and MIR**.
- 3 Set **Signal to Noise Ratio Calculation during Link Test** attribute to enable to disable.
- 4 Set **Link Test VC Priority** attribute to either High and Low Priority VCs or Low Priority VC only.
- 5 Select the subscriber module to test using the Current Subscriber Module parameter. This parameter is not available in BHM.
- 6 Type into the **Duration** field how long (in seconds) the RF link must be tested.
- 7 Select the **Direction** – Bi-directional, Uplink Only or Downlink Only.
- 8 Type into the **Number of Packets** field a value of **0** to flood the link for the duration of the test.
- 6 Type into the **Packet Length** field a value of **1714** to send 1714-byte packets during the test.
- 7 Click the **Start Test** button.
- 8 In the Current Results Status block of this tab, view the results of the test. See [Figure 160](#) on page 8-22.

Figure 160 Link Capacity Test tab with 1714-byte packet length

Current Results Status					
Stats for LUID: 2 Test Duration: 10 Pkt Length: 1714 Test Direction Bi-Directional					
RF Link Test					
VC	Downlink	Uplink	Aggregate	Packet Transmit	Packet Receive
				Actual	Actual
18	40.95 Mbps	13.09 Mbps	54.05 Mbps, 3907 pps	9476 (947 pps)	29605(2960 pps)
Efficiency					
Efficiency	Downlink		Uplink		
	Fragments count		Fragments count		
	Actual	Expected	Efficiency	Actual	Expected
100%	799840	799840	100%	255856	255856
Link Test ran on 21:06:00 08/20/2015 IST					
Currently transmitting at:					
VC 18 Rate 8X/8X MIMO-B					

Performing Extrapolated Link Test

The Extrapolated Link Test estimates the link capacity by sending few packets and measuring link quality. Once the test is initiated, the radio starts session at the lower modulation, 1X. As traffic is passed successfully across the link, the radio decides to try the next modulation, 2X. This process repeats until it finds the best throughput to estimate the capacity of the link.



Note


It is recommended to run Extrapolated Link Test where the session must have been up and have traffic present on it in order to get accurate test results. This is essential for the radio to modulate up to get an accurate measurement.

Running the Extrapolated test just after establishing session will not provide accurate results.

The procedure for performing Extrapolated Link Test is as follows:

Procedure 32 Performing an Extrapolated Link Test

- 1 Access the Link Capacity Test tab in the Tools web page of the module.
- 2 Select Link Test Mode **Extrapolated Link Test**
- 3 Click the **Start Test** button.
- 4 In the Current Results Status block of this tab, view the results of the test.

Figure 161 Extrapolated Link Test results

Link Capacity Test page of AP

The Link Capacity Test page of AP is explained in [Table 174](#).

Table 174 Link Capacity Test page attributes – AP

Link Test Configurations	
Link Test Mode :	RF Link Test
Signal to Noise Ratio Calculation during Link Test :	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Link Test VC Priority :	<input checked="" type="radio"/> High and Low Priority VCs <input type="radio"/> Low Priority VC only Note: High and Low Priority VCs option requires that the SM already has high priority channel enabled.

Link Test Settings	
Current Subscriber Module :	No Site Name [0a003ea0a066] Luid: 2
Duration :	1 Seconds (2 — 10)
Direction :	Bi-directional
Number of Packets :	64 (0 — 64) Zero will flood the link for duration of test
Packet Length :	1714 Bytes (64 — 1714 bytes)
Start Test	

Attribute	Meaning
Link Test Mode	Select Link Test Mode from drop down menu : <ul style="list-style-type: none"> • RF Link Test • Link Test with Bridging • Link Test with Bridging and MIR • Extrapolated Link Test
Signal to Noise Ratio Calculation during Link Test	Enable this attribute to display Signal-to-Noise information for the downlink and uplink when running the link test.
Link Test VC Priority	This attribute may be used to enable/disable usage of the high priority virtual channel during the link test.
Current Subscriber Module	The SM with which the Link Capacity Test is run. This field is only applicable for AP (not SM page).
Duration	This field allows operators to configure a specified time for which the spectrum is scanned. If the entire spectrum is scanned prior to the end of the configured duration, the analyzer will restart at the beginning of the spectrum.
Direction	Configure the direction of the link test. Specify Downlink or Uplink to run the test only in the corresponding direction only. Specific Bi-Directional to run the test in both directions.
Number of Packets	The total number of packets to send during the Link Capacity Test. When Link Test Mode is set to RF Link Test this field is not configurable.
Packet Length	The size of the packets in Bytes to send during the Link Capacity Test

Link Capacity Test page of BHM/BHS/SM

The Link Capacity Test page of BHM/BHS is explained in [Table 175](#).

Table 175 Link Capacity Test page attributes – BHM/BHS

Link Test Configurations	
Link Test Mode :	Link Test with Bridging ▼
Signal to Noise Ratio Calculation during Link Test :	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
Link Test VC Priority :	<input type="radio"/> High and Low Priority VCs <input checked="" type="radio"/> Low Priority VC only

Link Test Settings	
Duration :	10 Seconds (2 — 10)
Direction :	Bi-directional ▼
Number of Packets :	0 (0 — 64) Zero will flood the link for duration of test
Packet Length :	1714 Bytes (64 — 1714 bytes)
Start Test	

Current Results Status	
No test results available.	

Attribute	Meaning
Link Test Mode	See Table 174 on page 8-25
Signal to Noise Ratio Calculation during Link Test	See Table 174 on page 8-25
Link Test VC Priority	See Table 174 on page 8-25
Duration	See Table 174 on page 8-25
Direction	See Table 174 on page 8-25
Number of Packets	See Table 174 on page 8-25
Packet Length	See Table 174 on page 8-25

Using AP Evaluation tool

The **AP Evaluation** tab on **Tools** web page of the SM provides information about the AP that the SM sees.



Note

The data for this page may be suppressed by the **SM Display of AP Evaluation Data** setting in the **Configuration > Security** tab of the AP.

The AP Eval results can be accessed via SNMP and config file.

AP Evaluation page of AP

The AP Evaluation page of AP is explained in [Table 176](#).

Table 176 AP Evaluation tab attributes - AP

AP List

AP Selection Method used: Optimize for Throughput
 Current entry index: 0 Session Status: REGISTERED (via Primary Color Code 254)

Index: 0 Frequency: 5490.000 MHz Channel Bandwidth: 10.0 MHz Cyclic Prefix: 1/16
 ESN: 0a-00-3e-bb-00-fb Region: Other
 Beacon Receive Power: -46.0 (-49.0 V / -49.0 H) dBm Beacon Count: 18 FECEn: 1
 Type: Multipoint Avail: 1 Age: 0 Lockout: 0 RegFail 0 Range: 0 feet MaxRange: 2 miles TxBER: 1 EBcast: 0
 Session Count: 6 NoLUIDS: 0 OutOfRange: 0 AuthFail: 0 EncryptFail: 0 Rescan Req: 0 SMLimitReached: 0
 NoVC's: 0 VCRsv/430smFail: 0 VCActFail: 0
 AP Gain: -10 dBm AP RcvT: -55 dBm SectorID: 0 Color Code: 254 BeaconVersion: 1 SectorUserCount: 0
 SyncSrc: 0
 NumULSlots: 9 NumDLSlots: 26 NumULContSlots: 4
 WhiteSched: 0 ICC: 0 Authentication: Disabled
 SM PPPoE: Supported
 Frame Period: 2.5 ms

Beacon Statistics

Unsupported Feature Beacon Received :	0
Unknown Feature Beacon Received :	0
Old Version Beacon Received :	0
Wrong Frequency Beacon Received :	0
Non Lite Beacon Received :	0

Attribute	Meaning
Index	This field displays the index value that the system assigns (for only this page) to the AP where this SM is registered.
Frequency	This field displays the frequency that the AP transmits.
Channel Bandwidth	The channel size used by the radio for RF transmission. The setting for the channel bandwidth must match between the AP and the SM.

Cyclic Prefix	OFDM technology uses a cyclic prefix, where a portion of the end of a symbol (slot) is repeated at the beginning of the symbol to allow multipath to settle before receiving the desired data. A 1/16 cyclic prefixes mean that for every 16 bits of throughput data transmitted, an additional bit is used. The Cyclic Prefix 1/16 only can be selected at this time.
ESN	This field displays the MAC address (electronic serial number) of the AP. For operator convenience during SM aiming, this tab retains each detected ESN for up to 15 minutes. If the broadcast frequency of a detected AP changes during a 15-minute interval in the aiming operation, then a multiple instance of the same ESN is possible in the list. Eventually, the earlier instance expires and disappears and the later instance remains to the end of its interval, but you can ignore the early instance(s) whenever two or more are present.
Region	This field displays the AP's configured Country Code setting.
Power Level	This field displays the SM's combined received power level from the AP's transmission.
Beacon Count	A count of the beacons seen in a given time period.
FECEn	This field contains the SNMP value from the AP that indicates whether the Forward Error Correction feature is enabled. 0: FEC is disabled 1: FEC is enabled
Type	Multipoint indicates that the listing is for an AP.
Age	This is a counter for the number of minutes that the AP has been inactive. At 15 minutes of inactivity for the AP, this field is removed from the AP Evaluation tab in the SM.
Lockout	This field displays how many times the SM has been temporarily locked out of making registration attempts.
RegFail	This field displays how many registration attempts by this SM failed.
Range	This field displays the distance in feet for this link. To derive the distance in meters, multiply the value of this parameter by 0.3048.
MaxRange	This field indicates the configured value for the AP's Max Range parameter.
TxBER	A 1 in this field indicates the AP is sending Radio BER.
EBcast	A 1 in this field indicates the AP or BHM is encrypting broadcast packets. A 0 indicates it is not.

Session Count	<p>This field displays how many sessions the SM (or BHS) has had with the AP (or BHM). Typically, this is the sum of Reg Count and Re-Reg Count. However, the result of internal calculation may display here as a value that slightly differs from the sum.</p> <p>In the case of a multipoint link, if the number of sessions is significantly greater than the number for other SMs, then this may indicate a link problem or an interference problem.</p>
NoLUIDs	<p>This field indicates how many times the AP has needed to reject a registration request from a SM because its capacity to make LUID assignments is full. This then locks the SM out of making any valid attempt for the next 15 minutes. It is extremely unlikely that a non-zero number would be displayed here.</p>
OutOfRange	<p>This field indicates how many times the AP has rejected a registration request from a SM because the SM is a further distance away than the range that is currently configured in the AP. This then locks the SM out of making any valid attempt for the next 15 minutes.</p>
AuthFail	<p>This field displays how many times authentication attempts from this SM have failed in the AP.</p>
EncryptFail	<p>This field displays how many times an encryption mismatch has occurred between the SM and the AP.</p>
Rescan Req	<p>This field displays how many times a re-range request has occurred for the BHM that is being evaluated in the AP Eval page of a BHS.</p>
SMLimitReached	<p>This field displays 0 if additional SMs may be registered to the AP. If a 1 is displayed, the AP will not accept additional SM registrations.</p>
NoVC's	<p>This counter is incremented when the SM is registering to an AP which determines that no VC resources are available for allocation. This could be a primary data VC or a high priority data VC.</p>
VCRsvFail	<p>This counter is incremented when the SM is registering to an AP which has a VC resource available for allocation but cannot reserve the resource for allocation.</p>
VCActFail	<p>This counter is incremented when the SM is registering to an AP which has a VC resource available for allocation and has reserved the VC, but cannot activate the resource for allocation.</p>
AP Gain	<p>This field displays the total external gain (antenna) used by the AP.</p>
RcvT	<p>This field displays the AP's configured receive target for receiving SM transmissions (this field affects automatic SM power adjust).</p>
Sector ID	<p>This field displays the value of the Sector ID field that is provisioned for the AP.</p>

Color Code	<p>This field displays a value from 0 to 254 indicating the AP's configured color code. For registration to occur, the color code of the SM and the AP <i>must</i> match. Color code is not a security feature. Instead, color code is a management feature, typically for assigning each sector a different color code.</p> <p>Color code allows you to force a SM to register to only a specific AP, even where the SM can communicate with multiple APs. The default setting for the color code value is 0. This value matches only the color code of 0 (<i>not</i> all 255 color codes).</p>
BeaconVersion	This field indicates that the beacon is OFDM (value of 1).
Sector User Count	This field displays how many SMs are registered on the AP.
NumULHalfSlots	This is the number of uplink slots in the frame for this AP.
NumDLHalfSlots	This is the number of downlink slots in the frame for this.
NumULContSlots	This field displays how many Contention Slots are being used in the uplink portion of the frame.
WhiteSched	Flag to display if schedule whitening is supported via FPGA
ICC	This field lists the SMs that have registered to the AP with their Installation Color Code (ICC), Primary CC, Secondary CC or Tertiary CC.
SM PPPoE	This field provides information to the user whether the SM is supporting PPPoE or not.
Frame Period	This field displays the configured Frame Period of the radio.

Using BHM Evaluation tool

The **BHM Evaluation** tab on **Tools** web page of the BHS provides information about the BHM that the BHS sees.

BHM Evaluation page of BHS

The BHM Evaluation page of BHS is explained in [Table 177](#).

Table 177 BHM Evaluation tab attributes - BHS



Attribute	Meaning
Index	This field displays the index value that the system assigns (for only this page) to the BHM where this BHS is registered.
Frequency	This field displays the frequency that the BHM transmits.
Channel Bandwidth	The channel size used by the radio for RF transmission. The setting for the channel bandwidth must match between the BHM and the BHS.
Cyclic Prefix	OFDM technology uses a cyclic prefix, where a portion of the end of a symbol (slot) is repeated at the beginning of the symbol to allow multipathing to settle before receiving the desired data. A 1/16 cyclic prefixes mean that for every 16 bits of throughput data transmitted, an additional bit is used.

ESN	This field displays the MAC address (electronic serial number) of the BHM. For operator convenience during BHS aiming, this tab retains each detected ESN for up to 15 minutes. If the broadcast frequency of a detected BHM changes during a 15-minute interval in the aiming operation, then a multiple instance of the same ESN is possible in the list. Eventually, the earlier instance expires and disappears and the later instance remains to the end of its interval, but you can ignore the early instance(s) whenever two or more are present.
Region	This field displays the BHM's configured Country Code setting.
Power Level	This field displays the BHS's combined received power level from the BHM's transmission.
Beacon Count	A count of the beacons seen in a given time period.
FECEn	This field contains the SNMP value from the BHM that indicates whether the Forward Error Correction feature is enabled. 0: FEC is disabled 1: FEC is enabled
Type	Multipoint indicates that the listing is for a BHM.
Age	This is a counter for the number of minutes that the BHM has been inactive. At 15 minutes of inactivity for the BHS, this field is removed from the BHM Evaluation tab in the BHS.
Lockout	This field displays how many times the BHS has been temporarily locked out of making registration attempts.
RegFail	This field displays how many registration attempts by this BHS failed.
Range	This field displays the distance in feet for this link. To derive the distance in meters, multiply the value of this parameter by 0.3048.
MaxRange	This field indicates the configured value for the AP's Max Range parameter.
TxBER	A 1 in this field indicates the BHM is sending Radio BER.
EBcast	A 1 in this field indicates the BHM is encrypting broadcast packets. A 0 indicates it is not.
Session Count	This field displays how many sessions the BHS has had with the BHM. Typically, this is the sum of Reg Count and Re-Reg Count. However, the result of internal calculation may display here as a value that slightly differs from the sum. In the case of a multipoint link, if the number of sessions is significantly greater than the number for other BHS's, then this may indicate a link problem or an interference problem.

NoLUIDs	This field indicates how many times the BHM has needed to reject a registration request from a BHS because its capacity to make LUID assignments is full. This then locks the BHS out of making any valid attempt for the next 15 minutes. It is extremely unlikely that a non-zero number would be displayed here.
OutOfRange	This field indicates how many times the BHM has rejected a registration request from a BHS because the BHS is a further distance away than the range that is currently configured in the BHM. This then locks the BHS out of making any valid attempt for the next 15 minutes.
AuthFail	This field displays how many times authentication attempts from this SM have failed in the BHM.
EncryptFail	This field displays how many times an encryption mismatch has occurred between the BHS and the BHM.
Rescan Req	This field displays how many times a re-range request has occurred for the BHM that is being evaluated in the BHM Eval page of a BHM.
SMLimitReached	This field displays 0 if additional BHSs may be registered to the BHM. If a 1 is displayed, the BHM will not accept additional BHS registrations.
NoVC's	This counter is incremented when the BHS is registering to a BHM which determines that no VC resources are available for allocation. This could be a primary data VC or a high priority data VC.
VCRsvFail	This counter is incremented when the BHS is registering to a BHM which has a VC resource available for allocation but cannot reserve the resource for allocation.
VCActFail	This counter is incremented when the BHS is registering to a BHM which has a VC resource available for allocation and has reserved the VC, but cannot activate the resource for allocation.
AP Gain	This field displays the total external gain (antenna) used by the BHM.
RcvT	This field displays the AP's configured receive target for receiving BHS transmissions (this field affects automatic BHS power adjust).
Sector ID	This field displays the value of the Sector ID field that is provisioned for the BHM.
Color Code	<p>This field displays a value from 0 to 254 indicating the BHM's configured color code. For registration to occur, the color code of the BHS and the BHM <i>must</i> match. Color code is not a security feature. Instead, color code is a management feature, typically for assigning each sector a different color code.</p> <p>Color code allows you to force a BHS to register to only a specific BHM, even where the BHS can communicate with multiple BHMs. The default setting for the color code value is 0. This value matches only the color code of 0 (<i>not</i> all 255 color codes).</p>

BeaconVersion	This field indicates that the beacon is OFDM (value of 1).
Sector User Count	This field displays how many BHS's are registered on the BHM.
NumULHalfSlots	This is the number of uplink slots in the frame for this BHM.
NumDLHalfSlots	This is the number of downlink slots in the frame for this.
NumULContSlots	This field displays how many Contention Slots are being used in the uplink portion of the frame.
WhiteSched	Flag to display if schedule whitening is supported via FPGA
ICC	This field lists the BHSs that have registered to the BHM with their Installation Color Code (ICC), Primary CC, Secondary CC or Tertiary CC.
SM PPPoE	This field provides information to the user whether the BHS is supporting PPPoE or not.
Frame Period	This field displays the configured Frame Period of the radio.

Using the OFDM Frame Calculator tool

The first step to avoid interference in wireless systems is to set all APs/BHMs to receive timing from a synchronization source (Cluster Management Module, or Universal Global Positioning System). This ensures that the modules are in sync and start transmitting at the same time each frame.

The second step to avoid interference is to configure parameters on all APs/BHMs of the same frequency band in proximity such that they have compatible transmit/receive ratios (all stop transmitting each frame before any start receiving). This avoids the problem of one AP/BHM attempting to receive the signal from a distant SM/BHS while a nearby AP transmits, which could overpower that signal.

The following parameters on the AP determine the transmit/receive ratio:

- Max Range
- Downlink Data percentage
- (reserved) Contention Slots

If OFDM (PMP 430, PMP 450, PTP 230) and FSK (PMP 1x0) APs/BHMs of the same frequency band are in proximity, or if APs/BHMs set to different parameters (differing in their Max Range values, for example), then operator must use the Frame Calculator to identify compatible settings.

The frame calculator is available on the Frame Calculator tab of the Tools web page. To use the Frame Calculator, type various configurable parameter values into the calculator for each proximal AP and then record the resulting AP/BHM Receive Start value. Next vary the Downlink Data percentage in each calculation and iterate until the calculated AP/BHM Receive Start for all collocated AP/BHMs where the transmit end does not come before the receive start.

The calculator does not use values in the module or populate its parameters. It is merely a convenience application that runs on a module. For this reason, you can use any FSK module (AP, SM, BHM, BHS) to perform FSK frame calculations for setting the parameters on an FSK AP and any OFDM module (AP, SM, BHM, BHS) to perform OFDM frame calculations for setting the parameters on an OFDM AP/BHM.

For more information on PMP/PTP 450 platform co-location, see

<http://www.cambiumnetworks.com/solution-papers> The co-location is also supported for 900 MHz PMP 450i APs (OFDM) and PMP 100 APs (FSK). Please refer *Co-location of PMP 450 and PMP 100 systems in the 900 MHz band and migration recommendations* document for details.



Caution

APs/BHMs that have slightly mismatched transmit-to-receive ratios and low levels of data traffic may see little effect on throughput. A system that was not tuned for co-location may work fine at low traffic levels, but encounter problems at higher traffic levels. The conservative practice is to tune for co-location before traffic ultimately increases. This prevents problems that occur as sectors are built.

The OFDM Frame Calculator page is explained in [Table 178](#).

Table 178 OFDM Frame Calculator page attributes

OFDM Frame Calculator Parameters	
Link Mode :	<input checked="" type="radio"/> Point-To-Point Link <input type="radio"/> Multipoint Link
Platform Type AP/BHM :	PMP/PTP 450/450i ▼
Platform Type SM/BHS :	PMP/PTP 450/450i ▼
Channel Bandwidth :	20.0 MHz ▼
Cyclic Prefix :	One Sixteenth ▼
Frame Period :	<input type="radio"/> 5.0 ms <input checked="" type="radio"/> 2.5 ms
Max Range :	2 Miles (Range: 1 - 40 miles)
Downlink Data :	75 %
Contention Slots :	1 (Range: 0 — 15)
SM/BHS One Way Air Delay :	0 ns
Calculate	

Calculated Frame Results	
CANOPY 14.1.1 BHUL450-DES	
Modulation:OFDM	
Total Frame Bits : 25000	
Frame Period : 2.5 ms	
BHM Details :	
Data Slots (Down/Up) : 64 /21	
BHM Antenna Transmit End : 16926, 1.692616 ms	
BHM Antenna Receive Start : 17548, 1.754800 ms	
BHM Antenna Receive End : 24097	
BHS Details :	
BHS Receive End : 17507	
BHS Transmit Start : 17548	
BHS One Way Air Delay : 0 ns	
BHS Approximate distance : 0.000 miles (0 feet)	

Attribute	Meaning
Link Mode	For AP to SM frame calculations, select Multipoint Link For BHM to BHS frame calculations, select Point-To-Point Link
Platform Type AP/BHM	Use the drop-down list to select the hardware series (board type) of the AP/BHM.
Platform Type SM/BHS	Use the drop-down list to select the hardware series (board type) of the SM/BHS.
Channel Bandwidth	Set this to the channel bandwidth used in the AP/BHM.
Cyclic Prefix	Set this to the cyclic prefix used in the AP/BHM.
Max Range	Set to the same value as the Max Range parameter is set in the AP(s) or BHM(s).
Frame Period	Set to the same value as the Frame Period parameter is set in the AP(s) or BHM(s).

Downlink Data	<p>Initially set this parameter to the same value that the AP/BHM has for its Downlink Data parameter (percentage). Then, use the Frame Calculator tool procedure as described in Using the Frame Calculator on page 8-38, you will vary the value in this parameter to find the proper value to write into the Downlink Data parameter of all APs or BHMs in the cluster.</p> <p>PMP 450 platform Series APs or BHMs offer a range of 15% to 85% and default to 75%. The value that you set in this parameter has the following interaction with the value of the Max Range parameter (above):</p> <p>The default Max Range value is 5 miles and, at that distance, the maximum Downlink Data value (85% in PMP 450 platform) is functional.</p>
Contention Slots	This field indicates the number of (reserved) Contention Slots configured by the operator. Set this parameter to the value of the Contention Slot parameter is set in the APs or BHMs.
SM/BHS One Way Air Delay	This field displays the time in <i>ns</i> (nano seconds), that a SM/BHS is away from the AP/BHM.

The Calculated Frame Results display several items of interest:

Table 179 OFDM Calculated Frame Results attributes

Attribute	Meaning
Modulation	The type of radio modulation used in the calculation (OFDM for PMP/PTP 450 platform)
Total Frame Bits	The total number of bits used in the calculated frames
Data Slots (Down/Up)	This field is based on the Downlink Data setting. For example, a result within the typical range for a Downlink Data setting of 75% is 61/21, meaning 61 data slots down and 21 data slots up.
Contention Slots	This field indicates the number of (reserved) Contention Slots configured by the operator.
Air Delay for Max Range	This is the roundtrip air delay in bit times for the Max Range value set in the calculator
Approximate distance for Max Range	The Max Range value used for frame calculation
AP Transmit End	In bit times, this is the frame position at which the AP/BHM ceases transmission.
AP Receive Start	In bit times, this is the frame position at which the AP/BHM is ready to receive transmission from the SM/BHS.

AP Receive End	In bit times, this is the frame position at which the AP/BHM will cease receiving transmission from the SM/BHS.
SM Receive End	In bit times, this is the frame position at which the SM/BHS will cease receiving transmission from the AP/BHM.
SM Transmit Start	In bit times, this is the frame position at which the SM/BHS starts the transmission.
SM One Way Air Delay	This field displays the time in <i>ns</i> , that SM/BHS is away from the AP/BHM.
SM Approximate distance	This field displays an approximate distance in miles (feet) that the SM/BHS is away from the AP/BHM.

To use the Frame Calculator to ensure that all APs or BHMs are configured to transmit and receive at the same time, follow the procedure below:

Procedure 33 Using the Frame Calculator

- 1 Populate the OFDM Frame Calculator parameters with appropriate values as described above.
- 2 Click the **Calculate** button.
- 3 Scroll down the tab to the Calculated Frame Results section
- 4 Record the value of the **AP Receive Start** field
- 5 Enter a parameter set from another AP in the system – for example, an AP in the same cluster that has a higher **Max Range** value configured.
- 6 Click the **Calculate** button.
- 7 Scroll down the tab to the Calculated Frame Results section
- 8 If the recorded values of the **AP Receive Start** fields are within 150 bit times of each other, skip to step 10.

If the recorded values of the **AP Receive Start** fields are not within 150 bit times of each other, modify the **Downlink Data** parameter until the calculated results for **AP Receive Start** are within 300 bit time of each other, if possible, 150 bit time.

- 10 Access the Radio tab in the Configuration web page of each AP in the cluster and change its **Downlink Data** parameter (percentage) to the last value that was used in the Frame Calculator.


Using the Subscriber Configuration tool

The **Subscriber Configuration** page in the Tools page of the AP displays:

- The current values whose control may be subject to the setting in the **Configuration Source** parameter.
- An indicator of the source for each value.

This page may be referenced for information on how the link is behaving based on where the SM is retrieving certain QoS and VLAN parameters.

Figure 162 SM Configuration page of AP



The AP displays one of the following for the configuration source:

- (SM) – QoS/VLAN parameters are derived from the SM's settings
- (APCAP) – QoS/VLAN parameters are derived from the AP's settings, including any keyed capping (for radios capped at 4 Mbps, 10 Mbps, or 20 Mbps)
- (D) – QoS/VLAN parameters are retrieved from the device, due to failed retrieval from the AAA or WM server.
- (AAA) – QoS/VLAN parameters are retrieved from the RADIUS server
- (BAM) – QoS/VLAN parameters are retrieved from a WM BAM server

Using the Link Status tool

The Link Status Tool displays information about the most-recent Link Test initiated on the SM or BHS. Link Tests initiated from the AP or BHM are not included in the Link Status table. This table is useful for monitoring link test results for all SMs or BHS in the system.

The Link Status table is color coded to display health of link between AP/BHM and SM/BHS. The current Modulation Level Uplink/Downlink is chosen to determine link health and color coded accordingly.

Uplink/Downlink Rate Column will be color coded using current Rate as per the table below:

Table 180 Color code vers uplink/downlink rate column

Actual Rate	1x	2x	3x	4x	6x	8x
SISO	RED	ORANGE	GREEN	BLUE	NA	NA
MIMO-A	RED	ORANGE	GREEN	BLUE	NA	NA
MIMO B	NA	RED	NA	ORANGE	GREEN	BLUE


Link Status – AP/BHM

The current Uplink Rate (both low and high VC) for each SM or BHS in Session in now available on AP or BHM Link Status Page.

The Link Status tool results include values for the following fields for AP/BHM.

Table 181 Link Status page attributes – AP/BHM

Link Status												
Due to current system load, Downlink Statistics will only be updated at most every 5 seconds.												
Note: To measure the receive modulation of every fragment, Receive Quality Debug must be enabled.												
■ MIMO-B:2X MIMO-A/SISO:1X ■ MIMO-B:4X MIMO-A/SISO:2X ■ MIMO-B:6X MIMO-A/SISO:3X ■ MIMO-B:8X MIMO-A/SISO:4X												
Subscriber	Uplink Statistics					Downlink Statistics				BER Results	Reg	ReReg
	Power Level dBm: Signal Strength Ratio (dB V - H)	Fragments Modulation	Signal to Noise Ratio (dB)	Link Test Efficiency	Rate	Power Level dBm: Signal Strength Ratio (dB V - H)	Signal to Noise Ratio (dB)	Link Test Efficiency	Rate			
Site Name - LUID: 002	-52.5 (-55.3 V / -55.7 H):0.4	Path V:QPSK:37% 16-QAM:21% 64-QAM:20% 256-QAM:20% Path H:QPSK:39% 16-QAM:23% 64-QAM:23% 256-QAM:14%	44 V / 42 H	NA	8X/8X MIMO-B	-42.2 (-44.0 V / -47.0 H):4.0	43 V / 43 H	NA	8X/8X MIMO-B	2.065307e-07	3	0

Attribute	Meaning
Subscriber	<p>This field displays the LUID (logical unit ID), MAC address and Site Name of the SM. As each SM registers to the AP, the system assigns an LUID of 2 or a higher unique number to the SM. If a SM loses registration with the AP and then regains registration, the SM will retain the same LUID.</p> <hr/> <div data-bbox="532 470 626 548" style="display: inline-block; vertical-align: middle;">  </div> <div data-bbox="662 470 1421 968" style="display: inline-block; vertical-align: middle; margin-left: 10px;"> <p>Note</p> <p>The LUID associated is lost when a power cycle of the AP occurs.</p> <p>Both the LUID and the MAC are hot links to open the interface to the SM. In some instances, depending on network activity and network design, this route to the interface yields a blank web page. If this occurs, refresh your browser view.</p> <p>Site Name indicates the name of the SM. You can assign or change this name on the Configuration web page of the SM. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.</p> </div>
Uplink Statistics - Power Level: Signal Strength Ratio	<p>This field represents the combined received power level at the AP/BHM as well as the ratio of horizontal path signal strength to vertical path signal strength.</p>
Uplink Statistics – Fragments Modulation	<p>This field represents the percentage of fragments received at each modulation state, per path (polarization).</p>
Uplink Statistics – Signal to Noise Ratio	<p>This field represents the signal to noise ratio for the uplink (displayed when parameter Signal to Noise Ratio Calculation during Link Test is enabled) expressed for both the horizontal and vertical channels.</p>
Uplink Statistics – Link Test Efficiency	<p>This field displays the efficiency of the radio link, expressed as a percentage, for the radio uplink.</p>
Downlink Statistics – Power Level: Signal Strength Ratio	<p>This field represents the received power level at the SM/BHS as well as the ratio of horizontal path signal strength to vertical path signal strength at the SM/BHS.</p>
Downlink Statistics – Signal to Noise Ratio	<p>This field represents the signal to noise ratio for the downlink (displayed when parameter Signal to Noise Ratio Calculation during Link Test is enabled) expressed for both the horizontal and vertical channels.</p>
Downlink Statistics – Link Test Efficiency	<p>This field displays the efficiency of the radio link, expressed as a percentage, for the radio downlink.</p>

BER Results	<p>This field displays the over-the-air Bit Error Rates for each downlink. (The ARQ [Automatic Resend reQuest] ensures that the transport BER [the BER seen end-to-end through a network] is essentially zero.) The level of acceptable over-the-air BER varies, based on operating requirements, but a reasonable value for a good link is a BER of $1e-4$ (1×10^{-4}) or better, approximately a packet resend rate of 5%.</p> <p>BER is generated using unused bits in the downlink. During periods of peak load, BER data is not updated as often, because the system puts priority on transport rather than on BER calculation.</p>
Reg Requests	<p>A Reg Requests count is the number of times the SM/BHS registered after the AP/BHM determined that the link had been down.</p> <p>If the number of sessions is significantly greater than the number for other SMs/BHS, then this may indicate a link problem (check mounting, alignment, receive power levels) or an interference problem (conduct a spectrum scan).</p>
ReReg Requests	<p>A ReReg Requests count is the number of times the AP/BHM received a SM/BHS registration request while the AP/BHM considered the link to be still up (and therefore did not expect registration requests).</p> <p>If the number of sessions is significantly greater than the number for other SMs/BHS, then this may indicate a link problem (check mounting, alignment, receive power levels) or an interference problem (conduct a spectrum scan).</p>

Link Status – SM/BHS

The Link Status tool of SM/BHS displays Downlink Status and Uplink Status information.

Table 182 Link Status page attributes – SM/BHS

Downlink Status	
Receive Power :	-38.5 dBm (-44.0 dBm V / -40.0 dBm H)
Signal Strength Ratio :	-4.0dB V - H
Signal to Noise Ratio :	38 V / 33 H dB
Beacons :	100 %
Receive Fragments Modulation :	Path V:QPSK:33% 16-QAM:23% 64-QAM:23% 256-QAM:21% Path H:QPSK:53% 16-QAM:28% 64-QAM:13% 256-QAM:6%
Latest Remote Link Test Efficiency Percentage :	NA %
BER Total Avg Results :	7.328226e-06
Beacons Received Last 15 minutes :	100/100/100% (min/avg/max)

Uplink Status	
Transmit Power :	13 dBm
Max Transmit Power :	21 dBm
Power Level :	-52.5 (-56.0 V / -55.0 H) dBm
Signal Strength Ratio :	-1.0dB V - H
Signal to Noise Ratio :	36 dB V / NA H
Latest Remote Link Test Efficiency Percentage :	NA %

Local Status	
Session Status :	REGISTERED VC 18 Rate 8X/4X MIMO-A

Latest Local Link Test Results	
No test results available.	
<input type="button" value="Run Link Test"/>	

Attribute	Meaning
Downlink Status	
Receive Power	This field lists the current combined receive power level, in dBm.
Signal Strength Ratio	This field displays the difference of the Vertical path received signal power to the Horizontal path received signal power for downlink.
Signal to Noise Ratio	This field lists the current signal-to-noise level, an indication of the separation of the received power level vs. noise floor for downlink.
Beacons	Displays a count of beacons received by the SM in percentage. This value must be typically between 99-100%. If lower than 99%, it indicates a problematic link. This statistic is updated every 16 seconds.
Received Fragments Modulation	This field represents the percentage of fragments received at each modulation state, per path (polarization)
Latest Remote Link Test Efficiency Percentage	This field is not applicable.
BER Total Avg Results	This field displays the over-the-air average Bit Error Rates (BER) for downlink.
Beacons Received Last 15 minutes	The beacon count on the SM can be used to estimate the interference in the channel. The min/avg/max beacon percentage displayed based on this value for the last 15 mins.

Uplink Status	
Transmit Power	This field displays the current combined transmit power level, in dBm.
Max Transmit Power	This field displays the maximum transmit power of SM.
Power Level	This field indicates the combined power level at which the SM is set to transmit, based on the Country Code and Antenna Gain settings.
Signal Strength Ratio	This field displays the difference of the Vertical path received signal power to the Horizontal path received signal power for uplink.
Signal to Noise Ratio	This field lists the current signal-to-noise level, an indication of the separation of the received power level vs. noise floor for uplink.
Latest Remote Link Test Efficiency Percentage	This field is not applicable.
Session Status	This field displays the current state, Virtual channel, high-priority/ low priority channel rate adaptation and MIMO-A/MIMO-B/SISO status of SM.
Run Link Test	<div data-bbox="501 898 690 940" style="border: 1px solid gray; padding: 2px; display: inline-block;">Run Link Test</div> <p>See Exploratory Test section of Performing Extrapolated Link Test on page 8-23</p>

Using BER Results tool

Radio BER data represents bit errors at the RF link level. Due to CRC checks on fragments and packets and ARQ (Automatic Repeat reQuest), the BER of customer data is essentially zero. Radio BER gives one indication of link quality. Other important indications to consider includes the received power level, signal to noise ratio and link tests.


BER is only instrumented on the downlink and is displayed on the BER Results tab of the Tools page in any SM. Each time the tab is clicked, the current results are read and counters are reset to zero.

The BER Results tab can be helpful in troubleshooting poor link performance.

The link is acceptable if the value of this field is less than 10^{-4} . If the BER is greater than 10^{-4} , re-evaluate the installation of both modules in the link.

The BER test signal is broadcast by the AP/BHM (and compared to the expected test signal by the SM/BHS) only when capacity in the sector allows it. This signal is the lowest priority for AP/BHM transmissions.


Figure 163 BER Results tab of the SM



Using the Sessions tool

The PMP 450 platform AP has a tab **Sessions** under the Tools category which allows operators to drop one or all selected SM sessions and force a SM re-registration. This operation is useful to force QoS changes for SMs without losing AP logs or statistics. This operation may take 5 minutes to regain all SM registrations.

Figure 164 Sessions tab of the AP



Chapter 9: Operation

This chapter provides instructions for operators of the PMP/PTP 450 platform wireless Ethernet Bridge. The following topics are described in this chapter:

- [System information](#) on page [9-2](#)
 - [Viewing General Status](#) on page [9-2](#)
 - [Viewing Session Status](#) on page [9-16](#)
 - [Viewing Remote Subscribers](#) on page [9-22](#)
 - [Interpreting messages in the Event Log](#) on page [9-23](#)
 - [Viewing the Network Interface](#) on page [9-25](#)
 - [Viewing the Layer 2 Neighbors](#) on page [9-26](#)
- [System statistics](#) on page [9-27](#)
 - [Viewing the Scheduler statistics](#) on page [9-27](#)
 - [Viewing list of Registration Failures statistics](#) on page [9-29](#)
 - [Interpreting Bridging Table statistics](#) on page [9-30](#)
 - [Interpreting Translation Table statistics](#) on page [9-31](#)
 - [Interpreting Ethernet statistics](#) on page [9-32](#)
 - [Interpreting RF Control Block statistics](#) on page [9-35](#)
 - [Interpreting VLAN statistics](#) on page [9-36](#)
 - [Interpreting Data VC statistics](#) on page [9-38](#)
 - [Interpreting Throughput statistics](#) on page [9-40](#)
 - [Interpreting Overload statistics](#) on page [9-43](#)
 - [Interpreting DHCP Relay statistics](#) on page [9-44](#)
 - [Interpreting Filter statistics](#) on page [9-46](#)
 - [Viewing ARP statistics](#) on page [9-47](#)
 - [Viewing NAT statistics](#) on page [9-47](#)
 - [Viewing NAT DHCP Statistics](#) on page [9-49](#)
 - [Interpreting Sync Status statistics](#) on page [9-50](#)
 - [Interpreting PPPoE Statistics for Customer Activities](#) on page [9-51](#)
 - [Interpreting Bridge Control Block statistics](#) on page [9-52](#)
 - [Interpreting Pass Through Statistics](#) on page [9-54](#)
 - [Interpreting SNMPv3 Statistics](#) on page [9-55](#)
 - [Interpreting syslog statistics](#) on page [9-57](#)
 - [Interpreting Frame Utilization statistics](#) on page [9-57](#)
- [Radio Recovery](#) on page [9-61](#)

System information

This section describes how to use the summary and status pages to monitor the status of the Ethernet ports and wireless link.

- [Viewing General Status](#) on page 9-2
- [Viewing Session Status](#) on page 9-16
- [Viewing Remote Subscribers](#) on page 9-22
- [Interpreting messages in the Event Log](#) on page 9-23
- [Viewing the Network Interface](#) on page 9-25
- [Viewing the Layer 2 Neighbors](#) on page 9-26

Viewing General Status

The **General Status** tab provides information on the operation of this AP/BHM and SM/BHS. This is the page that opens by default when you access the GUI of the radio.

General Status page of AP

The AP's **General Status** page is explained in [Table 183](#).

Table 183 General Status page attributes - AP

Device Information	
Device Type :	5.4GHz MIMO OFDM - Access Point - 0a-00-3e-bb-00-fb
Board Type :	P13 C110_SOC
Software Version :	CANOPY 14.1 AP-DES
Board MSN :	PMP450IMSN
FPGA Version :	100615
Uptime :	2d, 21:49:56
System Time :	12:45:34 10/12/2015 IST
Ethernet Interface :	100Base-TX Full Duplex
Region Code :	Other
Regulatory :	Passed
Antenna Type :	External
Channel Frequency :	5490.0 MHz
Channel Bandwidth :	10.0 MHz
Cyclic Prefix :	1/16
Frame Period :	2.5 ms
Color Code :	254
Max Range :	2 Miles
Transmit Power :	-10 dBm
Temperature :	34 °C / 93 °F

Access Point Stats	
Registered SM Count :	1 (1 Data VCs)
Sync Pulse Status :	Generating Sync
Sync Pulse Source :	Self Generate
Maximum Count of Registered SMs :	1


Frame Configuration Information	
Data Slots Down :	27
Data Slots Up :	9
Contention Slots :	3

Site Information	
Site Name :	No Site Name
Site Contact :	No Site Contact
Site Location :	No Site Location

Key Features Information	
Time Updated and Location Code :	08/18/2015 06:41:40 - INTL

Attribute	Meaning
Device Type	This field indicates the type of the module. Values include the frequency band of the SM, its module type and its MAC address.

Software Version	This field indicates the system release, the time and date of the release and whether communications involving the module are secured by DES or AES encryption. If you request technical support, provide the information from this field.
Board Type	This field indicates the series of hardware.
Combo Radio Mode	This field indicates the mode of operation, currently only 'MIMO OFDM Only' is supported.
FPGA Version	This field indicates the version of the field-programmable gate array (FPGA) on the module. If you request technical support, provide the value of this field.
FPGA Type	Where the type of logic as a subset of the logic version in the module as manufactured distinguishes its circuit board, this field is present to indicate that type. If you request technical support, provide the value of this field.
PLD Version	This field indicates the version of the programmable logic device (PLD) on the module. If you request technical support, provide the value of this field.
Uptime	This field indicates how long the module has operated since power was applied.
System Time	This field provides the current time. If the AP is connected to a CMM4, then this field provides GMT (Greenwich Mean Time). Any SM that registers to the AP inherits the system time.
Last NTP Time Update	This field displays when the AP last used time sent from an NTP server. If the AP has not been configured in the Time tab of the Configuration page to request time from an NTP server, then this field is populated by 00:00:00 00/00/00.
Ethernet Interface	This field indicates the speed and duplex state of the Ethernet interface to the AP.
Region Code	A parameter that offers multiple fixed selections, each of which automatically implements frequency band range restrictions for the selected region. Units shipped to regions other than the United States must be configured with the corresponding Region Code to comply with local regulatory requirements.
Regulatory	This field indicates whether the configured Country Code and radio frequency are compliant with respect to their compatibility. PMP 450 equipment shipped to the United States is locked to a Country Code setting of "United States". Units shipped to regions other than the United States must be configured with the corresponding Country Code to comply with local regulatory requirements.
Antenna Type	The current antenna type that has been selected.

Channel Center Frequency	This field indicates the current operating center frequency, in MHz.
Channel Bandwidth	This field indicates the current size of the channel band used for radio transmission.
Cyclic Prefix	OFDM technology uses a cyclic prefix, where a portion of the end of a symbol (slot) is repeated at the beginning of the symbol to allow multipathing to settle before receiving the desired data. A 1/16 cyclic prefix means that for every 16 bits of throughput data transmitted, an additional bit is used.
Frame Period	This field indicates the current Frame Period setting of the radio in ms.
Color Code	<p>This field displays a value from 0 to 254 indicating the AP's configured color code. For registration to occur, the color code of the SM and the AP <i>must</i> match. Color code is not a security feature. Instead, color code is a management feature, typically for assigning each sector a different color code.</p> <p>Color code allows you to force a SM to register to only a specific AP, even where the SM can communicate with multiple APs. The default setting for the color code value is 0. This value matches only the color code of 0 (<i>not</i> all 255 color codes).</p>
Max Range	This field indicates the setting of the Max Range parameter, which contributes to the way the radio transmits. Verify that the Max Range parameter is set to a distance slightly greater than the distance between the AP and the furthest SM that must register to this AP.
Transmitter Output Power	This field indicates the combined power level at which the AP is set to transmit, based on the Country Code and Antenna Gain settings.
Temperature	This field indicates the current operating temperature of the device board.
Registered SM Count	This field indicates how many SMs are registered to the AP.
Sync Pulse Status	<p>This field indicates the status of synchronization as follows:</p> <p>Generating Sync indicates that the module is set to <i>generate</i> the sync pulse.</p> <p>Receiving Sync indicates that the module is set to <i>receive</i> a sync pulse from an outside source and is receiving the pulse.</p> <p>No Sync Since Boot up / ERROR: No Sync Pulse indicates that the module is set to <i>receive</i> a sync pulse from an outside source and is not receiving the pulse.</p>
	<p> Note</p> <p>When this message is displayed, the AP transmitter is turned off to avoid self-interference within the system.</p>

Sync Pulse Source	<p>This field indicates the status of the synchronization source:</p> <p>Searching indicates that the unit is searching for a GPS fix</p> <p>Timing Port/UGPS indicates that the module is receiving sync via the timing AUX/SYNC timing port</p> <p>Power Port indicates that the module is receiving sync via the power port (Ethernet port).</p> <p>On-board GPS indicates that the module is receiving sync via the unit's internal GPS module</p>
Maximum Count of Registered SMs	<p>This field displays the largest number of SMs that have been simultaneously registered in the AP since it was last rebooted. This count can provide some insight into sector history and provide comparison between current and maximum SM counts at a glance.</p>
Data Slots Down	<p>This field indicates the number of frame slots that are designated for use by data traffic in the downlink (sent from the AP to the SM). The AP calculates the number of data slots based on the Max Range, Downlink Data and (reserved) Contention Slots configured by the operator.</p>
Data Slots Up	<p>This field indicates the number of frame slots that are designated for use by data traffic in the uplink (sent from the SM to the AP). The AP calculates the number of data slots based on the Max Range, Downlink Data and (reserved) Contention Slots configured by the operator.</p>
Contention Slots	<p>This field indicates the number of (reserved) Contention Slots configured by the operator. See Contention slots on page 7-238.</p>
Site Name	<p>This field indicates the name of the physical module. You can assign or change this name in the SNMP tab of the AP Configuration page. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.</p>
Site Contact	<p>This field indicates contact information for the physical module. You can provide or change this information in the SNMP tab of the AP Configuration page. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.</p>
Site Location	<p>This field indicates site information for the physical module. You can provide or change this information in the SNMP tab of the AP Configuration page.</p>
Time Updated and Location Code	<p>This field displays information about the keying of the radio.</p>

General Status page - SM

The SM's **General Status** page is explained in [Table 184](#).



Note

In order for accurate power level readings to be displayed, traffic must be present on the radio link.

Table 184 General Status page attributes - SM

Device Information	
Device Type :	4.9/5.9GHz MIMO OFDM - Subscriber Module - 0a-00-3e-bb-01-04
Board Type :	P13 C110_SOC
Software Version :	CANOPY 14.1 SM-DES
Board MSN :	PMP450IMSN
FPGA Version :	100615
Uptime :	2d, 19:49:28
System Time :	12:51:51 10/12/2015 IST
Ethernet Interface :	No Link
Region Code :	Other
DFS :	Idle
Antenna Type :	External
Frame Period :	2.5 ms
Temperature :	36 °C / 97 °F

Subscriber Module Stats	
Session Status :	REGISTERED VC 18 Rate 8X/8X MIMO-B
Session Uptime :	2 d, 19:48:29
Registered AP :	0a-00-3e-bb-00-fb No Site Name
Color Code :	254 (Primary)
Channel Frequency :	5490.0 MHz
Channel Bandwidth :	10.0 MHz
Cyclic Prefix :	1/16
Air Delay :	0 ns, approximately 0.000 miles (0 feet)
Receive Power :	-42.5 dBm
Signal Strength Ratio :	3.0dB V - H
Signal to Noise Ratio :	43 V / 43 H dB
Beacons :	100 %
Transmit Power :	-20 dBm

Frame Configuration Information	
Data Slots Down :	27
Data Slots Up :	9
Contention Slots :	3


Region Specific Information	
Region Code :	Other

Site Information	
Site Name :	No Site Name
Site Contact :	No Site Contact
Site Location :	No Site Location

Key Features Information	
Maximum Throughput :	Unlimited
Time Updated and Location Code :	08/18/2015 06:44:37 - INTL

Attribute	Meaning
Device Type	This field indicates the type of the module. Values include the frequency band of the SM, its module type and its MAC address.
Board Type	This field indicates the series of hardware.
Software Version	This field indicates the system release, the time and date of the release. If you request technical support, provide the information from this field.
FPGA Version	This field indicates the version of the field-programmable gate array (FPGA) on the module. When you request technical support, provide the information from this field.
PLD Version	This field indicates the version of the programmable logic device (PLD) on the module. If you request technical support, provide the value of this field.
Uptime	This field indicates how long the module has operated since power was applied.
System Time	This field provides the current time. Any SM that registers to an AP inherits the system time, which is displayed in this field as GMT (Greenwich Mean Time).
Ethernet Interface	This field indicates the speed and duplex state of Ethernet interface to the SM.
Regional Code	A parameter that offers multiple fixed selections, each of which automatically implements frequency band range restrictions for the selected region. Units shipped to regions other than the United States must be configured with the corresponding Country Code to comply with local regulatory requirements.
DFS	This field indicates that DFS operation is enabled based on the configured region code, if applicable.
Antenna Type	The current antenna type that has been selected.
Frame Period	This field indicates the current Frame Period setting of the radio in ms.
Temperature	The current operating temperature of the board.
Session Status	<p>This field displays the following information about the current session:</p> <p>Scanning indicates that this SM currently cycles through the radio frequencies that are selected in the Radio tab of the Configuration page.</p> <p>Syncing indicates that this SM currently attempts to receive sync.</p> <p>Registering indicates that this SM has sent a registration request message to the AP and has not yet received a response.</p> <p>Registered indicates that this SM is both:</p> <ul style="list-style-type: none"> • registered to an AP. • ready to transmit and receive data packets.

Session Uptime	This field displays the duration of the current link. The syntax of the displayed time is <i>hh:mm:ss</i> .
Registered AP	Displays the MAC address and site name of the AP to which the SM is registered to. This parameter provides click-through proxy access to the AP's management interface.
Color Code	<p>This field displays a value from 0 to 254 indicating the SM's configured color code. For registration to occur, the color code of the SM and the AP <i>must</i> match. Color code is not a security feature. Instead, color code is a management feature, typically for assigning each sector a different color code.</p> <p>Color code allows you to force a SM to register to only a specific AP, even where the SM can communicate with multiple APs. The default setting for the color code value is 0. This value matches only the color code of 0 (<i>not</i> all 255 color codes).</p>
Channel Frequency	This field lists the current operating frequency of the radio.
Channel Bandwidth	The size in MHz of the operating channel.
Cyclic Prefix	OFDM technology uses a cyclic prefix, where a portion of the end of a symbol (slot) is repeated at the beginning of the symbol to allow multipathing to settle before receiving the desired data. A 1/16 cyclic prefix means that for every 16 bits of throughput data transmitted, an additional bit is used.
Air Delay	This field displays the distance in feet between this SM and the AP. To derive the distance in meters, multiply the value of this parameter by 0.3048. Distances reported as less than 200 feet (61 meters) are unreliable.
Receive Power	This field lists the current combined receive power level, in dBm.
Signal Strength Ratio	This field displays the difference of the Vertical path received signal power to the Horizontal path received signal power.
Signal to Noise Ratio	This field lists the current signal-to-noise level, an indication of the separation of the received power level vs. noise floor.
Beacons	Displays a count of beacons received by the SM in percentage. This value must be typically between 99-100%. If lower than 99%, it indicates a problematic link. This statistic is updated every 16 seconds.
Transmit Power	This field lists the current combined transmit power level, in dBm.



Note
The red SM message "target power exceeded maximum" does not necessarily indicate a problem.

7 dBm (target power [24 dBm] exceeded maximum)

In this case, the AP is requesting the SM to transmit at a higher power level, but the SM is restricted due to EIRP limits or hardware capabilities. This message can be an indication that the SM is deployed further from the AP than optimal, causing the AP to adjust the SM to maximum transmit power.

Data Slots Down	This field lists the number of slots used for downlink data transmission.
Data Slots Up	This field lists the number of slots used for uplink data transmission.
Contention Slots	This field indicates the number of (reserved) Contention Slots configured by the operator. See Contention slots on page 7-238.
Site Name	This field indicates the name of the physical module. You can assign or change this name in the SNMP tab of the SM Configuration page. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.
Site Contact	This field indicates contact information for the physical module. You can provide or change this information in the SNMP tab of the SM Configuration page. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.
Site Location	This field indicates site information for the physical module. You can provide or change this information in the SNMP tab of the SM Configuration page.
Maximum Throughput	This field indicates the limit of aggregate throughput for the SM and is based on the default (factory) limit of the SM and any floating license that is currently assigned to it.
Time Updated and Location Code	This field displays information about the keying of the radio.

**Note**

For PMP 450 900 MHz SM, there is additional parameter Path Info (under Subscriber Module Stats) which displays polarization path(A & B) information.

Path Info :	Path A = -45° Path B = +45°
-------------	-----------------------------

General Status page of BHM

The BHM's **General Status** page is explained in [Table 185](#).

Table 185 General Status page attributes - BHM

Device Information	
Device Type :	5.4GHz MIMO OFDM - Backhaul - Timing Master - 0a-00-3e-bb-00-fb
Board Type :	P13 C110_SOC
Software Version :	CANOPY 14.1 BHUL450-DES
Board MSN :	PMP450iMSN
FPGA Version :	100615
Uptime :	04:21:16
System Time :	16:53:01 10/13/2015 IST
Ethernet Interface :	100Base-TX Full Duplex
Region Code :	Other
Regulatory :	Passed
Antenna Type :	External
Channel Frequency :	5490.0 MHz
Channel Bandwidth :	10.0 MHz
Cyclic Prefix :	1/16
Frame Period :	2.5 ms
Color Code :	254
Transmit Power :	-10 dBm
Temperature :	33 °C / 91 °F

Backhaul Stats	
Timing Slave Status :	Connected
Sync Pulse Status :	Generating Sync
Sync Pulse Source :	Self Generate

Frame Configuration Information	
Data Slots Down :	29
Data Slots Up :	10

Site Information	
Site Name :	No Site Name
Site Contact :	No Site Contact
Site Location :	No Site Location

Key Features Information	
Time Updated and Location Code :	08/28/2015 08:29:34 - INTL

Attribute	Meaning
Device Type	This field indicates the type of the module. Values include the frequency band of the BHM, its module type and its MAC address.
Board Type	This field indicates the series of hardware.
Software Version	This field indicates the system release, the time and date of the release. If you request technical support, provide the information from this field.
Board MSN	This field indicates the Manufacture's Serial number. A unique serial number assigned to each radio at the factory for inventory and quality control.

FPGA Version	This field indicates the version of the field-programmable gate array (FPGA) on the module. When you request technical support, provide the information from this field.
Uptime	This field indicates how long the module has operated since power was applied.
System Time	This field provides the current time. Any BHS that registers to a BHM inherits the system time, which is displayed in this field as GMT (Greenwich Mean Time).
Ethernet Interface	This field indicates the speed and duplex state of Ethernet interface to the BHM.
Antenna Type	The current antenna type that has been selected.
Temperature	The current operating temperature of the board.
Session Status	This field displays the following information about the current session: Scanning indicates that this BHS currently cycles through the radio frequencies that are selected in the Radio tab of the Configuration page. Syncing indicates that this BHM currently attempts to receive sync. Registering indicates that this BHM has sent a registration request message to the BHM and has not yet received a response. Registered indicates that this BHM is both: <ul style="list-style-type: none"> Registered to a BHM. Ready to transmit and receive data packets.
Session Uptime	This field displays the duration of the current link. The syntax of the displayed time is <i>hh:mm:ss</i> .
Registered Backhaul	Displays the MAC address and site name of the BHM to which the BHS is registered to. This parameter provides click-through proxy access to the BHM's management interface.
Channel Frequency	This field lists the current operating frequency of the radio.
Receive Power	This field lists the current combined receive power level, in dBm.
Signal Strength Ratio	This field displays the difference of the Vertical path received signal power to the Horizontal path received signal power.
Transmit Power	This field lists the current combined transmit power level, in dBm.
Signal to Noise Ratio	This field lists the current signal-to-noise level, an indication of the separation of the received power level vs. noise floor.
Beacons	Displays a count of beacons received by the BHM in percentage. This value must be typically between 99-100%. If lower than 99%, it indicates a problematic link. This statistic is updated every 16 seconds.

Air Delay	This field displays the distance in feet between this BHS and the BHM. To derive the distance in meters, multiply the value of this parameter by 0.3048. Distances reported as less than 200 feet (61 meters) are unreliable.
Data Slots Down	This field lists the number of slots used for downlink data transmission.
Data Slots Up	This field lists the number of slots used for uplink data transmission.
Regional Code	A parameter that offers multiple fixed selections, each of which automatically implements frequency band range restrictions for the selected region. Units shipped to regions other than the United States must be configured with the corresponding Country Code to comply with local regulatory requirements.
Site Name	This field indicates the name of the physical module. Assign or change this name in the Configuration > SNMP page. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.

General Status page of BHS

The BHS's **General Status** page is explained in [Table 186](#).

Table 186 General Status page attributes - BHS

Device Information	
Device Type :	4.9/5.9GHz MIMO OFDM - Backhaul - Timing Slave - 0a-00-3e-bb-01-04
Board Type :	P13 C110_SOC
Software Version :	CANOPY 14.1 BHUL450-DES
Board MSN :	PMP450IMSN
FPGA Version :	100615
Uptime :	04:19:28
System Time :	16:55:09 10/13/2015 IST
Ethernet Interface :	No Link
Region Code :	Other
DFS :	Idle
Antenna Type :	External
Frame Period :	2.5 ms
Temperature :	35 °C / 95 °F

Timing Slave Stats	
Session Status :	REGISTERED VC 18 Rate 8X/2X MIMO-B VC 255 Rate 8X/1X MIMO-B
Session Uptime :	04:18:32
Registered Backhaul :	0a-00-3e-bb-00-fb No Site Name
Channel Frequency :	5490.0 MHz
Receive Power :	-42.5 dBm
Signal Strength Ratio :	3.0dB V - H
Transmit Power :	16 dBm
Signal to Noise Ratio :	43 V / 43 H dB
Beacons :	100 %
Air Delay :	0 ns, approximately 0.000 miles (0 feet)

Frame Configuration Information	
Data Slots Down :	29
Data Slots Up :	10

Region Specific Information	
Region Code :	Other

Site Information	
Site Name :	No Site Name
Site Contact :	No Site Contact
Site Location :	No Site Location

Key Features Information	
Time Updated and Location Code :	08/28/2015 08:23:30 - INTL

Attribute	Meaning
Device Type	
Board Type	
Software Version	See Table 186 on page 9-14
Board MSN	
FPGA Version	

Uptime	
System Time	
Ethernet Interface	
Antenna Type	
Temperature	
Session Status	
Session Uptime	
Registered Backhaul	
Channel Frequency	
Receive Power	
Signal Strength Ratio	See Table 186 on page 9-14
Transmit Power	
Signal to Noise Ratio	
Beacons	
Air Delay	
Data Slots Down	
Data Slots Up	
Regional Code	
Site Name	
Site Contact	
Site Location	
Time Updated and Location Code	

Viewing Session Status

The **Session Status** page in the Home page provides information about each SM or BHS that has registered to the AP or BHM. This information is useful for managing and troubleshooting a system. This page also includes the current active values on each SM or BHS for MIR and VLAN, as well as the source of these values, representing the SM/BHS itself, Authentication Server, or the Authentication Server and SM/BHS.



Note

In order for accurate power level readings to be displayed, traffic must be present on the radio link.

The Session Status List has four tabs: Device, Session, Power and Configuration.

The SessionStatus.xml hyper link allows user to export session status page from web management interface of AP or BHM. The session status page will be exported in xml file.

Device tab

The Device tab provides information on the Subscriber's LUID and MAC, Hardware, Software, FPGA versions and the state of the SM/BHS (Registered and/or encrypted).

Table 187 Device tab attributes

Subscriber	Hardware	Software Version	FPGA Version	State
LUID: 002 - [0a-00-3e-bb-01-04] No Site Name	PMP 450i	CANOPY 14.1	100615 (DES, Sched, US/ETSI) P13	IN SESSION (Encrypt Disabled)

Attribute	Meaning
Subscriber	This field displays the LUID (logical unit ID), MAC address and Site Name of the SM/BHS. As each SM or BHS registers to the AP/BHM, the system assigns an LUID of 2 or a higher unique number to the SM/BHS. If a SM/BHS loses registration with the AP/BHS and then regains registration, the SM/BHS will retain the same LUID.



Note

The LUID associated is lost when a power cycle of the AP/BHM occurs.

Both the LUID and the MAC are hot links to open the interface to the SM/BHS. In some instances, depending on network activity and network design, this route to the interface yields a blank web page. If this occurs, refresh your browser view.

Site Name indicates the name of the SM/BHS. Change this name on the Configuration web page of the SM/BHS. This information is also set into the *sysName* SNMP MIB-II object and can be polled by an SNMP management server.

Hardware	This field displays the SMs or BHS hardware type.
Software Version	This field displays the software release that operates on the SM/BHS, the release date and time of the software.
FPGA Version	This field displays the version of FPGA that runs on the SM/BHS
State	<p>This field displays the current status of the SM/BHS as either</p> <ul style="list-style-type: none"> • IN SESSION to indicate that the SM/BHS is currently registered to the AP/BHM. • IDLE to indicate that the SM/BHS was registered to the AP/BHM at one time, but now is not. <p>This field also indicates whether the encryption scheme in the module is enabled.</p>

Session tab


The Session tab provides information on the SMs or BHS Session Count, Reg Count, Re-Reg Count, Uptime, Air delay, PPPoE State and Timeouts.

Table 188 Session tab attributes

The screenshot shows a web interface titled "Session Status List" with a data source of "SessionStatus.xml". It features four tabs: "Device", "Session", "Power", and "Configuration". The "Session" tab is active, displaying a table with the following columns: Subscriber, Count, Reg Count, Re-Reg Count, Uptime, CC Priority, Air Delay (Distance, ns, bits), PPPoE State, and Time. Two rows of data are visible:

Subscriber	Count	Reg Count	Re-Reg Count	Uptime	CC Priority	Air Delay			PPPoE State	Time
						Distance	ns	bits		
LUID: 002 - [0a-00-3e-a0-a6-80]	1	1	0	00:03:31	Secondary	0.000 miles (0 feet)	0	0	NA	0
LUID: 003 - [0a-00-3e-a0-a0-66] No Site Name	1	1	0	00:00:09	ICC	0.002 miles (12 feet)	25	0	NA	0

Attribute	Meaning
Subscriber	See Table 187 on page 9-16.

Count	<p>This field displays how many sessions the SM/BHS has had with the AP/BHM. Typically, this is the sum of Reg Count and Re-Reg Count. However, the result of internal calculation may display here as a value that slightly differs from the sum.</p> <p>If the number of sessions is significantly greater than the number for other SMs or BHS, then this may indicate a link problem or an interference problem.</p>
Reg Count	<p>When a SM/BHS makes a Registration Request, the AP/BHM checks its local session database to see whether it was registered earlier. If the AP/BHM concludes that the SM/BHS is not currently in session database and it is valid Registration Request, then the request increments the value of this field.</p> <p>In ideal situation, the Reg Count indicates total number of connected SMs to an AP.</p>
	<p>Note</p> <p>The user can clear Reg Count by dropping all current sessions of SM (or BHS) from Configuration > Tools > Sessions menu.</p>
	Re-Reg Count
Uptime	<p>Once a SM/BHS successfully registers to an AP/BHM, this timer is started. If a session drops or is interrupted, this timer is reactivated once re-registration is complete.</p>
CC Priority	<p>The field displays Color Code Priority (ICC, Primary, Secondary or Tertiary) of all connected SM.</p>

AirDelay	This field displays the distance of the SM/BHS from the AP/BHM in meters, nanoseconds and bits. At close distances, the value in this field is unreliable.
PPPoE state	This field displays the current PPPoE state (whether configured) of the SM/BHS.
Timeout	This field displays the timeout in seconds for management sessions via HTTP, ftp access to the SM/BHS. 0 indicates that no limit is imposed.

Power tab

Table 189 Power tab attributes

Subscriber	Hardware	Downlink Rate	AP Rx Power (dBm)	Signal Strength Ratio (dB)	Signal to Noise Ratio (dB)
LUID: 002 - [0a-00-3e-bb-01-04]	PMP 450i	VC 18 Rate 8X/8X MIMO-B	-51.7	1.0dB V - H	44 V / 44 H

Attribute	Meaning
Subscriber	See Table 187 on page 9-16.
Hardware	This field displays the SMs or BHS hardware type.
Rate	<p>This field displays whether the high-priority channel is enabled in the SM/BHS and the status of rate adapt. For example, if “8X/4X” is listed, the radio is capable of operating at 8X but is currently operating at 4X, due to RF conditions.</p> <p>This field also states whether it is MIMO-A or MIMO-B radio e.g. “8X/8X MIMO-B” indicates MIMO-B and “8X/4X MIMO-A” indicates MIMO-A.</p> <p>A VC starts at its lowest modulation and slowly rate adapts up, as traffic is successfully transmitted over the VC. It is normal for one VC to have a different modulation rate than another VC, if only one VC has traffic on it. For example if High Priority VC is enabled, but only low priority VC has traffic the reading will show:</p> <p>REGISTERED VC 18 Rate 8X/8X MIMO-B VC 255 Rate 8X/1X MIMO-B</p>
AP Rx Power (dBm)	This field indicates the AP’s or BHM’s combined receive power level for the listed SM/BHS.

Signal Strength Ratio (dB) This field displays the ratio of the Vertical path received signal power to the Horizontal path received signal power. This ratio can be useful for determining multipathing conditions (high vertical to horizontal ratio) for Uplink.

Signal to Noise Ratio (dB) This field lists the current signal-to-noise level, an indication of the separation of the received power level vs. noise floor. In other words, it indicates signal to noise ratio for Uplink.

Configuration tab

The **Configuration** tab provides information on the SMs or BHS Uplink or Downlink (UL/DL) Sustained Data Rate, UL/DL Burst Allocation, UL/DL Burst Rate, UL/DL Low Priority CIR, UL/DL High CIR, UL/DL High Priority Queue Information and the UL/DL Broadcast or Multicast Allocation. This data is refreshed based on the Web Page Auto Update setting on the AP's or BHS's General Configuration page.

Table 190 Configuration tab attributes

Subscriber	Session	Sustained Data Rate (kbps)	Burst Allocation (kbit)	Max Burst Rate (kbit)	Low Priority CIR (kbps)	High CIR (kbps)	Broadcast/Multicast Allocation	RADIUS Authentication Reply	RADIUS Authentication Server
LJID-002 - [0a-00-3e-a0-e8-60] No Site Name	Uplink	6500(SM)	2500000(SM)	0(SM)	0(SM)	0(SM)	0(SM)	Hello from freeradius	10.110.61.7
	Downlink	6500(SM)	2500000(SM)	0(SM)	0(SM)	0(SM)			
LJID-003 - [0a-00-3e-a2-cf-5d] No Site Name	Uplink	2000(SM)	2500000(SM)	0(SM)	0(SM)	NA	0(SM)	Hello from Microsoft	10.120.133.1
	Downlink	2000(SM)	2500000(SM)	0(SM)	0(SM)	NA			

Attribute	Meaning
Subscriber	See Table 187 on page 9-16.
Sustained Data Rate (kbps) - Uplink	This field displays the value that is currently in effect for the SM/BHS, with the source of that value in parentheses. This is the specified rate at which each SM/BHS registered to this AP/BHM is replenished with credits for transmission. The configuration source of the value is indicated in parentheses. See Maximum Information Rate (MIR) Parameters on page 7-259.
Sustained Data Rate (kbps) - Downlink	This field displays the value that is currently in effect for the SM/BHS, with the source of that value in parentheses. This is the specified the rate at which the AP/BHM should be replenished with credits (tokens) for transmission to each of the SMs/BHS's in its sector. The configuration source of the value is indicated in parentheses. See Maximum Information Rate (MIR) Parameters on page 7-259.

Burst Allocation (kbit) - Uplink	<p>This field displays the value that is currently in effect for the SM/BHS, with the source of that value in parentheses. This is the specified maximum amount of data that each SM/BHS is allowed to transmit before being recharged at the Sustained Uplink Data Rate with credits to transmit more. The configuration source of the value is indicated in parentheses.</p> <p>See Interaction of Burst Allocation and Sustained Data Rate Settings on page 7-261</p>
Burst Allocation (kbit) - Downlink	<p>This field displays the value that is currently in effect for the SM/BHS, with the source of that value in parentheses. This is the specified the rate at which the AP/BHM should be replenished with credits (tokens) for transmission to each of the SMs/BHS's in its sector. The configuration source of the value is indicated in parentheses.</p> <p>See Interaction of Burst Allocation and Sustained Data Rate Settings on page 7-261</p>
Max Burst Rate (kbit) - Uplink	<p>The data rate at which an SM/BHS is allowed to burst (until burst allocation limit is reached) before being recharged at the Sustained Uplink Data Rate with credits to transit more. When set to 0 (default), the burst rate is unlimited.</p> <p>See Interaction of Burst Allocation and Sustained Data Rate Settings on page 7-261</p>
Max Burst Rate (kbit) - Downlink	<p>The data rate at which an SM/BHS is allowed to burst (until burst allocation limit is reached) before being recharged at the Sustained Downlink Data Rate with credits to transit more. When set to 0 (default), the burst rate is unlimited.</p> <p>See Interaction of Burst Allocation and Sustained Data Rate Settings on page 7-261</p>
Low Priority CIR	<p>This field indicates the minimum rate at which low priority traffic is sent over the uplink and downlink (unless CIR is oversubscribed or RF link quality is degraded).</p>
High CIR	<p>This field indicates the minimum rate at which high priority traffic is sent over the uplink and downlink (unless CIR is oversubscribed or RF link quality is degraded).</p>
Broadcast/Multicast Allocation	<p>This field displays the data rate at which Broadcast and Multicast traffic is sent via the radio link.</p>
RADIUS Authentication Reply	<p>This field displays whether RADIUS server is reachable or not.</p>


RADIUS Authentication Server	This field displays the associated RADIUS Authentication Server for each SM where it was authenticated. This information is useful when there are multiple RADIUS servers (maximum three servers supported by Cambium). If one server is not reachable, other configured servers are tried in sequential order as a fall-back. In this scenario, the Session Status is useful to identify associate RADIUS Authentication Server for all connected SMs.
------------------------------	---

Table 191 Session Status > Configuration CIR configuration denotations

Attribute	Meaning
(SM)	QoS/VLAN parameters are derived from the SM's/BHS's settings
(APCAP)	QoS/VLAN parameters are derived from the AP's settings, including any keyed capping (for radios capped at 4 Mbps, 10 Mbps, or 20 Mbps)
(D)	QoS/VLAN parameters are retrieved from the device, due to failed retrieval from the AAA or WM server.
(AAA)	QoS/VLAN parameters are retrieved from the RADIUS server
(BAM)	QoS/VLAN parameters are retrieved from a WM BAM server

Viewing Remote Subscribers

This page allows to view the web pages of registered SMs or BHS over the RF link. To view the pages for a selected SM/BHS, click its link. The **General Status** page of the SM opens.

Figure 165 Remote Subscribers page of AP

Interpreting messages in the Event Log

Each line in the Event Log of a module Home page begins with a time and date stamp. However, some of these lines wrap as a combined result of window width, browser preferences and line length. You may find this tab easiest to use if you expand the window till all lines are shown beginning with time and date stamp.

Time and Date Stamp

The time and date stamp reflect one of the following:

- GPS time and date directly or indirectly received from the CMM4.
- NTP time and date from a NTP server (CMM4 may serve as an NTP server)
- The running time and date that you have set in the Time & Date web page.



Note

In the Time & Date web page, if you have left any time field or date field unset and clicked the **Set Time and Date** button, then the time and date default to **00:00:00 UT : 01/01/00**.

A reboot causes the preset time to pause or, in some cases, to run in reverse. Additionally, a power cycle resets the running time and date to the default **00:00:00 UT : 01/01/00**. Thus, whenever either a reboot or a power cycle has occurred, must reset the time and date in the Time & Date web page of any module that is not set to receive sync.


Event Log Data Collection

The collection of event data continues through reboots and power cycles. When the buffer allowance for event log data is reached, the system adds new data into the log and discards an identical amount of the oldest data.

Each line that contains the expression WatchDog flags an event that was both:

- considered by the system software to have been an exception
- recorded in the preceding line.

Conversely, a Fatal Error () message flags an event that is recorded in the next line. Some exceptions and fatal errors may be significant and require either operator action or technical support.

Figure 166 Event log data

Messages that Flag Abnormal Events

The messages listed below flag abnormal events and, case by case, may signal the need for corrective action or technical support.

Table 192 Event Log messages for abnormal events

Event Message	Meaning
Expected LUID = 6 Actual LUID = 7	Something is interfering with the control messaging of the module. Also ensure that you are using shielded cables to minimize interference. Consider trying different frequency options to eliminate or reduce interference.
FatalError()	The event recorded on the line immediately beneath this message triggered the Fatal Error ().
Loss of GPS Sync Pulse	Module has lost GPS sync signal.
Machine Check Exception	This is a symptom of a possible hardware failure. If this is a recurring message, begin the RMA process for the module.
RcvFrmNum = 0x00066d ExpFrmNum = 0x000799	Something is interfering with the control messaging of the module. Also ensure that you are using shielded cables to minimize interference. Consider trying different frequency options to eliminate or reduce interference.
System Reset Exception -- External Hard Reset	The unit lost power or was power cycled.

System Reset	
Exception -- External	The event recorded on the preceding line triggered this WatchDog
Hard Reset	message.
WatchDog	

Messages that Flag Normal Events

The messages listed below record normal events and typically *do not* signal a need for any corrective action or technical support.

Table 193 Event Log messages for normal events


Event Message	Meaning
Acquired GPS Sync Pulse.	Module has acquired GPS sync signal.
FPGA Features	Type of encryption.
FPGA Version	FPGA (JBC) version in the module.
GPS Date/Time Set	Module is now on GPS time.
Reboot from Webpage	Module was rebooted from management interface.
Software Boot Version	Boot version in the module.
Software Version	The software release and authentication method for the unit.
System Log Cleared	Event log was manually cleared.

Viewing the Network Interface

In any module, the LAN1 Network Interface section of this tab displays the defined Internet Protocol scheme for the Ethernet interface to the module. In SM/BHS devices, this page also provides an RF Public Network Interface section, which displays the Internet Protocol scheme defined for network access through the master device (AP/BHM).

Figure 167 Network Interface tab of the AP

LAN1 Network Interface	
Ethernet Interface :	1000Base-TX Full Duplex
IP address :	10.120.226.64
Subnet Mask :	255.255.254.0
Gateway IP address :	10.120.226.254
Preferred DNS Server :	10.120.12.31
Alternate DNS Server :	10.120.12.30
DHCP status :	DHCP not enabled

Figure 168 Network Interface tab of the SM

The screenshot shows a window titled "LAN1 Network Interface" with a table of configuration parameters. The table has two columns: the parameter name and its value. The parameters listed are Ethernet Interface, IP address, Subnet Mask, Gateway IP address, Preferred DNS Server, Alternate DNS Server, and DHCP status.

Parameter	Value
Ethernet Interface :	1000Base-TX Full Duplex
IP address :	10.120.216.220
Subnet Mask :	255.255.255.0
Gateway IP address :	10.120.216.254
Preferred DNS Server :	0.0.0.0
Alternate DNS Server :	0.0.0.0
DHCP status :	DHCP not enabled

Viewing the Layer 2 Neighbors

In the Layer 2 Neighbors tab, a module reports any device from which it has received a message in Link Layer Discovery Protocol within the previous two minutes. Given the frequency of LLDP messaging, this means that the connected device will appear in this tab 30 seconds after it is booted and remain until two minutes after its shutdown.

Figure 169 Layer 2 Neighbors page

The screenshot shows a window titled "Layer 2 Neighbors Log" with a list of neighbor information. The information displayed includes the MAC address, IP address, and Site Name.

MAC address:	0a-00-3e-a0-01-75
IP address:	192.168.2.6
Site Name:	No Site Name

System statistics

This section describes how to use the system statistics pages to manage the performance of the PMP/PTP 450 platform link.

Viewing the Scheduler statistics

The **Statistics > Scheduler** page is applicable for all modules (AP/SM/BHM/BHS) and the parameters are displayed as shown below:

Table 194 Scheduler tab attributes

Radio Statistics	
Transmit Unicast Data Count :	0
Transmit Broadcast Data Count :	176
Transmit Multicast Data Count :	0
Receive Unicast Data Count :	0
Receive Broadcast Data Count :	0
Receive Multicast Data Count :	0
Transmit Control Count :	0
Receive Control Count :	0
In Sync Count :	0
Out of Sync Count :	0
Overrun Count :	0
Underrun Count :	0
Receive Corrupt Data Count :	0
Receive Corrupt Control Data Count :	0
Receive Bad Broadcast Control Count :	0
Bad In Sync ID Received :	0
Rcv LT Start :	0
Rcv LT Start HS :	0
Rcv LT Result :	0
Xmt LT Result :	0
Frame Too Big :	0
Bad Acknowledgment :	0
Bad Fragment :	0

Attribute	Meaning
Transmit Unicast Data Count	The total amount of unicast packets transmitted from the radio
Transmit Broadcast Data Count	The total amount of broadcast packets transmitted from the radio
Transmit Multicast Data Count	The total amount of multicast packets transmitted by the radio
Receive Unicast Data Count	The total amount of unicast packets received by the radio

Receive Broadcast Data Count	The total amount of broadcast packets received by the radio
Transmit Control Count	The amount of radio control type messages transmitted (registration requests and grants, power adjust, etc.).
Receive Control Count	The amount of radio control type messages received (registration requests and grants, power adjust, etc.).
In Sync Count	Number of times the radio has acquired sync. In the case of an AP generating sync this is when generated sync has been locked, or if GPS synchronization is used it is number of times GPS sync acquired. For the SM, it is the number of times the SM successfully obtained sync with an AP.
Out of Sync Count	Number of times the radio lost same sync lock.
Overflow Count	Number of times FPGA frame has overrun its TX Frame
Underrun Count	Number of times FPGAs TX Frame aborted prematurely.
Receive Corrupt Data Count	Number of times a corrupt fragment has been received at the FPGA.
Receive Bad Broadcast Control Count	Number of times the radio has received an invalid control message via broadcast (SM only).
Bad In Sync ID Received	Currently unused
Rcv LT Start	Number of Link Test Start messages received. A remote radio has requested that this radio start a link test to it.
Rcv LT Start HS	Number of Link Test Start Handshake messages received. This radio requested that a remote radio start a link test and the remote radio has sent a handshake back acknowledging the start.
Rcv LT Result	This radio received Link Test results from the remote radio under test. When this radio initiates a link test, the remote radio will send its results to this radio for display.
Xmt LT Result	This radio transmitted its link test results to the remote radio under test. When the remote radio initiates a link test, this radio must send its results to the remote radio for display there.
Frame Too Big	This statistics indicates the number of packets received and processed by the radios which were greater than max packet size 1700 bytes.
Bad Acknowledgment	This statistics indicates the number of packets received as bad acknowledgment. It is for engineering use only.
Bad Fragment	This statistic indicates number of fragments tagged internally as bad. It is for engineering use only.

Viewing list of Registration Failures statistics

SM Registration Failures page of AP

The SM Registration Failures tab identifies SMs that have recently attempted and failed to register to this AP. With its time stamps, these instances may suggest that a new or transient source of interference exists.

Table 195 SM Registration Failures page attributes - AP

<div style="border: 1px solid #0056b3; padding: 5px;"> Registration Failures Statistics </div> Number of Registration Grant Failures : 1	
<div style="border: 1px solid #0056b3; padding: 5px;"> Most Recent Registration Failure List </div> MAC : 0a-00-3e-04-a7-26 AAA Session Retry 12/31/2010 : 19:23:30 CST : Status : 17 Flag : 0	
Attribute	Meaning
Status 17 Flag 0	No response was received from the AAA server and hence SM is trying to send a session request again.

BHS Registration Failures page of BHM

Table 196 BHS Registration Failures page attributes - BHM

<div style="border: 1px solid #0056b3; padding: 5px;"> Registration Failures Statistics </div> Number of Registration Grant Failures : 1	
<div style="border: 1px solid #0056b3; padding: 5px;"> Most Recent Registration Failure List </div> MAC : 0a-00-3e-04-a7-26 AAA Session Retry 12/31/2010 : 19:23:30 CST : Status : 17 Flag : 0	
Attribute	Meaning
Status 17 Flag 0	No response was received from the AAA server and hence SM is trying to send a session request again.

There is a list of flags from 0 to 20 as shown in [Table 197](#) and the “Flags” can be ignored.

Table 197 Flags status

Flag	Meaning	Flag	Meaning
0	Normal	11	AP Lite Limit Reached
1	Out of Range	12	Only Ver 9.5+ Allowed
2	No Luids	13	Temporary Data VC for AAA
3	BH ReRange	14	AAA Authentication Failure
4	Auth Fail	15	Registration Grant Reject
5	Encrypt Fail	16	Blank
6	Power Adjust	17	AAA Session Retry
7	No VCs	18	AAA Reauth Failure
8	Reserve VC Fail	19	RegReq at zero power
9	Activate VC Fail	20	RegReq no time ref
10	Hi VC Setup Fail	-	-

Interpreting Bridging Table statistics

If NAT (network address translation) is not active on the SM/BHS, then the Bridging Table page provides the MAC address of all devices that are attached to registered SMs/BHS (identified by LUIDs).

The SM/BHS management MAC addresses are also added in bridge table upon SMs/BHS registration. These entries will be removed automatically from the table once SMs/BHS is de-registered. This alleviates the arp cache > bridge cache timeout problems.


The bridging table allows data to be sent to the correct module as follows:

- For the AP/BHM, the uplink is from RF to Ethernet. Thus, when a packet arrives in the *RF* interface to the AP/BHM, the AP/BHM reads the MAC address from the inbound packet and creates a bridging table entry of the source MAC address on the other end of the *RF* interface.
- For the SM/BHS, the uplink is from Ethernet to RF. Thus, when a packet arrives in the Ethernet interface to one of these modules, the module reads the MAC address from the inbound packet and creates a bridging table entry of the source MAC address on the other end of the Ethernet interface.

Figure 170 Bridging Table page

Statistics → Bridging Table

5.4GHz MIMO OFDM - Access Point - 0a-00-3e-bb-00-fb




Physical Address	Dest LUID	Age	Hash	Ent
0A003EBB00FB	258	-1	0576	02
0A003EBB0104	002	-1	0959	02
1A003EBB00FB	259	-1	0576	02
1A003EBB0104	002	-1	0959	02

Used: 4 BridgeFree: 4092 BridgeFullErr: 0

The Bridging Table supports up to 4096 entries.

Interpreting Translation Table statistics

When Translation Bridging is enabled in the AP, each SM keeps a table mapping MAC addresses of devices attached to the AP to IP addresses, as otherwise the mapping of end-user MAC addresses to IP addresses is lost. (When Translation Bridging is enabled, an AP modifies all uplink traffic originating from registered SMs such that the source MAC address of every packet is changed to that of the SM which bridged the packet in the uplink direction.)

Figure 171 Translation Table page of SM


Mac	IpAddress	Age
002275394384	192.168.2.1	0
001F3B4AC679	192.168.2.7	0
902155C788E8	192.168.2.2	0
000D4B76388B	192.168.2.4	0
AC81128BCCF4	192.168.2.3	0
0004236DA056	192.168.2.8	3
00265507A92B	192.168.2.5	4
902155C788E8	173.158.9.186	68
5CDAD4818A2F	192.168.2.9	50
001F3B4AC679	192.168.50.137	26

Interpreting Ethernet statistics

The **Statistics > Ethernet** page reports TCP throughput and error information for the Ethernet connection of the module. This page is applicable for all modules (AP/SM/BHM/BHS).

The **Ethernet** page displays the following fields.

Table 198 Ethernet tab attributes

Ethernet Control Block Statistics	
Ethernet Link Detected :	1
Ethernet Link Lost :	0
Undersized Toss Count :	0
inoctets Count :	139159
inucastpkts Count :	420
Innucastpkts Count :	86
indiscards Count :	0
inerrors Count :	0
inunknownprotos Count :	0
outoctets Count :	56864
outucastpktsCount :	184
outnucastpkts Count :	3
outdiscards Count :	0
outerrors Count :	1
RxBabErr :	0
TxHbErr :	0
EthBusErr :	0
CRCErr :	0
RcvFifoNoBuf :	0
RxOverrun :	0
LateCollision :	0
RetransLimitExp :	0
TxUnderrun :	0
CarSenseLost :	0
No Carrier :	1

Attribute	Meaning
Ethernet Link Detected	1 indicates that an Ethernet link is established to the radio, 0 indicates that no Ethernet link is established
Ethernet Link Lost	This field indicates a count of how many times the Ethernet link was lost.
Undersized Toss Count	This field indicates the number of packets that were too small to process and hence discarded.
inoctets Count	This field displays how many octets were received on the interface, including those that deliver framing information.
inucastpkts Count	This field displays how many inbound subnetwork-unicast packets were delivered to a higher-layer protocol.
Innucastpkts Count	This field displays how many inbound non-unicast (subnetwork-broadcast or subnetwork-multicast) packets were delivered to a higher-layer protocol.

indiscards Count	This field displays how many inbound packets were discarded without errors that would have prevented their delivery to a higher-layer protocol. (Some of these packets may have been discarded to increase buffer space.)
inerrors Count	This field displays how many inbound packets contained errors that prevented their delivery to a higher-layer protocol.
inunknownprotos Count	This field displays how many inbound packets were discarded because of an unknown or unsupported protocol.
outoctets Count	This field displays how many octets were transmitted out of the interface, including those that deliver framing information.
outucastpkts Count	This field displays how many packets for which the higher-level protocols requested transmission to a subnetwork-unicast address. The number includes those that were discarded or not sent.
outnucastpkts Count	This field displays how many packets for which the higher-level protocols requested transmission to a non-unicast (subnetwork-broadcast or subnetwork-multicast) address. The number includes those that were discarded or not sent.
outdiscards Count	This field displays how many outbound packets were discarded without errors that would have prevented their transmission. (Some of these packets may have been discarded to increase buffer space.)
outerrors Count	This field displays how many outbound packets contained errors that prevented their transmission.
RxBabErr	This field displays how many receiver babble errors occurred.
TxHbErr	This field displays how many transmit heartbeat errors have occurred.
EthBusErr	This field displays how many Ethernet bus errors occurred on the Ethernet controller.
CRCErr	This field displays how many CRC errors occurred on the Ethernet controller.
RcvFifoNoBuf	This field displays the number of times no FIFO buffer space was able to be allocated
RxOverrun	This field displays how many receiver overrun errors occurred on the Ethernet controller.
Late Collision	This field displays how many late collisions occurred on the Ethernet controller. A normal collision occurs during the first 512 bits of the frame transmission. A collision that occurs after the first 512 bits is considered a late collision.

**Caution**


A late collision is a serious network problem because the frame being transmitted is discarded. A late collision is most commonly caused by a mismatch between duplex configurations at the ends of a link segment.

RetransLimitExp	This field displays how many times the retransmit limit has expired.
TxUnderrun	This field displays how many transmission-underrun errors occurred on the Ethernet controller.
CarSenseLost	This field displays how many carrier sense lost errors occurred on the Ethernet controller.
No Carrier	This field displays how many no carrier errors occurred on the Ethernet controller.

Interpreting RF Control Block statistics

The **Statistics > Radio** page is applicable for all module (AP/SM/BHM/BHS). The Radio page of the Statistics page displays the following fields.

Table 199 Radio (Statistics) page attributes



RF Control Block Statistics	
inoctets Count :	653532396
inucastpkts Count :	423096
Innucastpkts Count :	35848043
indiscards Count :	0
inerrors Count :	0
inunknownprotos Count :	0
outoctets Count :	138721214
outucastpktsCount :	401826
outnucastpkts Count :	13855
outdiscards Count :	120
outerrors Count :	0

Attribute	Meaning
inoctets Count	This field displays how many octets were received on the interface, including those that deliver framing information.
inucastpkts Count	This field displays how many inbound subnetwork-unicast packets were delivered to a higher-layer protocol.
Innucastpkts Count	This field displays how many inbound non-unicast (subnetwork-broadcast or subnetwork-multicast) packets were delivered to a higher-layer protocol.
indiscards Count	<p>This field displays how many inbound packets were discarded without errors that would have prevented their delivery to a higher-layer protocol. This stat is pegged whenever corrupt data is received by software or whenever the RF Software Bridge queue is full.</p> <p>Corrupt data is a very unusual event because all packets are CRC checked by hardware before being passed into software.</p> <p>The likely case for indiscards is if the RF bridge queue is full. If this is the case the radio is most likely PPS limited due to excessive small packet traffic or a problem at the Ethernet interface. If there is a problem at the Ethernet interface there is likely to be discards at the Ethernet as well.</p>
inerrors Count	This field displays how many inbound packets contained errors that prevented their delivery to a higher-layer protocol.
inunknownprotos Count	This field displays how many inbound packets were discarded because of an unknown or unsupported protocol.

outoctets Count	This field displays how many octets were transmitted out of the interface, including those that deliver framing information.
outucastpkts Count	This field displays how many packets for which the higher-level protocols requested transmission to a subnetwork-unicast address. The number includes those that were discarded or not sent.
outnucastpkts Count	This field displays how many packets for which the higher-level protocols requested transmission to a non-unicast (subnetwork-broadcast or subnetwork-multicast) address. The number includes those that were discarded or not sent.
outdiscards Count	This field displays how many outbound packets were discarded without errors that would have prevented their transmission. (Some of these packets may have been discarded to increase buffer space.)
outerrors Count	This field displays how many outbound packets contained errors that prevented their transmission.

Interpreting VLAN statistics

The **Statistics > VLAN** page provides a list of the most recent packets that were filtered because of VLAN membership violations. It is applicable for all modules (AP/SM/BHM/BHS).

Table 200 VLAN page attributes

The screenshot shows three panels from the VLAN Statistics page:

- VLAN Statistics Configuration:** Shows a configuration for VLAN 1, with a range of 1 to 4094 or 0 for Priority-tagged.
- VLAN Statistics:** Shows statistics for VID 1:
 - VID Stats Frames Received : 1823
 - Bytes Received : 586624
 - Frames Transmitted : 1640
 - Bytes Transmitted : 585735
- Most Recent Filtered Frames:** Shows no ingress filtered frames and zero total frames/bytes filtered for both ingress and egress.

Attribute	Meaning
Unknown	This must not occur. Contact Technical Support.
Only Tagged	The packet was filtered because the configuration is set to accept only packets that have an 802.1Q header and this packet did not.

Ingress	When the packet entered through the wired Ethernet interface, the packet was filtered because it indicated an incorrect VLAN membership.
Local Ingress	When the packet was received from the local TCP/IP stack, the packet was filtered because it indicated an incorrect VLAN membership. This must not occur. Contact Technical Support.
Egress	When the packet attempted to leave through the wired Ethernet interface, the packet was filtered because it indicated an incorrect VLAN membership.
Local Egress	When the packet attempted to reach the local TCP/IP stack, the packet was filtered because it indicated an incorrect VLAN membership.

Interpreting Data VC statistics

The **Statistics > Data VC** page displays information about Virtual Channel (VC) used in data communications. This page is applicable for all modules (AP/SM/BHM/BHS).

The **Data VC** tab displays the fields as explained in [Table 201](#).

Table 201 Data VC page attributes

Data VC Statistics (CoS: 00 = Lowest Priority, 07 = Highest Priority)																			
Note: To measure the receive modulation of every fragment, Receive Quality Debug must be enabled.																			
Subscriber	VC	CoS	Inbound Statistics										Outbound Statistics					Queue Overflow	High Priority Queue
			octets	ucast pkts	nucast pkts	discards	errors	QPSK frgmts	16-QAM frgmts	64-QAM frgmts	256-QAM frgmts	octets	ucast pkts	nucast pkts	discards	errors			
LUID: 002	018	00	471342	1400	4	0	0	1082 365	298 166	268 114	246 112	513512	1405	7	0	0	0	889	
Multicast	016	00	NA	NA	NA	NA	NA	NA	NA	NA	NA	0	0	0	0	0	0	NA	NA
Broadcast	012	00	NA	NA	NA	NA	NA	NA	NA	NA	NA	66936	1	940	0	0	0	NA	NA

Attribute	Meaning
Subscriber	This field displays the LUID (logical unit ID), MAC address and Site Name of the SM/BHS. As each SM or BHS registers to the AP/BHM, the system assigns an LUID of 2 or a higher unique number to the SM/BHS. If a SM/BHS loses registration with the AP/BHM and then regains registration, the SM/BHS retains the same LUID.
VC	This field displays the virtual channel number. Low priority channels start at VC18 and count up. High priority channels start at VC255 and count down. If one VC is displayed, the high-priority channel is disabled. If two are displayed, the high-priority channel is enabled.
CoS	This field displays the Class of Service for the virtual channel. The low priority channel is a CoS of 00 and the high priority channel is a CoS of 01. CoS of 02 through 07 are not currently used.
Inbound Statistics, octets	This field displays how many octets were received on the interface, including those that deliver framing information.
Inbound Statistics, ucastpkts	This field displays how many inbound subnetwork-unicast packets were delivered to a higher-layer protocol.
Inbound Statistics, nucastpkts	This field displays how many inbound non-unicast (subnetwork-broadcast or subnetwork-multicast) packets were delivered to a higher-layer protocol.

Inbound Statistics, discards	This field displays how many inbound packets were discarded without errors that would have prevented their delivery to a higher-layer protocol. Inbound discard statistics are incremented similar to the indiscards stat on the RF control block stats page. The sum of all data VC indiscards must be close to the RF control block in discards. If indiscards are evenly distributed across SMs, then the radio is PPS limited due to either excessive small packet transmissions, or a problem at the Ethernet link. If indiscards are contained to one or a few SMs, then there is likely a problem at or underneath the SM which is incrementing the count.
Inbound Statistics, errors	This field displays how many inbound packets contained errors that prevented their delivery to a higher-layer protocol.
Inbound Statistics, QPSK frgmts	This field displays how many inbound fragments were received via the QPSK modulation scheme.
Inbound Statistics, 16-QAM frgmts	This field displays how many inbound fragments were received via the 16-QAM modulation scheme.
Inbound Statistics, 64-QAM frgmts	This field displays how many inbound fragments were received via the 64-QAM modulation scheme.
Inbound Statistics, 256-QAM frgmts	This field displays how many inbound fragments were received via the 256-QAM modulation scheme.
Outbound Statistics, octets	This field displays how many octets were transmitted out of the interface, including those that deliver framing information.
Outbound Statistics, ucastpkts	This field displays how many packets for which the higher-level protocols requested transmission to a subnetwork-unicast address. The number includes those that were discarded or not sent.
Outbound Statistics, nucastpkts	This field displays how many packets for which the higher-level protocols requested transmission to a non-unicast (subnetwork-broadcast or subnetwork-multicast) address. The number includes those that were discarded or not sent.
Outbound Statistics, discards	This field displays how many outbound packets were discarded without errors that would have prevented their transmission. Outbound discard statistics are incremented if a VC is not active when a packet is ready to send. This is a rare condition.
Outbound Statistics, errors	This field displays how many outbound packets contained errors that prevented their transmission.

Queue Overflow	This is a count of packets that were discarded because the queue for the VC was already full. If Queue Overflows are being seen across most or all SMs, then there is either an interferer local to the AP or the APs RF link is at capacity. If Queue Overflows are being seen at one or only a few SMs, then it is likely that there is a problem with those specific links whether it is insufficient signal strength, interferer, or a problem with the actual SM hardware.
High Priority Queue	This is a count of packets that were received on high priority queue.

Interpreting Throughput statistics

The PMP/PTP 450 platform has a **Statistics > Throughput** page which shows historical information about sector or backhaul throughput and packet discards. This page is applicable for AP and BHM modules. This information can be useful to identify an overloaded sector or heavy bandwidth users. This page also shows the user throughput in terms of data rate (kbps) and packet rate (packets per second, or PPS), as well as the average packet size during the sample period.

Operators may set the AP/BHM to send an SNMP trap when it detects an RF overload condition based on a configurable threshold.

The following configuration parameters are available on the Throughput tab GUI pane and a radio reboot is not required when configuring these parameters:

Table 202 RF overload Configuration attributes – AP/BHM

Attribute	Meaning
Throughput Monitoring	This enables or disables the monitoring of sector throughput and packet discards. This parameter is disabled by default.
SNMP Trap on RF Overload	This enables or disables the sending of an SNMP trap when an AP/BHM overload condition is reached (based on Downlink RF Overload Threshold).
Downlink RF Overload Threshold	This parameter determines the overload threshold in percent of packets discarded that triggers the generation of an SNMP trap.

Downlink RF Link Status	This field displays the status of the capacity of the RF link.
Time Period Length Time Period Ending	These two configuration parameters determine what set of collection samples to show on the GUI display. The Time Period Length can be set from one to three hours. Time Period Ending allows the operator to set the end time for the set of collection samples to display.

Below the configuration settings are three tables that display the statistics that are collected.

Board Performance statistics

This table contains a row that corresponds to each 1 minute statistics collection interval. Each row contains the following data aggregated for the entire AP/BHM:

- **Ethernet Throughput** - Statistics collected at the Ethernet port:
 - **kbps in** – average throughput over the collection interval in Kbps into the AP/BHM on the Ethernet Interface
 - **kbps out** – average throughput over the collection interval in Kbps out of the AP/BHM on the Ethernet Interface
 - **PPS in** – average packets per second over the collection interval into the AP/BHM on the Ethernet Interface
 - **PPS out** – average packets per second over the collection interval out of the AP/BHM on the Ethernet Interface
- **RF Throughput** - Statistics collected at the RF Interface:
 - **kbps in** – average throughput over the collection interval in Kbps into the AP/BHM on the RF Interface
 - **kbps out** – average throughput over the collection interval in Kbps out of the AP/BHM on the RF Interface
 - **PPS in** – average packets per second over the collection interval into the AP/BHM on the RF Interface
 - **PPS out** – average packets per second over the collection interval out of the AP/BHM on the RF Interface
- **Aggregate Through Board** – Sum of bidirectional data transferred *through* (not originating or terminating at) the AP/BHM:
 - **kbps** – average bidirectional throughput over the collection interval in Kbps
 - **PPS** – average bidirectional packets per second over the collection interval
 - **Ave Pkt Size** – Average Packet size over the collection interval of bidirectional data transferred

Board Throughput statistics

This table contains a row that corresponds to each one minute statistics collection interval. This table may be used to determine if there are problems with any of the interfaces. For example, if the Ethernet in packets is much higher than the RF out packets it could indicate a denial of service (DoS) attack on the AP/BHM. Each row contains the following data aggregated for the entire AP/BHM:

- **Ethernet Statistics** - Statistics collected at the Ethernet port:
 - **inOctets** – Number of octets (bytes) received by the AP/BHM at the Ethernet Interface over the collection interval
 - **outOctets** – Number of octets (bytes) sent by the AP/BHM at the Ethernet Interface over the collection interval
 - **inPkts** – Number of packets received by the AP/BHM at the Ethernet Interface over the collection interval
 - **outPkts** – Number of packets sent by the AP/BHM at the Ethernet Interface over the collection interval
 - **Discards (in/out)** – Number of packets that had to be discarded by the AP/BHM at the respective Ethernet Interface Queue
- **RF Statistics** - Statistics collected at the RF Interface:
 - **inOctets** – Number of octets (bytes) received by the AP/BHM at the RF Interface over the collection interval
 - **outOctets** – Number of octets (bytes) sent by the AP/BHM at the RF Interface over the collection interval
 - **inPkts** – Number of packets received by the AP/BHM at the RF Interface over the collection interval
 - **outPkts** – Number of packets sent by the AP/BHM at the RF Interface over the collection interval
 - **Discards (in/out)** – Number of packets that had to be discarded by the AP/BHM at the respective RF Interface Queue during the collection interval
 - **Discards % (in/out)** – Percent of the total packets received / transmitted that had to be discarded during the collection interval

LUID RF Throughput statistics

This table contains a row that corresponds to each active LUID served by the AP/BHM. Note that an LUID may be assigned 1 or 2 VCs. If the LUID is assigned 2 VCs, then the data in the table is the sum of the activity for both VCs. This table may be used to determine which LUIDs are experiencing overload so that corrective action can be taken (i.e. fixing a poor RF link or moving a heavily loaded link to a less congested AP/BHM). Each row contains counters and statistics related to the RF Interface that are updated once per minute:

- **Inbound Statistics** - Statistics collected at the RF Interface for the Uplink:
 - **octets** – Number of octets (bytes) received by the AP/BHM at the RF Interface for this LUID over the collection interval
 - **pkts** – Number of packets received by the AP/BHM at the RF Interface for this LUID over the collection interval
 - **Ave Pkt Size** – Average size of the packets received by the AP/BHM at the RF Interface for this LUID over the collection interval
 - **discards** – Number of packets received by the AP/BHM at the RF Interface for this LUID over the collection interval that had to be discarded because the RF In Queue was full
 - **discards %** – Percent of the total packets received by the AP/BHM at the RF Interface for this LUID over the collection interval that had to be discarded because the RF In Queue was full
- **Outbound Statistics** - Statistics collected at the RF Interface for the Downlink:
 - **octets** – Number of octets (bytes) transmitted by the AP/BHM at the RF Interface for this LUID over the collection interval


- **pkts** – Number of packets transmitted by the AP/BHM at the RF Interface for this LUID over the collection interval
- **Ave Pkt Size** – Average size of the packets transmitted by the AP/BHM at the RF Interface for this LUID over the collection interval
- **discards** – Number of packets to be transmitted by the AP/BHM at the RF Interface for this LUID over the collection interval that had to be discarded because the RF Out Queue was full
- **discards %** – Percent of the total packets to be transmitted by the AP/BHM at the RF Interface for this LUID over the collection interval that had to be discarded because the RF Out Queue was full.

Interpreting Overload statistics

The Statistics > Overload page displays statistics on packet overload and resultant packet discards. Unlike the other fields, the Total Packets Overload Count is expressed in only this page. It is not a count of how many packets have been lost, but rather of how many discard events (packet loss bursts) have been detected due to overload condition.

This statistics page is applicable for all modules (AP/SM/BHM/BHS) and explained in [Table 203](#).

Table 203 Overload page attributes – AP/SM/BHM/BHS



Packet Overload Statistics	
Total Packets Overload Count :	0
Ethernet In Discards (Statistics=>Ethernet=>RxOverrun + Statistics=>Bridge Control Block=>ErrApFecQSend) :	0
Ethernet Out Discards (Statistics=>Ethernet=>outdiscards count) :	0
RF In Discards (Sum of all VCs of: Statistics=>Data VC=>indiscards count) :	0
RF Out Discards (Statistics=>Radio=>outdiscards count) :	0

Attribute	Meaning
Total Packets Overload Count	This field represents the sum of all RF and Ethernet in/out discards.
Ethernet In Discards	This field represents the number of packets tossed due to the Ethernet queue being full. If a climb in this stat accompanies a climb in RF Out Discards stat, then most likely the board is at RF capacity either due to traffic exceeding the RF pipe, or interference temporarily limiting the RF throughput. If this stat climbs without the RF Out Discards stat climbing, then the radio is most likely PPS limited.

Ethernet Out Discards	This field represents the number of packets tossed due to an Ethernet out overload. This stat must not climb in normal operation because the Ethernet link is much higher capacity than the RF link. If this stat is incrementing, then either the Ethernet link is established at a low speed (i.e. 10Mbps – half duplex), or there is a problem with cabling/Ethernet hardware.
RF In Discards	This field indicates the number of packets tossed due to no resources available within the radio to process them. This stat also must not be increasing because the system is designed to shed packets on the RF Out interface. If this stat is incrementing the board, it is most likely congested due to high PPS rate in combination with an Ethernet Out problem, which limits packet flow off the device.
RF Out Discards	This field indicates the number of packets tossed due to RF link at capacity. This stat will increase whenever the RF link is at capacity. When the internal FPGA RF input queue overflows, this stat is incremented. If this stat is seen to be incrementing at the AP, then the sector is congested. If seen at the SM, the number of Contention Slots must be looked at to ensure that enough Contention Slots are allocated to allow for bandwidth requests to be seen at the AP.

Interpreting DHCP Relay statistics

The **Statistics > DHCP Relay** page displays requests and replies received, relayed and discarded when the AP is configured as a DHCP relay. Typically, in a working DHCP relay configuration a one-to-one ratio is established between requests and replies that are received and relayed. This statistics page is only applicable for PMP (AP and SM modules) and it is explained in [Table 204](#).

Table 204 DHCP Relay page attributes – AP/SM

Packet Overload Statistics	
Total Packets Overload Count :	0
Ethernet In Discards (Statistics=>Ethernet=>RxOverrun + Statistics=>Bridge Control Block=>ErrApFecQSend) :	0
Ethernet Out Discards (Statistics=>Ethernet=>outdiscards count) :	0
RF In Discards (Sum of all VCs of. Statistics=>Data VC=>indiscards count) :	0
RF Out Discards (Statistics=>Radio=>outdiscards count) :	0

Attribute	Meaning
Requests Received	This field represents the number of DHCP relay requests received by the AP.
Requests Relayed	This field represents the number of DHCP relay requests relayed by the AP.
Requests Discarded	This field represents the number of DHCP relay requests discarded by the AP due to errors in the request.
Replies Received	This field represents the number of DHCP relay replies received by the AP.
Replies Relayed	This field represents the number of DHCP relay replies relayed by the AP.
Replies Discarded	This field represents the number of DHCP relay replies discarded by the AP due to errors in the reply.
Untrusted Message Discards	This field indicates messages that were discarded because the message already contained Option 82 information with no Relay Agent specified.
Max Hop Exceeded Discards	This field indicates messages that have been relayed too many times, exceeding the max hop count (16).
Invalid Relay Agent Address Discards	This field indicates messages that have been discarded because the message relay agent address is already in place (relay agent address does not equal address of the AP).
Relay Info Exceeding Max Message Size (DHCP message relayed without Option 82)	This field indicates DHCP messages too large to fit Option 82 data. These messages are sent on without Option 82 information.

Interpreting Filter statistics

The **Statistics > Filter** page displays statistics on packets that have been filtered (dropped) due to the filters set on the **Protocol Filtering** page. The filter page of SM is explained in [Table 205](#).

Table 205 Filter page attributes - SM

Packet Filter Statistics	
PPPoE Count :	0
All IPv4 Count :	0
All Other IPv4 Count :	0
SMB Count :	0
SNMP Count :	0
Bootp Client Count :	0
Bootp Server Count :	0
IPv4 Multicast Count :	0
All IPv6 Count :	0
All Other IPv6 Count :	0
IPv6 SMB Count :	0
IPv6 SNMP Count :	0
IPv6 Bootp Client Count :	0
IPv6 Bootp Server Count :	0
IPv6 Multicast Count :	0
ARP Count :	0
All Others Count :	0
User Defined Port1 Count :	0
User Defined Port2 Count :	0
User Defined Port3 Count :	0


Attribute	Meaning
PPPoE Count	Number of PPOE packets filtered.
All IPv4 Count	Number of IPv4 packets filtered.
All Other IPv4 Count	Any IPv4 message that was not SMB, SNMP, Bootp, Multicast or one of the user defined filters, that was filtered out.
SMB Count	Number of IPv4 Server Message Block (file sharing) packets filtered.
SNMP Count	Number of IPv4 SNMP packets filtered.
Bootp Client Count	Total number of IPv4 DHCP requests filtered.
Bootp Server Count	Total number of IPv4 DHCP replies filtered.
IPv4 Multicast Count	Number of IPv4 Multicast messages filtered.
All IPv6 Count	Number of IPv6 messages filtered.
All Other IPv6 Count	Any IPv6 message that was not SMB, SNMP, Bootp, Multicast or one of the user defined filters, that was filtered out.
IPv6 SMB Count	Number of IPv6 Server Message Block (file sharing) packets filtered
IPv6 SNMP Count	Number of IPv6 SNMP messages filtered
IPv6 Bootp Client Count	Total number of IPv6 DHCP replies filtered
IPv6 Bootp Server Count	Total number of IPv6 DHCP replies filtered
IPv6 Multicast Count	Number of IPv6 Multicast messages filtered

ARP Count	Total number of ARP packets filtered.
All other Count	The count of any messages that did not fit above that were filtered out
User Defined Port1 Count	Number of packets defined by the user port1 that were filtered.
User Defined Port2 Count	Number of packets defined by the user port2 that were filtered.
User Defined Port3 Count	Number of packets defined by the user port3 that were filtered.

Viewing ARP statistics

The **Statistics > ARP** page in a SM module correlated the IP address of the Ethernet-connected device to its MAC address and provides data about the connection.

Figure 172 ARP page of the SM



IP Address	Physical Address	Interface	Pending	Create Time	Last Time
192.168.2.7	00-1f-3b-4a-c6-79	et1	N	20:52:44 01/01/2011	21:02:43 01/01/2011

Viewing NAT statistics

When NAT is enabled on a SM, statistics are kept on the Public and Private (WAN and LAN) sides of the NAT and displayed on the **Statistics > NAT Stats** page. The NAT page of SM is explained in [Table 206](#).

Table 206 NAT page attributes - SM

Private NAT Statistics	
Packet In Count :	0
Packet Out Count :	0
Packet Out Toss Count :	0
Out Of Resources Count :	0
Failed Hash Insert Count :	0

Public NAT Statistics	
Packet In Count :	0
Packet Out Count :	0
Packet Out Toss Count :	0
Out Of Resources Count :	0
Failed Hash Insert Count :	0

Attribute	Meaning
Private NAT Statistics, Packet In Count	This field represents the number of packets received on the SM's LAN/Ethernet interface
Private NAT Statistics, Packet Out Count	This field represents the number of packets sent from the SM's LAN/Ethernet interface
Private NAT Statistics, Packet Out Toss Count	This field represents the number of packets that we not sent from the SM's LAN/Ethernet interface due to addressing issues.
Private NAT Statistics, Out of Resources Count	This field represents the number of times the NAT table for the SM's LAN/Ethernet interfaces has been filled.
Private NAT Statistics, Failed Hash Insert Count	This field represents the number of times that the device failed to insert an address binding into the NAT hash table.
Public NAT Statistics, Packet In Count	This field represents the number of packets received on the SM's WAN/wireless interface
Public NAT Statistics, Packet Out Count	This field represents the number of packets sent from the SM's WAN/wireless interface
Public NAT Statistics, Out of Resources Count	This field represents the number of packets that we not sent from the SM's WAN/wireless interface due to addressing issues.
Public NAT Statistics, Failed Hash Insert Count	This field represents the number of times the NAT table for the SM's WAN/wireless interfaces has been filled.

Viewing NAT DHCP Statistics

The Statistics > NAT DHCP page displays NAT enabled DHCP client statistics. This is statistics page is applicable for SM only.

When NAT is enabled on a SM with DHCP client (**DHCP** selected as the **Connection Type** of the WAN interface) and/or DHCP Server, statistics are kept for packets transmitted, received and tossed, as well as a table of lease information for the DHCP server (Assigned IP Address, Hardware Address and Lease Remained/State).

Table 207 NAT DHCP Statistics page attributes - SM

The image shows two screenshots from a network management interface. The top window, titled 'DHCP Client Statistics', displays the following data:

```

PktXmt Count: 34
PktRcv Count: 0
PktToss ARPUnresolved Overflow Count: 0
PktToss Unsupported MsgType Count: 0
PktToss XID Mismatch Count: 0
PktToss NoSID Count: 0
PktToss SID Mismatch Count: 0
Failure To Reset Client Count: 0
  
```

The bottom window, titled 'DHCP Server Statistics', displays the following data:

```

Assigned IP Address  Hardware Address  Lease Remained/State
169.254.1.2         001eec1e0260      0d, 00:01:30

PktXmt Count: 2
PktRcv Count: 2
PktToss Count: 0
  
```

Attribute	Meaning
PktXmt Count	Represents the number of DHCP packets transmitted from the client
PktRcv Count	This field represents the number of DHCP packets received by the client
PktToss ARPUnresolved Overflow Count	This field represents the number of packets tossed due to failed attempts to resolve an IP address into a physical MAC address
PktToss Unsupported MsgType Count	This field represents the number of packets tossed due to the receipt of an unsupported message type (cannot be interpreted by DHCP client)
PktToss XID Mismatch Count	The field represents the number of packets that were tossed due to a transaction ID mismatch
PktToss NoSID Count	This field represents the number of packets that were tossed due to lack of a DHCP session ID
PktToss SID Mismatch Count	Represents the number of packets tossed due to a session ID mismatch

Failure to Reset Client Count	This field represents the number of times the DHCP client was unable to be reset (resulting in no IP address being served).
-------------------------------	---

Interpreting Sync Status statistics

The **Statistics > Sync Status** page of AP is only displayed when the Sync Input is set to AutoSync or AutoSync+Free Run.

The Sync Status page is explained in [Table 208](#).

Table 208 Sync Status page attributes - AP

Sync Status	
Sync Pulse Source :	Power Port
Sync Pulse Status :	Receiving Sync
Sync Pulse Status - Timing Port/UGPS :	No Sync
Sync Pulse Status - Power Port :	Receiving Sync
UGPS Power Status :	Power Off

Attribute	Meaning
Sync Pulse Source	This field indicates the status of the synchronization source: <ul style="list-style-type: none"> • Searching indicates that the unit is searching for a GPS fix • Timing Port/UGPS indicates that the module is receiving sync via the timing AUX/SYNC timing port • Power Port indicates that the module is receiving sync via the power port (Ethernet port).
Sync Pulse Status	This field indicates synchronization source pulse status.
Sync Pulse Status – Timing Port/UGPS	This field indicates synchronization pulse status over Timing Port/UGPS port.
Sync Pulse Status - Power Port	This field indicates synchronization pulse status over power port.
UGPS Power Status	This field indicates UGPS power up status (on or off).

This information may be helpful in a decision of whether to climb a tower to diagnose a perceived antenna problem.

Interpreting PPPoE Statistics for Customer Activities

The page can be access under **Statistics > PPPoE** of SM GUI.

When the PPPoE feature is enabled on the SM, PPPoE statistics provide data about activities of the customer.

The PPPoE Statistics of SM is explained in [Table 209](#).

Table 209 PPPoE Statistics page attributes - SM

PPPoE Statistics	
IP address :	0.0.0.0
PPPoE Session Status :	Connecting
PPPoE AC Name :	
PPPoE Service Name :	
PPPoE Session ID :	0
PPPoE Session Uptime :	00:00:00
PPPoE Session Idle Time :	00:00:00
PPPoE Session MTU :	0
Primary DNS Address :	0.0.0.0
Secondary DNS Address :	0.0.0.0
PPPoE Control Bytes Sent :	168
PPPoE Control Bytes Received :	0
PPPoE Data Session Bytes Sent :	0
PPPoE Data Session Bytes Received :	0

Attribute	Meaning
IP address	This field displays the IP address of the PPPoE session initiator (situated below the SM)
PPPoE Session Status	This field displays the operational status of the PPPoE Session
PPPoE AC Name	This field displays access concentrator name used in the PPPoE session
PPPoE Service Name	This field displays the PPPoE service name associated with the PPPoE server in use
PPPoE Session ID	This field displays the current PPPoE session ID
PPPoE Session Uptime	This field displays the total session uptime for the PPPoE session
PPPoE Session Idle Time	This field displays the total idle time for the PPPoE session
PPPoE Session MTU	This field displays Maximum Transmission Unit configured for the PPPoE session
Primary DNS Address	This field displays the primary DNS server used by the PPPoE session
Secondary DNS Address	This field displays the secondary DNS server used by the PPPoE session

PPPoE Control Bytes Sent	Displays the total number of PPPoE session control bytes sent from SM
PPPoE Control Bytes Received	This field displays the total number of PPPoE session control bytes received by the SM
PPPoE Data Session Bytes Sent	This field displays the total number of PPPoE data session (non-control/non-session management user data) sent by the SM
PPPoE Data Session Bytes Received	This field displays the total number of PPPoE data session (non-control/non-session management user data)

Interpreting Bridge Control Block statistics

The **Statistics > Bridge Control Block** page displays statistics of Bridge FEC, Bridge ratio and Bridge error. The page is applicable for all modules (AP/SM/BHM/BHS). The Bridge Control Block Statistics page is explained in [Table 210](#).

Table 210 Bridge Control Block page attributes – AP/SM/BHM/BHS

Bridge FEC Stats	
FEC bin :	37469
FEC bout :	5373
FEC btoss :	0
FEC btosscap :	0
FEC uin :	1414950
FEC uout :	1179451
FEC utoss :	650
FEC utosscap :	0

Bridge Radio Stats	
RF bin :	0
RF bout :	37471
RF btoss :	0
RF btosscap :	0
RF uin :	3335
RF uout :	4928
RF utoss :	0
RF utosscap :	0

Bridge Error Stats	
ErrN1QSend :	0
ErrN2QSend :	0
ErrBridgeFull :	0
ErrSendMsg :	0
ErrApFecQSend :	0
ErrApRfQSend :	0

Attribute	Meaning
FEC bin	This field indicates the number of broadcast packets received by the bridge control block on the Ethernet interface
FEC bout	This field indicates the number of broadcast packets sent by the bridge control block on the Ethernet interface
FEC btoss	This field indicates the number of broadcast packets tossed out by the bridge control block on the Ethernet interface
FEC btossap	This field indicates the number of broadcast packets tossed out at the Ethernet interface due to MIR cap being exceeded.
FEC uin	This field indicates the number of unicast packets received by the bridge control block on the Ethernet interface
FEC uout	This field indicates the number of unicast packets sent by the bridge control block on the Ethernet interface
FEC utoss	This field indicates the number of unicast packets tossed by the bridge control block on the Ethernet interface
FEC utossap	This field indicates the number of unicast packets tossed out at the Ethernet interface due to MIR cap being exceeded.
RF bin	This field indicates the number of broadcast packets received by the bridge control block on the radio interface
RF bout	This field indicates the number of broadcast packets sent by the bridge control block on the radio interface
RF btoss	This field indicates the number of broadcast packets tossed by the bridge control block on the radio interface
RF btossap	This field indicates the number of broadcast packets tossed out at the radio interface due to MIR cap being exceeded.
RF uin	This field indicates the number of unicast packets received by the bridge control block on the radio interface
RF uout	This field indicates the number of unicast packets sent by the bridge control block on the radio interface
RF utoss	This field indicates the number of unicast packets tossed by the bridge control block on the radio interface
RF utossap	This field indicates the number of unicast packets tossed out at the radio interface due to MIR cap being exceeded.
ErrNI1QSend	This field indicates that a packet which was sourced from the radio network stack interface 1 (Ethernet interface) could not be sent because the radio bridge queue was full. The packet was tossed out.

ErrNI2QSend	This field indicates that a packet which was sourced from the radio network stack interface 2 (RF interface) could not be sent because the radio bridge queue was full. The packet was tossed out.
ErrBridgeFull	This field indicates the total number of times the bridging table was full and could not accept new entries.
ErrSendMsg	This field displays the error message from bridge core call back routine.
ErrApFecQSend	This field indicates that a packet which was received on the Ethernet interface could not be processed because the radio bridge queue was full and packet was tossed out.
ErrApRfQSend	This field indicates that a packet which was received on the RF interface could not be processed because the radio bridge queue was full. The packet was tossed out.

Interpreting Pass Through Statistics

The **Statistics > Pass Through Statistics** page displays radius related statistics. The page is applicable for PMP 450 platform AP only. The Pass Through Statistics page is explained in [Table 211](#).

Table 211 Pass Through Statistics page attributes – AP

Attribute	Meaning
IdentityReqSent	This field indicates the number of EAP Identity requests sent through the AP with respect to an SM.
PktsEncapsulated	This field indicates no of packets received from the SM which are encapsulated by the AP.
PktsDecasulated	This field indicates no of packets received from the radius server and are decapsulated by the AP with respect to an SM
AccessAcceptRcvd	This field indicates no of RADIUS Access Accept message received by the AP with respect to an SM.

Interpreting SNMPv3 Statistics

The **Statistics > SNMPv3 Statistics** page displays all SNMPv3 related statistics. The page is applicable for all platform of PMP 450 platform. The SNMPv3 Statistics page is explained in [Table 212](#).

Table 212 SNMPv3 Statistics page attributes – AP

The screenshot shows the 'SNMPv3 Statistics' page with the following content:

```

SNMPv3 Statistics
Statistics for snmpMPDStats group
snmpUnknownSecurityModels = 0
snmpInvalidMsgs = 0
snmpUnknownPDUHandlers = 0
Statistics for usmStats group
usmStatsUnsupportedSecLevels = 0
usmStatsNotInTimeWindows = 0
usmStatsUnknownUserNames = 0
usmStatsUnknownEngineIDs = 0
usmStatsWrongDigests = 0
usmStatsDecryptionErrors = 0
Statistics for snmpTargetObjects group
snmpTargetSpinLock = 0
snmpUnavailableContexts = 0
snmpUnknownContexts = 0
Statistics for usmUser group
usmUserSpinLock = 0
Statistics for vacmMIBViews group
vacmViewSpinLock = 0
Value of Globals
engine id = 80 00 00 a1 03 0a 00 3e a0 2b c8
engineId length = 11
number of engine boots = 237
time since engine is up = 54598
next saltId = 0
next messageId = 100
next localPortNum = 2000
max msg size = 1460
default context =
authoritative = YES
localize keys = YES
Misc. statistics
assertsfailed = 0
lenassertsfailed = 0
oidlenassertsfailed = 0
delfailed = 0
Compile time options
Authentication = enabled
Privacy = enabled
CipherEngine = disabled
SNMP over IPv6 = disabled
  
```

Attribute	Meaning
Statistics for snmpMPDStats group	SNMP Message Processing and Dispatching RFC 3412


snmpUnknownSecurityModels	The total number of packets received by the SNMP engine which were dropped because they referenced a securityModel that was not known to or supported by the SNMP engine.
snmpInvalidMsgs	The total number of packets received by the SNMP engine which were dropped because there were invalid or inconsistent components in the SNMP message.
snmpUnknownPDUHandlers	The total number of packets received by the SNMP engine which were dropped because the PDU contained in the packet could not be passed to an application responsible for handling the pduType, e.g. no SNMP application had registered for the proper combination of the contextEngineID and the pduType.
usmStatsUnsupportedSecurityLevels	The total number of packets received by the SNMP engine which were dropped because they requested a securityLevel that was unknown to the SNMP engine or otherwise unavailable.
usmStatsNotInTimeWindows	The total number of packets received by the SNMP engine which were dropped because they appeared outside of the authoritative SNMP engine's window.
usmStatsUnknownUserNames	The total number of packets received by the SNMP engine which were dropped because they referenced a user that was not known to the SNMP engine.
usmStatsUnknownEngineIDs	The total number of packets received by the SNMP engine which were dropped because they referenced a snmpEngineID that was not known to the SNMP engine.
usmStatsWrongDigests	The total number of packets received by the SNMP engine which were dropped because they didn't contain the expected digest value.
usmStatsDecryptionErrors	The total number of packets received by the SNMP engine which were dropped because they could not be decrypted.
snmpTargetSpinLock	This object is used to facilitate modification of table entries in the SNMP-TARGET-MIB module by multiple managers.
snmpUnavailableContexts	The total number of packets received by the SNMP engine which were dropped because the context contained in the message was unavailable.
snmpUnknownContexts	The total number of packets received by the SNMP engine which were dropped because the context contained in the message was unknown.
usmUserSpinLock	The use of usmUserSpinlock is to avoid conflicts with another SNMP command generator application which may also be acting on the usmUserTable.

vacmViewSpinLock	An advisory lock used to allow cooperating SNMP Command Generator applications to coordinate their use of the Set operation in creating or modifying views.
snmpEngineBoots	It is a count of the number of times the SNMP engine has re-booted/re-initialized since snmpEngineID was last configured
snmpEngineTime time since engine is up	which is the number of seconds since the snmpEngineBoots counter was last incremented

Interpreting syslog statistics

The **Statistics > Syslog Statistics** page displays statistics of syslog messages. The page is applicable for all modules (AP/SM/BHM/BHS). The Syslog Statistics page is explained in [Table 213](#).

Table 213 Syslog statistics page attributes – AP/SM/BH

Attribute	Meaning
	
Syslog Server	This displays dotted decimal or DNS name (if the DNS is enabled) of the syslog server address.
Syslog Server Port	The syslog server port (default 514) to which syslog messaging is sent.
Syslog Status	This indicates status of syslog messaging. It can be Enable or Disabled based on configuration
Syslog Message Transmissions	This field indicates the count of syslog messages sent to UDP layer.
Syslog Message Dropped	This field indicates the count of dropped syslog messages.

Interpreting Frame Utilization statistics

The Frame Utilization Statistics is a feature helps user to understand how effectively the RF channel is being utilized. This feature allows to check Time Division Duplex (TDD) frame utilization pattern and diagnose for any excessive usage in uplink or downlink direction.

This forms the first step of identifying the TDD frame utilization information. If the user finds excessive utilization based on this stats, the second step would be to take several actions like sectorization, tuning the uplink/downlink ratio etc. to improve RF channel utilization. Efficient use of the TDD frame will help to achieve optimum performance of link.

**Note:**

The backhauls (BHM and BHS) will have only the downlink scheduler based statistics

Table 214 Frame utilization statistics

Frame Utilization Interval	
Statistics Display Interval :	1 minute ▾
Next Update :	40 seconds
Frame Utilization	
Downlink :	0 %
Uplink :	0 %
Bandwidth Requests :	100 %
	Note: Bandwidth request statistics not available for all currently registered SMS. Only support 450/450i SMS on 14.2 or later.
Downlink Counts	
Total :	271
Per Frame Average :	0
Low Priority :	6
High Priority :	0
Broadcast/Multicast :	243
Canopy MAC Acknowledgments :	22
Registration Messages :	0
Uplink Counts	
Total :	35
Per Frame Average :	0
Low Priority :	29
High Priority :	0
Canopy MAC Acknowledgments :	6
Contention Slots :	1079965
Contention Slots Average Per Frame :	44
Bandwidth Requests Received :	800
Bandwidth Requests Missed :	0
Maximum Possible Counts	
Downlink :	960000
Uplink :	984000
Contention :	1080000
Packet Discard Counts	
Ethernet indiscards :	0
Ethernet outdiscards :	0
Radio indiscards :	0
Radio outdiscards :	0

Attribute	Meaning
Frame Utilization Interval	
Statistics Display interval	This allows to configure timer interval to monitor and display the frame utilization statistics. It can be configured for 30 seconds (low interval), 3 minutes (medium interval) or 15 minutes (high interval) based on requirement.
Frame Utilization	
Downlink	This indicates the percentage of downlink data slots used against the maximum number of slots possible in configured interval.

Uplink	This indicates the percentage of uplink data slots used against the maximum number of uplink slots possible in configured interval.
Downlink Counts	
Total	This indicates the sum of all downlink data slots used in the configured interval.
Low Priority	The number of downlink data slots used for low priority downlink traffic.
High Priority	The number of downlink data slots used for high priority downlink traffic.
Broadcast/Multicast	The number of downlink data slots used for broadcast and multicast traffic.
Canopy MAC Acknowledgements	The number of downlink data slots used as ACKs.
Registration and Control message slots	The number of downlink data slots used for registration and other control messages.
Uplink Counts	
Total	This indicates the sum of all uplink data slots used in configured interval.
Low Priority	The number of uplink data slots used for low priority uplink traffic.
High Priority	The number of uplink data slots used for high priority uplink traffic.
Canopy MAC Acknowledgements	The number of uplink data slots used as ACKs.
Contention Slots	The number of (reserved) Contention slots configured by the operator.
Contention Slots Average Per Frame	It is the average number of contention slots in a frame for the last duration. Duration is 1/5/15 mins.
Maximum possible counts	
Downlink	This indicates the maximum possible downlink data slots. This is based on the configuration of Channel Bandwidth, Frame period, uplink/downlink allocation, contention slots and configured Statistics Display interval.

Uplink	This indicates the maximum possible uplink data slots. This is based on the configuration of Channel Bandwidth, Frame period, uplink/downlink allocation, contention slots and configured Statistics Display interval.
--------	--

Packet Discard counts	
------------------------------	--

Ethernet indiscards	This indicates the number of Ethernet packets discarded in the IN queue.
---------------------	--

Ethernet outdiscards	This indicates the number of Ethernet packets discarded in the OUT queue.
----------------------	---

Radio indiscards	This indicates the number of packets discarded over radio in the IN queue.
------------------	--

Radio outdiscards	This indicates the number of packets discarded over radio in the OUT queue.
-------------------	---

Radio Recovery

This section describes:

- How to recover a PMP/PTP 450i unit from configuration errors or software image corruption
- How to override a PMP/PTP 450 unit from forgotten IP address and password to factory default

Radio Recovery Console– PMP/PTP 450i

Recovery mode allows to restore IP address and password. Also, it allows new main application software to be loaded even when the integrity of the existing main application software image has been compromised. The most likely cause of an integrity problem with the installed main application software is where the power supply has been interrupted during a software upgrade.



Note

When Recovery has been entered through a power on/off/on cycle, the ODU will revert to normal operation if no web access has been made to the unit within 30 seconds. This prevents the unit remaining inadvertently in recovery following a power outage.

Options in recovery mode are:

- Boot with normal operation
- Boot with default Canopy system software settings
- Load a previous SW image

The last most recent software images loaded to the board are retained. However the factory image is not retained.

Boot with default Canopy system software settings (similar to the hardware Ddefault Plug based on PMP/PTP 450 platforms).



Note

The unit may enter recovery console automatically, in response to some failures.



Note

Once the unit has entered recovery, it will switch back to normal operation if no access has been made to the recovery web page within 30 seconds.

Use below procedure to enter in recovery console manually.

Procedure 34 Radio Recovery Console

- 1 Apply power to PSU for at least 10 seconds.
- 2 Remove power for two seconds.
- 3 Re-apply power to the PSU.
- 4 When the unit is in recovery mode, access the web interface by entering the default IP address **169.254.1.1**. The Recovery Image Warning page is displayed.
- 5 Review the Boot Selection ([Table 215](#)).
- 6 Select a recovery option

Figure 173 Recovery Options page

Table 215 Recovery Options attributes

Attribute	Meaning
Boot Selection	<p>Boot – Default Mode: Use this option to temporarily set the IP and Ethernet attributes to factory defaults until the next reboot.</p> <p>Boot – Normal: Use this option to reboot the unit.</p>
IP address, Netmask, Gateway	These fields display IP address, Netmask and Gateway of the radio while it is in recovery or default mode.

Default Mode (or Default/Override Plug) - PMP/PTP 450

The default mode allows to temporarily override some PMP/PTP 450 ODU settings and thereby regain control of the module by powering the module on with the Default Plug inserted into the unit's synchronization (RJ11) port.

This override plug is needed for access to the module in any of the following cases:

- You have forgotten either
 - the IP address assigned to the ODU.
 - the password that provides access to the ODU.
- The ODU has been locked by the No Remote Access feature.
- You want local access to a module that has had the 802.3 link disabled in the Configuration page.

You can configure the module such that, when it senses the override plug, it responds by either

- resetting the LAN1 IP address to 169.254.1.1, allowing access through the default configuration without *changing* the configuration, whereupon you will be able to view and reset any non-default values as you wish.
- resetting all configurable parameters to their factory default values.



Note

The Default Plug is available from Best-Tronics Manufacturing, Inc. See <http://www.best-tronics.com/cambium.htm> as Part BT-0583 (RJ-11 Default Plug). Alternatively, you can fabricate an override plug. See [Override plug cable](#) on page 5-14 for pinout.

Using the Default/Override Plug

The following section details usage of the override plug to regain access to PMP/PTP 450 ODU.



Note

While the override plug is connected to a PMP/PTP 450 ODU, the ODU can neither register nor allow registration of another ODU.



Note

Since the 900 MHz SM is based on the 450 platform, it only supports the "Default Plug" mode of overriding.

Use below procedure to enter in default mode manually.

Procedure 35 Default mode

- 1** Insert the override plug into the RJ-11 GPS utility port of the module.
- 2** Power cycle by removing, then re-inserting, the Ethernet cable.
RESULT: The module boots with the default IP address of 169.254.1.1, password fields blank, and all other configuration values as previously set.
- 3** Wait approximately 30 seconds for the boot to complete.
- 4** Remove the override plug.
- 5** Set passwords and IP address as desired.
- 6** Change configuration values if desired.
- 7** Click the Save Changes button.
- 8** Click the Reboot button.

Chapter 10: Reference Information

This chapter contains reference information and regulatory notices that apply to the PMP/PTP 450 platform Series products.

The following topics are described in this chapter:

- [Equipment specifications](#) on page [10-2](#) contains specifications of the PMP/PTP 450 platform, ODU specifications including RF bands, channel width and link loss.
- [Data network specifications](#) on page [10-33](#) shows the PMP/PTP 450 platform Ethernet interface specifications.
- [Compliance with safety standards](#) on page [4-22](#) lists the safety specifications against which the PMP/PTP 450 platform has been tested and certified. It also describes how to keep RF exposure within safe limits.
- [Country specific radio regulations](#) on page [10-35](#) describes how the PMP/PTP 450 platform complies with the radio regulations that are enforced in various countries.
- [Equipment Disposal](#) on page [10-37](#) describes the Equipment Disposal system for Electronic and Electric Equipment.

Equipment specifications

This section contains specifications of the AP, SM, BHM and BHS associated supplies required for PMP/PTP 450 platform installations.

Specifications for PMP 450m AP

The PMP 450m AP conforms to the specifications listed in [Table 216](#).

Table 216 PMP 450m AP specifications

Category		Specification
Model Number		PMP 450m AP
Spectrum		
Channel Spacing		Configurable on 2.5 MHz increments
Frequency Range		5150 to 5925 MHz
Channel Bandwidth		20 MHz
Interface		
MAC (Media Access Control) Layer		Cambium Proprietary
Physical Layer		14x14 Multi-User MIMO OFDM
Ethernet Interface		100/1000BaseT, half/full duplex, rate auto negotiated (802.3 compliant)
Protocols Used		IPv4, UDP, TCP, IP, ICMP, Telnet, SNMP, HTTP, FTP
Network Management		HTTP, HTTPS, Telnet, FTP, SNMP v3
VLAN		802.1ad (DVLAN Q-in-Q), 802.1Q with 802.1p priority, dynamic port VID
Sensitivity		
Nominal Receive Sensitivity (w/ FEC) @ 20 MHz Channel	5.1 GHz	1x-A = -88 dBm, 2x-A = -81 dBm, 3x-A = -75 dBm, 4x-A = -67 dBm, 2x-B = -85 dBm, 4x-B = -78 dBm, 6x-B = -72 dBm, 8x-B = -64 dBm
	5.2 GHz	1x-A = -88 dBm, 2x-A = -81 dBm, 3x-A = -75 dBm, 4x-A = -67 dBm, 2x-B = -85 dBm, 4x-B = -78 dBm, 6x-B = -72 dBm, 8x-B = -64 dBm

	5.4 GHz	1x-A = -88 dBm, 2x-A = -81 dBm, 3x-A = -75 dBm, 4x-A = -67 dBm, 2x-B = -85 dBm, 4x-B = -78 dBm, 6x-B = -72 dBm, 8x-B = -64 dBm		
	5.8 GHz	1x-A = -88 dBm, 2x-A = -81 dBm, 3x-A = -75 dBm, 4x-A = -67 dBm, 2x-B = -85 dBm, 4x-B = -78 dBm, 6x-B = -72 dBm, 8x-B = -64 dBm		
Performance				
Subscriber Per Sector		Up to 238		
ARQ		Yes		
Cyclic Prefix		1/16		
Frame Period		2.5 ms or 5.0 ms		
Modulation Levels (Adaptive)		Modulation Levels	MCS	SNR (in dB)
		2x	QPSK	10
		4x	16QAM	17
		6x	64QAM	24
		8x	256QAM	32
Latency		10 ms, typical		
Maximum Deployment Range		Up to 40 miles (64 km)		
GPS Synchronization		Yes, via Autosync (CMM5 or UGPS)		
Quality of Service		Diffserv QoS		
Link Budget				
Antenna Beam Width	5 GHz	90° integrated sector (Dual polarity, H+V)		
Antenna Gain		+14 dBi		
Maximum Transmit Power		+24 dBm combined		
Physical				
Data, Sync/AUX and SFP port	RJ45	<ul style="list-style-type: none"> 1000BASE-T Ethernet Data AUX port for uGPS or PoE out to 802.3at SFP – Single-mode fiber, multi-mode fiber and copper Gigabit Ethernet option 		
Antenna Connection		Integrated Sector Array		

Surge Suppression (with LPU)	EN61000-4-5: 1.2 us/50 us, 500 V voltage waveform Recommended external surge suppressor: Cambium Networks Model # C000065L007A		
Mean Time Between Failure	> 40 Years		
Environmental	IP66, IP67		
Temperature / Humidity	-40°C to +60°C (-40°F to +140°F) 0-95% non-condensing		
Weight	Integrated	Approx. 14.2 kg (31 bs)	
Wind Loading – Front Facing	@ 90 mph / 144 kph		460 N
	@ 110 mph / 177 kph		700 N
Dimension (HxWxD)	Integrated	52 x 65 x 11 cm (20.3" x 25.7" x 4.4")	
Power Consumption	70 W typical, 80 W peak (up to 110 W max with AUX port PoE enabled)		
Input Voltage	58 V, 1.7 A		
Mounting	Pole mount with included brackets		
Security			
Encryption	56-bit DES, FIPS-197 128-bit AES		

Specifications for PMP 450i AP

The PMP 450i AP conforms to the specifications listed in [Table 217](#).

Table 217 PMP 450i AP specifications

Category		Specification
Model Number		PMP 450i AP
Spectrum		
Channel Spacing		5, 7, 10, 15, 20 and 30 MHz Channel Bandwidth Configurable on 2.5 MHz increments
Frequency Range		902 to 928 MHz 4900 - 5925 MHz
Channel Bandwidth	902 – 928 MHz	5, 7, 10 and 20 MHz
	4900 – 5925 MHz	5, 7, 10, 15, 20 and 30 MHz
Interface		
MAC (Media Access Control) Layer		Cambium Proprietary
Physical Layer		2x2 MIMO OFDM
Ethernet Interface		10/100/1000BaseT, half/full duplex, rate auto negotiated (802.3 compliant)
Protocols Used		IPv4, UDP, TCP, IP, ICMP, Telnet, SNMP, HTTP, FTP
Network Management		HTTP, HTTPS, Telnet, FTP, SNMP v3
VLAN		802.1ad (DVLAN Q-in-Q), 802.1Q with 802.1p priority, dynamic port VID
Sensitivity		
Nominal Receive Sensitivity (w/ FEC) @ 5 MHz Channel	900 MHz	1x = -91.9 dBm, 2x = -86.7 dBm, 4x = -80.9 dBm, 6x = -75 dBm, 8x = -68.8 dBm
	4.9 GHz	1x = -91.6 dBm, 2x = -87.6 dBm, 4x = -80.4 dBm, 6x = -73.2 dBm, 8x = -66 dBm
	5.4 GHz	1x = -92 dBm, 2x = -87 dBm, 4x = -80.8 dBm, 6x = -73.7 dBm, 8x = -66.6 dBm
	5.8 GHz	1x = -91.5 dBm, 2x = -87 dBm, 4x = -80.2 dBm, 6x = -73.1 dBm, 8x = -66 dBm

Nominal Receive Sensitivity (w/ FEC) @ 7 MHz Channel	900 MHz	1x = -90 dBm, 2x = -85.9 dBm, 4x = -79.8 dBm, 6x = -73.6 dBm, 8x = -67.9 dBm
Nominal Receive Sensitivity (w/ FEC) @ 10 MHz Channel	900 MHz	1x = -90.6 dBm, 2x = -85.2 dBm, 4x = -79.1 dBm, 6x = -73.2 dBm, 8x = -66.2 dBm
	4.9 GHz	1x = -89.1 dBm, 2x = -85 dBm, 4x = -77.9 dBm, 6x = -71.8 dBm, 8x = -64.6 dBm
	5.4 GHz	1x = -89.5 dBm, 2x = -85.4 dBm, 4x = -78.2 dBm, 6x = -72.2 dBm, 8x = -64.8 dBm
	5.8 GHz	1x = -89.5 dBm, 2x = -84.7 dBm, 4x = -77.8 dBm, 6x = -71.6 dBm, 8x = -64 dBm
Nominal Receive Sensitivity (w/ FEC) @ 15 MHz Channel	4.9 GHz	1x = -87.2 dBm, 2x = -83 dBm, 4x = -75.8 dBm, 6x = -69.6 dBm, 8x = -62.6 dBm
	5.4 GHz	1x = -87.2 dBm, 2x = -83.3 dBm, 4x = -76.2 dBm, 6x = -70.1 dBm, 8x = -63 dBm
	5.8 GHz	1x = -87.7 dBm, 2x = -82.7 dBm, 4x = -75.5 dBm, 6x = -69.6 dBm, 8x = -62.4 dBm
Nominal Receive Sensitivity (w/ FEC) @ 20 MHz Channel	900 MHz	1x = -86.99 dBm, 2x = -82 dBm, 4x = -75.9 dBm, 6x = -69.9 dBm, 8x = -62.9 dBm
	4.9 GHz	1x = -86.1 dBm, 2x = -82.1 dBm, 4x = -74.8 dBm, 6x = -68.8 dBm, 8x = -61.7 dBm
	5.4 GHz	1x = -86.6 dBm, 2x = -81.3 dBm, 4x = -75.5 dBm, 6x = -68.6 dBm, 8x = -62 dBm
	5.8 GHz	1x = -85.8 dBm, 2x = -80.7 dBm, 4x = -74.6 dBm, 6x = -68.7 dBm, 8x = -61 dBm
Nominal Receive Sensitivity (w/ FEC) @ 30 MHz Channel	4.9 GHz	1x = -84.1 dBm, 2x = -80 dBm, 4x = -73 dBm, 6x = -66.4 dBm, 8x = -59.6 dBm
	5.4 GHz	1x = -84.5 dBm, 2x = -82 dBm, 4x = -75.3 dBm, 6x = -67.4 dBm, 8x = -60.2 dBm
	5.8 GHz	1x = -84.1 dBm, 2x = -80 dBm, 4x = -73 dBm, 6x = -66.5 dBm, 8x = -59.4 dBm

Performance			
ARQ	Yes		
Cyclic Prefix	1/16		
Frame Period	2.5 ms or 5.0 ms		
Modulation Levels (Adaptive)	Modulation Levels	MCS	SNR (in dB)
	2x	QPSK	10
	4x	16QAM	17
	6x	64QAM	24
	8x	256QAM	32
Latency	3 - 5 ms		
Maximum Deployment Range	Up to 40 miles (64 km)		
GPS Synchronization	Yes, via Autosync (CMM4), via UGPS		
Quality of Service	Diffserv QoS		
Link Budget			
Antenna Beam Width	900 MHz	65° sector antenna (Dual Slant)	
	5 GHz	90° (3dB rolloff) sector for integrated (Dual polarity, H+V)	
Antenna Gain (Does not include cable loss, ~1dB)	900 MHz	13 dBi	
	5 GHz	17 dBi integrated 90° sector or external	
Transmit Power Range	40 dB dynamic range (to EIRP limit by region) (1 dB step)		
Maximum Transmit Power	+27 dBm combined output (for 5 GHz) +25 dBm combined output (for 900MHz)		
Physical			
Sync/AUX port	RJ45	<ul style="list-style-type: none"> 10/100/100BASE-T Ethernet Data PoE output (planned for future release) Sync input or output (Connection and powering of UGPS Sync input) 	
Antenna Connection	50 ohm, N-type (Connectorized version only)		

Surge Suppression EN61000-4-5	EN61000-4-5: 1.2 us/50 us, 500 V voltage waveform Recommended external surge suppressor: Cambium Networks Model # C000000L033A	
Mean Time Between Failure	> 40 Years	
Environmental	IP66, IP67	
Temperature / Humidity	-40°C to +60°C (-40°F to +140°F), 0-95% non- condensing	
Weight	Connectorized	Approx. 2.0 kg (4.5 lbs)
	Integrated	Approx. 2.5 kg (5.5 lbs)
Wind Survival	Connectorized	322 km/h (200 mi/h)
	Integrated	200 km/h (124 mi/h)
Dimension(HxWxD)	Connectorized	26.0 x 13.4 x 6.4 cm (10.3" x 5.3" x 3.3")
	Integrated	37.0 x 37.0 x 6.3 cm (14.5" x 14.5" x 3.2")
Power Consumption	15 W typical, 25 W max, 55 W max with Aux port PoE out enabled	
Input Voltage	48-59 V DC, 802.3at compliant	
Mounting	Wall or Pole mount with Cambium Networks Model # N000045L002A	
Security		
Encryption	56-bit DES, FIPS-197 128-bit AES	

Specifications for PMP 450i SM

The PMP 450i SM conforms to the specifications listed in [Table 218](#).

Table 218 PMP 450i SM specifications

Category		Specification
Model Number		PMP 450i SM
Spectrum		
Channel Spacing		5, 10, 15, 20 and 30 Channel Bandwidth Configurable on 2.5 MHz increments
Frequency Range		4900 - 5925 MHz
Channel Bandwidth	4900 – 5925 MHz	5, 10, 15, 20 and 30 MHz
Interface		
MAC (Media Access Control) Layer		Cambium Proprietary
Physical Layer		2x2 MIMO OFDM
Ethernet Interface		10/100/1000BaseT, half/full duplex, rate auto negotiated (802.3 compliant)
Protocols Used		IPv4, UDP, TCP, IP, ICMP, Telnet, SNMP, HTTP, FTP
Network Management		HTTP, HTTPS, Telnet, FTP, SNMP v2c and v3
VLAN		802.1ad (DVLAN Q-in-Q), 802.1Q with 802.1p priority, dynamic port VID
Sensitivity		
Nominal Receive Sensitivity (w/ FEC) @ 5 MHz Channel	4.9 GHz	1x = -92.5 dBm, 2x = -88.5 dBm, 4x = -81 dBm, 6x = -74.2 dBm, 8x = -66 dBm
	5.4 GHz	1x = -93 dBm, 2x = -89.1 dBm, 4x = -81.5 dBm, 6x = -74.8 dBm, 8x = -67.4 dBm
	5.8 GHz	1x = -92 dBm, 2x = -88.3 dBm, 4x = -80.8 dBm, 6x = -74 dBm, 8x = -66.2 dBm
Nominal Receive Sensitivity (w/ FEC) @ 10 MHz Channel	4.9 GHz	1x = -90.2 dBm, 2x = -85.2 dBm, 4x = -78.8 dBm, 6x = -71.4 dBm, 8x = -64.5 dBm
	5.4 GHz	1x = -90 dBm, 2x = -85.8 dBm, 4x = -78.5 dBm, 6x = -72.2 dBm, 8x = -65.8 dBm

	5.8 GHz	1x = -89.9 dBm, 2x = -84.9 dBm, 4x = -78.5 dBm, 6x = -71.2 dBm, 8x = -63.8 dBm		
Nominal Receive Sensitivity (w/ FEC) @ 15 MHz Channel	4.9 GHz	1x = -88.2 dBm, 2x = -83.1 dBm, 4x = -76.9 dBm, 6x = -70.5 dBm, 8x = -62.3 dBm		
	5.4 GHz	1x = -87.7 dBm, 2x = -83.9 dBm, 4x = -76.6 dBm, 6x = -70.4 dBm, 8x = -63 dBm		
	5.8 GHz	1x = -88 dBm, 2x = -82.9 dBm, 4x = -76.7 dBm, 6x = -69.4 dBm, 8x = -62.3 dBm		
Nominal Receive Sensitivity (w/ FEC) @ 20 MHz Channel	4.9 GHz	1x = -87 dBm, 2x = -81.8 dBm, 4x = -75.8 dBm, 6x = -68.5 dBm, 8x = -61.4 dBm		
	5.4 GHz	1x = -87 dBm, 2x = -82.8 dBm, 4x = -75.6 dBm, 6x = -69.3 dBm, 8x = -61.6 dBm		
	5.8 GHz	1x = -85.9 dBm, 2x = -81.5 dBm, 4x = -74.8 dBm, 6x = -68.7 dBm, 8x = -61.2 dBm		
Nominal Receive Sensitivity (w/ FEC) @ 30 MHz Channel	4.9 GHz	1x = -84.9 dBm, 2x = -80.9 dBm, 4x = -73.2 dBm, 6x = -67.4 dBm, 8x = -59.3 dBm		
	5.4 GHz	1x = -85.2 dBm, 2x = -80.2 dBm, 4x = -74.1 dBm, 6x = -67.9 dBm, 8x = -59.8 dBm		
	5.8 GHz	1x = -84.9 dBm, 2x = -80 dBm, 4x = -73.2 dBm, 6x = -67.4 dBm, 8x = -59.4 dBm		
Performance				
ARQ	Yes			
Cyclic Prefix	1/16			
Frame Period	2.5 ms or 5.0 ms			
Modulation Levels (Adaptive)	Modulation Levels	MCS	SNR (in dB)	
	2x	QPSK	10	
	4x	16QAM	17	
	6x	64QAM	24	
	8x	256QAM	32	
Latency	3 - 5 ms			

Maximum Deployment Range	Up to 40 miles (64 km)	
GPS Synchronization	Yes, via Autosync (CMM4)	
Quality of Service	Diffserv QoS	
Link Budget		
Antenna Beam Width	10° azimuth for 23 dBi integrated antenna	
Antenna Gain (Does not include cable loss, ~1dB)	5 GHz	+23 dBi H+V, integrated or external
Transmit Power Range	40 dB dynamic range (to EIRP limit by region) (1 dB step)	
Maximum Transmit Power	+27 dBm combined output (for 5 GHz)	
Physical		
Sync/AUX port	RJ45	<ul style="list-style-type: none"> 10/100/1000BASE-T Ethernet Data PoE output (planned for future release) Sync input or output (Connection and powering of UGPS Sync input)
Antenna Connection	50 ohm, N-type (Connectorized version only)	
Surge Suppression EN61000-4-5	EN61000-4-5: 1.2us/50us, 500 V voltage waveform Recommended external surge suppressor: Cambium Networks Model # C000000L033A	
Mean Time Between Failure	> 40 Years	
Environmental	IP66, IP67	
Temperature / Humidity	-40°C to +60°C (-40°F to +140°F), 0-95% non-condensing	
Weight	Connectorized	Approx. 2.0 kg (4.5 lbs)
	Integrated	Approx. 2.5 kg (5.5 lbs)
Wind Survival	Connectorized	322 km/h (200 mi/h)
	Integrated	200 km/h (124 mi/h)
Dimension(HxWxD)	Connectorized	26.0 x 13.4 x 6.4 cm (10.3" x 5.3" x 3.3")
	Integrated	31.0 x 31.0 x 6.4 cm (12" x 12" x 2.5")

Power Consumption	15 W typical, 25 W max, 55 W max with Aux port PoE out enabled
Input Voltage	48-59 V DC, 802.3at compliant
Mounting	Wall or Pole mount with Cambium Networks Model # N000045L002A
Security	
Encryption	56-bit DES, FIPS-197 128-bit AES

Specifications for PTP 450i BH

The PTP 450i BH conforms to the specifications listed in [Table 219](#).

Table 219 PTP 450i BH specifications

Category		Specification
Model Number		PTP 450i BH
Spectrum		
Channel Spacing		5, 10, 15, 20 and 30 MHz Channel Bandwidth Configurable on 2.5 MHz increments
Frequency Range		902 to 928 MHz 4900 - 5925 MHz
Channel Bandwidth	902 – 928 MHz	5, 7, 10 and 20 MHz
	4900 – 5925 MHz	5, 10, 15, 20 and 30 MHz
Interface		
MAC (Media Access Control) Layer		Cambium Proprietary
Physical Layer		2x2 MIMO OFDM
Ethernet Interface		10/100/1000BaseT, half/full duplex, rate auto negotiated (802.3 compliant)
Protocols Used		IPv4, UDP, TCP, IP, ICMP, Telnet, SNMP, HTTP, FTP
Network Management		HTTP, HTTPS, Telnet, FTP, SNMP v2c and v3
VLAN		802.1ad (DVLAN Q-in-Q), 802.1Q with 802.1p priority, dynamic port VID
Sensitivity		
Nominal Receive Sensitivity (w/ FEC) @ 5 MHz Channel	900 MHz	1x = -93 dBm, 2x = -88 dBm, 4x = -81 dBm, 6x = -75 dBm, 8x = -68 dBm
	4.9 GHz	1x = -93 dBm, 2x = -88.3 dBm, 4x = -82 dBm, 6x = -74.4 dBm, 8x = -67.9 dBm
	5.4 GHz	1x = -93 dBm, 2x = -88.4 dBm, 4x = -81.3 dBm, 6x = -75.5 dBm, 8x = -67.8 dBm
	5.8 GHz	1x = -93.2 dBm, 2x = -88.3 dBm, 4x = -80.8 dBm, 6x = -74.3 dBm, 8x = -66.8 dBm

Nominal Receive Sensitivity (w/ FEC) @ 7 MHz Channel	900 MHz	1x = -91 dBm, 2x = -86 dBm, 4x = -80 dBm, 6x = -74 dBm, 8x = -67 dBm	
Nominal Receive Sensitivity (w/ FEC) @ 10 MHz Channel	900 MHz	1x = -90 dBm, 2x = -84 dBm, 4x = -79 dBm, 6x = -73 dBm, 8x = -66 dBm	
	4.9 GHz	1x = -90 dBm, 2x = -85 dBm, 4x = -78.6 dBm, 6x = -72.5dBm, 8x = -65 dBm	
	5.4 GHz	1x = -87.6 dBm, 2x = -82.5 dBm, 4x = -76.5 dBm, 6x = -70.5 dBm, 8x = -61.5dBm	
Nominal Receive Sensitivity (w/ FEC) @ 15 MHz Channel	5.8 GHz	1x = -89.9 dBm, 2x = -84.8 dBm, 4x = -78.5 dBm, 6x = -71.4 dBm, 8x = -64 dBm	
	4.9 GHz	1x = -88 dBm, 2x = -83.9 dBm, 4x = -76.9 dBm, 6x = -70.7 dBm, 8x = -63.6 dBm	
	5.4 GHz	1x = -88 dBm, 2x = -84.2 dBm, 4x = -76.9 dBm, 6x = -70.8 dBm, 8x = -62.7 dBm	
Nominal Receive Sensitivity (w/ FEC) @ 20 MHz Channel	5.8 GHz	1x = -87.8 dBm, 2x = -82.8 dBm, 4x = -6.6 dBm, 6x = 69.3 dBm, 8x = -62.1 dBm	
	900 MHz	1x = -86 dBm, 2x = -82 dBm, 4x = -75 dBm, 6x = -69 dBm, 8x = -62 dBm	
	4.9 GHz	1x = -86.9 dBm, 2x = -82.5 dBm, 4x = -75.7 dBm, 6x = -69.4 dBm, 8x = -62.3 dBm	
Nominal Receive Sensitivity (w/ FEC) @ 30 MHz Channel	5.4 GHz	1x = -84.5 dBm, 2x = -80.5 dBm, 4x = -73.4 dBm, 6x = -66.4 dBm, 8x = -56.4 dBm	
	5.8 GHz	1x = -85.8 dBm, 2x = -81.7 dBm, 4x = -75 dBm, 6x = -68.4 dBm, 8x = -61.2 dBm	
	4.9 GHz	1x = -85 dBm, 2x = -80.7 dBm, 4x = -73.7 dBm, 6x = -66.5 dBm, 8x = -60 dBm	
	5.4 GHz	1x = -85.3 dBm, 2x = -80.5 dBm, 4x = -74.2 dBm, 6x = -67.2 dBm, 8x = -60 dBm	
	5.8 GHz	1x = -84.6 dBm, 2x = -80 dBm, 4x = -73,3 dBm, 6x = -66.5 dBm, 8x = -59.1 dBm	
	Performance		
ARQ	Yes		
Cyclic Prefix	1/16		
Frame Period	2.5 ms or 5.0 ms		
Modulation Levels (Adaptive)	Modulation Levels	MCS	SNR (in dB)
	2x	QPSK	10

	4x	16QAM	17
	6x	64QAM	24
	8x	256QAM	32
Latency	3 - 5 ms		
Maximum Deployment Range	Up to 40 miles (64 km)		
GPS Synchronization	Yes, via Autosync (CMM4)		
Quality of Service	Diffserv QoS		
Link Budget			
Antenna Beam Width	900 MHz	37° azimuth for 12 dBi Yagi antenna	
	5 GHz	10° azimuth for 23 dBi integrated antenna	
Antenna Gain (Does not include cable loss, ~1dB)	900 MHz	12 dBi Yagi antenna	
	5 GHz	+23 dBi H+V, integrated or external	
Transmit Power Range	40 dB dynamic range (to EIRP limit by region) (1 dB step)		
Maximum Transmit Power	+27 dBm combined output		
Physical			
Sync/AUX port	RJ45	<ul style="list-style-type: none"> • 10/100/1000BASE-T Ethernet Data • PoE output • Sync input or output (Connection and powering of UGPS Sync input) 	
Antenna Connection	50 ohm, N-type (Connectorized version only)		
Surge Suppression EN61000-4-5	EN61000-4-5: 1.2us/50us, 500 V voltage waveform Recommended external surge suppressor: Cambium Networks Model # C000000L033A		
Mean Time Between Failure	> 40 Years		
Environmental	IP66, IP67		
Temperature / Humidity	-40°C to +60°C (-40°F to +140°F), 0-95% non-condensing		
Weight	Connectorized	Approx. 2.0 kg (4.5 lbs)	

	Integrated	Approx. 2.5 kg (5.5 lbs)
Wind Survival	Connectorized	322 km/h (200 mi/h)
	Integrated	200 km/h (124 mi/h)
Dimension(HxWxD)	Connectorized	26.0 x 13.4 x 6.4 cm (10.25" x 5.25" x 3.25")
	Integrated	31.0 x 31.0 x 6.4 cm (12" x 12" x 2.5")
Power Consumption		15 W typical, 25 W max, 55 W max with Aux port PoE out enabled
Input Voltage		48-59 V DC, 802.3at compliant
Mounting		Wall or Pole mount with Cambium Networks Model # N000045L002A
Security		
Encryption		56-bit DES, FIPS-197 128-bit AES

Specifications for PMP 450 AP

The PMP 450 AP conforms to the specifications listed in [Table 220](#).

Table 220 PMP 450 AP specifications

Category		Specification
Model Number		PMP 450 AP
Spectrum		
Channel Spacing		5, 7, 10, 15, 20 and 30 MHz Channel Bandwidth Configurable on 2.5 MHz increments
Frequency Range	2.4 GHz	2400 – 2483.5 MHz
	3.5 GHz	3300 – 3600 MHz
	3.65 GHz	3500 – 3850 MHz
	5 GHz	5470 – 5875 MHz
Channel Bandwidth	3.5 and 3.65 GHz	5, 7, 10, 15, 20 and 30 MHz
	2.4 and 5 GHz	5, 10, 15, 20 and 30 MHz
OFDM Subcarriers		512 FFT
Interface		
MAC (Media Access Control) Layer		Cambium Proprietary
Physical Layer		2x2 MIMO OFDM
Ethernet Interface		10/100/1000BaseT, half/full duplex, rate auto negotiated (802.3 compliant)
Protocols Used		IPv4, UDP, TCP, IP, ICMP, Telnet, SNMP, HTTP, FTP, TFTP, RADIUS
Network Management		HTTP, HTTPS, Telnet, FTP, SNMP v3, TFTP, Syslog
VLAN		802.1ad (DVLAN Q-in-Q), 802.1Q with 802.1p priority, dynamic port VID
Sensitivity		
Nominal Receive Sensitivity (w/ FEC) @ 5 MHz Channel	2.4 GHz	1x = -92 dBm, 2x = -87.8 dBm, 4x = -80.4 dBm, 6x = -74.4 dBm, 8x = -66.5 dBm
	3.5 GHz	1x = -92.4 dBm, 2x = -88.3 dBm, 4x = -81.3 dBm, 6x = -75.3 dBm, 8x = -67.7 dBm

	3.65 GHz	1x = -10 dBm, 2x = -86.1 dBm, 4x = -80.2 dBm, 6x = -73.1 dBm, 8x = -66 dBm
	5.4 GHz	1x = -88.7 dBm, 2x = -84 dBm, 4x = -77.6 dBm, 6x = -71.6 dBm, 8x = -63.7 dBm
	5.8 GHz	1x = -91.5 dBm, 2x = -87 dBm, 4x = -80.2 dBm, 6x = -73.1 dBm, 8x = -66 dBm
Nominal Receive Sensitivity (w/ FEC) @ 7 MHz Channel	3.5 GHz	1x = -90.5 dBm, 2x = -86.4 dBm, 4x = -80.3 dBm, 6x = -73.4 dBm, 8x = -66.9 dBm
	3.65 GHz	1x = -89.1 dBm, 2x = -85.1 dBm, 4x = -78.1 dBm, 6x = -72.1 dBm, 8x = -64.5 dBm
Nominal Receive Sensitivity (w/ FEC) @ 10 MHz Channel	2.4 GHz	1x = -89.9 dBm, 2x = -85.6 dBm, 4x = -80 dBm, 6x = -73.5 dBm, 8x = -66.9 dBm
	3.5 GHz	1x = -89.8 dBm, 2x = -85.6 dBm, 4x = -80 dBm, 6x = -73 dBm, 8x = -66.3 dBm
	3.65 GHz	1x = -89 dBm, 2x = -85.2 dBm, 4x = -78.1 dBm, 6x = -72.1 dBm, 8x = -64.5 dBm
	5.4 GHz	1x = -86.1 dBm, 2x = -82.2 dBm, 4x = -75.3 dBm, 6x = -69.3 dBm, 8x = -61.3 dBm
	5.8 GHz	1x = -86 dBm, 2x = -82.2 dBm, 4x = -75.1 dBm, 6x = -69 dBm, 8x = -60 dBm
Nominal Receive Sensitivity (w/ FEC) @ 15 MHz Channel	2.4 GHz	1x = -88.4 dBm, 2x = -84.1 dBm, 4x = -77.1 dBm, 6x = -71.4 dBm, 8x = -65 dBm
	3.5 GHz	1x = -88.5 dBm, 2x = -84.5 dBm, 4x = -77.5 dBm, 6x = -71.5 dBm, 8x = -64.3 dBm
	3.65 GHz	1x = -87.4 dBm, 2x = -83.7 dBm, 4x = -76.3 dBm, 6x = -69.7 dBm, 8x = -62.2 dBm
	5.4 GHz	1x = -84.2 dBm, 2x = -80.2 dBm, 4x = -73.2 dBm, 6x = -67.2 dBm, 8x = -60 dBm
	5.8 GHz	1x = -85 dBm, 2x = -80 dBm, 4x = -74.3 dBm, 6x = -67 dBm, 8x = -58 dBm
Nominal Receive Sensitivity (w/ FEC) @ 20 MHz Channel	2.4 GHz	1x = -85 dBm, 2x = -85 dBm, 4x = -79 dBm, 6x = -72 dBm, 8x = -66 dBm
	3.5 GHz	1x = -85 dBm, 2x = -85 dBm, 4x = -79 dBm, 6x = -72 dBm, 8x = -65 dBm
	3.65 GHz	1x = -86 dBm, 2x = -86 dBm, 4x = -78 dBm, 6x = -71 dBm, 8x = -63 dBm

	5.4 GHz	1x = -81 dBm, 2x = -81 dBm, 4x = -75 dBm, 6x = -68 dBm, 8x = -59 dBm
	5.8 GHz	1x = -82 dBm, 2x = -82 dBm, 4x = -75 dBm, 6x = -69 dBm, 8x = -60 dBm
Nominal Receive Sensitivity (w/ FEC) @ 30 MHz Channel	2.4 GHz	1x = -85.4 dBm, 2x = -80.4 dBm, 4x = -74 dBm, 6x = -68 dBm, 8x = -61 dBm
	3.5 GHz	1x = -85.5 dBm, 2x = -81.5 dBm, 4x = -74.5 dBm, 6x = -68.2 dBm, 8x = -61.3 dBm
	3.65 GHz	1x = -84 dBm, 2x = -79.5 dBm, 4x = -73.4 dBm, 6x = -66.4 dBm, 8x = -59.2 dBm
	5.4 GHz	1x = -81 dBm, 2x = -76.9 dBm, 4x = -70.9 dBm, 6x = -63.8 dBm, 8x = -55.8 dBm
	5.8 GHz	1x = -80.9 dBm, 2x = -76.8 dBm, 4x = -70 dBm, 6x = -63.8 dBm, 8x = -55 dBm

Performance

Subscribers Per Sector	Up to 238		
ARQ	Yes		
Cyclic Prefix	1/16		
Frame Period	2.5 ms or 5.0 ms		
Modulation Levels (Adaptive)	Modulation Levels	MCS	SNR (in dB)
	2x	QPSK	10
	4x	16QAM	17
	6x	64QAM	24
	8x	256QAM	32
Latency	3 - 5 ms for 2.5 ms Frame Period 6-10 ms for 5.0 ms Frame Period		
Maximum Deployment Range	Up to 40 miles (64 km)		
Packets Per Second	12,500		
GPS Synchronization	Yes, via CMM3, CMM4 or UGPS		
Quality of Service	Diffserv QoS		

Link Budget

Antenna Gain (Does not include cable loss, ~1dB)	2.4 GHz	18 dBi Dual Slant
	3.5 GHz	16 dBi Dual Slant
	3.65 GHz	16 dBi Dual Slant
	5 GHz	17 dBi Horizontal and Vertical
Combined Transmit Power		-30 to +22 dBm (to EIRP limit by region) in 1 dB-configurable intervals (2.4 GHz, 5 GHz) -30 to +25 dBm (to EIRP limit by region) in 1 dB-configurable intervals (3.5 GHz) -30 to +25 dBm (to EIRP limit by region and channel bandwidth) in 1 dB-configurable intervals (3.6 GHz)
Maximum Transmit Power		22 dBm combined OFDM (2.4 GHz, 5 GHz) (dependent upon Region Code setting) 25 dBm combined OFDM (3.5 GHz, 3.6 GHz), (dependent upon Region Code setting)
Physical		
Wind Survival		200 mph (322 kph)
Antenna Connection		50 ohm, N-type (Connectorized version only)
Environmental		IP66, IP67
Temperature / Humidity		-40°C to +60°C (-40°F to +140°F) / 0-95% non-condensing
Weight	2.4 GHz	15 kg (33 lbs) with antenna 2.5 kg (5.5 lbs) without antenna
		3.5 GHz
	3.6 GHz	15 kg (33 lbs) with antenna 2.5 kg (5.5 lbs) without antenna
	5 GHz	5.9 kg (13 lbs) with antenna 2.5 kg (5.5 lbs) without antenna
Dimension(HxWxD)	2.4 GHz	Radio: 27 x 21 x 7 cm (10.6" x 8.3" x 2.8") Antenna: 112.2 x 24.5 x 11.7 cm (44.2" x 9.6" x 4.6")
		3.5 GHz
	3.6 GHz	Radio: 27 x 21 x 7 cm (10.6" x 8.3" x 2.8")
	5 GHz	Radio: 27 x 21 x 7 cm (10.6" x 8.3" x 2.8")

	Antenna: 51 x 13 x 7.3 cm (20.2" x 5.1" x 2.9")
Power Consumption	14 W
Input Voltage	22 to 32 VDC
Security	
Encryption	56-bit DES, AES

Specifications for PMP 450 SM

The PMP 450 SM conforms to the specifications listed in [Table 221](#).

Table 221 PMP 450 SM specifications

Category		Specification
Model Number		PMP 450 SM
Spectrum		
Channel Spacing		5, 7, 10, 15, 20 and 30 MHz Channel Bandwidth Configurable on 2.5 MHz increments
Frequency Range	900 MHz	902 – 928 MHz
	2.4 GHz	2400 – 2483.5 MHz
	3.5 GHz	3300 – 3600 MHz
	3.65 GHz	3500 – 3850 MHz
	5 GHz	5470 – 5875 MHz
Channel Bandwidth	900 MHz,	5, 7, 10 and 20 MHz
	2.4, 3.5 GHz, 3.65 GHz and 5 GHz	5, 10, 15, 20 and 30 MHz
OFDM Subcarriers		512 FFT
Interface		
MAC (Media Access Control) Layer		Cambium Proprietary
Physical Layer		2x2 MIMO OFDM
Ethernet Interface		10/100 BaseT, half/full duplex, rate auto negotiated (802.3 compliant)
Protocols Used		IPv4, UDP, TCP, IP, ICMP, Telnet, SNMP, HTTP, FTP
Network Management		HTTP, HTTPS, Telnet, FTP, SNMP v3
VLAN		802.1ad (DVLAN Q-in-Q), 802.1Q with 802.1p priority, dynamic port VID
Sensitivity		
900 MHz		1x = -91 dBm, 2x = -91 dBm, 4x = -85 dBm, 6x = -78 dBm, 8x = -70 dBm

Nominal Receive Sensitivity (w/ FEC) @ 5 MHz Channel	2.4 GHz	1x = -92.5 dBm, 2x = -89.9 dBm, 4x = -82.9 dBm, 6x = -75.9, dBm, 8x = -67.9 dBm
	3.5 GHz	1x = -93.5 dBm, 2x = -89.4 dBm, 4x = -83.5 dBm, 6x = -76.4 dBm, 8x = -68.3 dBm
	3.65 GHz	1x = -91.3 dBm, 2x = -89.1 dBm, 4x = -82.2 dBm, 6x = -75.2 dBm, 8x = -67.3 dBm
	5.4 GHz	1x = -89.3 dBm, 2x = -87.3 dBm, 4x = -80.3 dBm, 6x = -74.3 dBm, 8x = -66.3 dBm
	5.8 GHz	1x = -89 dBm, 2x = -87 dBm, 4x = -80 dBm, 6x = -73.9 dBm, 8x = -64.9 dBm
Nominal Receive Sensitivity (w/ FEC) @ 7 MHz Channel	900 MHz	1x = -91 dBm, 2x = -84 dBm, 4x = -83 dBm, 6x = -77 dBm, 8x = -71 dBm
	3.5 GHz	1x = -92.2 dBm, 2x = -88.5 dBm, 4x = -81.4 dBm, 6x = -74.5 dBm, 8x = -67.6 dBm
	3.65 GHz	1x = -90.4 dBm, 2x = -87.3 dBm, 4x = -80.6 dBm, 6x = -73 dBm, 8x = -65.6 dBm
Nominal Receive Sensitivity (w/ FEC) @ 10 MHz Channel	900 MHz	1x = -90 dBm, 2x = -83 dBm, 4x = -80 dBm, 6x = -74 dBm, 8x = -68 dBm
	2.4 GHz	1x = -88 dBm, 2x = -88 dBm, 4x = -81 dBm, 6x = -75 dBm, 8x = -69 dBm
	3.5 GHz	1x = -88 dBm, 2x = -88 dBm, 4x = -81 dBm, 6x = -76 dBm, 8x = -68 dBm
	3.65 GHz	1x = -86 dBm, 2x = -86 dBm, 4x = -80 dBm, 6x = -73 dBm, 8x = -66 dBm
	5.4 GHz	1x = -84 dBm, 2x = -84 dBm, 4x = -78 dBm, 6x = -72 dBm, 8x = -63 dBm
	5.8 GHz	1x = -84 dBm, 2x = -84 dBm, 4x = -77 dBm, 6x = -71 dBm, 8x = -63 dBm
Nominal Receive Sensitivity (w/ FEC) @ 15 MHz Channel	2.4 GHz	1x = -88.5 dBm, 2x = -84.5 dBm, 4x = -77.5 dBm, 6x = -71.5 dBm, 8x = -64.5 dBm
	3.5 GHz	1x = -89.5 dBm, 2x = -84.5 dBm, 4x = -78.5 dBm, 6x = -71.5 dBm, 8x = -65.1 dBm
	3.65 GHz	1x = -87.3 dBm, 2x = -84.3 dBm, 4x = -77.3 dBm, 6x = -70.3 dBm, 8x = -62.2 dBm
	5.4 GHz	1x = -84.5dBm, 2x = -82.5 dBm, 4x = -75.5 dBm, 6x = -69.5 dBm, 8x = -59.5 dBm

	5.8 GHz	1x = -84 dBm, 2x = -84 dBm, 4x = -77 dBm, 6x = -71 dBm, 8x = -63 dBm
Nominal Receive Sensitivity (w/ FEC) @ 20 MHz Channel	900 MHz	1x = -87 dBm, 2x = -80 dBm, 4x = -77 dBm, 6x = -72 dBm, 8x = -65 dBm
	2.4 GHz	1x = -86.9 dBm, 2x = -82.9 dBm, 4x = -75.9 dBm, 6x = -69.9 dBm, 8x = -63.5 dBm
	3.5 GHz	1x = -87.5 dBm, 2x = -83.5 dBm, 4x = -76.5 dBm, 6x = -69.5 dBm, 8x = -63.1 dBm
	3.65 GHz	1x = -86 dBm, 2x = -83 dBm, 4x = -76.2 dBm, 6x = -68.2 dBm, 8x = -61 dBm
	5.4 GHz	1x = -83.4 dBm, 2x = -81.7 dBm, 4x = -74.4 dBm, 6x = -67.2 dBm, 8x = -57.3 dBm
	5.8 GHz	1x = -84 dBm, 2x = -80.5 dBm, 4x = -74 dBm, 6x = -66.9 dBm, 8x = -56 dBm
Nominal Receive Sensitivity (w/ FEC) @ 30 MHz Channel	2.4 GHz	1x = -85.9 dBm, 2x = -80.9 dBm, 4x = -73.9 dBm, 6x = -67.8 dBm, 8x = -60.9 dBm
	3.5 GHz	1x = -86.5 dBm, 2x = -81.5 dBm, 4x = -74.5 dBm, 6x = -68.2 dBm, 8x = -61.3 dBm
	3.65 GHz	1x = -84.3 dBm, 2x = -80.3 dBm, 4x = -74.3 dBm, 6x = -66.2 dBm, 8x = -58 dBm
	5.4 GHz	1x = -82 dBm, 2x = -78.3 dBm, 4x = -72.3 dBm, 6x = -65.3 dBm, 8x = -55.3 dBm
	5.8 GHz	1x = -81.7 dBm, 2x = -78.6 dBm, 4x = -71.6 dBm, 6x = -64.4 dBm, 8x = -54 dBm

Performance

Subscribers Per Sector	Up to 238		
ARQ	Yes		
Cyclic Prefix	1/16		
Frame Period	2.5 ms or 5.0 ms		
Modulation Levels (Adaptive)	Modulation Levels	MCS	SNR (in dB)
	2x	QPSK	10
	4x	16QAM	17
	6x	64QAM	24

		8x	256QAM	32
Latency		3 - 5 ms for 2.5 ms Frame Period 6-10 ms for 5.0 ms Frame Period		
Maximum Deployment Range		Up to 40 miles (64 km)		
GPS Synchronization		Yes		
Quality of Service		Diffserv QoS		
Link Budget				
Antenna Gain (Does not include cable loss, ~1dB)	900 MHz	12 dBi Yagi antenna		
	2.4 GHz	7 dBi Dual Slant, integrated patch		
	3.5 GHz	8 dBi Dual Slant, integrated patch		
		19 dBi Flat Plate, integrated patch		
	3.65 GHz	8 dBi Dual Slant, integrated patch		
		19 dBi Flat Plate, integrated patch		
	5 GHz	9 dBi H+V, integrated patch		
		25 dBi H+V, integrated dish		
Combined Transmit Power		-30 to +22 dBm (to EIRP limit by region) – 2.4, 5 GHz -30 to +25 dBm (to EIRP limit by region) – 3.5, 3.6 GHz		
Maximum Transmit Power		22 dBm combined OFDM (2.4 GHz, 5 GHz) (dependent upon Region Code setting) 25 dBm combined OFDM (900 MHz, 3.5 GHz, 3.6 GHz), (dependent upon Region Code setting)		
Reflector antenna gain	2.4 GHz	+12 dBi		
	3.5 GHz	+11 dBi		
	3.65 GHz	+11 dBi		
	5 GHz	+15 dBi		
Other antenna (5 GHz only)	CLIP Gain	+8 dBi		
	LENS Gain	+5.5 dBi		
Physical				
Wind Survival		200 mph (322 kph)		

Antenna Connection	50 ohm, N-type (Connectorized version only)	
Environmental	IP55	
Temperature / Humidity	-40°C to +60°C (-40°F to +140°F) / 0-95% non-condensing	
Weight	2.4 GHz	15 kg (33 lbs) with antenna 2.5 kg (5.5 lbs) without antenna
	3.5 GHz	15 kg (33 lbs) with antenna 2.5 kg (5.5 lbs) without antenna 2.5 kg (5.5 lbs) for 450 ruggedized
	3.6 GHz	15 kg (33 lbs) with antenna 2.5 kg (5.5 lbs) without antenna 2.5 kg (5.5 lbs) for 450 ruggedized
	5 GHz	5.9 kg (13 lbs) with antenna 2.5 kg (5.5 lbs) without antenna 3.5 kg (7.7 lbs) for 450d
Dimensions (H x W x D)	30 x 9 x 9 cm (11.75" x 3.4" x 3.4") 50 x 50 x 38 cm (19.69" x 19.69" x 14.96") for 450d 31.0 x 31.0 x 6.4 cm (12" x 12" x 2.5") for 450 ruggedized	
Power Consumption	12 W	
Input Voltage	20 to 32 VDC	
Security		
Encryption	56-bit DES, AES	

Specifications for PTP 450 BH

The PTP 450 BH conforms to the specifications listed in [Table 222](#).

Table 222 PTP 450i BH specifications

Category	Specification
Model Number	PTP 450 BH
Spectrum	
Channel Spacing	5, 7, 10, 15, 20 and 30 MHz Channel Bandwidth Configurable on 2.5 MHz increments

Frequency Range	3.5 GHz	3300 – 3600 MHz
	3.65 GHz	3500 – 3850 MHz
	5 GHz	5470 – 5875 MHz
Channel Bandwidth	5, 7, 10, 15, 20 and 30 MHz 7 MHz Channel bandwidth configurable for 3.5 GHz and 3.65 GHz band only.	
OFDM Subcarriers	512 FFT	
Interface		
MAC (Media Access Control) Layer	Cambium Proprietary	
Physical Layer	2x2 MIMO OFDM	
Ethernet Interface	10/100 BaseT, half/full duplex, rate auto negotiated (802.3 compliant)	
Protocols Used	IPv4, UDP, TCP, IP, ICMP, Telnet, SNMP, HTTP, FTP, TFTP, RADIUS	
Network Management	HTTP, HTTPS, Telnet, FTP, SNMP v2c and v3, TFTP, Syslog	
VLAN	802.1ad (DVLAN Q-in-Q), 802.1Q with 802.1p priority, dynamic port VID	
Sensitivity		
Nominal Receive Sensitivity (w/ FEC) @ 5 MHz Channel	3.5 GHz	OFDM: 1x = -92 dBm, 2x = -90 dBm, 4x = -83 dBm, 6x = -76 dBm, 8x = -69 dBm
	3.6 GHz	OFDM: 1x = -94 dBm, 2x = -89.3 dBm, 4x = -82.3 dBm, 6x = -75.2 dBm, 8x = -68.4 dBm
	5.4 GHz	OFDM: 1x = -90.4 dBm, 2x = -86 dBm, 4x = -79.4 dBm, 6x = -73.2 dBm, 8x = -65.4 dBm
	5.8 GHz	OFDM: 1x = -90 dBm, 2x = -85.4 dBm, 4x = -79.4 dBm, 6x = -73.4 dBm, 8x = -64.9 dBm
Nominal Receive Sensitivity (w/ FEC) @ 7 MHz Channel	3.5 GHz	OFDM: 1x = -90 dBm, 2x = -88 dBm, 4x = -81 dBm, 6x = -74 dBm, 8x = -67 dBm
	3.6 GHz	OFDM: 1x = -92 dBm, 2x = -87.3 dBm, 4x = -81.3 dBm, 6x = -74.3 dBm, 8x = -66.4 dBm
Nominal Receive Sensitivity (w/ FEC) @ 10 MHz Channel	3.5 GHz	OFDM: 1x = -91 dBm, 2x = -87.2 dBm, 4x = -80 dBm, 6x = -73 dBm, 8x = -65.6 dBm
	3.6 GHz	OFDM: 1x = -90.4 dBm, 2x = -86.3 dBm, 4x = -80 dBm, 6x = -73 dBm, 8x = -64.5 dBm

	5.4 GHz	OFDM: 1x = -87.6 dBm, 2x = -82.5 dBm, 4x = -76.5 dBm, 6x = -70.5 dBm, 8x = -61.5 dBm
	5.8 GHz	OFDM: 1x = -87.5 dBm, 2x = -82.7 dBm, 4x = -76.8 dBm, 6x = -70.5 dBm, 8x = -61.4 dBm
Nominal Receive Sensitivity (w/ FEC) @ 15 MHz Channel	3.5 GHz	OFDM: 1x = -89 dBm, 2x = -85 dBm, 4x = -78 dBm, 6x = -71.1 dBm, 8x = -64.7 dBm
	3.6 GHz	OFDM: 1x = -89 dBm, 2x = -84.3 dBm, 4x = -78 dBm, 6x = -71 dBm, 8x = -63 dBm
	5.4 GHz	OFDM: 1x = -85.6 dBm, 2x = -81.6 dBm, 4x = -74.5 dBm, 6x = -68.5 dBm, 8x = -57.5 dBm
	5.8 GHz	OFDM: 1x = -85.6 dBm, 2x = -80.9 dBm, 4x = -75 dBm, 6x = -68 dBm, 8x = -58 dBm
Nominal Receive Sensitivity (w/ FEC) @ 20 MHz Channel	3.5 GHz	OFDM: 1x = -88 dBm, 2x = -84 dBm, 4x = -77 dBm, 6x = -70 dBm, 8x = -62.2 dBm
	3.6 GHz	OFDM: 1x = -87.3 dBm, 2x = -83.3 dBm, 4x = -76.3 dBm, 6x = -69.3 dBm, 8x = -62 dBm
	5.4 GHz	OFDM: 1x = -84.5 dBm, 2x = -80.5 dBm, 4x = -73.4 dBm, 6x = -66.4 dBm, 8x = -56.4 dBm
	5.8 GHz	OFDM: 1x = -84.8 dBm, 2x = -80.8 dBm, 4x = -74.7 dBm, 6x = -66.4 dBm, 8x = -56 dBm
Nominal Receive Sensitivity (w/ FEC) @ 30 MHz Channel	3.5 GHz	OFDM: 1x = -86 dBm, 2x = -82 dBm, 4x = -75 dBm, 6x = -68 dBm, 8x = -60 dBm
	3.6 GHz	OFDM: 1x = -86 dBm, 2x = -81.3 dBm, 4x = -74.3 dBm, 6x = -67.3 dBm, 8x = -59 dBm
	5.4 GHz	OFDM: 1x = -82.5 dBm, 2x = -78.5 dBm, 4x = -71.5 dBm, 6x = -64.4 dBm, 8x = -53.4 dBm
	5.8 GHz	OFDM: 1x = -82.5 dBm, 2x = -78.5 dBm, 4x = -71.5 dBm, 6x = -64.4 dBm, 8x = -54 dBm

Performance

ARQ	Yes		
Cyclic Prefix	1/16		
Frame Period	2.5 ms or 5.0 ms		
Modulation Levels (Adaptive)	Modulation Levels	MCS	SNR (in dB)
	2x	QPSK	10

		4x	16QAM	17
		6x	64QAM	24
		8x	256QAM	32
Latency		3 - 5 ms for 2.5 ms frame period 6 - 10 ms for 5.0 ms frame period		
Packets Per Second		12,500		
Maximum Deployment Range		Up to 40 miles (64 km)		
GPS Synchronization		Yes, via Autosync (CMM4)		
Quality of Service		Diffserv QoS		
Link Budget				
Combined Transmit Power	-	30 to +22 dBm (to EIRP limit by region) in 1 dB-configurable intervals (5 GHz) -30 to +25 dBm (to EIRP limit by region) in 1 dB-configurable intervals (3.5 GHz) -30 to +25 dBm (to EIRP limit by region and channel bandwidth) in 1 dB-configurable intervals (3.6 GHz)		
Antenna Gain (Does not include cable loss, ~1dB)	3.5 GHz	8 dBi Dual Slant, integrated patch		
		19 dBi Flat Plate, integrated patch		
	3.65 GHz	8 dBi Dual Slant, integrated patch		
		19 dBi Flat Plate, integrated patch		
	5 GHz	9 dBi H+V, integrated patch		
		25 dBi H+V, integrated dish		
Transmit Power Range		40 dB dynamic range (to EIRP limit by region) (1 dB step)		
Maximum Transmit Power		22 dBm combined OFDM (5 GHz) (dependent upon Region Code setting) 25 dBm combined OFDM (3.5 GHz, 3.6 GHz), (dependent upon Region Code setting)		
Reflector antenna gain	3.5 GHz	+11 dBi		
	3.65 GHz	+11 dBi		
	5 GHz	+15 dBi		

Other antenna (5 GHz only)	CLIP Gain	+8 dBi
	LENS Gain	+5.5 dBi
Physical		
Sync/AUX port	RJ45	<ul style="list-style-type: none"> • 10/100/1000BASE-T Ethernet Data • PoE output • Sync input or output (Connection and powering of UGPS Sync input)
Antenna Connection	50 ohm, N-type (Connectorized version only)	
Surge Suppression EN61000-4-5	EN61000-4-5: 1.2us/50us, 500 V voltage waveform Recommended external surge suppressor: Cambium Networks Model # C000000L033A	
Mean Time Between Failure	> 40 Years	
Environmental	IP66, IP67	
Temperature / Humidity	-40°C to +60°C (-40°F to +140°F), 0-95% non-condensing	
Weight	15 kg (33 lbs) with antenna 2.5 kg (5.5 lbs) without antenna	
Wind Survival	200 mph (322 kph)	
Dimension(HxWxD)	30 x 9 x 9 cm (11.75" x 3.4" x 3.4")	
Maximum Power Consumption	14 W	
Input Voltage	22 to 32 VDC	
Security		
Encryption	56-bit DES, AES	

PSU specifications

The PMP/PTP 450i AC+DC Enhanced Power Injector conforms to the specifications listed in [Table 223](#).

Table 223 PMP/PTP 450i AC power Injector specifications

Category	Specification
Dimensions	137 mm (5.4 in) x 56 mm (2.2 in) x 38 mm (1.5 in)
Weight	0.240 Kg (0.5 lbs)
Temperature	0°C to +40°C
Humidity	90% non-condensing
Waterproofing	Not waterproof
Altitude	Sea level to 5000 meters (16000 ft)
AC Input	Min 90 V AC, 57 – 63 Hz, max 264 V AC, 47 – 53 Hz.
DC output voltage to the ODU	55V +/- 5%
AC connector	IEC-320-C8
Efficiency	Better than 85%, efficiency level 'V'
Over Current Protection	Hiccup current limiting, trip point set between 120% to 150% of full load current
Hold up time	At least 10 milliseconds



Warning

Do not use above PSU to power up other than 450 platform radios.

The PMP/PTP 450 power supply conforms to the specifications listed in [Table 224](#).

Table 224 PMP/PTP 450 power supply specifications (part number: N000900L001A)

Category	Specification
Dimensions	118 mm (4.66 in) x 45 mm (1.75 in) x 32 mm (1.25 in)
Weight	0.240 Kg (0.5 lbs)
Temperature	0°C to +40°C
Humidity	20 to 90%
AC Input	90-264 VAC, 47 – 63 Hz, 0.5 A rms at 120 VAC, 0.25 A rms at 240 VAC.

DC output voltage to the ODU	30 V \pm 5%
AC connector	IEC-320-C8
Efficiency	Better than 85%, efficiency level 'V'
Over Current Protection	Short circuit, with auto recovery; Should restart between every 0.5 to 2 sec.
Hold up time	10mS min at max load, 120VAC

**Note**

The 30V PSU (part number: #N000900L001A) has to be used for PMP 450 900 MHz SM.

**Warning**

The PMP 450 Ruggedized High Gain Integrated Subscriber Module (Cambium part numbers C035045C014A and C036045C014A), while encapsulated in a 450i-type enclosure, contains 450 circuitry which must be powered via 30VDC. Powering these SMs with a 56 VDC will damage the device.

Data network specifications

This section contains specifications of the PMP/PTP 450 platform Ethernet interface.

Ethernet interface

PMP/PTP 450i

The PMP/PTP 450i Ethernet port conforms to the specifications listed in [Table 225](#).

Table 225 PMP/PTP 450i Main and Aux Ethernet bridging specifications

Ethernet Bridging	Specification
Protocol	IEEE 802.3 compatible
QoS	IEEE 802.1p, IEEE 802.1Q, IEEE 802.1ad, DSCP IPv4
Main Ethernet port	10/100/1000 BaseT, half/full duplex, rate auto negotiated
Aux Ethernet port	10/100 BaseT, half/full duplex, rate auto negotiated
Maximum Ethernet Frame Size	1700 Bytes

PMP/PTP 450

Table 226 PMP/PTP 450 Ethernet bridging specifications

Ethernet Bridging	Specification
Protocol	IEEE 802.3 compatible
QoS	IEEE 802.1p, IEEE 802.1Q, IEEE 802.1ad, DSCP IPv4
Interface	10/100/1000 BaseT, half/full duplex, rate auto negotiated
Maximum Ethernet Frame Size	1700 Bytes



Note

Practical Ethernet rates depend on network configuration, higher layer protocols and platforms used.

Over the air throughput is restricted to the rate of the Ethernet interface at the receiving end of the link.

Wireless specifications

This section contains specifications of the PMP/PTP 450 platform wireless interface. These specifications include RF bands, channel bandwidth, spectrum settings, maximum power and link loss.

General wireless specifications

The wireless specifications that apply to all PMP/PTP 450 platform variants are listed under [Table 227](#).

Table 227 PMP/PTP 450 platform wireless specifications

Item	Specification																		
Channel selection	Manual selection (fixed frequency).																		
Manual power control	To avoid interference to other users of the band, maximum power can be set lower than the default power limit.																		
Duplex scheme	Adaptive TDD																		
Range	<table border="1"> <thead> <tr> <th>Band</th> <th>Platform</th> <th>Range</th> </tr> </thead> <tbody> <tr> <td>900 MHz</td> <td>PMP 450i AP and PMP 450 SM</td> <td>40 mi / 64 km</td> </tr> <tr> <td>2.4 GHz</td> <td>PMP 450</td> <td>40 mi / 64 km</td> </tr> <tr> <td>3.5 GHz</td> <td>PMP/PTP 450</td> <td>40 mi / 64 km</td> </tr> <tr> <td>3.65 GHz</td> <td>PMP/PTP 450</td> <td>40 mi / 64 km</td> </tr> <tr> <td>5 GHz</td> <td>PMP/PTP 450/450i and PMP 450m AP</td> <td>40 mi / 64 km</td> </tr> </tbody> </table>	Band	Platform	Range	900 MHz	PMP 450i AP and PMP 450 SM	40 mi / 64 km	2.4 GHz	PMP 450	40 mi / 64 km	3.5 GHz	PMP/PTP 450	40 mi / 64 km	3.65 GHz	PMP/PTP 450	40 mi / 64 km	5 GHz	PMP/PTP 450/450i and PMP 450m AP	40 mi / 64 km
Band	Platform	Range																	
900 MHz	PMP 450i AP and PMP 450 SM	40 mi / 64 km																	
2.4 GHz	PMP 450	40 mi / 64 km																	
3.5 GHz	PMP/PTP 450	40 mi / 64 km																	
3.65 GHz	PMP/PTP 450	40 mi / 64 km																	
5 GHz	PMP/PTP 450/450i and PMP 450m AP	40 mi / 64 km																	
Over-the-air encryption	DES, AES																		
Error Correction	Rate 3/4 RS coder																		

Link Range and Throughput

Link range and throughput estimates are based on site-specific attributes and configuration parameters. For the most up-to-date information on link range and throughput for your equipment see the *Capacity Planner and LINKPlanner software tools*:

- For average-deployment link range and throughput planning information, see: <https://support.cambiumnetworks.com/files/pmp450>
- For site-specific link range and throughput planning information, see: <https://support.cambiumnetworks.com/files/linkplanner>

Country specific radio regulations

This section describes how the PMP/PTP 450 platform complies with the radio regulations that are enforced in various countries.



Caution

Changes or modifications not expressly approved by Cambium could void the user's authority to operate the system.

Type approvals

This system has achieved Type Approval in various countries around the world. This means that the system has been tested against various local technical regulations and found to comply. The frequency bands in which the system operates may be 'unlicensed' and, in these bands, the system can be used provided it does not cause interference. The system is not guaranteed protection against interference from other products and installations.

The radio specification type approvals that have been granted for 450 platform frequency variants are listed in [Table 228](#).

Table 228 Radio certifications

Variant	Region	Specification (Type Approvals)
900 MHz PMP 450i	Canada	RSS Gen and RSS 210
	USA	FCC Part 15.247
	Mexico	NOM-121-SCT1-2009
2.4 GHz PMP 450	Canada	RSS Gen and RSS 210
	USA	FCC Part 15 Class B
3.5 GHz PMP/PTP 450	Canada	RSS Gen and RSS 192
	Europe	ETSI EN 302 326-2 V1.2.2
3.6 GHz PMP/PTP 450	Canada	RSS Gen and RSS 192
	USA	FCC Part 15 Class B
5.4 GHz PMP/PTP 450 and 450i	Europe	ETSI EN 301 893 v1.6.1
	USA	FCC Part 15 Class B
5.8 GHz PMP/PTP 450 and 450i	Canada	RSS Gen and RSS 210
	USA	FCC Part 15 Class B
	Europe	ETSI EN 302 502 v1.2.1

DFS for 2.4 and 5 GHz Radios

Dynamic Frequency Selection (DFS) is a requirement in several countries and regions for 2.4 and 5 GHz unlicensed systems to detect radar systems and avoid co-channel operation.

The details of DFS operation and channels available for each Country Code, including whether DFS is active on the AP, SM, which DFS regulation apply, and any channel restrictions are shown in [Table 229](#) on page 10-36.

Table 229 Country & Bands DFS setting

Region Code	Country Code	Band	AP	SM	Weather Radar Notch-Out
North America	Mexico	2.4 GHz	No effect	No effect	No
		5.4 GHz	ANATEL Res506-2008	No effect	No
		5.8 GHz	No effect	No effect	No
South America	Brazil	5.4 GHz	ETSI EN 301 893 v1.7.1 DFS	No effect	No
		5.8 GHz	No effect	No effect	No
Europe	ETSI	5.4 GHz	ETSI EN 301 893 v1.7.1 DFS	ETSI EN 301 893 v1.7.1 DFS	Yes
		5.8 GHz	ETSI EN 302 502 v1.2.1 DFS	ETSI EN 302 502 v1.2.1 DFS	Yes
Other-Regulatory	Other-FCC	2.4 GHz	No effect	No effect	No
		5.4 GHz	FCC DFS	No effect	No
		5.8-GHz	No effect	No effect	No
	Other-ETSI	5.4 GHz	ETSI EN 301 893 v1.7.1 DFS	ETSI EN 301 893 v1.7.1 DFS	No
		5.8 GHz	ETSI EN 302 502 v1.2.1 DFS	ETSI EN 302 502 v1.2.1 DFS	No

Equipment Disposal

Waste (Disposal) of Electronic and Electric Equipment



Waste (Disposal) of Electronic and Electric Equipment

Please do not dispose of Electronic and Electric Equipment or Electronic and Electric Accessories with your household waste. In some countries or regions, collection systems have been set up to handle waste of electrical and electronic equipment. In European Union countries, please contact your local equipment supplier representative or service center for information about the waste collection system in your country.

Country specific maximum transmit power

Maximum transmit power 900 MHz band

Table 230 Default combined transmit power per country – 900 MHz band PMP 450i

Countries	Device Type (AP/SM/BH)	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)
USA, Mexico, Canada, Other FCC	Any	Any	5 MHz	-	36
			7 MHz	-	36
			10 MHz	-	36
			20 MHz	-	36
Brazil	Any	Any	5 MHz	-	36
			7 MHz	-	36
			10 MHz	-	36
			20 MHz	-	36
Other	Any	Any	Any	-	-

Maximum transmit power 2.4 GHz band

Table 231 Default combined transmit power per country – 2.4 GHz band PMP/PTP 450

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)
USA, Canada, Other FCC	AP	Sector	Any	18	36
	SM, BH	Integrated	Any	-	36
		Reflector	Any	24	36
		Integrated Dish (450d)	Any	11	36
Other	Any	Any	Any	30	-

Maximum transmit power 3.5 GHz band

Table 232 Default combined transmit power per country – 3.5 GHz band PMP/PTP 450

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)
Other-ETSI	AP	Sector	Any	-	66
	SM, BH	Any	Any	-	63
Brazil, China, India, Indonesia, Mexico, Other	Any	Any	Any	-	-
Canada	Any	Any	Any	-	62
Australia	Any	Any	Any	-	63

Maximum transmit power 3.65 GHz band

Table 233 Default combined transmit power per country – 3.65 GHz band PMP/PTP 450

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)
-----------	-------------	--------------	------------	-----------------------------	------------------

Australia, India, Indonesia, Mexico, Other	Any	Any	Any	-	-
Other-ETSI	AP	Any	Any	-	66
	SM, BH				63
Canada, USA, Other-FCC	AP	Sector	Any	25	43
	SM, BH	Integrated		-	
		Reflector		-	
		Integrated Dish (450d)		18	

Maximum transmit power 4.9 GHz band

Table 234 Default combined transmit power per country – 4.9 GHz band PMP/PTP 450/450i

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)	
USA, Mexico, Canada, Other FCC	AP	Sector	5 MHz	24	40	
			10 MHz	24	40	
			20 MHz	23	39	
		Omni	5 MHz	24	35	
			10 MHz	24	36	
			20 MHz	23	35	
	SM, BH	4ft parabolic	Flate plate	5 MHz	24	51
				10 MHz	24	51
				20 MHz	23	50
		6ft parabolic	4ft parabolic	5 MHz	24	52
				10 MHz	24	55
				20 MHz	23	56
			6ft parabolic	5 MHz	24	52
				10 MHz	24	55
				20 MHz	23	58
Brazil	Any	Any	5 MHz	23	54	

			10 MHz	27	57
			20 MHz	27	60
Other	Any	Any	Any	27	-

Maximum transmit power 5.1 GHz band

Table 235 Default combined transmit power per Country – 5.1 GHz band PMP/PTP 450i

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)		
USA, Other FCC	AP	Sector	5 MHz	12	28		
			10 MHz	15	31		
			20 MHz	16	32		
	SM, BH	Omni		5 MHz	16	28	
				10 MHz	19	31	
				20 MHz	22	34	
		4ft parabolic	Flat plate		5 MHz	-2	25
					10 MHz	1	28
					20 MHz	3	30
4ft parabolic				5 MHz	6	39	
				10 MHz	9	42	
				20 MHz	9	43	
Mexico	Any	Any	5 MHz	-	17		
			10 MHz	-	20		
			20 MHz	-	23		
Other	Any	Any	Any	27	-		

Table 236 Default combined transmit power per Country – 5.1 GHz band PMP 450m

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)
USA, Other FCC	AP	Sector	20 MHz	NA	32
Mexico	Any	Any	20 MHz	NA	23
Other	Any	Any	Any	NA	-

Maximum transmit power 5.2 GHz band

Table 237 Default combined transmit power per country – 5.2 GHz band

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)
USA, Other FCC	AP	Sector	5 MHz	6	22
			10 MHz	9	25
			20 MHz	12	28
		Omni	5 MHz	10	22
			10 MHz	13	25
			20 MHz	16	28
	SM, BH	Flat plate	5 MHz	-7	20
			10 MHz	-4	23
			20 MHz	-1	26
		4ft parabolic	5 MHz	-13	19
			10 MHz	-11	22
			20 MHz	-8	25
Mexico	Any	Any	5 MHz	-	24
			10 MHz	-	27
			20 MHz	-	30
Other	Any	Any	Any	27	-

Table 238 Default combined transmit power per Country – 5.2 GHz band PMP 450m

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)
USA, Other FCC	AP	Sector	20 MHz	NA	32
Mexico	Any	Any	20 MHz	NA	32
Other	Any	Any	Any	NA	-

Maximum transmit power 5.4 GHz band

Table 239 Default combined transmit power per country – 5.4 GHz band PMP/PTP 450i

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)
USA, Other FCC	AP	Sector	5 MHz	6	22
			10 MHz	9	25
			20 MHz	12	28
		Omni	5 MHz	10	22
			10 MHz	13	25
			20 MHz	16	28
	SM, BH	Flat plate	5 MHz	-7	20
			10 MHz	-4	23
			20 MHz	-1	26
		4ft parabolic	5 MHz	-6	21
			10 MHz	-3	24
			20 MHz	0	27
Brazil	Any	Any	10 MHz	19	27
			20 MHz	23	30
Mexico	Any	Any	10 MHz	-	27
			20 MHz	-	30
Other	Any	Any	Any	27	-
ETSI	Any	Any	5 MHz	-	24
			10 MHz	-	27
			20 MHz	-	30
Australia	Any	Any	10 MHz	-	30
			20 MHz	-	30

Table 240 Default combined transmit power per Country – 5.4 GHz band PMP 450m

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)
USA, Other FCC	AP	Sector	20 MHz	NA	32
Mexico	Any	Any	20 MHz	NA	23
Other	Any	Any	Any	NA	-

Table 241 Default combined transmit power per country – 5.4 GHz band PMP 450

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)
United States, Canada, Brazil, Australia, Denmark, Finland, Germany, Greece, Liechtenstein, Norway, Portugal, Spain, UK, Vietnam	AP	Sector (18 dBi – 1dB cable loss)	10 MHz	10	27
			20 MHz	13	30
Austria, Belgium, Bosnia & Herzegovina, Bulgaria, Croatia, Cyprus, Czech Republic, France, , Hungary, Ireland, Italy, Latvia, Lithuania, Luxembourg, Macedonia, Malta, Netherlands, Poland, Romania, Slovakia, Slovenia , Sweden	AP	Sector (18 dBi – 1dB cable loss)	10 MHz	10	27 [*]
			20 MHz	13	30
Algeria	AP	Sector (18 dBi – 1dB cable loss)	10 MHz	10	27
			20 MHz	13	30
Other	AP	Sector (18 dBi – 1dB cable loss)	10 MHz	19	No EIRP limit
			20 MHz	19	No EIRP limit

(*) At 5.4 GHz, EU regulations are harmonized. 5600 – 5650 MHz excluded, as ten minute Channel Availability Check (CAC) is required

Maximum transmit power 5.8 GHz band

Table 242 Default combined transmit power per country – 5.8 GHz band PMP/PTP 450i

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)
USA, Canada, Brazil, Other FCC	AP	Sector, Omni	5 MHz	-	36
			10 MHz	-	36
			20 MHz	-	36
	SM, BH	Flat plate, 4ft parabolic, 6ft parabolic	5 MHz	27	-
			10 MHz	27 (26 for 5733 MHz and below)	-
			20 MHz	27	-
Mexico	Any	Any	5 MHz	-	30
			10 MHz	-	33
			20 MHz	-	36
Other	Any	Any	5 MHz	27	-

Table 243 Default combined transmit power per Country – 5.8 GHz band PMP 450m

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)
USA, Other FCC	AP	Sector	20 MHz	NA	32
Mexico	Any	Any	20 MHz	NA	23
Other	Any	Any	Any	NA	-

Table 244 Default combined transmit power per country – 5.8 GHz band PMP 450

Countries	Device Type	Antenna Type	Channel BW	Conducted Power Limit (dBm)	EIRP Limit (dBm)
	AP		5 MHz	19	36

Australia, India, United States		Sector (18 dBi – 1dB cable loss)	10 MHz	19	36
			20 MHz	19	36
Brazil, Vietnam	AP	Sector (18 dBi – 1dB cable loss)	5 MHz	7	24
			10 MHz	10	27
			20 MHz	13	30
Canada	AP	Sector (18 dBi – 1dB cable loss)	5 MHz	9	26
			10 MHz	19	36
			20 MHz	19	36
Denmark, Finland, Germany, Greece, Iceland, Ireland, Liechtenstein, Norway, Portugal, Serbia, Spain, Switzerland, United Kingdom,	AP	Sector (18 dBi – 1dB cable loss)	5 MHz	-	-
			10 MHz	16	33
			20 MHz	19	36
Indonesia	AP	Sector (18 dBi – 1dB cable loss)	5 MHz	13	30
			10 MHz	19	36
			20 MHz	19	36

Country specific frequency range

Frequency range 900 MHz band

Table 245 Frequency range per country – 900 MHz band

Region	Country	Channel center Frequency limits (MHz)	
		Lower	Upper
Other	Other	902	928
	Other-FCC	902	928
North America	Canada	902	928
	United States	902	928
	Mexico	902	928
	Puerto Rico	902	928
Oceania	Australia	918	926
	New Zealand	921 (7 MHz)	928 (7 MHz)
		921.5 (5 MHz)	928 (5 MHz)
	Brazil	902	907.5
		915	928
	Ecuador	902	928
	Colombia	902	928
Venezuela	902	928	

Frequency range 2.4 GHz band

Table 246 Frequency range per country – 2.4 GHz band PMP/PTP 450

Countries	Antenna Type	Channel BW	Channel center Frequency limits (MHz)	
			Lower	Upper
Canada, United States, Other, Other- FCC	Any	5 MHz	2402.5	2475
		10 MHz	2405	2470
		20 MHz	2417.5	2460

Frequency range 3.5 GHz band

Table 247 Frequency range per country – 3.5 GHz band PMP/PTP 450

Countries	Antenna Type	Channel BW	Channel center Frequency limits (MHz)	
			Lower	Upper
Brazil, Other- ETSI	Any	5 MHz	3402.5	3597.5
		7 MHz	3403.5	3596.5
		10 MHz	3405	3595
		20 MHz	3410	3590
China, Indonesia	Any	5 MHz	3302.5	3397.5
		7 MHz	3303.5	3396.5
		10 MHz	3305	3395
		20 MHz	3310	3390

Frequency range 3.65 GHz band

Table 248 Frequency range per country – 3.65 GHz band PMP/PTP 450

Countries	Antenna Type	Channel BW	Channel center Frequency limits (MHz)	
			Lower	Upper
Australia, India, Other	Any	5 MHz	3502.5	3847.5
		10 MHz	3505	3845
		20 MHz	3510	3840
Other – ETSI	Any	5 MHz	3552.5	3797.5
		10 MHz	3555	3795
		20 MHz	3560	3790
Indonesia	Any	5 MHz	3602.5	3797.5
		10 MHz	3605	3795
		20 MHz	3610	3790
Mexico	Any	5 MHz	3552.5	3747.5
		10 MHz	3555	3745
		20 MHz	3560	3740

Frequency range 4.9 GHz band

Table 249 Frequency range per country – 4.9 GHz band PMP/PTP 450i

Countries	Antenna Type	Channel BW	Channel center Frequency limits (MHz)	
			Lower	Upper
USA, Mexico, Canada, Other FCC	Any	5 MHz	4942.5	4987.5
		10 MHz	4945	4985
		20 MHz	4950	4980
Brazil	Any	5 MHz	4912.5	4987.5
		10 MHz	4915	4985
		20 MHz	4920	4980
Other	Any	5 MHz	4902.5	4997.5
		10 MHz	4905	4995
		20 MHz	4910	4990

Frequency range 5.4 GHz band

Table 250 Frequency range per country – 5.4 GHz band PMP/PTP 450i

Countries	Antenna Type	Channel BW	Channel center Frequency limits (MHz)	
			Lower	Upper
Brazil	Any	10 MHz	5475	5720
		20 MHz	5480	5715
Mexico	Any	10 MHz	5475	5595
			5655	5720
		20 MHz	5480	5590
			5660	5710
Other	Any	5 MHz	5742.5	5722.5
		10 MHz	5475	5720
		20 MHz	5480	5715

Table 251 Frequency range per country – 5.4 GHz band PMP/PTP 450

Region code	Country Code	Channel BW	Channel center Frequency limits (MHz)	
			Lower	Upper
Other	Any	5 MHz	5472.5	5722.5
		10 MHz	5475	5720
		20 MHz	5480	5715
	Other-FCC (Any non-US country that follows FCC rules)	10 MHz	5475	5595
			5645	5720
		20 MHz	5465	5490
	Other-ETSI (Any country that follows ETSI rules)	10 MHz	5475	5595
			5645	5720
		20 MHz	5465	5490
Oceania	Australia	10 MHz	5475	5595
		20 MHz	5645	5720
			5465	5490
North America	Canada	10 MHz	5475	5595
		20 MHz	5645	5720
			5465	5490
South America	Brazil	10 MHz	5475	5720
		20 MHz	5480	5715
Asia	Vietnam	10 MHz	5475	5720
		20 MHz	5480	5715
Africa	Algeria	5 MHz	5472.5	5597.5
		10 MHz	5475	5595
		20 MHz	5465	5490
Europe	Europe (Denmark, Finland, France, Germany, Greece, Iceland, Ireland, Italy, Liechtenstein, Norway, Portugal, Serbia, Spain, Switzerland, United Kingdom)	10 MHz	5475	5595
		20 MHz	5645	5720
			5465	5490
		20 MHz	5640	5715

Frequency range 5.8 GHz band

Table 252 Frequency range per country – 5.8 GHz band PMP/PTP 450i

Countries	Antenna Type	Channel BW	Channel center Frequency limits (MHz)	
			Lower	Upper
USA, Canada, Brazil, Other FCC	Any	5 MHz	5730	5845
		10 MHz	5730	5845
		20 MHz	5735	5840
Mexico	Any	5 MHz	5727.5	5847.5
		10 MHz	5730	5845
		20 MHz	5735	5840
Other	Any	5 MHz	5727.5	5897.5
		10 MHz	5730	5895
		20 MHz	5735	5890

Table 253 Frequency range per country – 5.8 GHz band PMP/PTP 450

Countries	Antenna Type	Channel BW	Channel center Frequency limits (MHz)	
			Lower	Upper
Denmark, Norway, United Kingdom, Finland	Any	10 MHz	5730	5790
			5820	5845
		20 MHz	5735	5785
			5825	5840
Germany	Any	10 MHz	5760	5870
		20 MHz	5765	5865
Spain	Any	10 MHz	5730	5790
			5820	5850
		20 MHz	5735	5785
			5825	5845
Greece	Any	10 MHz	5730	5790
		20 MHz	5735	5785
Portugal, Iceland, Serbia	Any	10 MHz	5730	5870
		20 MHz	5735	5865

Switzerland, Liechtenstein	Any	10 MHz	5730	5790		
			5820	5870		
		20 MHz	5735	5785		
			5825	5865		
		Australia	Any	5 MHz	5727.5	5847.5
				10 MHz	5730	5845
20 MHz	5735			5840		
Canada, United States	Any	5 MHz	5730	5845		
		10 MHz	5730	5845		
		20 MHz	5735	5845		
India	Any	5 MHz	5727.5	5872.5		
		10 MHz	5730	5870		
		20 MHz	5735	5865		
Brazil, Vietnam	Any	5 MHz	5727.5	5847.5		
		10 MHz	5730	5845		
		20 MHz	5735	5840		
Indonesia	Any	5 MHz	5727.5	5822.5		
		10 MHz	5730	5820		
		20 MHz	5735	5815		
Malaysia	Any	5 MHz	5727.5	5872.5		
		10 MHz	5830	5870		
		20 MHz	5835	5865		

FCC specific information

FCC compliance testing

With GPS synchronization installed, the system has been tested for compliance to US (FCC) specifications. It has been shown to comply with the limits for emitted spurious radiation for a Class B digital device, pursuant to Part 15 of the FCC Rules in the USA. These limits have been designed to provide reasonable protection against harmful interference. However the equipment can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to other radio communications. There is no guarantee that interference does not occur in a particular installation.



Note

A Class B Digital Device is a device that is marketed for use in a residential environment, notwithstanding use in commercial, business and industrial environments.



Note

Notwithstanding that Cambium has designed (and qualified) the PMP/PTP 450 platform products to generally meet the Class B requirement to minimize the potential for interference, the PMP/PTP 450 platform product range is not marketed for use in a residential environment.

FCC IDs

Table 254 US FCC IDs

FCC ID	Product	Frequency Band	Channel Bandwidth	Frequencies	Maximum Combined Tx Output Power
Z8H89FT 0021 and Z8H89FT 0022	900 MHz PMP 450i AP & PMP 450 SM	900 MHz	5 MHz	904.5 - 925.5 MHz	25 dBm
			7 MHz	905.5 - 924.5 MHz	25 dBm
			10 MHz	907 - 923 MHz	25 dBm
			20 MHz	912 - 918 MHz	25 dBm
Z8H89FT 0003 and Z8H89FT 004	2.4 GHz PMP 450 AP & SM	2.4 GHz	5 MHz	2402.5 - 2475 MHz	19 dBm
			10 MHz	2405 - 2470 MHz	19 dBm
			20 MHz	2417.5 - 2460 MHz	19 dBm
Z8H89FT 0009 and	3.5 GHz PMP 450 AP & SM	3.5 GHz	5 MHz	3452.5 - 3647.5 MHz	25 dBm
			10 MHz	3455 - 3645 MHz	25 dBm
			20 MHz	3460 - 3640 MHz	25 dBm

FCC ID	Product	Frequency Band	Channel Bandwidth	Frequencies	Maximum Combined Tx Output Power
Z8H89FT 0010	3.65 GHz PMP 450 AP & SM	3.65 GHz	5 MHz	3652.5 -3697.5 MHz	19 dBm
			10 MHz	3655 – 3695 MHz	22 dBm
			20 MHz	3660 – 3690 MHz	25 dBm
Z8H89FT 0001, Z8H89FT 0002 and QWP- 50450I	5 GHz PMP 450/ 450i/450m AP, SM & PTP 450/450i BH	4.9 GHz (PMP/PTP 450i only)	5 MHz	4942.5 – 4987.5 MHz	24 dBm
			10 MHz	4945.0 – 4985.0 MHz	24 dBm
			20 MHz	4950.0 – 4980.0 MHz	23.5 dBm
		5.1 GHz (PMP/PTP 450i only)	5 MHz	5156.0 – 5247.5 MHz	16 dBm
			10 MHz	5160.0 – 5164.75 MHz	17 dBm
			20 MHz	5165.0 – 5245.0 MHz	19 dBm
		5.2 GHz (PMP/PTP 450i only)	5 MHz	5252.5 – 5343.0 MHz	10 dBm
			10 MHz	5255.0 – 5340.5 MHz	13 dBm
			20 MHz	5260.0 – 5333.75 MHz	16 dBm
		5.4 GHz	5 MHz	5473.0 – 5721.25 MHz	10 dBm
			10 MHz	5475.5 – 5719.25 MHz	13 dBm
			20 MHz	5480.0 – 5715.0 MHz	16 dBm
5.8 GHz	5 MHz	5730.0 – 5845.0 MHz	28 dBm		
	10 MHz	5730.0 – 5845.0 MHz	28 dBm		
	20 MHz	5735.0 – 5840.0 MHz	28 dBm		

FCC approved antenna list

The lists of antennas which have been approved for operation by the FCC are provided in:

- [Table 255](#) for 4.9 GHz
- [Table 256](#) for 5.1 and 5.2 GHz
- [Table 257](#) for 5.4 GHz
- [Table 258](#) for 5.8 GHz



Note

Any antenna of the same type and of gain equal or lower than the one approved by the FCC can be used in the countries following the FCC rules.

Table 255 USA approved antenna list 4.9 GHz

Directivity	Type	Manufacturer	Reference	Stated Gain (dBi)
Directional	Integrated flat plate	Cambium Networks	N/A	23.0
	2 ft dual polarised flat plate	Mars Antennas	MA-WA56-DP-28N	28.0
	4 ft parabolic dual polarised	Gabriel Antennas	Dual QuickFire QFD4-49-N	33.7
	6 ft parabolic dual polarised	Gabriel Antennas	QuickFire QF6-49-N	37.2
Sector	Integrated 90° sector flat plate	Cambium Networks	A005240	16.0
	90° sectorised	Cambium Networks	85009324001	17.0
	60° sectorised	Cambium Networks	85009325001	17.0
Omni-directional	Dual polar omni-directional	KP	KPPA-5.7-DPOMA	13.0

Table 256 USA approved antenna list 5.1 and 5.2 GHz

Directivity	Type	Manufacturer	Reference	Stated Gain (dBi)
Directional	Integrated flat plate	Cambium Networks	N/A	23.0
	2ft dual polarised flat plate	Mars Antennas	MA-WA56-DP-28N	28.5
	4ft parabolic dual polarised	Gabriel Antennas	PX4F-52-N7A/A	34.5
Sector	Integrated 90° sector flat plate	Cambium Networks	A005240	16.0
	90° sectorised	Cambium Networks	85009324001	17.0
Omni-directional	Dual polar omni-directional	KP	KPPA-5.7-DPOMA	13.0
	Dual polar omni-directional	Mars Antennas	MA-WO56-DP10	10.0

Table 257 USA approved antenna list 5.4 GHz

Directivity	Type	Manufacturer	Reference	Stated Gain (dBi)
Directional	Integrated flat plate	Cambium Networks	N/A	23.0
	2 ft dual polarised flat plate	Mars Antennas	MA-WA56-DP-28N	28.5
	2 ft dual polarised parabolic	MTI	MT-486013-NVH	28.5
Sector	Integrated 90° sector flat plate	Cambium Networks	A005240	16.0
	90° sectorised	Cambium Networks	85009324001	17.0
Omni-directional	Dual polar omni-directional	KP	KPPA-5.7-DPOMA	13.0
	Dual polar omni-directional	Mars Antennas	MA-WO56-DP10	10.0

Table 258 USA approved antenna list 5.8 GHz

Directivity	Type	Manufacturer	Reference	Stated Gain (dBi)
Directional	Integrated flat plate	Cambium Networks	N/A	23.0
	2 ft dual polarised flat plate	Mars Antennas	MA-WA56-DP-28N	28.0
	4 ft parabolic dual polarised	Gabriel Antennas	PX4F-52-N7A/A	35.3
	6 ft Parabolic dual polarised	Gabriel Antennas	PX6F-52/A	38.1
Sector	Integrated 90° sector flat plate	Cambium Networks	A005240	16.0
	90° sectorised	Cambium Networks	85009324001	17.0
	60° sectorised	Cambium Networks	85009325001	17.0
Omni-directional	Dual polar omni-directional	KP	KPPA-5.7-DPOMA	13.0

Innovation Science and Economic Development Canada (ISED) specific information

900 MHz ISED notification

Radio Standards Specification RSS-247, Issue 1, Digital Transmission Systems (DTSs), Frequency Hopping Systems (FHSs) and Licence-Exempt Local Area Network (LE-LAN) Devices, is a new standard to replace annexes 8 and 9 of RSS-210, Issue 8.

4.9 GHz ISED notification

The system has been approved under ISED RSS-111 for Public Safety Agency usage. The installer or operator is responsible for obtaining the appropriate site licenses before installing or using the system.

Utilisation de la bande 4.9 GHz FCC et ISED

Le système a été approuvé en vertu d' ISED RSS-111 pour l'utilisation par l'Agence de la Sécurité publique. L'installateur ou l'exploitant est responsable de l'obtention des licences de appropriées avant d'installer ou d'utiliser le système.

5.2 GHz and 5.4 GHz ISEDC notification

This device complies with ISEDC RSS-247. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Users should be cautioned to take note that high power radars are allocated as primary users (meaning they have priority) of 5250 – 5350 MHz and 5650 – 5850 MHz and these radars could cause interference and/or damage to license-exempt local area networks (LELAN).

For the connectorized version of the product and in order to reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (EIRP) is not more than that permitted by the regulations. The transmitted power must be reduced to achieve this requirement.

Utilisation de la bande 5.2 and 5.4 GHz ISEDC

Cet appareil est conforme à ISEDC RSS-247. Son fonctionnement est soumis aux deux conditions suivantes: (1) Ce dispositif ne doit pas causer d'interférences nuisibles, et (2) Cet appareil doit tolérer toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable. Les utilisateurs doivent prendre garde au fait que les radars à haute puissance sont considérés comme les utilisateurs prioritaires de 5250 à 5350 MHz et 5650 à 5850 MHz et ces radars peuvent causer des interférences et / ou interférer avec un réseau local ne nécessitant pas de licence.

Pour la version du produit avec antenne externe et afin de réduire le risque d'interférence avec d'autres utilisateurs, le type d'antenne et son gain doivent être choisis afin que la puissance isotrope rayonnée équivalente (PIRE) ne soit pas supérieure à celle permise par la réglementation. Il peut être nécessaire de réduire la puissance transmise doit être réduite pour satisfaire cette exigence.

ISEDC notification 5.8 GHz

RSS-GEN issue 3 (7.1.3) Licence-Exempt Radio Apparatus:

This device complies with ISEDC license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

In Canada, high power radars are allocated as primary users (meaning they have priority) of the 5600 – 5650 MHz spectrum. These radars could cause interference or damage to license-exempt local area network (LE-LAN) devices.

Utilisation de la bande 5.8 GHz ISEDC

RSS-GEN issue 3 (7.1.3) appareil utilisant la bande sans licence:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Au Canada, les radars à haute puissance sont désignés comme utilisateurs principaux (ils ont la priorité) dans la bande 5600 à 5650 MHz. Ces radars peuvent causer des interférences et / ou interférer avec un réseau local ne nécessitant pas de licence.

ISED Certification numbers

Table 259 ISED Certification Numbers

ISED Cert.	Product	Frequency Band	Channel Bandwidth	Frequencies	Maximum Combined Tx Output Power
109AO-50450I (Pending)	5 GHz AP, SM & BHM	4.9 GHz	5 MHz	4942.5 – 4987.5 MHz	24 dBm
			10 MHz	4945.0 – 4985.0 MHz	24 dBm
			20 MHz	4950.0 – 4980.0 MHz	23.5 dBm
		5.8 GHz	5 MHz	5730.0 – 5845.0 MHz	28 dBm
			10 MHz	5730.0 – 5845.0 MHz	28 dBm
			20 MHz	5735.0 – 5840.0 MHz	28 dBm

Canada approved antenna list

Under ISED regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by ISED . To reduce potential radio interference to other users, the antenna type and its gain must be so chosen that the equivalent isotropically radiated power (EIRP) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (PIRE) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

This radio transmitter (identify the device by certification number) has been approved by ISED to operate with the antenna types listed in [Country specific radio regulations, Innovation Science and Economic Development Canada \(ISED\)](#) , [Table 260](#) with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Le présent émetteur radio (identifier le dispositif par son numéro de certification) a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans la section [Country specific radio regulations, Innovation Science and Economic Development Canada \(ISED\)](#) , [Table 260](#) et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

Table 260 Canada approved antenna list 4.9 and 5.8 GHz

Antenna type	Description	Manufacturer	Reference	Gain (dBi)	
				4.9 GHz	5.8 GHz
Directional	Integrated flat plate	Cambium Networks	N/A	23	23
	2 ft dual polarised flat plate	MARS Antennas	MA-WA56-DP-28N	28.5	28
	4 ft parabolic dual polarised	Andrews Antennas	PX4F-52-N7A/A	N/A	35.3
	6 ft Parabolic dual polarised	Gabriel Antennas	QF6-49-N	37.2	N/A
Sector	Integrated 90° sector flat plate	Cambium Networks	A005240	16	16
	90°sector	Cambium Networks	85009324001	17	17
	60° sectorised	Cambium Networks	85009325001	16	16
Omni-directional	Omni-directional	KP Antennas	KPPA-5.7-DPOMA	13	13
	Omni-directional	MARS Antennas	MA-WO56-DP10	10	10

Table 261 Canada approved antenna list 5.2 and 5.4 GHz

Directivity	Type	Manufacturer	Reference	Stated Gain (dBi)
Directional	Integrated flat plate	Cambium Networks	N/A	23.0
	2ft dual polarised flat plate	Mars Antennas	MA-WA56-DP-28N	28.5
	2ft dual polarised parabolic	MTI	MT-486013-NVH	28.5
Sector	Integrated 90° sector flat plate	Cambium Networks	A005240	16.0
	90° sectorised	Cambium Networks	85009324001	17.0
Omni-directional	Dual polar omni-directional	KP	KPPA-5.7-DPOMA	13.0
	Dual polar omni-directional	Mars Antennas	MA-WO56-DP10	10.0

Chapter 11: Troubleshooting

This chapter contains procedures for identifying and correcting faults in a PMP/PTP 450 platform link. These procedures can be performed either on a newly installed link, or on an operational link if communication is lost, or after a lightning strike.

The following topics are described in this chapter:

- [General troubleshooting procedure](#) on page 11-65
- [Troubleshooting procedures](#) on page 11-68
- [Power-up troubleshooting](#) on page 11-77
- [Registration and connectivity troubleshooting](#) on page 11-78

General troubleshooting procedure

General planning for troubleshooting

Effective troubleshooting depends in part on measures that you take before you experience trouble in your network. Cambium recommends the following measures for each site:

- Identify troubleshooting tools that are available at your site (such as a protocol analyzer).
- Identify commands and other sources that can capture baseline data for the site. These may include:
 - Ping
 - Tracert or traceroute
 - Link Capacity Test results
 - Throughput data
 - Configuration tab captures
 - Status tab captures
 - Session logs
 - Web browser used
- Start a log for the site.
- Include the following information in the log:
 - Operating procedures
 - Site-specific configuration records
 - Network topology
 - Software releases, boot versions and FPGA firmware versions
 - Types of hardware deployed
 - Site-specific troubleshooting processes
 - Escalation procedures
- Capture baseline data into the log from the sources listed above

General fault isolation process

Effective troubleshooting also requires an effective fault isolation methodology that includes the following:

- Attempting to isolate the problem to the level of a system, subsystem, or link, such as
 - AP to SM
 - AP to CMM4
 - AP to GPS
 - Backhaul(BH)
 - Backhaul(BH) to CMM4
 - Power
- Researching Event Logs of the involved equipment
- Interpreting messages in the Event Log
- Answering the questions listed in the following sections.
- Reversing the last previous corrective attempt before proceeding to the next.
- Performing only one corrective attempt at a time.

Questions to help isolate the problem

When a problem occurs, attempt to answer the following questions:

- What is the history of the problem?
 - Have we changed something recently?
 - Have we seen other symptoms before this?
- How wide-spread is the symptom?
 - Is the problem on only a single SM? (If so, focus on that SM.)
 - Is the problem on multiple SMs? If so
 - is the problem on one AP in the cluster? (If so, focus on that AP)
 - is the problem on multiple, but not all, APs in the cluster? (If so, focus on those APs)
 - is the problem on all APs in the cluster? (If so, focus on the CMM4 and the GPS signal.)
- Based on data in the Event Log
 - does the problem correlate to External Hard Resets with no WatchDog timers? (If so, this indicates a loss of power. Correct your power problem.)
 - is intermittent connectivity indicated? (If so, verify your configuration, power level, cables and connections and the speed duplex of both ends of the link).
 - does the problem correlate to loss-of-sync events?
- Are connections made via *shielded* cables?
- Does the GPS antenna have an *unobstructed* view of the entire horizon?
- Has the site grounding been verified?

Secondary Steps

After preliminary fault isolation is completed through the above steps, follow these:

- Check the Canopy knowledge base (<https://support.cambiumnetworks.com/forum>) to find whether other network operators have encountered a similar problem.
- Proceed to any appropriate set of diagnostic steps. These are organized as follows:
 - [Module has lost or does not establish connectivity](#) on page 11-68
 - [NAT/DHCP-configured SM has lost or does not establish connectivity](#) on page 11-70
 - [SM Does Not Register to an AP](#) on page 11-72
 - [Module has lost or does not gain sync](#) on page 11-73
 - [Module does not establish Ethernet connectivity](#) on page 11-74
 - [CMM4 does not pass proper GPS sync to connected modules](#) on page 11-75
 - [Module Software Cannot be Upgraded](#) on page 11-76
 - [Module Functions Properly, Except Web Interface Became Inaccessible](#) on page 11-76

Troubleshooting procedures

Proceed to any appropriate set of diagnostic steps. These are organized as follows:

- [Module has lost or does not establish connectivity](#) on page 11-68
- [NAT/DHCP-configured SM has lost or does not establish connectivity](#) on page 11-70
- [SM Does Not Register to an AP](#) on page 11-72
- [Module has lost or does not gain sync](#) on page 11-73
- [Module does not establish Ethernet connectivity](#) on page 11-74
- [CMM4 does not pass proper GPS sync to connected modules](#) on page 11-75
- [Module Software Cannot be Upgraded](#) on page 11-76
- [Module Functions Properly, Except Web Interface Became Inaccessible](#) on page 11-76

Module has lost or does not establish connectivity

To troubleshoot a loss of connectivity, perform the following steps:

Procedure 36 Troubleshooting loss of connectivity

- 1 Isolate the end user/SM from peripheral equipment and variables such as routers, switches and firewalls.
- 2 Set up the minimal amount of equipment.
- 3 On each end of the link:
 - Check the cables and connections.
 - Verify that the cable/connection scheme—straight-through or crossover—is correct.
 - Verify that the LED labeled LNK is green.
 - Access the General Status tab in the Home page of the module.
 - Verify that the SM is registered.
 - Verify that Received Power Level is -87 dBm or higher.
 - Access the IP tab in the Configuration page of the module.
 - Verify that IP addresses match and are in the same subnet.
 - If RADIUS authentication is configured, ensure that the RADIUS server is operational

- 4 On the SM end of the link:
 - Verify that the PC that is connected to the SM is correctly configured to obtain an IP address through DHCP.
 - Execute **ipconfig** (Windows) or **ifconfig** (linux)
 - Verify that the PC has an assigned IP address.
- 5 On each end of the link:
 - Access the **General** tab in the Configuration page of each module.
 - Verify that the setting for **Link Speeds** (or negotiation) matches that of the other module.
 - Access the **Radio** tab in the Configuration page of each module.
 - Verify that the **Radio Frequency Carrier** setting is checked in the Custom Radio Frequency Scan Selection List.
 - Verify that the **Color Code** setting matches that of the other module.
 - Access the browser LAN settings (for example, at **Tools > Internet Options > Connections > LAN Settings** in Internet Explorer).
 - Verify that none of the settings are selected.
 - Access the **Link Capacity Test** tab in the Tools page of the module.
 - Perform a link test
 - Verify that the link test results show efficiency greater than 90% in both the uplink and downlink
 - Execute **ping**.
 - Verify that no packet loss was experienced.
 - Verify that response times are not significantly greater than
 - 4 ms from AP to SM
 - 15 ms from SM to AP
 - Replace any cables that you suspect may be causing the problem.

**Note**

A ping size larger than 1494 Bytes to a module times out and fails. However, a ping of this size or larger to a system that is behind a Canopy module typically succeeds. It is generally advisable to ping such a system, since Canopy handles that ping with the same priority as is given all other transport traffic. The results are unaffected by ping size and by the load on the Canopy module that brokers this traffic.

- 6 After connectivity has been re-established, reinstall network elements and variables that you removed in Step 1.

NAT/DHCP-configured SM has lost or does not establish connectivity

Before troubleshooting this problem, identify the NAT/DHCP configuration from the following list:

- NAT with DHCP Client (**DHCP** selected as the **Connection Type** of the WAN interface) and DHCP Server
- NAT with DHCP Client (**DHCP** selected as the **Connection Type** of the WAN interface)
- NAT with DHCP Server
- NAT without DHCP

To troubleshoot a loss of connectivity for a SM configured for NAT/DHCP, perform the following steps.

Procedure 37 Troubleshooting loss of connectivity for NAT/DHCP-configured SM

- 1 Isolate the end user/SM from peripheral equipment and variables such as routers, switches and firewalls.
- 2 Set up the minimal amount of equipment.
- 3 On each end of the link:
 - Check the cables and connections.
 - Verify that the cable/connection scheme—straight-through or crossover—is correct.
 - Verify that the LED labeled LNK is green.
- 4 At the SM:
 - Access the NAT Table tab in the Logs web page.
 - Verify that the correct NAT translations are listed.
RESULT: NAT is eliminated as a possible cause if these translations are correct.
- 5 If this SM is configured for NAT with DHCP, then at the SM:
 - Execute `ipconfig` (Windows) or `ifconfig` (Linux)
 - Verify that the PC has an assigned IP address.
 - If the PC *does not* have an assigned IP address, then
 - enter `ipconfig /release "Adapter Name"`.
 - enter `ipconfig /renew "Adapter Name"`.
 - reboot the PC.
 - after the PC has completed rebooting, execute `ipconfig`
 - if the PC has an assigned IP address, then
 - access the NAT DHCP Statistics tab in the Statistics web page of the SM.
 - verify that DHCP is operating as configured.
- 6 After connectivity has been re-established, reinstall network elements and variables that you removed in Step 1.

SM Does Not Register to an AP

To troubleshoot a SM failing to register to an AP, perform the following steps.

Procedure 38 Troubleshooting SM failing to register to an AP

- 1 Access the Radio tab in the Configuration page of the SM.
- 2 Note the **Color Code** of the SM.
- 3 Access the Radio tab in the Configuration page of the AP.
- 4 Verify that the **Color Code** of the AP matches that of the SM.
- 5 Note the **Radio Frequency Carrier** of the AP.
- 6 Verify that the value of the **RF Frequency Carrier** of the AP is selected in the **Custom Radio Frequency Scan Selection List** parameter in the SM.
- 7 In the AP, verify that the **Max Range** parameter is set to a distance slightly greater than the distance between the AP and the furthest SM that must register to this AP.
- 8 Verify that no obstruction significantly penetrates the Fresnel zone of the attempted link.
- 9 Access the **General Status** tab in the Home page of each module.
- 10 Remove the bottom cover of the SM to expose the LEDs.
- 11 Power cycle the SM.
RESULT: Approximately 25 seconds after the power cycle, the green LED labeled LNK must light to indicate that the link has been established. If the orange LED labeled SYN is lit instead, then the SM is in Alignment mode because the SM failed to establish the link.
- 12 If the AP is configured to require authentication, ensure proper configuration of RADIUS or Pre-shared AP key.
- 13 In this latter case and if the SM has encountered no customer-inflicted damage, then request an RMA for the SM.

Module has lost or does not gain sync

To troubleshoot a loss of sync, perform the following steps.

Procedure 39 Troubleshooting loss of sync

- 1 Access the Event Log tab in the Home page of the SM
- 2 Check for messages with the following format:
RcvFrmNum =
ExpFrmNum =
- 3 If these messages are present, check the Event Log tab of another SM that is registered to the same AP for messages of the same type.
- 4 If the Event Log of this second SM *does not* contain these messages, then the fault is isolated to the first SM.
If the Event Log page of this second SM contains these messages, access the GPS Status page of the AP.
- 5 If the **Satellites Tracked** field in the GPS Status page of the AP indicates fewer than 4 or the **Pulse Status** field does not indicate Generating Sync, check the GPS Status page of another AP in the same AP cluster for these indicators. GPS signal acquisition must not take longer than 5 minutes from unit startup.
- 6 If these indicators are present in the second AP, then:
 - Verify that the GPS antenna still has an unobstructed view of the entire horizon.
 - Visually inspect the cable and connections between the GPS antenna and the CMM4. If this cable is not shielded, replace the cable with shielded cable
- 7 If these indicators *are not* present in the second AP, visually inspect the cable and connections between the CMM4 and the AP antenna. If this cable is not shielded, replace the cable with shielded cable.

Module does not establish Ethernet connectivity

To troubleshoot a loss of Ethernet connectivity, perform the following steps:

Procedure 40 Troubleshooting loss of Ethernet connectivity

- 1 Verify that the connector crimps on the Ethernet cable are not loose.
- 2 Verify that the Ethernet cable is not damaged.
- 3 If the Ethernet cable connects the module to a network interface card (NIC), verify that the cable is pinned out as a straight-through cable.
- 4 If the Ethernet cable connects the module to a hub, switch, or router, verify that the cable is pinned out as a crossover cable.
- 5 Verify that the Ethernet port to which the cable connects the module is set to auto-negotiate speed.
- 6 Verify VLAN configuration in the network, which may cause loss of module access if the accessing device is on a separate VLAN from the radio.
- 7 Power cycle the module.
RESULT: Approximately 25 seconds after the power cycle, the green LED labeled LNK must light up to indicate that the link has been established. If the orange LED labeled SYN is lit instead, then the module is in Alignment mode because the module failed to establish the link.
- 8 In this latter case and if the module has encountered no customer-inflicted damage, then request an RMA for the module.

CMM4 does not pass proper GPS sync to connected modules

If the Event Log tabs in all connected modules contain Loss of GPS Sync Pulse messages, perform the following steps.

Procedure 41 Troubleshooting CMM4 not passing sync

- 1 Verify that the GPS antenna has an unobstructed view of the entire horizon.
- 2 Verify that the GPS coaxial cable meets specifications.
- 3 Verify that the GPS sync cable meets specifications for wiring and length.
- 4 If the web pages of connected modules indicate any of the following, then find and eliminate the source of noise that is being coupled into the GPS sync cable:
 - In the GPS Status page:
 - anomalous number of **Satellites Tracked** (greater than 12, for example)
 - incorrect reported **Latitude** and/or **Longitude** of the antenna
 - In the Event Log page:
 - garbled GPS messages
 - large number of Acquired GPS Sync Pulse messages

GPS signal acquisition must not take longer than 5 minutes from unit startup.
- 5 If these efforts fail to resolve the problem, then request an RMA for the CMM4.

Module Software Cannot be Upgraded

If your attempt to upgrade the software of a module fails, perform the following steps.

Procedure 42 Troubleshooting an unsuccessful software upgrade

- 1 Download the latest issue of the target release and the associated release notes.
- 2 Verify that the latest version of CNUT is installed.
- 3 Compare the files used in the failed attempt to the newly downloaded software.
- 4 Compare the procedure used in the failed attempt to the procedure in the newly downloaded release notes.
- 5 If these comparisons reveal a difference, retry the upgrade, this time with the newer file or newer procedure.
- 6 If, during attempts to upgrade the FPGA firmware, the following message is repeatable, then request an RMA for the module:

```
Error code 6, unrecognized device
```

Module Functions Properly, Except Web Interface Became Inaccessible

If a module continues to pass traffic and the SNMP interface to the module continues to function, but the web interface to the module does not display, perform the following steps:

Procedure 43 Restoring web management GUI access

- 1 Enter **telnet *DottedIPAddress***.
RESULT: A telnet session to the module is invoked.
- 2 At the Login prompt, enter **root**.
- 3 At the Password prompt, enter ***PasswordIfConfigured***.
- 4 At the Telnet +> prompt, enter **reset**.
RESULT: The web interface is accessible again and this telnet connection is closed.




Note

The module may also be rebooted via an SNMP-based NMS (Wireless Manager, for example)

- 5 If the issue persists, turn off any SNMP-based network/radio monitoring software and repeat steps 1-4.

Power-up troubleshooting



Registration and connectivity troubleshooting

SM/BMS Registration

If no SMs are registered to this AP, then the Session Status tab displays the simple message **No sessions**. In this case, try the following steps.

- 1** More finely aim the SM or SMs toward the AP.
- 2** Recheck the Session Status tab of the AP for the presence of LUIDs.
- 3** If still no LUIDs are reported on the Session Status tab, click the **Configuration** button on the left side of the **Home** page.
RESULT: The AP responds by opening the AP Configuration page.
- 4** Click the Radio tab.
- 5** Find the **Color Code** parameter and note the setting.
- 6** In the same sequence as you did for the AP directly under **Configuring Link for Test** on Page 5-15, connect the SM to a computing device and to power.
- 7** On the left side of the SM Home page, click the **Configuration** button.
RESULT: The Configuration page of the SM opens.
- 8** Click the Radio tab.
- 9** If the transmit frequency of the AP is not selected in the **Custom Radio Frequency Scan Selection List** parameter, select the frequency that matches.
- 10** If the **Color Code** parameter on this page is not identical to the **Color Code** parameter you noted from the AP, change one of them so that they match.
- 11** At the bottom of the Radio tab for the SM, click the **Save Changes** button.
- 12** Click the **Reboot** button.
- 13** Allow several minutes for the SM to reboot and register to the AP.
- 14** Return to the computing device that is connected to the AP.
- 15** Recheck the Session Status tab of the AP for the presence of LUIDs.

Glossary

Term	Definition
10Base-T	Technology in Ethernet communications that can deliver 10 Mb of data across 328 feet (100 meters) of CAT 5 cable.
169.254.0.0	Gateway IP address default in Cambium fixed wireless broadband IP network modules.
169.254.1.1	IP address default in Cambium fixed wireless broadband IP network modules.
255.255.0.0	Subnet mask default in Cambium fixed wireless broadband IP network modules and in Microsoft and Apple operating systems.
802.3	An IEEE standard that defines the contents of frames that are transferred through Ethernet connections. Each of these frames contains a preamble, the address to which the frame is sent, the address that sends the frame, the length of the data to expect, the data, and a checksum to validate that no contents were lost.
Access Point Cluster	Two to six Access Point Modules that together distribute network or Internet services to a community of subscribers. Each Access Point Module covers a 60° or 90° sector. This cluster covers as much as 360°. Also known as AP cluster.
Access Point Module	Also known as AP. One module that distributes network or Internet services in a 60° or 90° sector.
ACT/4	Second-from-left LED in the module. In the operating mode, this LED is lit when data activity is present on the Ethernet link.
Address Resolution Protocol	Protocol defined in RFC 826 to allow a network element to correlate a host IP address to the Ethernet address of the host. See http://www.faqs.org/rfcs/rfc826.html .
Aggregate Throughput	The sum of the throughputs in the uplink and the downlink.
AP	Access Point Module. One module that distributes network or Internet services to subscriber modules.
ARP	Address Resolution Protocol. A protocol defined in RFC 826 to allow a network element to correlate a host IP address to the Ethernet address of the host. See http://www.faqs.org/rfcs/rfc826.html .

Term	Definition
APs MIB	Management Information Base file that defines objects that are specific to the Access Point Module. See also Management Information Base.
ASN.1	Abstract Syntax Notation One language. The format of the text files that compose the Management Information Base.
Attenuation	Reduction of signal strength caused by the travel from the transmitter to the receiver, and caused by any object between. In the absence of objects between, a signal that has a short wavelength experiences a high degree of attenuation nevertheless.
BER	Bit Error Rate. The ratio of incorrect data received to correct data received.
Bit Error Rate	Ratio of incorrect data received to correct data received.
Box MIB	Management Information Base file that defines module-level objects. See also Management Information Base.
Bridge	Network element that uses the physical address (not the logical address) of another to pass data. The bridge passes the data to either the destination address, if found in the simple routing table, or to all network segments other than the one that transmitted the data. Modules are Layer 2 bridges except that, where NAT is enabled for an SM, the SM is a Layer 3 switch. Compare to Switch and Router, and see also NAT.
Buckets	Theoretical data repositories that can be filled at preset rates or emptied when preset conditions are experienced, such as when data is transferred.
Burst	Preset amount limit of data that may be continuously transferred.
CAT 5 Cable	Cable that delivers Ethernet communications from module to module. Later modules auto-sense whether this cable is wired in a straight-through or crossover scheme.
CIR	Committed Information Rate. For an SM or specified group of SMs, a level of bandwidth that can be guaranteed to never fall below a specified minimum (unless oversubscribed). In the Cambium implementation, this is controlled by the Low Priority Uplink CIR, Low Priority Downlink CIR, High Priority Uplink CIR, and High Priority Downlink CIR parameters.
Cluster Management Module	Module that provides power, GPS timing, and networking connections for an AP cluster. Also known as CMM4.
CMM	Cluster Management Module. A module that provides power, GPS timing, and networking connections for an Access Point cluster.

Term	Definition
CodePoint	See DiffServ.
Color Code Field	Module parameter that identifies the other modules with which communication is allowed. The range of valid values is 0 to 255.
Community String Field	Control string that allows a network management station to access MIB information about the module.
Country Code	A parameter that offers multiple fixed selections, each of which automatically implements frequency band range restrictions for the selected country. Units shipped to countries other than the United States must be configured with the corresponding Region Code and Country Code to comply with local regulatory requirements.
CRCError Field	This field displays how many CRC errors occurred on the Ethernet controller.
Data Encryption Standard	Over-the-air link option that uses secret 56-bit keys and 8 parity bits. Data Encryption Standard (DES) performs a series of bit permutations, substitutions, and recombination operations on blocks of data.
Demilitarized Zone	Internet Protocol area outside of a firewall. Defined in RFC 2647. See http://www.faqs.org/rfcs/rfc2647.html .
DES	Data Encryption Standard. An over-the-air link option that uses secret 56-bit keys and 8 parity bits. DES performs a series of bit permutations, substitutions, and recombination operations on blocks of data.
DFS	See Dynamic Frequency Selection
DHCP	Dynamic Host Configuration Protocol, defined in RFC 2131. Protocol that enables a device to be assigned a new IP address and TCP/IP parameters, including a default gateway, whenever the device reboots. Thus DHCP reduces configuration time, conserves IP addresses, and allows modules to be moved to a different network within the system. See http://www.faqs.org/rfcs/rfc2131.html . See also Static IP Address Assignment.

Term	Definition
DiffServ	Differentiated Services, consistent with RFC 2474. A byte in the type of service (TOS) field of packets whose values correlates to the channel on which the packet should be sent. The value is a numeric code point. Cambium modules map each of 64 code points to values of 0 through 7. Three of these code points have fixed values, and the remaining 61 are settable. Values of 0 through 3 map to the low-priority channel; 4 through 7 to the high-priority channel. The mappings are the same as 802.1p VLAN priorities. (However, configuring DiffServ does not automatically enable the VLAN feature.) Among the settable parameters, the values are set in the AP for all downlinks within the sector and in the SM for each uplink.
DMZ	Demilitarized Zone as defined in RFC 2647. An Internet Protocol area outside of a firewall. See http://www.faqs.org/rfcs/rfc2647.html .
Dynamic Frequency Selection	A requirement in certain countries and regions for systems to detect interference from other systems, notably radar systems, and to avoid co-channel operation with these systems.
Dynamic Host Configuration Protocol	See DHCP.
Electronic Serial Number	Hardware address that the factory assigns to the module for identification in the Data Link layer interface of the Open Systems Interconnection system. This address serves as an electronic serial number. Same as MAC Address.
ESN	Electronic Serial Number. The hardware address that the factory assigns to the module for identification in the Data Link layer interface of the Open Systems Interconnection system. This address serves as an electronic serial number. Same as MAC Address.
Ethernet Protocol	Any of several IEEE standards that define the contents of frames that are transferred from one network element to another through Ethernet connections.
ETSI	European Telecommunications Standards Institute
Fade Margin	The difference between strength of the received signal and the strength that the receiver requires for maintaining a reliable link. A higher fade margin is characteristic of a more reliable link. Standard operating margin.
FCC	Federal Communications Commission of the U.S.A.
Field-programmable Gate Array	Array of logic, relational data, and wiring data that is factory programmed and can be reprogrammed.

Term	Definition
File Transfer Protocol	Utility that transfers of files through TCP (Transport Control Protocol) between computing devices that do not operate on the same platform. Defined in RFC 959. See http://www.faqs.org/rfcs/rfc959.html .
FPGA	Field-programmable Gate Array. An array of logic, relational data, and wiring data that is factory programmed and can be reprogrammed.
Free Space Path Loss	Signal attenuation that is naturally caused by atmospheric conditions and by the distance between the antenna and the receiver.
Fresnel Zone	Space in which no object should exist that can attenuate, diffract, or reflect a transmitted signal before the signal reaches the target receiver.
FTP	File Transfer Protocol, defined in RFC 959. Utility that transfers of files through TCP (Transport Control Protocol) between computing devices that do not operate on the same platform. See http://www.faqs.org/rfcs/rfc959.html .
Global Positioning System	Network of satellites that provides absolute time to networks on earth, which use the time signal to synchronize transmission and reception cycles (to avoid interference) and to provide reference for troubleshooting activities.
GPS	Global Positioning System. A network of satellites that provides absolute time to networks on earth, which use the time signal to synchronize transmission and reception cycles (to avoid interference) and to provide reference for troubleshooting activities.
GPS/3	Third-from-left LED in the module. In the operating mode for an Access Point Module, this LED is continuously lit as the module receives sync pulse. In the operating mode for a Subscriber, this LED flashes on and off to indicate that the module is not registered.
GUI	Graphical user interface.
High-priority Channel	Channel that supports low-latency traffic (such as Voice over IP) over low-latency traffic (such as standard web traffic and file downloads). To recognize the latency tolerance of traffic, this channel reads the IPv4 Type of Service DiffServ Control Point (DSCP) bits. Enabling the high-priority channel reduces the maximum number of SMs that can be served in the sector.
HTTP	Hypertext Transfer Protocol, used to make the Internet resources available on the World Wide Web. Defined in RFC 2068. See http://www.faqs.org/rfcs/rfc2068.html .

Term	Definition
HTTPS	Hypertext Transfer Protocol Secure (HTTPS)
ICMP	Internet Control Message Protocols defined in RFC 792, used to identify Internet Protocol (IP)-level problems and to allow IP links to be tested. See http://www.faqs.org/rfcs/rfc792.html .
IP	Internet Protocol defined in RFC 791. The Network Layer in the TCP/IP protocol stack. This protocol is applied to addressing, routing, and delivering, and re-assembling data packets into the Data Link layer of the protocol stack. See http://www.faqs.org/rfcs/rfc791.html .
IP Address	32-bit binary number that identifies a network element by both network and host. See also Subnet Mask.
IPv4	Traditional version of Internet Protocol, which defines 32-bit fields for data transmission.
ISM	Industrial, Scientific, and Medical Equipment radio frequency band, in the 900-MHz, 2.4-GHz, and 5.8-GHz ranges.
L2TP over IPsec	Level 2 Tunneling Protocol over IP Security. One of several virtual private network (VPN) implementation schemes. Regardless of whether Subscriber Modules have the Network Address Translation feature (NAT) enabled, they support VPNs that are based on this protocol.
Late Collision Field	This field displays how many late collisions occurred on the Ethernet controller. A normal collision occurs during the first 512 bits of the frame transmission. A collision that occurs after the first 512 bits is considered a late collision. A late collision is a serious network problem because the frame being transmitted is discarded. A late collision is most commonly caused by a mismatch between duplex configurations at the ends of a link segment.
Line of Sight	Wireless path (not simply visual path) direct from module to module. The path that results provides both ideal aim and an ideal Fresnel zone.
LNK/5	Furthest left LED in the module. In the operating mode, this LED is continuously lit when the Ethernet link is present. In the aiming mode for a Subscriber Module, this LED is part of a bar graph that indicates the quality of the RF link.
Logical Unit ID	Final octet of the 4-octet IP address of the module.
LOS	Line of sight. The wireless path (not simply visual path) direct from module to module. The path that results provides both ideal aim and an ideal Fresnel zone.

Term	Definition
LUID	Logical Unit ID. The final octet of the 4-octet IP address of the module.
MAC Address	Media Access Control address. The hardware address that the factory assigns to the module for identification in the Data Link layer interface of the Open Systems Interconnection system. This address serves as an electronic serial number.
Management Information Base	Space that allows a program (agent) in the network to relay information to a network monitor about the status of defined variables (objects).
Maximum Information Rate (MIR)	The cap applied to the bandwidth of an SM or specified group of SMs. In the Cambium implementation, this is controlled by the Sustained Uplink Data Rate, Uplink Burst Allocation, Sustained Downlink Data Rate, and Downlink Burst Allocation parameters.
MIB	Management Information Base. Space that allows a program (agent) in the network to relay information to a network monitor about the status of defined variables (objects).
MIR	See Maximum Information Rate.
NAT	Network Address Translation defined in RFC 1631. A scheme that isolates Subscriber Modules from the Internet. See http://www.faqs.org/rfcs/rfc1631.html .
NEC	National Electrical Code. The set of national wiring standards that are enforced in the U.S.A.
NetBIOS	Protocol defined in RFC 1001 and RFC 1002 to support an applications programming interface in TCP/IP. This interface allows a computer to transmit and receive data with another host computer on the network. RFC 1001 defines the concepts and methods. RFC 1002 defines the detailed specifications. See http://www.faqs.org/rfcs/rfc1001.html and http://www.faqs.org/rfcs/rfc1002.html .
Network Address Translation	Scheme that defines the Access Point Module as a proxy server to isolate registered Subscriber Modules from the Internet. Defined in RFC 1631. See http://www.faqs.org/rfcs/rfc1631.html .
Network Management Station	See NMS.
NMS	Network Management Station. A monitor device that uses Simple Network Management Protocol (SNMP) to control, gather, and report information about predefined network variables (objects). See also Simple Network Management Protocol.

Term	Definition
Default Mode	Device that enables the operator to regain control of a module that has been locked by the No Remote Access feature, the 802.3 Link Disable feature, or a password or IP address that cannot be recalled. This device can be either fabricated on site or ordered.
PMP	See Point-to-Multipoint Protocol.
Point-to-Multipoint Protocol	Defined in RFC 2178, which specifies that data that originates from a central network element can be received by all other network elements, but data that originates from a non-central network element can be received by only the central network element. See http://www.faqs.org/rfcs/rfc2178.html . Also referenced as PMP.
PPPoE	Point to Point Protocol over Ethernet. Supported on SMs for operators who use PPPoE in other parts of their network operators who want to deploy PPPoE to realize per-subscriber authentication, metrics, and usage control.
PPS	Packet Per Second
PPTP	Point to Point Tunneling Protocol. One of several virtual private network implementations. Regardless of whether the Network Address Translation (NAT) feature enabled, Subscriber Modules support VPNs that are based on this protocol.
Protective Earth	Connection to earth (which has a charge of 0 volts). Also known as ground.
Proxy Server	Network computer that isolates another from the Internet. The proxy server communicates for the other computer, and sends replies to only the appropriate computer, which has an IP address that is not unique or not registered.
Radio Signal Strength Indicator	Relative measure of the strength of a received signal. An acceptable link displays a Radio Signal Strength Indicator (RSSI) value of greater than 700.
Reflection	Change of direction and reduction of amplitude of a signal that encounters an object larger than the wavelength. Reflection may cause an additional copy of the wavelength to arrive after the original, unobstructed wavelength arrives. This causes partial cancellation of the signal and may render the link unacceptable. However, in some instances where the direct signal cannot be received, the reflected copy may be received and render an otherwise unacceptable link acceptable.

Term	Definition
Region Code	A parameter that offers multiple fixed selections, each of which automatically implements frequency band range restrictions for the selected region. Units shipped to regions other than the United States must be configured with the corresponding Region Code to comply with local regulatory requirements.
RF	Radio frequency. How many times each second a cycle in the antenna occurs, from positive to negative and back to positive amplitude.
RJ-12	Standard cable that is typically used for telephone line or modem connection.
RJ-45	Standard cable that is typically used for Ethernet connection. This cable may be wired as straight-through or as crossover. Later modules auto-sense whether the cable is straight-through or crossover.
Router	Network element that uses the logical (IP) address of another to pass data to only the intended recipient. Compare to Switch and Bridge.
RSSI	Radio Signal Strength Indicator. A relative measure of the strength of a received signal. An acceptable link displays an RSSI value of greater than 700.
Self-interference	Interference with a module from another module in the same network.
Simple Network Management Protocol	Standard that is used for communications between a program (agent) in the network and a network management station (monitor). Defined in RFC 1157. See http://www.faqs.org/rfcs/rfc1157.html .
SM	Customer premises equipment (CPE) device that extends network or Internet services by communication with an Access Point Module or an Access Point cluster.
SNMP	See Simple Network Management Protocol, defined in RFC 1157.
SNMPv3	SNMP version 3
SNMP Trap	Capture of information that informs the network monitor through Simple Network Management Protocol of a monitored occurrence in the module.

Term	Definition
Static IP Address Assignment	Assignment of Internet Protocol address that can be changed only manually. Thus static IP address assignment requires more configuration time and consumes more of the available IP addresses than DHCP address assignment does. RFC 2050 provides guidelines for the static allocation of IP addresses. See http://www.faqs.org/rfcs/rfc2050.html . See also DHCP.
Subnet Mask	32-bit binary number that filters an IP address to reveal what part identifies the network and what part identifies the host. The number of subnet mask bits that are set to 1 indicates how many leading bits of the IP address identify the network. The number of subnet mask bits that are set 0 indicate how many trailing bits of the IP address identify the host.
Subscriber Module	Customer premises equipment (CPE) device that extends network or Internet services by communication with an Access Point Module or an Access Point cluster.
Sustained Data Rate	Preset rate limit of data transfer.
Switch	Network element that uses the port that is associated with the physical address of another to pass data to only the intended recipient. Compare to Bridge and Router.
Sync	GPS (Global Positioning System) absolute time, which is passed from one module to another. Sync enables timing that prevents modules from transmitting or receiving interference . Sync also provides correlative time stamps for troubleshooting efforts.
TCP	Alternatively known as Transmission Control Protocol or Transport Control Protocol. The Transport Layer in the TCP/IP protocol stack. This protocol is applied to assure that data packets arrive at the target network element and to control the flow of data through the Internet. Defined in RFC 793. See http://www.faqs.org/rfcs/rfc793.html .
TDD	Time Division Duplexing. Synchronized data transmission with some time slots allocated to devices transmitting on the uplink and some to the device transmitting on the downlink.
telnet	Utility that allows a client computer to update a server. A firewall can prevent the use of the telnet utility to breach the security of the server. See http://www.faqs.org/rfcs/rfc818.html , http://www.faqs.org/rfcs/rfc854.html and http://www.faqs.org/rfcs/rfc855.html .
Tokens	Theoretical amounts of data. See also Buckets.

Term	Definition
TxUnderrun Field	This field displays how many transmission-underrun errors occurred on the Ethernet controller.
UDP	User Datagram Protocol. A set of Network, Transport, and Session Layer protocols that RFC 768 defines. These protocols include checksum and address information but does not retransmit data or process any errors. See http://www.faqs.org/rfcs/rfc768.html .
udp	User-defined type of port.
U-NII	Unlicensed National Information Infrastructure radio frequency band, in the 5.1GHz through 5.8 GHz ranges.
VID	VLAN identifier. See also VLAN.
VLAN	Virtual local area network. An association of devices through software that contains broadcast traffic, as routers would, but in the switch-level protocol.
VPN	Virtual private network for communication over a public network. One typical use is to connect remote employees, who are at home or in a different city, to their corporate network over the Internet. Any of several VPN implementation schemes is possible. SMs support L2TP over IPSec (Level 2 Tunneling Protocol over IP Security) VPNs and PPTP (Point to Point Tunneling Protocol) VPNs, regardless of whether the Network Address Translation (NAT) feature enabled.