



BEFORE USING THE UNIT FOR THE FIRST TIME...



1. Use a phillips head screwdriver to open the battery compartment cover on the back of the unit.
2. Remove the insulating paper from between the batteries and contacts.
3. Replace the battery compartment cover.

GENERAL GUIDE


- The configuration of your clock may differ somewhat from that shown in the illustration.
- Hold down the Snooze/Light button to illuminate the display. The display remains illuminated for a few seconds after you release the button.




SETTING THE TIME

[Control buttons]

GQ-100: on the front




GQ-200: on the bottom



1. Hold down TIME-SET until the time starts to flash on the display.
2. Each press of the + button increases the time by one minute, and pressing - decreases it by one minute.

- Holding down either button changes the time setting at high speed.
- The hour setting is changed automatically whenever a change in the minutes increases past 59 minutes or decreases past 00 minutes.
- The seconds are reset to "00" whenever you change the minutes setting.
- The time display uses a 12-hour format, so evening is indicated by "PM".



3. After you finish setting the time press TIME-SET to return to the Normal Display.
- If you do not operate any button for a few minutes while the time is flashing, the flashing stops and the clock goes back to the Normal Display automatically.


USING THE ALARM

The alarm of this clock features a Snooze Function, which lets you catch a few more minutes sleep in the morning. For full details on how to use this function, see "To use the alarm".


To set the alarm

[Control buttons]

GQ-100: on the front




GQ-200: on the bottom



Each press of the + button increases the time by one minute, and pressing - decreases it by one minute.


- Holding down either button changes the time setting at high speed.
- The hour setting is changed automatically whenever a change in the minutes increases past 59 minutes or decreases past 00 minutes.
- The time display uses a 12-hour format, so evening is indicated by "PM".



To switch the alarm on and off


Slide the Alarm On/Off switch to the ON position to switch the alarm on, or to the OFF position to switch it off.

- When you switch the alarm on, the alarm on indicator "(●)" appears on the display.



To use the alarm

1. Set the alarm time and switch the alarm on.
2. When the alarm time you set is reached, the alarm starts to sound. It continues for about one minute or until you stop it by pressing the Snooze/Light button.



- When the alarm starts to sound, the alarm on indicator "(●)" flashes on the display. This indicates that the Snooze function is activated.
- 3. About four minutes after you press the Snooze/Light button, the alarm starts to sound again.
- 4. The above repeats up to seven times, or until you switch the alarm off (by sliding the Alarm On/Off switch to the OFF position).
- You can stop the repeating alarm at any time by sliding the Alarm On/Off Switch to the OFF position.
- The beep pattern of the alarm changes (becomes faster) as the alarm sounds. The pattern changes up to five times.

BATTERY REPLACEMENT

Replace the batteries whenever the display of the clock becomes dim and difficult to read, or when the display light fails.

To replace batteries

1. Use phillips head screwdriver to open the battery compartment cover on the back of the unit.
2. Remove both old batteries.
3. Load two new AA-size batteries. Make sure that their positive (+) and negative (-) ends face in the correct directions. If you load batteries incorrectly they can leak and cause damage to the clock.
4. Replace the battery compartment cover.
5. Press the all reset button to reset the digital display information.
6. Set the current time and alarm time.

