



**Parts and functions**





**3-STEP power switch**

To prevent other user from turning off the power, you may slide this switch to the right to lock the microphone on stand-by or mute status. Slide to the left to unlock.




## Battery installation & indicator




Note: Batteries contain a corrosive acid that may leak and damage the transmitter when stored for a long period. Batteries should be removed from the transmitter before storing without use for more than 4 weeks.


## Changing CHANNEL / FREQUENCY


- 1** Press-release **MENU** button until the CHANNEL-FREQUENCY page appears.



CH:079   
2480 MHz


- 
- 2** Press and hold **SET** button until the channel number flashes to denote readiness for setting.



CH:079   
2480 MHz

- 
- 3** Press-release **SET** (UP) or **MENU** (DOWN) button to select a new channel.




CH:076   
2477 MHz


- 
- 4** After a channel is chosen, wait about 3 seconds to store the setting.

## Channel synchronizing of the receiver and transmitter

- 1 Unscrew the microphone's lower housing and then press and hold the synchronizing button until **LINK** flashes on the LCD.




- 
- 2 Press and press and hold the receiver's **SYNC** button until the frequency icon **FREQ** appears. After successful channel synchronizing, this icon will disappear automatically.




## Battery type setting

- 1 Press-release **MENU** button until the CHANNEL-BATTERY TYPE page appears.



CH:076   
AKLN


- 
- 2 Press and hold **SET** button until NIMH or AKLN flashes to denote readiness for setting.



CH:076   
AKLN

- 
- 3 Press-release **SET** or **MENU** button to select either NiMH (rechargeable battery) or AKLN (alkaline battery).





CH:076   
NiMH

- 
- 4 After a battery type is chosen, wait about 3 seconds to store the setting.


## RF power setting

- 1 Press-release **MENU** button until the CHANNEL-RF POWER page appears.



CH076   
RF08db


- 2 Press and hold **SET** button until the RF power figure flashes to denote readiness for setting.



CH076   
RF08db

- 3 Press-release **SET** (UP) or **MENU** (DOWN) button to choose an output level from 0db to 20db.



CH076   
RF 12db

- 4 After an output level is chosen, wait about 3 seconds to store the setting.

**IMPORTANT:** Lower output power will reduce the RF transmission distance and higher output power will extend the possible RF transmission distance. However, higher output power places slightly more load on the battery and will reduce operating duration faster than lower output power.

**Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Caution:** To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

**FCC Radiation Exposure Statement**

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0.5 centimeters between the radiator and your body.


This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The antennas used for this transmitter must be installed to provide a separation distance of at least 0.5 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Frequency: 2400~2483.5MHz      Maximal power: 9.14mW  
CE declaration info: [www.chiayo.com.tw/declaration.html](http://www.chiayo.com.tw/declaration.html)

	AT	BE	BG	HR	CY	CZ	DK
	EE	FI	FR	DE	EL	HU	IE
	IT	LV	LT	LU	MT	NL	PL
	PT	RO	SK	SI	ES	SE	UK





[www.chiayo.com.tw](http://www.chiayo.com.tw)

CHIAYO ELECTRONICS CO.,LTD.

[Http://www.chiayo.com.tw](http://www.chiayo.com.tw) | Email: [sales@chiayo.com.tw](mailto:sales@chiayo.com.tw)

Office: 30, Lane 27, Section 4, Jen-Ai Road, Taipei 10685, Taiwan

Tel: 886-2-27415741 | Fax: 886-2-27525242

Factory: 88, Chung-Hsiao Street 2, Chiayi 60080, Taiwan

Tel: 886-5-2711000 | Fax: 886-5-5767611