

## The Cobra line of quality products includes:

**CB Radios** 

**Dash Cams** 

Radar Detectors

**Marine VHF Radios** 

**Power Inverters** 

**Accessories** 



For more information or to order any of our products, please visit our website: www.cobra.com



Printed in the Philippines Part No. 480-1073-P



## Important Information and Customer Assistance

#### **Important Information**

#### Federal Laws Governing the Use of Radar Detectors

It is not against federal law to receive radar transmissions with your Cobra radar/ laser detector. The Communications Act of 1924 guarantees your right to receive radio transmissions on any frequency. Local laws that contravene this Act, while illegal, may be enforced by your local law enforcement officials until and unless they are prohibited from doing so by federal court action.

#### Safe Driving

Motorists, as well as operators of emergency or service vehicles, are expected to exercise all due caution while using this product, and to obey all applicable traffic laws. Do not attempt to change settings of the unit while in motion.

#### **Security of Your Vehicle**

Before leaving your vehicle, always remember to conceal your radar detector in order to reduce the possibility of break-in and theft.

> ©2016 Cobra Electronics Corporation Chicago, Illinois 60707 USA www.cobra.com

### **Controls Indicators and Connections**

### **Controls, Indicators and Connections**



\*GPS and iRadar-based features require connection to a Bluetooth® Smart ready device and the Cobra iRadar app. For a full list of Bluetooth® Smart ready devices visit www.bluetooth.com



## **Easy-to-Read Display**



#### **Product Features**

Congratulations! You've made a smart choice by purchasing a radar/laser detector from Cobra. Just look at some of the sophisticated features and capabilities your new unit includes:

This booklet describes the simple steps for mounting and setting up your detector. It also provides helpful information about how radar and laser guns are used and

#### Radar/Laser Protection

Detects all radar and laser guns.

#### iRadar®

iRadar® Community connects to the Cobra iRadar® app to alert to Red Light Cameras, Speed Cameras, Live Police.

#### Locations, and Shared Radar Alerts LaserEve Detects laser signals from both front and rear.

#### VoiceAlert

Digital voice announcements keep your eyes on the road.

#### **QuietDrive™**

Quiet Drive is a muted driving mode for times when a driver wants less audible feedback while talking with passengers, on the phone, etc.

#### Premium Anti-Falsing Circuitry

Automatically reduces false alerts from erroneous sources including vehicle collision avoidance systems, traffic flow monitoring devices and other radar detectors.

#### Updatable IVT Filter™

User updatable system automatically reduces false alerts from moving In-Vehicle Technology sources such as collision avoidance systems and adaptive cruise control.

how you can interpret the alerts you receive.

#### White OLED Display

Bright display with band identification icons and numeric signal strength meter.

#### Sensitivity Modes

Multiple sensitivity modes to reduce false alerts.

#### Auto Mute

Automatically mutes audio for sustained

#### **Dual Language**

English and Spanish voice and text alerts.

#### **User Updates**

Micro-USB port allows users to access future software updates.

#### Mount and Power Cord with Type-A USB Port Included

Can be used to charge your smartphone or tablet using the manufacturer's charging cable.



## **Contents**



#### Introduction

Important Information	Α
Controls, Indicators and Connections	
Display	
Product Features	



#### **Your Detector**

Installation 2
Getting Started 5
Buttons 5
SEN 5
MUTE 5
Quiet Drive
Battery Voltage
DIM
Menu-User Settings 6
Menu-Alert Settings
Detail 8
AutoMute
Language
Screen Saver
Smart Power
Low Car Voltage
System Info
Restore Defaults
Radar Alerts
Radar Detector-Detector Alerts10
Laser Alerts
Responding to Alerts & Firmware Update
AURA® Location-Based Alerts
Downloading the App
Cobra iRadar® App
Pair/Connecting with Your Detector
iRadar Community14
Understanding Radar and Laser
Understanding LIDAR
Customar Information



Maintenance	17
imited 1-Year Warranty	18
Product Service & Optional Accessories	19




### Installation


#### Installation

#### Where to mount your unit

You will get optimum performance from your detector if you mount it at a point approximately in the center of the vehicle, as low as possible on the front windshield without obstructing the unit's view of the road either to the front or rear. You can also mount it directly on the dashboard.



The unit's lens must not be blocked and the LaserEye should have a clear view out the back window to allow maximum detection.



Radar and laser signals pass through glass but not through other materials and objects. Objects that can block or weaken incoming signals include:

- Windshield wiper blades
- Mirrored sun screens
- Dark tinting at the top of the windshield
- Heated windshields currently available on some vehicles (Instaclear for Ford, Electriclear for GM). Consult your dealer to see if you have this option.

#### Windshield mounting

1. Attach the rubber cups to the bracket.



- 2. Make sure the rubber cups and your windshield are clean.
- 3. Push the bracket firmly onto the windshield.



4. Attach the detector to the bracket. Check that the unit is parallel to the road's surface.



To adjust the angle if necessary, gently push or pull on the bracket to bend it. DO NOT use the detector to bend the bracket.



Plug the power cord into the detector.



7. Plug the cigarette lighter adapter on the power cord into your vehicle's cigarette lighter.

## **Installation**

#### **Dashboard Mounting**

- Place the detector on the dashboard to find a location where the unit has a clear, level view of the road and is parallel to the road's surface. The angle CANNOT be adjusted after mounting
- 2. Remove the paper backing from one side of the hookand-loop fastener.
- 3. Attach the pad to the dashboard at your chosen location and remove the other paper backing.

- Attach the detector to the hook-and-loop fastener. You can remove and reattach the unit as often as you like.
- 5. Plug the power cord into the detector.
- Plug the cigarette lighter adapter on the power cord into your vehicle's cigarette lighter.



## **Getting Started**

### **Getting Started**

To Turn On The Unit And Adjust The Audio Volume		
Rotate the On-Off/	Audible Tone	Visual Display
Volume control clockwise (away from you).	"Testing" Three beeps "System Ready"	<u>ا</u>



NOTE: In some vehicles, power is supplied to the cigarette lighter even while the ignition is Off. If this is the case with your vehicle, you should turn Off or unplug your detector when parking for lengthy periods.

#### **SEN Button**

Setting your detector to **Low or Medium** sensitivity delays the audio alerts for weak X band and K band signals until they become stronger. (A single beep will sound when the signal is first detected.) Also, additional filtering is done to reduce false alerts while you are driving in, or near, urban areas where there are many sources for conflicting X and K band signals such as microwave towers and automatic door openers.

lcon	Sens Level	For
হ	High	No filtering for maximum range
Ş	Medium	Minimal filtering to reduce unwanted alerts
□	Low	Maximum filtering to reduce unwanted alerts

### **Using the REPORT Button**

You can report to the iRadar Community when you see an active police speed enforcement by pressing the REPORT button\*.

\*GPS and iRadar-based features require connection to a Bluetooth® Smart ready device and the Cobra iRadar app. For a full list of Bluetooth® Smart ready devices visit www.bluetooth.com

## Settings Settings

#### **MUTE Button**

Manual Mute: Your detector allows you to quickly turn OFF an audio alert by momentarily pressing the MUTE button. If you press the MUTE button a second time during the alert, the audio alert will be turned back ON. When an alert is being muted the audio icon on the display will change to



**Quiet Drive** is a muted driving mode for times when a driver wants less audible feedback while talking with passengers, on the phone, etc. Only the first few seconds of audio will be heard. This mode is **Off** by default.

This mode can be changed in the User Settings menu or by pressing and holding the MUTE button for two seconds. When Quiet Drive is on the audio icon on the display will change to

### **Battery Voltage**

To display your vehicle's battery voltage, press the MUTE button while no signal is being detected.

#### **DIM Button**

You can choose from four settings for the brightness of the display. Repeatedly push the DIM button to cycle through the settings. The factory setting is Bright.



#### **Menu - User Settings**

To change the User settings enter the Menu by pressing the **MENU** button. A voice announces "Menu" and the display will change to



Press the **DIM** ◀ button to enter the User settings menu.

Press the MUTE or MENU ■ buttons to switch between the User settings.

Press the **DIM** ∢ or **SEN** ▶ buttons to change the selected User setting's value. The value that is shown on the display is the selected value. To exit the menu simply wait several seconds or select **Exit Menu**.

USER SETTING	VALUE
Detail	More*/Less
Quiet Drive	Off*/On
Auto Mute	Off/On*
Voice	Off/On*
Language	English*/Spanish
Screen Saver	Off/1 Minute*/3 Minute
Low V. Warning	Off*/On
Smart Power	Off*/On
System Info	Press the SEN button to display system information.
Restore Defaults	Press the SEN button to restore factory default settings then press SEN button again to confirm.
Exit Menu	Press the MUTE button to exit the menu.

<sup>\* =</sup> Factory default setting



### **Menu - Alert Settings**

To change the Alert settings enter the Menu by pressing the **MENU** button. A voice announces "Menu" and the display will change to

USER **◀** MENU ▶ ALERT

Press the **SEN** ▶ button to enter the Alert settings menu.

Press the MUTE or MENU ■ buttons to switch between the Alert settings.

Press the **DIM ◆** or **SEN ▶** buttons to change the selected Alert setting's value. The value that is shown on the display is the selected value. To exit the menu simply wait several seconds or select **Exit Menu**.

RADAR SETTING	VALUE
X Band	Off/On*
K Band	Off/On*
Ka Band	Off/On*
VG-2	Off*/On
Spectre	Off*/On
Exit Menu	Press the MUTE button to exit the menu.

<sup>\* =</sup> Factory default setting

#### Detail

In the **More** detail mode, information about the radar band, signal strength and frequency will be displayed.

In Less detail mode, only the threat level is displayed (see page 10).

#### **AutoMute**

**AutoMute** will automatically reduce the audio volume of all alerts after four seconds for as long as the signal is detected. The factory setting for AutoMute is On.

#### Language

The detector can be set to either English or Spanish for all text and voice audio.



#### **Screen Saver**

Your detector has a SCREEN SAVER mode. When SCREEN SAVER is turned **On** (factory default is 3 minutes), the screen will change to Dark from it's Bright, Dim, or Dimmer setting after the time interval selected. While the screen is Dark, the scanner will be displayed dimly.

**NOTE:** While SCREEN SAVER is activated, any alert will turn the display back on at the last brightness setting (Bright, Dim or Dimmer). Touching any button will also turn **On** the display.

#### **Smart Power**

Your detector includes the SMARTPOWER feature that, when turned **On**, will put the unit into Low Power mode 15 minutes after the car's engine has been turned **Off**.

Before SMARTPOWER enters Low Power mode, you will hear three beeps and SMARTPOWER will flash on the display. To return the unit to Normal Power mode and exit Low Power mode, start the car, press any button or turn the unit **Off** and then **On** again.

#### **Low Car Voltage**

Displays your car battery voltage and automatically warns you if this drops below 11.9V. Your detector will then shut off to prevent further draining of your car battery.

#### System Info

Displays information about the versions of software/firmware that are installed on your detector.

#### **Restore Defaults**

To return your detector to factory default settings, press the **SEN** Button. Press the **SEN** Button again to confirm that you want to restore factory settings. Press the **MUTE** Button to exit.

## Your Detector

### **Settings and Detection**

#### **Radar Alerts**

In **More** detail mode the radar band, signal strength and frequency of the detected radar signal will be displayed.



If you are a new user of radar detectors, you may want to use the Less detail mode. In this mode the display will only show one, two, or three bars which indicate how likely the alert is to be a police radar or laser gun. This threat level indication takes into account the laser or radar band, strength, and frequency of the detected signal.

Level	Display	Threat
1	LOW	Low
2	MED	Medium
3	HIGH	High

#### Radar Alerts - Radar Detector-Detectors

Police use radar detector detectors (RDDs) to spot users of radar detectors. Your detector is able to identify signals from VG-2, Spectre I and Spectre IV+RDDs and can provide alerts when any of these or similar devices are in use near your vehicle.

#### **Laser Alerts**

With Laser signals you will always receive a full strength alert. In More Detail mode the word Laser will be shown on the display along with the pulse rate of the Laser signal. In Less Detail mode three signal strength bars will be shown.



#### **Responding to Alerts**

Description	Interpretation	Recommended Response
Tone repeats slowly at first, then speeds up rapidly.	Probably police radar.	FULL ALERT
Tone sounds one time only.	Probably a false alarm, but possibly pulsed radar or VG-2 nearby.	Exercise caution
Tone instantly begins repeating rapidly.	Radar or VG-2 nearby has been activated suddenly.	FULL ALERT
Tone repeats slowly as you approach a hill or bridge, then speeds up sharply as you reach it.	Probably police radar beyond the hill or bridge.	FULL ALERT
Tone repeats slowly for a short period.	Probably a false alarm.	Exercise caution
Any type of laser alert.	Laser alerts are never false alarms.	FULL ALERT

#### **Firmware Update**

To update the firmware of your iRAD use a micro-USB data transfer cable to connect the detector to a Windows based computer. You do not need to connect the detector's power cord to update the firmware. With the detector connected to your computer you should see "Download" on the detector's display. Go to the Software Downloads section in the Support area of the Cobra.com website and search for iRAD then follow the instructions on the System Update link to install the latest firmware available to your detector.

## Your Detector Det

#### Detection

## AURA® Location-based Alerts (LBAs) and iRadar Community

Your detector is capable of providing you with LBAs and iRadar Community threat sharing data when connected to iPhone or Android phones. The detector uses the GPS in your smartphone to connect to and obtain the latest LBA's and alert you to them. Vehicle speed and compass headings use your phone's GPS as well. See the section on Downloading the App to add these features and more.

### **Downloading the App**

For optimal performance and access to all this detectors advanced features, you should download the iRadar app and use it when you drive with this detector. To download the app you must enter the iTunes Store or Google Play and search for "Cobra iRadar". Follow the onscreen instructions to download and install the Cobra iRadar app.

### Cobra iRadar® App

The iRadar app separates Cobra from any other detectors out there.

Make sure to check out the Tutorial for a full explanation of app features. The Tutorial can be accessed from the Menu.

Information on specific settings and explanations of radar bands can be found by pressing the green info icons in the settings menus. The iradar app can also be used to change and easily adjust the detectors settings!



#### **Pairing/Connecting With Your Detector**

GPS and iRadar-based features require connection to a Bluetooth® Smart ready device and the Cobra iRadar app. For a full list of Bluetooth® Smart ready devices visit www.bluetooth.com

Please note, this is the newer Bluetooth® Smart technology and pairing is not always done in the same manner and menus as conventional Bluetooth. This detector will NOT APPEAR in the Bluetooth Settings menu of your iPhone®.

#### For iPhone® 5s and later with Bluetooth® Smart:

- a. Power on the detector. If not connected, it will be in the Pairing Mode automatically.
- b. Make sure your iPhone Bluetooth is turned On.
- c. Start the Cobra iRadar application. Press the Menu icon in the upper left corner of the app and select Devices. Follow the onscreen instructions to complete the pairing and connection.
- d. When complete, you will see "iRAD Connected" appear on the detector screen.
- e. Enter the app to complete the connection.

#### For Android™:

- a. Power on the detector. If not connected, it will be in the Pairing Mode automatically.
- b. Make sure the your Android™ device's Bluetooth is turned On and go to the Bluetooth Settings Menu. For most devices this can be found by pressing; Settings > Bluetooth.
- c. Press Scan for Devices and/or wait for the device list to populate and then select iRadar. Pairing can take up to 30 seconds.
- d. The phone might show "Paired but not connected" in this menu. That's OK as the connection will be completed after opening the iRadar App.

For more information on pairing with **Bluetooth** devices consult your phone's owners manual.

If you are having trouble initializing or maintaining your **Bluetooth** connection completely turn off your smartphone and detector device, wait 30 seconds, and then turn them back on.

## Detection Detection

### **iRadar Community**


When you, or any other iRadar user, detects a radar or laser signal the alert information is anonymously sent to Cobra's cloud servers. Within seconds, that information is processed and displayed on your map as part of a Threat Area.

#### **Using the Report Button**

You can report to the iRadar Community when you see an active police speed enforcement by pressing the REPORT button for 2 seconds.




#### **Location Based Alerts:**



The distance will count down as you approach the Location-based Alerts (LBA) Area. The alert types are:

Photo-enforced Areas







LBAs will start as you approach the actual location. If both a radar and Location-based alerts happen at the same time, both will be displayed side by side. As you approach a specific Threat Area you will hear a short beep and then the app will indicate the Cobra's assessment of the reliability of the threat. High-Threat Area means multiple reports have confirmed a legitimate threat in the area recently. Medium or Low-Threat Area means signals have been detected but have either not been confirmed or have not been reported lately.

Paying attention to threat areas will allow you to be warned of potential threats before you enter radar detection range. Community Radar/Laser alert sharing means that you have an entire network of users working to keep you and your wallet safe.

# Understanding Radar & LIDAR

#### **Understanding Radar and Laser**

#### **Radar Speed Monitoring Systems**

Three band frequencies have been approved by the Federal Communications Commission (FCC) for use by speed monitoring radar equipment:

GHz), which is an approved frequency used in parts of Europe and Asia.

X band 10.525 GHz K band 24.150 GHz Ka band 33.400 – 36.00 GHz

Your detector detects signals in all three radar bands, plus Ku band (13.435

#### VG-2

VG-2 is a "detector detector" that works by detecting low-level signals emitted by most radar detectors. Your detector does not emit signals that can be detected by VG-2, but does detect VG-2 signals and will alert you when a device is in use near your vehicle. While no signal is being detected, press and hold the Dim button for four seconds.

Your detector can be spotted by Spectre IV+ RDDs, but is invisible to VG-2 and Spectre I RDDs. You can choose whether you want to be alerted to VG-2 and Spectre I & IV+ RDD signals. The factory setting for VG-2 and Spectre I & IV+ alerts is Off. It is recommended to leave these Off unless you are concerned about being monitored for having a radar detector.

The factory setting for VG-2 alerts is **Off**.



## Understanding Radar & LIDAR

#### LIDAR (Laser)

The correct name for the technology that most people refer to as laser is actually **LIDAR**, which stands for Light Detection and Ranging.

LIDAR operates much like radar. Its signal spreads out like a radar signal, though not as widely. Unlike radar, LIDAR must have a clear line of sight to its target vehicle throughout the entire measurement interval. Obstructions such as sign posts, utility poles, tree branches, etc., will prevent valid speed measurement. Some common questions about LIDAR include:

- Does weather have any affect on LIDAR?
   Yes. Rain, snow, smoke, fog or airborne dust particles will reduce the effective range of LIDAR and can, if dense enough, prevent its operation.
- Can LIDAR operate through glass?
   Yes. Newer LIDAR guns can obtain readings through most types of glass.
   However, the laser pulse also can be received through glass to trigger an alarm by your detector.
- Can LIDAR operate while in motion?
  No. Because LIDAR operates by line of sight, the person using it cannot drive the vehicle, aim and operate the gun all at the same time.
- Is it legal for police to use LIDAR? Yes, LIDAR is allowed to be used in all 50 States by police. Your detector detects LIDAR (laser).



## Specifications & Maintenance

#### **Specifications**

#### **Band and Frequencies**

Band	Frequencies		
X Band	10.525	± 0.050	GHz
K Band	24.125	± 0.125	GHz
Ka Band	34.700	± 1.300	GHz
Laser	910 ± 50 nm	100	PPS
VG-2	11.500	± 0.250	GHz



WARNING Modifications or parts substitutions not approved by Cobra Electronics Corporation may violate FCC Rules and void your authority to operate this equipment.

U.S. Patent Number: 6,078,279

#### **Maintenance**

Your detector is designed and built to give you years of trouble-free performance without the need for service. No routine **Maintenance** is required.

If your unit does not appear to be operating properly, please follow these troubleshooting steps:

- Make sure the power cord is properly connected.
- Make sure the socket of your vehicle's cigarette lighter is clean and free of corrosion.
- Make sure the power cord's cigarette lighter adapter is firmly seated in your cigarette lighter.



### **Limited 1-Year Warranty**

Cobra Electronics Corporation warrants that this product and the component parts thereof, will be free of defects in workmanship and materials for a period of one year from the date of first consumer purchase. This warranty may be enforced by the first consumer purchaser. If the product is under warranty, it will be repaired or exchanged depending on the model as determined at Cobra's sole discretion. Such remedy shall be your sole and exclusive remedy for any breach of warranty.

The procedure for obtaining service and support, and the applicability of this warranty, will vary depending on the country or jurisdiction in which you purchased and utilize the product. For the details on obtaining product service, support and warranty please visit www.cobra.com/support

Provided that the product is utilized within the U.S.A.- Cobra will, without charge, repair or replace, at its option, defective products, products or component parts upon delivery to the Cobra Factory Service department, accompanied by proof of the date of first consumer purchase, such as a duplicated copy of a sales receipt. You must pay any initial shipping charges required to ship the product for warranty service, but the return charges, to an address in the U.S.A., will be at Cobra's expense, if the product is repaired or replaced under warranty.

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state and country to country.

Exclusions: This limited warranty does not apply: 1) To any product damaged by accident; 2) In the event of misuse, ordinary wear, failure to follow directions, or improper maintenance of the product or as a result of unauthorized alterations or repairs; 3) If the serial number has been altered, defaced, or removed; 4) If the product was purchased or is utilized in a jurisdiction not covered by the limited warranty.

All implied warranties, including warranties of merchantability and fitness for a particular purpose are limited in duration to the length of this warranty. Cobra shall not be liable for any incidental, consequential or other damages; including, without limitation, damages resulting from loss of use or cost of installation.

Some states and countries do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state and country to country.



## Product Service & Support and Optional Accessories

#### **Product Service and Support**

For any questions about operating or installing this new Cobra product, PLEASE CONTACT COBRA FIRST...do not return this product to the retail store. The contact information for Cobra will vary depending on the country in which you purchased and utilize the product. For the latest contact information, please go to www.cobra.com/support

For products purchased in the U.S.A. you may also call 1-773-889-3087.

For Products Purchased in the U.S.A., if your product should require factory service, please go to www.cobra.com/support and follow the instructions for returning your product to the Cobra Factory Service Department for service.

### **Optional Accessories**

You can find quality Cobra products and accessories at your local Cobra dealer, or in the U.S.A., you can order directly from Cobra at www.cobra.com



Windshield Mounting Bracket Includes suction cups Item #545-159-N-001



Includes plug and fuse Item #420-030-N-001



Includes plug and fuse Item # 420-026-N-001



Straight Combination Radar USB Cord

Includes plug and USB Output Item # PWR USB-01



Dual Port Power Adapter Includes adjustable plug (up to 90°) and fuse Item # CLP-2B



Hardwire Cord for Radar Includes fuse Item # RA-PSCB



Install Mount Includes 3M Dual Lock™ Item # 545-002



### FCC Statement & Trademark Acknowledgement

#### **FCC Statement**

FCC NOTICE: This device complies with part 15 of FCC rules: Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

AVIS FCC: Cet appareil est conforme à la partie 15 des règles de la FCC: Son fonctionnement est soumis aux deux conditions suivantes: (1) Ce dispositif ne peut causer des interférences nuisibles, et (2) Cet appareil doit accepter toute interférence recue, y compris les interférences qui peuvent causer un mauvais fonctionnement.

NOTE: Cet équipement a été testé et jugé conforme aux limites d'un appareil numérique de classe B, conformément à la partie 15 des règles de la FCC. Ces limites sont conçues pour fournir une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet équipement génère, utilise et peut émettre de l'énergie radiofréquence et, si non installé et utilisé conformément aux instructions, il peut causer des interférences nuisibles aux communications radio. Cependant, il n'y a aucune garantie que l'interférence ne se produira pas dans une installation particulière. Si cet appareil provoque des interférences nuisibles à la réception radio ou de télévision, ce qui peut être déterminé en mettant l'appareil hors tension, l'utilisateur est invité à essayer de corriger l'interférence par une ou plusieurs des mesures suivantes:

- Réorienter ou déplacer l'antenne de réception.
- Augmenter la distance entre l'équipement et le récepteur.
- Branchez l'appareil dans une prise sur un circuit différent de celui auquel le récepteur est connecté.
- Consulter le revendeur ou un technicien radio / TV expérimenté.

#### **Trademark Acknowledgement**

Cobra®, DigiView®, EasySet®, Extra Sensory Detection®, LaserEye®, Nothing Comes Close to a Cobra®, VG-2 Alert®, Xtreme Range Superheterodyne® and the snake design are registered trademarks of Cobra Electronics Corporation, USA.

Cobra Electronics Corporation™, AURA™, IntelliLink™, IntelliScope™, IntelliView™, Revolution™ Series, IVT Filter™, SmartPower™, Super-Xtreme Range Superheterodyne™, S-XRS™, and Voice Alert™ are trademarks of Cobra Electronics Corporation, USA.

Instaclear® for Ford is a registered trademark of Ford Motor Company, Inc. Electriclear® for GM is a registered trademark of General Motors Corporation. LTI Laser™ and LTI 20-20™ are trademarks of Laser Technology, Inc. Kustom Laser™, Kustom Laser 340™ and ProLaser II™ are trademarks of Kustom Signals, Inc. SpeedLaser™ is a trademark of Laser Atlanta. Stalker™ LIDAR is a trademark of Applied Concepts, Inc. Spectre I™ and Spectre IV™ are trademarks of Stealth Micro Systems Pty. Ltd. SpeedLaser™ is a trademark of Laser Atlanta, LLC. Interceptor VG-2™ is a trademark of TechniSonic Industries LTD.