

CREATIVE
FreePoint
3500



Quick Start

CREATIVE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
a) This device may not cause harmful interference, and
b) This device must accept any interference received, including interference that may cause undesirable operation.


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Copyright © 2006 Creative Technology Ltd. All rights reserved. The Creative logo and FreePoint are registered trademarks or trademarks of Creative Technology Ltd. Windows is a registered trademark of Microsoft Corporation. All rights reserved. All other logos, brand or product names are trademarks or registered trademarks of their respective holders and are hereby recognised as such. All specifications are subject to change without notice. Actual contents may differ slightly from those pictured.


PN 0300000000318 Rev.C

CREATIVE FreePoint 3500 Quick Start

Overview




1. Inserting Batteries



If your mouse's batteries are running low, the red light-emitting diode (LED) in the RF receiver lights up.


2. Connecting Your Creative RF Receiver

a. Connect the RF receiver to the USB port on your computer. The green LED on the RF receiver blinks.



- Windows 98 and 98 SE users may need to install device drivers. For more information, see "Step 4: Installing Device Drivers and Software."
- To exit power saving mode, click a mouse button.

3. Activating Your Creative FreePoint 3500



Your mouse is a plug-and-play device and can be used when the RF receiver is connected to your computer.

Test the mouse. If it does not respond, do the following:

- Press the **Connect** button on the RF receiver, as shown above.
- Press the **Connect** button on the mouse, as shown above.

If the mouse pointer is responding erratically, reposition your mouse and try again. Make sure that there are no obstructions, such as electronic devices, between your RF receiver and mouse.

4. Installing Device Drivers and Software

You need to install the software in the Installation CD to configure the buttons on your Creative FreePoint™ 3500. The following instructions are applicable to Windows XP, Windows 2000, Windows Millennium Edition (Me), Windows 98 Second Edition (SE) and Windows 98.

- After you have connected Creative FreePoint 3500, Windows will detect your mouse and install the required drivers automatically.

Windows 98 and 98 SE users may be prompted by an **Add New Hardware Wizard** dialog box when Windows detects your USB device. Follow the instructions on the screen. You may need to insert the Windows Installation CD into the CD-ROM drive during installation. Some computers may be supplied without the Windows CD, but have the necessary files stored in `c:\windows\options\cabs` (replace `c:\` with the drive letter your Windows has been installed on).

- Insert the Creative FreePoint 3500 Installation CD into the CD-ROM drive. Your CD should start automatically. If it does not, follow the steps below:
 - Double-click the **My Computer** icon. Alternatively, click **Start** → **My Computer**.
 - Right-click the CD-ROM/DVD-ROM drive icon, and then click **Autoplay**.
- Select the applications to install, and then click the **OK** button.
- Follow the instructions on the screen to install your Creative FreePoint 3500.
- When prompted, restart your computer to complete the installation.