

3. User Interface

3.1 About the Home Screen

Getting Started



'Getting Started'

Quick menu will be shown to set up several basic functions.



You can make a decision whether Getting Stared is shown or not on Hone Screen through Add/remove Getting Started menu.













3. User Interface

3.2 Title Bar Status Icons

Icons

The network, phone, volume, battery and time of current device is shown as icons on the status bar. The following is explaining the meaning of each icon.

Title Bar Status Icon Descriptions


















Icons	Explanation
	You have a new notification.
	You have a new text message.
	You have a new e-mail message.
	You have a new instant message.
	You missed a call.
	The speakerphone is on.
	The phone is roaming.
	An alarm is set.
	The microphone is on.
	An internet call is in progress.



3. User Interface

3.2 Title Bar Status Icons


















Icons

Icons	Explanation
	A bluetooth headset is detected.
	An ActiveSync connection has been established.
	There was a problem with the ActiveSync synchronization.
	An ActiveSync synchronization is in progress over USB.
	A UMTS network is available.
	Connecting to a UMTS network.
	A UMTS connection is active.
	A 3G+ network is available.
	An EDGE network is available.
	Connecting to an EDGE network.
	An EDGE connection is active.
	A GPRS network is available.
	Connecting to a GPRS network.
	A GPRS connection is active.
	An HSDPA network is available.
	Connecting to an HSDPA network.
	An HSDPA connection is active.

3. User Interface

3.2 Title Bar Status Icons

Icons

Icons	Explanation
	Bluetooth is on.
	Wi-Fi is on but not connected, and no networks are detected.
	Wi-Fi is not connected to a network, and other networks are detected.
	Other wireless networks are detected.
	Connected to a wireless network.
	Synchronizing through a Wi-Fi connection.
	Connected to a wireless network, and other networks are detected.
	Information about a new wireless network is available.
	A network connection is active.
	A network connection is inactive.
	The phone has maximum signal strength.
	The phone has no signal.
	The phone capability is off.
	The phone has no service.
	The phone is searching for service.
	Data is being transferred.
	A voice call is in progress.



3. User Interface

3.2 Title Bar Status Icons

Icons

Icons	Explanation
	A voice call in on hold.
	There is no SIM card present in the computer.
	The volume is off and the phone is set to vibrate.
	The volume is on.
	The volume is off.
	The battery has a full charge.
	The battery has a high charge.
	The battery has a medium charge.
	The battery has a low charge.
	The battery has a very low charge.
	The battery is attached to external power and is charging.
	No battery is installed in the computer.
	Call forwarding is on.
	Voice mail is off.
	GPS locator is off.
	GPS locator is on.

4. Using the Phone

4.1 To use the phone function


Start the phone function




When you turn on the PDA, the standby screen is shown like the right picture. After that, you can use the phone function by touching Phone on the left bottom.

Add the phone number



1. Input phone numbers you want to add on the Phone screen.
2. Touch  in the bottom bar then the phone numbers can be added through Save to contacts menu.
3. Save them pressing the OK button after finishing inputting phone number after inputting Family/Sur name through New Contact



4. Using the Phone

4.1 To use the phone function


Designate abbreviated number



You can designate abbreviated numbers using Speed Dial key on Phone Screen.

It is progressing in the way of adding already saved number by Speed Dial.

Call using abbreviated number



You can make a call using the abbreviated number saved with a phone number. When you press the number longer, the line is connected. If an abbreviated number is saved in double digit, then press second digit longer than first number.

4. Using the Phone

4.2 To use the text message function

Text message




Text message function can be used by touching Text icon. Received messages can be checked and saved in, replies can be sent and the phone numbers can be saved in the directory.

You can write and send a new message by using New button.



You can write a message on the left screen. Recipient number is on the top.



In the Show menu, you can check sent messages or temporarily saved messages.

4. Using the Phone

4.2 To use the text message function

Text message



When you press the sky blue button once in the Text Messages, you can see the sky blue circle in the center of bottom line. It makes change to the former letter right after texting one letter.



It is the screen when you press the sky blue key twice. You can see the whole blue circle and that makes you write any letter continually.

Text message

EX) Enter 7,8,9

The values input in each mode are seen like the right pictures. Sky-Blue and Red are operating as the same function.



5. Others

5.1 Applications

Windows Media



Window Media supports the function that runs music and video files.

File Explorer



File manager supports Cut, Copy and Rename etc., like the functions of PC by File Explorer. It also provides Interface similar PC and is available to approach all files and folders inside and outside memory.



5. Others

5.1 Applications

Camera



You can take a picture, shoot a file clip and edit a photo by Pictures & Video. Press 'the image of Camera' first and then press 'Enter' on the hard key pad.

Task Manager



Application	Mem	CPU
Windows Media	2.13M	0 %
Pictures & Videos	692K	0 %
ActiveSync	456K	0 %
Contacts	240K	0 %
Tasks	240K	0 %
Wireless Manager	100K	0 %
Task Manager	87.0K	0 %

Task Manager shows current running APP. When an unwanted program or some programs are finished, you can manage the memory efficiently using Task Manager.

5. Applications


5.1 Data communication Applications

DATA Communication




Click WI-FI icon on the bottom right-corner of the screen and touch 'WLAN Insert' like the left picture. Then, PHONE supports phone function and 3G DATA, WI-FI supports the function of on/off WI-FI.

Internet Explorer



You can use Internet through Internet Explorer after connecting WLAN and can see various internet contents like searching and mails



5. Applications

5.2 Bluetooth Applications

Bluetooth



Activate Bluetooth.

'setting' -> 'Bluetooth'



You can search peripheral Bluetooth devices like the left screen
Touch 'Add new device' and search them.



After searching a device, connect the device you are going to use.



6. Others

6.1 Problem solving

Problem solving

1. Check followings first when a problem occurs while using the product.
2. If the problem is still not solved, contact the customer center with the phone number below.

A/S consultation phone no.: 02-850-3247

Problem

Product does not turn on.

No sound from the speaker.

Screen is dark.

I do not understand what is explained in the manual.



Solution

1. When the product is shipped from the factory, the circuitry is disconnected. Press the power button for 2 seconds or longer, when the product will turn on.
 2. Check if the battery is fully charged and charge the battery before using the product.
-

1. Check if the earphone is plugged in. If the earphone is not plugged in, the speaker will not output any sound.
 2. Check if the volume of the product is not set at 0.
-

1. Enter into 'Setup' and adjust the lighting.
-

1. Use customer support in the Web site or contact customer center over phone, when we will sincerely answer your questions.



6. Others

6.1 Problem solving

Problem

The product seems to be hot.

Buttons cannot be pressed or screen touch does not work.

The PC does not recognize the product.

Solution

1. This product is designed to properly radiate the heat generated inside the product through the case.
 2. If the product is used for a long period of time or the adapter is connected for long, you may feel warmth from the case. Please use the product at ease as there is no problem with the product.
-

1. Check if the line is connected or in hold state
-

1. If the connection is frequently cut and instable, please connect the product not to a separate hub but directly to the USB terminal of the PC.
-





6. Others

6.2 Guidance on customer support and after service

.....

1. Guidance on after service center

1) Telephone number

A/S consultation telephone : 82-2-850-3243

2) Consultation time

Mon. through Fri. : 9:00~18:00 (Not available during lunch time, 12:00~13:00,
Saturdays, Sundays and holidays)

3) Web site

Use the customer center after accessing the site at [www.dotel.co.kr/en/
Service & Support](http://www.dotel.co.kr/en/Service%20&%20Support) to download our current manuals.

4) Content of service

Free or charged repair of all the models of PDA and sale of various accessories.

2. Before asking for repair

1) Be sure to check the content of 'Problem solving' in the previous page before asking for repair. If the problem is still not solved, then ask for repair.

2) Do not forget to backup important data contained in the product in advance. Data may be deleted during repair due to memory formatting, etc. The Company does not take any responsibility for the data lost during after service repair.

3) Be sure to write your telephone number and address. If there is no contact information for the customer, a problem may occur in the process.

3. Quality Assurance

1) The warranty of the product is on the overleaf of the manual.

2) The products manufactured and sold by the Company are products shipped after going through strict quality control and inspection of DO Tel Co., Ltd.



6. Others

6.2 Guidance on customer support and after service

.....

3) Warranty period

- Main body: 1 year
- Accessories (consumables): 6 months (battery and items excluding the main body)
- Mandatory period to keep spare parts in stock: 3 years from the date of releasing the relevant model

4) Content of warranty

When a problem occurs during normal use within the warranty period, the after service center of the Company shall provide legitimate material and immaterial service in accordance with Consumer Damage Compensation Regulation by item. In following cases, repair may be inevitably impossible even within the warranty period and at a cost.

- a. if the product is out of order due to shock or water-logging caused by a mistake of the consumer;
- b. if the product has been randomly disassembled or remodeled;
- c. if the product is out of order due to natural disaster such as fire, earthquake or flood; or
- d. if the product has been repaired by others than the designated after service center. in another place than Individual matters not specified in this article shall be reviewed from the aspect of the internal regulation of DO Tel Co., Ltd. for after service and customer support but aiming at convenience of the final consumer

5) Warranty area: Korea

4. Expense for repair

- 1) If the product has failed due to defect of the product itself within the warranty period, it will be repaired at free of cost in accordance with the warranty standard of the Company and Consumer Damage Compensation Regulation
- 2) The repair expense shall be decided in accordance with the repair price for each item in the internal regulation of the Company. 3)Even within the warranty period, if it falls under article 3-4 above, a certain amount of repair expense will be charged. Please understand as repair may not be possible in some cases. 5. Hardware manufacturer: DO Tel Co., Ltd. www.dotel.co.kr



6. Others

6.3 Product Warranty

Product Warranty

Classification	Content
Model name	DOTH-300S
Date of purchase	
Purchased from	
Manufacturing no.	
Warranty period	One year from the date of purchase

Repair charge regulation

Product failure type		Within warranty period	After warranty period
When the failure occurred within 10 days after the purchase		Replace	
Repair able	When failure has occurred more than 3 times due to same defect	Free repair	Repair at a cost
	When failure has occurred more than 4 times due to same defect	Replace	Repair at a cost
Not repair able	If repair is impossible within one month	Replace	Replace after deducting a fixed amount of depreciation
	If repair is impossible due to unavailability of repair part	Replace	Replace after deducting a fixed amount of depreciation
	If replacement is impossible	Refund	Refund the amount after deducting a fixed amount of depreciation and adding 10 percents



6. Others

6.4 Communication and Product Specification

.....

Communication Specification

Classification	Content
Moblie	Frequency used: GSM/GPRS/EDGE: 850/1900MHz UMTS : 850/1900MHz
WLAN	Frequency used :2.434~2.484GHz IEEE 802.11b/g/p Standard
Bluetooth	Frequency used :2.4~2.482GHz
GPS	Frequency Used : 1575.42MHz



6. Others

6.5 System Product Specification

.....

System Product Specification

Classification	Content
C P U	ARM 11 PXA320
O S	Windows Mobile 6.5.3
R A M	256MB
R O M	512MB
DISPLAY	TFT LCD MODULE 3.5INCH,262K COLOR
INTERFACE	USB 2.0, 3.5 Phi Ear Jack
BATTERY	Standard Type : 2400mA
SIZE	75.6*159*25T
WEIGHT	278g
ADAPTER	5V/4A