

TANDBERG

FS-SSTB User Guide



INFORMATION TO USER :

This equipment has been tested and found to comply with limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment can generate, use, and radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause unacceptable interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced Radio/TV technician for help.

Caution

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



The lightning flash with arrowhead symbol within an equilateral triangle, is intended to alert the user of the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to people.




The exclamation point within an equilateral triangle is intended to alert the user of the presence of important operating and maintenance (servicing) instructions.

TABLE OF CONTENTS


1. Product Drawing-----	1
2. Front Specification -----	2
3. Connector Specification-----	2
4. Signal Connector Pin Assignments-----	3

1. Product Drawing



Unit : mm

2. Front Specification



Operating sequence

1. Make sure that SSTB is connected to console.
2. Supply DC power through FSP040-1ADF03A AC/DC adaptor.
3. Touch any button and you can see that LED is lighting.


3. Connector Specification



4. Signal Connector Pin Assignments

1. Data Port 1 (D-Sub 9Pin)

Pin No.	Assignment	Pin No.	Assignment
1	12V Power	6	DTRIN
2	TXD	7	CTSIN
3	RXD	8	RTSIN
4	DSRIN	9	No Connection
5	Ground		



2. Data Port 2 (D-Sub 9Pin)

Pin No.	Assignment	Pin No.	Assignment
1	12V Power	6	DSR
2	LRXD	7	RTS
3	LTXD	8	CTS
4	DTR	9	No Connection
5	Ground		

