


# User's Manual


## Wireless Headset



### 1. Package Contents



BASE Unit



HEADSET & HEADBAND



POWER ADAPTOR



EAR-HOOK




TELEPHONE CONNECTION CORD




USB CABLE  
(Optional)



### 2. Headset




- Speaker Volume Up/Down
- Microphone Mute (Press)




- Fit the headband or ear-hook on the headset
- Adjust the boom arm of your headset so that the microphone is positioned in the direction of your mouth, as close as possible to your mouth.



### 3. Base Unit




<b>Microphone Volume Switch</b>	When installed, adjust volume level for the best level of microphone volume.
<b>Compatibility Switch</b>	Select '1' or '2' until a dial tone is heard via the telephone connection.
<b>PC/TEL</b>	Only USB version has this function.
<b>Bluetooth Button</b>	Turn on and off Bluetooth mode



<b>AUX</b>	Connection for Handset LIFTER (optional extra)
<b>Handset port</b>	Plug Handset cord from the phone to Handset port
<b>Telephone port</b>	Connect telephone cord to the headset port or handset port of a telephone / base unit
<b>USB Port</b>	Connect USB cable between PC and base unit.
<b>DC Jack</b>	Connect Power Adapter to DC Jack

## 4. LED & Audio indicator




Charging Status	LEDs status
Charging	Battery Indicator : 'Blinking' 3 sec-ON, 1sec-OFF
Full Charged	Battery Indicator : 'ON'
Low Battery	Battery Indicator : 'Blinking' 0.5 sec-ON, 0.5 sec-OFF
Event	LEDs status
Press Microphone mute	Mute indicator : 'ON'
Press PC/TEL selection	PC/TEL Indicator - TEL : 'OFF' PC : 'ON'
Hook Off	Selected Mode indicator : 'ON'

## Audio Indicator

Event	Added
Speaker /Microphone volume UP/DOWN	Beep Sound (High tone/Low tone)
Max/Min speaker volume reached	Double beep
Max/Min microphone volume reached	Double beep
Microphone mute/unmute	Beep / Double beep
Mute reminder	Beep (every 3 seconds)
Hook Off / On	Double beep (High tone / Low tone)


## 5. Setting up the BASE

Diagram 1 (Desk phone with HEADSET port)



- Plug the supplied telephone cord into the TEL port of the BASE UNIT
- Connect the telephone cord to the HEADSET port of the desk phone

Diagram 2 (Desk phone without HEADSET port)



- On the desk phone, unplug the handset cable from the phone
- Plug the handset cable into the HANDSET port on the BASE UNIT
- Plug the telephone cord into the TEL port on the BASE UNIT and plug the other end of the telephone cord into the HADNSET port on the desk phone

#### **(Desk phone with DL-570 LIFTER)**

The DL-570 remote handset lifter manually lifts the desk phone handset to make or answer a call.

- Refer to the DL-570 installation guide

#### **(Desk phone with EHS Adapter)**

EHS Adapter enables an incoming call to be answered or ended by using the On/Off button on the Headset..

- Refer to the EHS Adapter installation guide

## 6. Operational Instruction

- Plug the Power Adapter cord on the Base unit.**(Note 1)**
- Press Hook On/Off switch to make a call
- Select compatibility switch '1' or '2' position until you can hear the dial tone
- Adjust speaker and microphone volume
- Press Hook On/Off switch to end a call

#### **Note 1 : Factory default setup : Paired**

Pairing process is automatically proceeding when plug the power adapter into the Base Unit. (Make sure that headset is placed on the cradle and should be powered on before power is turned on. If the headset is not placed on the cradle, pairing will be unsuccessful.)

## 7. Electronic Hook Switch (optional extra)

The unit enables you to answer and end calls remotely by using its built-in electronic hook switch (EHS). EHS of this unit is only compatible with certain telephone systems supporting EHS.

- ★ EHS is only compatible with certain telephone systems. In order to determine which telephones are compatible with the EHS feature, please refer to EHS guide or contact your local distributor. Please also refer to your telephone's user manual for clarification.

## 8. Trouble Shooting

### 1. Cannot hear a dial tone.

- ☞ Check the TEL/PC button.  
TEL Mote: PC/TEL indicator – 'OFF'
- ☞ Please check the cable connection between Base unit and Phone.
- ☞ Check that the power adapter is plugged in and has power
- ☞ Please check the compatibility switch. Adjust compatibility switch until you can hear the dial tone.

### 2. Microphone volume (TX) is low / dead.

- ☞ Make sure that the microphone (TX) mute function is deactivated.
- ☞ Check the position of the boom arm and make sure that the microphone is placed as close as possible to your mouth (approx. 2 fingers distance).
- ☞ Adjust the microphone (TX) volume on the bottom of base unit.

### 3. Buzzing sound on the headset

- ☞ Telephone may not be fully immune to the radio transmission between your headset and base. To overcome this problem, move the base unit to at least 30 cm/12" away from the phone.

### 4. Headset echoes

- ☞ Adjust the telephone's volume. If necessary, adjust your microphone volume

on the headset to a lower setting.

#### 5. EHS doesn't work with the telephone

☞ Make sure the telephone is compatible with the wireless headset. Refer to the EHS guide.

#### 6. Headset was working, but it has stopped.

☞ Headset may need pairing to the base again. Refer to the **'Note 1'** on **'Operational Instruction'**

☞ Headset battery may be dead. Return the headset to the cradle on the base unit for charging.

## 9. Bluetooth Usage

On the base top case, the Bluetooth mode button can be found. When this button is pressed, the blue LED is blinking and DW-779UB is on Bluetooth pairing mode.

To make pairing with smartphone, PC, or any other Bluetooth device, you should put other Bluetooth device is on pairing mode, too.

On other Bluetooth device finds "DW-779UB(xxxx)". Select it to finish the Bluetooth pairing.

After finishing pairing, "DW-779UB(xxxx)" should be selected on other Bluetooth devices.

During idle, the Blue color LED is blinking when the Bluetooth call is coming. And also ring beep can be heard on headset's earpiece speaker.

To take a call, press the hook button on headset and then Bluetooth call connection can be set.

When Bluetooth call talking, the blue LED is blinking with different period.

To finish a call, press the hook button on headset.

After finishing, the blue LED is turned off and previous mode LED will be turned on.

When user makes a Bluetooth call on Smartphone, the blue LED is also blinking and call processing beep can be heard on headset's earpiece speaker.

After other party takes a call, Bluetooth call is automatically connected.

## WARRANTY CARD

Mr./Mrs./Miss/Co. \_\_\_\_\_

Telephone No. \_\_\_\_\_

Address \_\_\_\_\_  
\_\_\_\_\_

Model No. \_\_\_\_\_

Brand \_\_\_\_\_

Serial No. \_\_\_\_\_

Invoice No. \_\_\_\_\_

Dealer \_\_\_\_\_

Date of Purchase \_\_\_\_\_

**Note : THIS WARRANTY CARD WILL BE VOID IF IT IS  
NOT MAILED BACK TO OUR COMPANY WITHIN  
10 DAYS FROM DATE OF PURCHASE,  
WARRANTY CONDITIONS  
(PLEASE SEE OVERLEAF)**

### Compliance Statement (Part 15.19)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

### Warning (Part 15.21)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### FCC Interference Statement (Part 15.105 (b))

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is