

User Guide

Smart Bracelet ID128Color HR



Thanks for choosing our device, please read the user guide carefully before using.

Setting

Use VeryFitPro on iOS or Android smart phone to set the wristband as follows:

Note: hardware and system of devices should meet the requirements:



1. Download VeryFitPro

Search and download

Search and download "VeryFitPro" from the Apple Store or Android App store.

Scan the QR code and download

It probably has a problem to open the link with WeChat or other scan tools, please copy the link and open it through browser.



2. Product activation and installation

The product must be activated by charging before initial use, and then charge the product to ensure normal power supply. The hand ring will automatically power on.

Take out: Pull open the strap and take out the bracelet body.



Charge the battery: Insert the chip-mounted end of the bracelet body into the USB interface to activate the product by charging (be cautious not to reverse the polarity, and comply with the required voltage and current: 5V / 500mA).



Installation: Mount the bracelet body into the slot of the wrist strap.



Wear on: Adjust the length of the wrist strap until it is appropriate to wear on the wrist.




3. Touch key



Single click the touch key: Interface switch
Press and hold the touch key: Enter

4. Make sure the Bluetooth of smart phone is ON, open app"VeryFitPro"



When selecting the right band from the search list, please slide the screen of wristband to wake up the device and then complete connecting.

Know your Device

1. Wearing Method

Wear the device on your wrist horizontally, about 2cm to carpal, the same method as wearing watches.

2. Heart Rate Monitoring


To monitor Heart Rate more accurately, please wear the device on the upper position of your wrist and a bit tighter than usual when you are taking exercise.

3. Heart Rate Monitoring

Automatic heart rate Monitoring is ON as default, monitor Heart Rate all the day automatically.

4. Interface

Click the touch key to display successively




Note: To go back to the Data Reading Mode by clicking the touch key on the final interface of Data Reading Sub-Mode.

Function Introduction

1.1 Time Mode

Instructions
Time dial can be switched as follows:
APP Devices Mode>More
[Click the touch key] to enter the next mode:
Data Mode
(you can customize the shortcut through the app).



1.2 Data Mode

[Click the touch key] to enter the next mode: Heart Rate Mode
[Press and hold the touch key for 2s] to enter the sub-mode of "Data Reading"



1.2.1 Data Reading Sub-Mode

[Click the touch key] to enter the next sub-mode: Sports Mode
[Press and hold the touch key for 2s] to start/close alarm clock.



Note: To go back to the Data Reading Mode by clicking the touch key on the final interface of Data Reading Sub-Mode.


1.3 Heart Rate Mode



Before Data Is Displayed / After Data Is Displayed / Change in 0.5s

1.5 Sports Mode

[Press and hold the touch key for 2s] to enter the Sports Mode
[Click the touch key] to enter the next sports mode; and in case there are no other sports modes, it will go back to the time mode.
Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities).



1.5.1 Sports Start Mode

1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)

1.5.2 Sports Underway Mode

[Click the touch key] to enter the sports data display mode



1.4 Alarm Clock Mode

Note: Alarm clock function should be turned on in App for the alarm clock to be displayed.



1.5.3 Sports Stop Mode


[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The speed and distance of riding can be displayed, but App need to be connected and the riding and App needs to start at the same time.

1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.

1.5.5 Abnormal operations during activity

The reminder will be available soon



1.5.3 Sports Stop Mode

1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)

1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.

1.5.5 Abnormal operations during activity

The reminder will be available soon




1.5.1 Sports Start Mode

[Click the touch key] to enter the next sub-mode of "Sports Underway"[Press and hold the touch key for 2s] to enter any interface of Data Reading, press and hold 2s to exit the sports mode.



1.5.2 Sports Underway Mode

[Click the touch key] to enter the sports data display mode



1.5.3 Sports Stop Mode


1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)

1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.


1.5.5 Abnormal operations during activity

The reminder will be available soon




1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



1.5.5 Abnormal operations during activity

The reminder will be available soon



1.5.3 Sports Stop Mode


1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)

1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.


1.5.5 Abnormal operations during activity

The reminder will be available soon




1.5.3 Sports Stop Mode

1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)




1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



1.5.5 Abnormal operations during activity

The reminder will be available soon



1.5.3 Sports Stop Mode

1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)

1.5.4 Event Reminder in Sports Mode


1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.

1.5.5 Abnormal operations during activity




1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



1.5.5 Abnormal operations during activity

The reminder will be available soon



1.5.3 Sports Stop Mode


1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)

1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.

1.5.5 Abnormal operations during activity

The reminder will be available soon



1.5.3 Sports Stop Mode

1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)



1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



1.5.5 Abnormal operations during activity

The reminder will be available soon



1.5.3 Sports Stop Mode

1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)

1.5.4 Event Reminder in Sports Mode


1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.

1.5.5 Abnormal operations during activity



1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



1.5.5 Abnormal operations during activity

The reminder will be available soon



1.5.3 Sports Stop Mode


1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)

1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.


1.5.5 Abnormal operations during activity

The reminder will be available soon




1.5.3 Sports Stop Mode

1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)




1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



1.5.5 Abnormal operations during activity

The reminder will be available soon



1.5.3 Sports Stop Mode

1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)

1.5.4 Event Reminder in Sports Mode


1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.

1.5.5 Abnormal operations during activity




1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



1.5.5 Abnormal operations during activity

The reminder will be available soon



1.5.3 Sports Stop Mode


1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)

1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.


1.5.5 Abnormal operations during activity

The reminder will be available soon




1.5.3 Sports Stop Mode

1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)



1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



1.5.5 Abnormal operations during activity

The reminder will be available soon



1.5.3 Sports Stop Mode

1) If the sports last less than 1 minute, the user will be reminded of not saving the data.
[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)

1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity
[Click the touch key] to remove the reminder of automatic quitting from sports mode.
Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.

1.5.5 Abnormal operations during activity



Declaration of toxic and hazardous substances in electronic information products



Wearing and Maintenance



Our products are designed for you to wear throughout the day. So please follow a few brief instructions when you are wearing and maintaining your smart devices. To keep your wristband clean and your skin comfortable, we put forward the following tips:

Regularly clean your wrist and the smart wristband, especially after sweating in the exercise or being exposed to substances such as soap or detergent which may attach on the internal side of the wristband.

Do not wash the wristband with household cleanser. Please use soapless detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

For spots or stains that are not easy to remove, scrub with alcohol and then follow the above steps.

FAQ