


User Guide Smart Bracelet



ID115Plus Color HR
Thanks for choosing our device, please read the user guide carefully before using.

Setting

Use VeryFitPro on iOS or Android smart phone to set the wristband as follows:
Note: hardware and system of devices should meet the requirements:



1. Download VeryFitPro

Search and download "VeryFitPro" from the Apple Store or Android App store.

Scan the QR code and download

It probably has a problem to open the link with WeChat or other scan tools, please copy the link and open it through browser.



01

2. Product activation and installation

The product must be activated by charging before initial use, and then charge the product to ensure normal power supply. The hand ring will automatically power on.

Take out: Pull open the strap and take out the bracelet body



Charge the battery: Insert the chip-mounted end of the bracelet body into the USB interface to activate the product by charging (be cautious not to reverse the polarity, and comply with the required voltage and current: 5V / 500mA)



Installation: Mount the bracelet body into the slot of the wrist strap.




Wear on: Adjust the length of the wrist strap until it is appropriate to wear on the wrist.



02

3. Touch key

Single click the touch key: Interface switch
Press and hold the touch key: Enter



4. Make sure the Bluetooth of smart phone is ON, open app"VeryFitPro"

When selecting the right band from the search list, please slide the screen of wristband to wake up the device and then complete connecting.



Know your Device

1. Wearing Method

Wear the device on your wrist horizontally, about 2cm to carpal, the same method as wearing watches.

2. Heart Rate Monitoring

To monitor Heart Rate more accurately, please wear the device on the upper position of your wrist and a bit tighter than usual when you are taking exercise.

3. Heart Rate Monitoring

Automatic heart rate Monitoring is ON as default, monitor Heart Rate all the day automatically.


03

4. Working Time

Continuously working for 8 days under normal conditions

5. Interface


Click the touch key to display successively



Function Introduction


1.1 Time Mode

Instructions: Time dial can be switched as follows: APP Devices Mode>More [Click the touch key] to enter the next mode: Data Mode (you can customize the shortcut through the app)



1.2 Data Mode


[Click the touch key] to enter the next mode: Heart Rate Mode [Press and hold the touch key for 2s] to enter the sub-mode of "Data Reading"



04


1.2.1 Data Reading Sub-Mode

[Click the touch key] to enter the next sub-mode



Note: To go back to the Data Reading Mode by clicking the touch key on the final interface of Data Reading Sub-Mode

1.3 Heart Rate Mode




Change in 0.5s

Note: Upon staying at the Heart Rate interface for 1s, start to monitor the heart rate, and a fig. like '168' is displayed before the correct data is monitored, and upon the correct data being monitored, data is displayed. [Click the touch key] to enter the next mode: Alarm Clock Mode

1.4 Alarm Clock Mode


Note: Alarm clock function should be turned on in App for the alarm clock to be displayed.



05


1.5 Sports Mode

[Press and hold the touch key for 2s] to enter the Sports Mode




Note: Types of Sports mode can be selected in App (App can handle 4 types of track recording sports and 10 types of other activities)

1.5.1 Sports Start Mode



After the countdown interface of 3-2-1-GO is the sports underway mode.


1.5.2 Sports Underway Mode



06

1.5.3 Sports Stop Mode


[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)



Note: The speed and distance of riding can be displayed, but App need to be reconnected and the riding and App needs to start at the same time.

1.5.4 Event Reminder in Sports Mode

1) Reminder of exiting from sports mode upon a period of no activity [Click the touch key] to remove the reminder of automatic quitting from sports mode.



Note: If there is no any activity in a period (15 minutes), reminder will be displayed 15s before it stop.

2) New activities will remove the reminder of automatic quitting from the sports mode.

3) If there are no any new operations before the end of the countdown of automatic quitting from the sports mode, it will exit from the sports mode.

1.5.5 Sports Underway Mode




Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode

07

3) Reminder of force quit for low-battery


[Click the touch key] to accept the force quit from the sports mode



Note: During the sports activities, when the power is too low, the sport mode will pause, and remind the user of force quit from the sports mode.

4) Reminder of inaccessible sport mode for low-battery

[Click the touch key] to accept the inaccessible sports mode for low-battery



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.

1.5.5 Abnormal operations during activity

The reminder will be available soon



08

1) Camera mode control

Entry mode: Start the camera entry by App, and the device will get in the camera mode successfully.




Photo taking methods: shake/wrist lifting/click the touch key


Modes of exit:

1. Press and hold the touch key to exit from the camera mode

2. Exit through App will make the wrist strap quit from the camera mode.

2. More modes of reminders


1) Call Reminder [Click the touch key] to remove the call reminder Press and hold the touch key to hang up the call



Note: The call reminder in the App needs to be set open.

2) Message Reminder


In case of pages of messages, Click the touch key to read the remained ones.



09

3) Alarm Clock


Alarm Clock: The relevant settings need to done in the App.



Alarm Clock Types: Wake up, Medicine taking, Sleeping, Party, Appointment, Exercise, Meeting

4) Long Sitting Reminder

Alarm Clock Reminder: The relevant settings need to done in the App. Click the touch key; It will remove the reminder.



5) Target completion reminder


When some goals are achieved, shake the wrist strap to get the interface of target completion reminder displayed Click the touch key to quit from the reminder



10


6) Low battery reminder

Low-Battery! Please recharge timely!



7) Device Error Notification

Note: When the device is detected with an abnormality, the interface herein will be displayed each time the device is opened.



Status Code: -01 means the abnormality of acceleration sensor -02 means the abnormality of heart rate sensor -03 means the abnormality of touch key IC -04 means the abnormality of flash


Basic Specifications

Model No.: ID115Plus Color HR
Battery Capacity: 90mAh
Working Voltage: 4.35V
Host weight: about 24.8g
Sync: Bluetooth 4.0
Working temperature: -20°C - 40°C
Waterproof: IP68
Working Time: 7days
Product frequency band: 2402-2480MHz
Maximum transmit power: -3.18dBm

11

Declaration of toxic and hazardous substances in electronic information products

The device meets the EU ROHS criterion. Please refer to IEC 62321, EU ROHS Directive 2011/65/EU and revised directive.



FAQ

◆ Failed to find the device when pairing

① Make sure the Bluetooth of smart phone is ON, and smart phone OS Android 4.4 & Above, iOS 7.0 & Above.

② Make sure the distance between phone and device is within 0.5meter, device is among the normal Bluetooth communication distance range(within 10meter) after pairing finished.

③ Make sure the device is not under low battery. If there is still a problem after fully charged, please contact us.

◆ Failed to connect with Bluetooth occasionally

① Caused by the abnormality of Bluetooth service when it restarted on the phone.

② Reboot mobile phone or re-start the Bluetooth service, then it works normal.


◆ How to restore factory defaults

Make sure the device is connected with smart phone, go in the App, enter "device-- System setting", and choose "reboot device".

12

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS




Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

13

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS



Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

14