

## DIGITAL STEEL FIRE & SECURITY SAFE

## COFFRE-FORT D'ACIER NUMÉRIQUE À L'ÉPREUVE DU VOL ET DES INCENDIES

## CAJA DE SEGURIDAD DIGITAL DE ACERO CONTRA INCENDIO



*The Honeywell trademark is used under license from Honeywell International Inc. Honeywell International Inc. makes no representations or warranties with respect to this product.*

*La marque déposée Honeywell est utilisée avec autorisation d'Honeywell International Inc. Honeywell international Inc. ne fait aucune affirmation et n'offre aucune garantie au sujet de ce produit.*

*La marca Honeywell se usa bajo licencia otorgada por Honeywell International Inc. Honeywell International Inc. no hace ningún tipo de representación ni garantía con respecto a este producto.*

**Read this manual carefully and never store it inside the safe!  
Lire attentivement ce manuel et ne jamais le garder à l'intérieur du coffre-fort !  
¡Lea este manual cuidadosamente y nunca lo guarde dentro de la caja fuerte!**

# Digital Steel Fire & Security Safe

## PACKAGE CONTENTS


- 1 – Digital Steel Fire & Security Safe
- 1 – Operation Manual
- 2 – Entry Keys
- 4 – “AA” Batteries
- 1 – Silica Gel Pack

### DO NOT RETURN SAFE TO STORE!

If there are any missing parts or you have difficulty setting up or operating your safe, please contact our Consumer Assistance Department by telephone:

1-877-354-5457  
(USA & Canada)  
Monday–Friday  
7am - 5pm PST

## PRODUCT OVERVIEW




- A - Entry Key Hole
- B - LED Display panel
- C - Battery Comp. Cover
- D - Door Hinges
- E - Rubber Feet
- F - Electronic Digital Keypad
- G - Safe Cabinet Body
- H - Safe Door
- I - Serial Number Label

## SETUP & OPERATION

### STEP 1: INSTALL BATTERIES

For your convenience, we have included 4 “AA” Batteries that provide the power for the electronic controls. These must be installed before using your safe.


1. Remove the battery compartment cover located on the right side of the control panel by pushing in and to the right.
2. Install the 4 “AA” batteries in the battery compartment as illustrated on the inside of the compartment.
3. If the batteries are put in correctly, the safe will beep and the LCD readout will flash, then it will read “GOOD”
4. Once the batteries are properly installed, replace the battery compartment cover.



### REPLACE BATTERIES:

For best results, it is recommended to replace the batteries when they become weak as shown on the Battery Power Level Indicator (A) or at least once a year.

**NOTE:** It is NOT RECOMMENDED to use Non-alkaline or rechargeable batteries.



If the batteries are removed or fail, the keypad memory will NOT be erased and the active programmed code will still work once power has been restored.

## SETUP & OPERATION

### STEP 2: SET CALENDAR AND CLOCK

Once batteries are installed and the control pad is powered, the next step is to begin by programming the clock and calendar. **READ ENTIRE DIRECTIONS AND WRITE DOWN DATE/DAY/TIME BEFORE PROGRAMMING. NOTE:** You must enter all information without delays. If the light goes off, you must begin programming again.

1. With the safe door closed and locked, press the “\*” key followed by the “9” key. The LCD readout will glow amber.



2. Enter the Year – 2 Digits
3. Enter the Month – 2 Digits
4. Enter the Date – 2 Digits
5. Enter the Day – 1 Digit (see chart below)
6. Enter the Hour – 2 Digits (see chart below)
7. Enter the Minutes – 2 Digits

#### EXAMPLE

2. 2010 = 1 0
3. February = 0 2
4. 30<sup>th</sup> = 3 0
5. Monday = 1
6. 9:26 am = 0 9
7. 9:26 am = 2 6


DAY	#
Monday	1
Tuesday	2
Wednesday	3
Thursday	4
Friday	5
Saturday	6
Sunday	7

HOUR	##
1:00 am	01
2:00 am	02
3:00 am	03
4:00 am	04
5:00 am	05
6:00 am	06
7:00 am	07
8:00 am	08

HOUR	##
9:00 am	09
10:00 am	10
11:00 am	11
12:00 pm	12
1:00 pm	13
2:00 pm	14
3:00 pm	15
4:00 pm	16

HOUR	##
5:00 pm	17
6:00 pm	18
7:00 pm	19
8:00 pm	20
9:00 pm	21
10:00 pm	22
11:00 pm	23
12:00 am	00

When correctly entered, the LCD readout will stop glowing and should display the information you just programmed.




## SETUP & OPERATION

### STEP 3: UNLOCK AND OPEN THE SAFE

This safe is equipped with a dual digital/key lock system that requires entering an active user code to unlock it and an entry key to open. It allows for two separate reprogrammable active user codes.


The preset factory user codes are “1 2 3 4” and “1 2 3 4 5 6”.

1. Begin by inserting the entry key into the cylindrical key hole on the left side of the control panel.
2. On the keypad enter the “#” key, then the user code “1 2 3 4”, followed by “#” key again.
3. If correct code is entered, **OPEN** will appear on the LCD panel, and you’ll hear a chime tone indicating the safe is unlocked.
4. Within 5 seconds, turn the key to the right (clockwise) and pull the door open.



### TO LOCK THE SAFE:

Carefully close the door, turn the key counterclockwise to the left and remove. The safe is now locked and an active user code will need to be re-entered to open.




## SETUP & OPERATION

### STEP 4: PROGRAM NEW USER CODES

**SECURITY NOTE:** To insure privacy, this procedure should be repeated for both of the factory pre-set codes

1. Unlock the safe with the first factory pre-set (or current active) code.
2. If correct code is entered, **"OPEN"** will appear on the LCD panel, and you will hear a chime tone indicating the safe is unlocked.
3. Immediately enter **"\*"** then a new 4-8 digit code followed by the **"#"** key.
4. If entered correctly, **"IN"** will appear on blue display followed by a chime and the new code number will appear for 1 second.



Repeat this process to reprogram the second factory pre-set code.

Your new code is now ready to use and the previous code is erased from memory. If you wish to change your new code, simply repeat the process with current active user code(s) and enter new code(s).


### TO OPEN THE SAFE USING NEW USER CODE(S):

Repeat the process described in **STEP 3: UNLOCK AND OPEN SAFE**, substituting the new user code(s) for the factory preset user code(s)

## SECURITY FEATURES

### PRIVACY MODE:

If you wish to prevent your personal code from being read on the digital readout, it can be hidden from view by inserting the **"\*"** after **"#"**.  
**Example:** **"# \* 1 2 3 4 #"**.



### INCORRECT CODE ENTRY:

If an incorrect code is entered, the word **"ERROR"** will appear on the digital readout and an alert tone will sound. At this time, re-enter the correct code.




### SECURITY LOCKOUT PERIOD:

If an incorrect code is entered (3) times, the system will enter lockout mode for 5 minutes.

The LCD will read **"HOLD-05"** showing the minutes remaining. During the first minute the security alarm will sound. During the entire 5-minute period, the safe cannot be entered.

If incorrect codes continue to be entered once the first five minute period has finished, a new 15-minute lockout period will begin and the alarm will sound during the first minute.



### SECURITY ALARM:

This safe is equipped with a security alarm. To activate alarm, press **"0"** with door closed.

Display will read **"ALERT-ON"**.



The alarm will sound whenever:

- The wrong code is entered 3 or more times to gain entry
- The safe is tilted more than 20° degrees
- The safe is shaken or experiences forceful impact.

To de-activate alarm or turn off alarm siren, enter an active user code.

## SECURITY FEATURES

### HISTORICAL ENTRY DATA RETRIEVAL

This safe has the ability to record into memory up to 50 entry records of those gaining access to the safe. To retrieve this data, do the following:

Enter user code 1 or user code 2 and display will read **"OPEN"**.



Immediately press **"0"** to view history beginning with the most recent event. To view previous events, continue pressing **"0"** to view up to 50 entries.

#### EXAMPLE

Press <b>0</b>		
	User Code 1 accessed on	June 29 <sup>th</sup> , 2010 at 4:17 pm
Press <b>0</b> Again		
	User Code 1 accessed on	June 28 <sup>th</sup> , 2010 at 10:49 am
Press <b>0</b> Again		
	User Code 1 accessed on	June 27 <sup>th</sup> , 2010 at 4:17 pm
	Etc.	

## LOST ENTRY CODE

If you have lost or forgotten the active user code(s), you must contact consumer assistance to receive authorization and instructions for reprogramming code(s).

## EMERGENCY ACCESS

### OPEN SAFE WITH EMERGENCY ACCESS KEY

If you have forgotten your personal access code or the electronic lock is not functioning properly, you can use the Emergency Override Key to gain access.


1. The emergency override lock is located behind the batteries under the round digital keypad housing. To gain access, lift the dust cover, rotate the housing to the left (counterclockwise) and carefully pull it forward and down.



2. Temporarily remove the batteries and insert the emergency override key into the lock (K) and turn it clockwise to the right.



3. Rotate the handle upwards and pull the door open.



4. Remove the key and replace the 4-AA batteries. Reposition the digital keypad housing into the locking holes and rotate the housing to the right (clockwise).



5. Follow Step 3 (Setting New Personal Entry Code) to re-set your code and test as instructed.

## ORDERING NEW KEYS

If a key is lost or you would like additional keys, you must first contact our Consumer Assistance Department to verify ownership.

You need to provide the following:

- Safe Serial Number
- Number of keys requested
- Name / Address / Telephone
- E-mail address if available

To order by telephone, call us toll-free at: **1-877-354-5457** (USA & Canada)  
Monday - Friday / 7am - 5pm PST

After speaking with a representative you may order keys via mail by sending the above information with a check or money order for \$12.00 (U.S. funds) to:

Consumer Assistance Dept.  
LH Licensed Products, Inc.,  
860 East Sandhill Avenue,  
Carson, CA 90746 USA

We do accept Visa and MasterCard payments for orders received by telephone. Express Delivery available for additional charge.

*Subject to change without prior notification.*

## SAFE SERIAL NUMBER

Whenever contacting our Consumer Assistance Department, you will need to provide them with the serial number of your safe. The serial number tag is located on the lower right corner on the front of the safe.



**IMPORTANT:** Do Not Remove Tags! This is needed if your safe fails or you lose your keys.

## CONSUMER ASSISTANCE

Contact us by mail at the following address:

Consumer Assistance Dept.  
LH Licensed Products, Inc.,  
860 East Sandhill Avenue,  
Carson, CA 90746 USA

Contact us by telephone (toll-free) at:

**1-877-354-5457**  
(USA & Canada)  
Monday–Friday  
7am - 5pm PST

## LIMITED WARRANTY

LH Licensed Products, Inc., ("LHLP, Inc.") warrants that for a period of seven (7) years from the date of purchase, this product will be free from structural or mechanical defects resulting from materials or workmanship. LHLP, Inc., at its sole option and as the purchaser's sole remedy under this warranty, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement or repair will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. THIS IS YOUR EXCLUSIVE WARRANTY.

This warranty is only valid for the original retail purchaser from the date of initial retail purchase and is not transferable. You must keep the original sales receipt. Proof of purchase is required to obtain warranty service.

LHLP, Inc. dealers, service centers, or retail stores selling this product do not have the right to alter, modify or in any way change the terms and conditions of this warranty.

This warranty does not apply to the finish on the product. This warranty does not cover normal wear and tear of parts or damage resulting from any of the following: negligent use or misuse of the product, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than LHLP, Inc. or an authorized service center, improper installation, or exposure to extremes of heat or humidity. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes.

LHLP, Inc. shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty or otherwise relating to the sale of this product. LHLP, Inc. is also not responsible for: costs associated with removing or installing the product; damage or loss of the contents of the product; nor for the unauthorized removal of the contents; or damages incurred during shipment.

THE ABOVE WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND LHLP, INC. DISCLAIMS ANY AND ALL OTHER COVENANTS AND WARRANTIES.

Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty period. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state, or province to province, or jurisdiction to jurisdiction.

## LIFETIME AFTER-FIRE REPLACEMENT GUARANTEE

If this Honeywell UL classified fire resistant product was purchased from LH Licensed Products, Inc. ("LHLP") and is damaged by fire at any time while still owned by you (the original owner), LHLP will ship a free replacement if you send the following to Customer Service, LH Licensed Products, Inc., 860 E. Sandhill Ave., Carson, CA 90746 USA:

1. Your name, mailing address, email address, and phone number with area code;
2. A description of the fire, the model number and a photo of the burned unit, and a copy of the report from the fire department, insurance or police.

Freight on the replacement unit is not included in the guarantee and must be paid by the consumer. If an identical product is no longer available, LHLP will provide a similar unit from its current product line. LHLP is not responsible for any loss or damage to the contents of the safe.

## **GARANTIE DE REMPLACEMENT À VIE APRÈS INCENDIE**

Si ce produit Honeywell résistant au feu classifié UL a été acheté à LH Licensed Products, Inc ("LHLP") et est endommagé par un incendie à un quelconque moment et vous appartient toujours (le propriétaire d'origine), LHLP expédiera gratuitement un remplacement si vous envoyez ce qui suit au Service Client de LH Licensed Products, Inc., 860 E. Sandhill Ave., Carson, CA 90746 USA :

1. Votre nom, adresse postale, adresse courriel et numéro de téléphone avec l'indicatif régional.
2. Une description de l'incendie, le numéro du modèle, une photo de l'unité brûlée et une copie du rapport du service des pompiers, de l'assurance et de la police.

Le fret de l'unité de remplacement n'est pas compris dans la garantie et doit être payé par le consommateur.

Si un produit identique n'est plus disponible, LHLP fournira une unité similaire de sa gamme actuelle de produits.

LHLP n'est pas responsable de toute perte ou dommage du contenu du coffre-fort.

## **GARANTÍA DE REEMPLAZO DURANTE TODA LA VIDA DESPUÉS DE INCENDIO**

Si se trata de un producto de Honeywell resistente al fuego, clasificado por los UL, comprado de LH Licensed Products, Inc. ("LHLP"), y el fuego lo ha dañado en algún momento, mientras todavía era de su propiedad (el propietario original), LHLP se lo reemplazará sin ningún costo, enviando la siguiente información a Customer Service, LH Licensed Products, Inc., 860 E. Sandhill Ave., Carson, CA 90746 USA:

1. Su nombre, dirección postal, dirección e-mail y número de teléfono con el código de área;
2. Descripción del incendio, número del modelo y fotografía de la unidad quemada, junto con una copia del reporte del departamento de bomberos, o de la empresa de seguros o de la policía.

No se incluye en la garantía el flete para reemplazar la unidad y lo debe pagar el consumidor.

En caso que ya no dispongamos de un producto igual, LHLP le enviará una unidad similar, de nuestra línea de productos actuales.

LHLP no se responsabiliza por ninguna pérdida o daños ocurridos al contenido de la caja fuerte.