

.REP a

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42

IDENTIFICATION

PRODUCT CODE: AC-F612J-MC
PRODUCT NAME: CKKTBD0 11/44 MEM MGMT PRT B
DATE: JANUARY, 1982
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: DAN P. MILLEVILLE

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1979, 1982 BY DIGITAL EQUIPMENT CORPORATION

43
44
45
46
47
48
49
50
51
52
53
54
55

PROGRAM HISTORY

DATE	REVISION	REASON FOR REVISION
OCTOBER, 1979	A	FIRST RELEASE
DECEMBER, 1979	B	ADDITION OF 'CSM' TEST 35
APRIL, 1981	C	USING NEW SYSMAC WITH ^Q CHECKS AND BIT CHECK OF THE POWER MONITOR BIT OF CPUERR REGISTER. MODIFIED CODE TO ACCOMODATE ECO # 8.
JANUARY, 1982	D	ECO # 8 WAS MODIFIED, CODE CHANGED TO REFLECT THE MODIFICATION.

TABLE OF CONTENTS

56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88

1.0	PROGRAM INFORMATION
1.1	ABSTRACT
1.2	REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	PRELIMINARY PROGRAMS
2.0	OPERATING INSTRUCTIONS
2.1	LOADING PROCEDURES
2.2	STARTING PROCEDURES
2.3	OPERATIONAL SWITCH SETTINGS
2.4	LOADING THE SWITCH REGISTER
2.5	EXECUTION TIMES
3.0	ERROR INFORMATION
3.1	ERROR REPORTING PROCEDURES
3.2	INTERPRETING ERROR REPORTS
3.3	SAMPLE ERROR REPORT
3.4	POWER MONITOR BIT ERRORS
4.0	MISCELLANEOUS INFORMATION
4.1	ACT/APT/XXDP COMPATABILITY
4.2	END-OF-PASS MESSAGE
4.3	T-BIT TRAPPING
4.4	POWER FAILURE HANDLING
4.5	PHYSICAL BUS ADDRESS CONSTRUCTION
5.0	PROGRAM DESCRIPTION
5.1	SUBROUTINES USED BY THIS PROGRAM
5.2	PROGRAM LISTING
5.3	USING THE PROGRAM TO DIAGNOSE A FAULT

90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140

1.0 PROGRAM INFORMATION

1.1 ABSTRACT

THIS PROGRAM WAS DESIGNED USING A 'BOTTOM UP' APPROACH STARTING WITH THE SMALLEST SEGMENT OF MEMORY MANAGEMENT LOGIC POSSIBLE AND BUILDING TO COVER ALL OF THE LOGIC. THE DIAGNOSTIC WILL PROVIDE ENOUGH INFORMATION SUCH THAT BY DEDUCTION, THE FAILURE CAN BE ISOLATED TO A SMALL SEGMENT OF THE MEMORY MANAGEMENT LOGIC.

PART A BEGINS BY TESTING SOME OF THE INTERNAL CPU DATA AND ADDRESS PATHS AND ADDRESS DETECTION LOGIC, THEN WORKS OUTWARD THROUGH THE MEMORY MANAGEMENT REGISTERS. AFTER THE REGISTERS ARE FOUND TO BE USEABLE, RELOCATION (CONSTRUCTION OF PHYSICAL ADDRESSES FROM A VIRTUAL ADDRESS AND THE ASSOCIATED PAR/PDR INFORMATION) IS TESTED. PART B BEGINS BY TESTING THE ABORT AND STATUS SEGMENTS OF LOGIC. PART B THEN CHECKS THE SPECIAL ABORT SEQUENCES, THE MFPI/MTPI INSTRUCTIONS AND THE CSM INSTRUCTION.

1.2 REQUIREMENTS

A PDP 11/44 PROCESSOR WITH A MINIMUM OF 16K OF MEMORY AND A CONSOLE TERMINAL ARE REQUIRED TO RUN THE PROGRAM UNLESS THE PROGRAM IS RUNNING UNDER APT OR ACT IN WHICH CASE THE CONSOLE TERMINAL IS NOT NECESSARY.

1.3 RELATED DOCUMENTS AND STANDARDS

1. ACT11/XXDP PROGRAMMING SPECIFICATION
2. STANDARD APT SYSTEM TO A PDP11 DIAGNOSTIC INTERFACE
3. DIAGNOSTIC ENGINEERING STANDARDS AND CONVENTIONS
4. PDP11 MAINDEC SYSMAC PACKAGE
5. XXDP USER'S MANUAL

1.4 PRELIMINARY PROGRAMS

BEFORE THIS MEMORY MANAGEMENT DIAGNOSTIC IS RUN, THE FOLLOWING DIAGNOSTICS SHOULD BE RUN:

CKKAAAO 11/4 CPU/EIS
CKKABAO TRAPS

ALSO, THE MAIN MEMORY DIAGNOSTIC (CZMSD) SHOULD BE RUN TO SCAN AT LEAST THE FIRST 16K TO SEE THAT A PROGRAM CAN BE EXECUTED.

141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169

2.0 OPERATING INSTRUCTIONS

2.1 LOADING PROCEDURES

THE PROGRAM IS SUPPLIED ON THE DIAGNOSTIC LOAD MEDIA. REFER TO THE XXDP USER'S MANUAL FOR FURTHER INFORMATION. FOR USE WITH ACT OR APT, REFER TO THEIR RESPECTIVE DOCUMENTS. THE PROGRAM CAN ALSO BE DIRECTLY LOADED USING THE ABSOLUTE LOADER AND THE BINARY PAPER TAPE.

2.2 STARTING PROCEDURES

THE PROGRAM IS STARTED BY LOADING ADDRESS 200 AND STARTING. THE SWITCH REGISTER SHOULD BE SET ACCORDING TO SECTION 2.3 BEFORE THE PROGRAM IS STARTED. HOWEVER, IF DESIRED, THE PROGRAM WILL USE THE SOFTWARE SWITCH REGISTER AT LOCATION 176 (LOCATION 174 WILL BE USED AS THE SOFTWARE DISPLAY REGISTER). IN THAT CASE, THE PROGRAM WILL ASK FOR THE INITIAL SWITCH REGISTER VALUE BY TYPING 'SWR= XXXXXX NEW= ' AFTER TYPING THE NAME OF THE PROGRAM (XXXXXX = THE OCTAL CONTENTS OF LOCATION 176). (SEE SECTION 2.4)

ALSO THE PROGRAM CAN BE MADE TO USE THE SOFTWARE SWITCH REG. EVEN IF THE CONSOLE SWITCH REG. IS PRESENT BY LOADING '177777' INTO THE CONSOLE SWITCH REG. BEFORE STARTING THE PROGRAM.

217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265

2.4 LOADING THE SWITCH REGISTER

THE CONSOLE SWITCH REGISTER PROVIDED IS LOADED DIRECTLY FROM THE CONSOLE BY TYPING A CONTROL P (^P), THEN WHEN THE CONSOLE PROMPT IS RECIEVED, TYPE 'D SW XXXXXX', WHERE 'XXXXXX' IS THE INTENDED VALUE OF THE SWITCH REGISTER. THE VALUE OF THE CONSOLE SWITCH REG. CAN BE CHANGED ANY TIME WHETHER THE PROGRAM IS RUNNING OR NOT.

TO LOAD THE SOFTWARE SWITCH REG. WHILE THE PROGRAM IS RUNNING, A CONTROL G (^G) SHOULD BE TYPED ON THE CONSOLE TERMINAL. (THE 'SCOPE' AND 'ERROR' ROUTINES CHECK TO SEE IF A ^G HAS BEEN TYPED.) THE ORIGINAL VALUE OF THE SOFTWARE SWTICH REG. WILL BE REQUESTED AS MENTIONED IN SECTION 2.2.

IN RESPONSE TO A ^G OR AT THE BEGINNING OF THE PROGRAM, THE PROGRAM WILL TYPE:

SWR = XXXXXX NEW =

WHERE 'XXXXXX' IS THE CURRENT OCTAL CONTENTS OF LOC. 176. THE OPERATOR MAY THEN TYPE ANY ONE OF THE FOLLOWING:

- XXXXXX<CR> ONE TO SIX OCTAL DIGITS FOLLOWED BY A CARRIAGE RETURN WHICH WILL BE LOADED AS THE NEW VALUE FOR THE SWITCH REG.
- <CR> JUST A <CR>, LEAVES THE SWITCH REG. AS IT IS.
- XXX^U A CONTROL-U (^U) WILL CAUSE ALL OF THE DIGITS TYPED SO FAR TO BE IGNORED.
- ^C WILL CAUSE THE PROGRAM TO TYPE THE PRESENT TEST AND PASS NUMBERS, REQUEST A NEW VALUE FOR THE SWITCH REG., AND JUMP TO THE END-OF-PASS ROUTINE SO THE PROGRAM WILL GO DIRECTLY TO THE NEXT PASS WITH A NEW SW. REG. VALUE
- <ILL.CHAR> ANY CHARACTER TYPED WHICH IS NOT ANY OF THE ABOVE OR AN OCTAL DIGIT WILL CAUSE THE PROGRAM TO TYPE A '?<CRLF>' AND REACT AS THOUGH A ^U HAD BEEN TYPED.

NOTE: RECOGNITION OF A ^G MAY BE HAMPERED BY
----- EXECUTION OF A COUPLE 'RESET' INSTRUCTIONS
WITHIN THE PROGRAM.

2.5 EXECUTION TIMES

THE RUN TIME FOR A SINGLE PASS WITH TRACE TRAPPING ENABLED IS APPROXIMATELY 5 SECONDS WITH CACHE.

266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312

3.0 ERROR INFORMATION

3.1 ERROR REPORTING PROCEDURES

IF AN ERROR IS DETECTED, THE PROGRAM WILL TRAP TO THE ERROR HANDLING ROUTINE (\$ERROR). THE VALUE OF BITS 15,13,10, AND 9 IN THE SWITCH REGISTER ARE CONSIDERED IN REPORTING AN ERROR (SEE SECTION 2.3). THE ERROR INFORMATION WILL BE TYPED UNLESS SW13 = 1.

IF SW15 = 1, THE PROCESSOR WILL HALT AFTER THE ERROR IS REPORTED. IF THE CONTENTS OF THE SOFTWARE SWITCH REGISTER ARE TO BE CHANGED, A ^G SHOULD BE TYPED BEFORE PRESSING 'CONTINUE' TO RESUME TESTING.

IF SW9 = 1 (LOOP ON ERROR), THE PROGRAM WILL GO TO THE ADDRESS CONTAINED IN LOCATION '\$LPERR'. AFTER REPORTING THE ERROR, '\$LPERR' IS SET BY EACH 'SCOPE' CALL AND IS SET DIRECTLY DURING SOME SUBTESTS TO PROVIDE THE SMALLEST LOOP FOR LOOPING ON ERROR. IF SW9 = 0, THE PROGRAM WILL RETURN TO THE INSTRUCTION FOLLOWING THE ERROR CALL. (SEE SECTION 5.3 FOR MORE ON 'LOOP ON ERROR').

3.2 INTERPRETING ERROR REPORTS

EVERY ERROR REPORT TYPES THE NUMBER OF THE TEST IN WHICH THE ERROR TOOK PLACE (TESTNO) AND THE LOCATION OF THE ERROR CALL (ERRORPC). THESE TWO VALUES PINPOINT THE PLACE IN THE CODE THAT THE ERROR OCCURRED. BY REFERRING TO THE PROGRAM LISTING, THE OPERATOR CAN THEN READ THE COMMENTS ASSOCIATED WITH THAT PARTICULAR ERROR AND SUBTEST. A DESCRIPTION OF THE TEST FOUND IN THE PROGRAM LISTING WILL ALSO PROVIDE THE OPERATOR WITH INFORMATION ON THE LOGIC AND FUNCTIONS BEING TESTED.

EVERY ERROR REPORT ALSO TYPES AN ERROR MESSAGE GIVING A VERBAL DESCRIPTION OF THE ERROR THAT HAS BEEN DETECTED.

BY USING THE COMMENTS AND TEST DESCRIPTION FOUND IN THE PROGRAM LISTING TO DETERMINE WHAT FUNCTION OR LOGIC WAS BEING TESTED, THE OPERATOR CAN THEN REFER TO THE ENGINEERING DRAWINGS TO ISOLATE THE PROBABLE CAUSE FOR THE FAILURE.

3.3 SAMPLE ERROR REPORT

BELOW IS AN EXAMPLE OF AN ERROR WHICH COULD HAVE OCCURRED DURING EXECUTION OF THE PROGRAM:

MEM. MGMT. REG. BITS NOT SET CORRECTLY					
REGISTR WROTE	READ	READ-(BINARY)			
ADDRESS (OCTAL)	(OCTAL)	5432109876543210	TESTNO	ERRORPC	
177572	040000	060000	0110000000000000	000012	022060

WE SEE THAT THE ERROR OCCURRED IN TEST 12 AT LOCATION 022060. THE 'REGISTER ADDRESS' TELLS US THAT WE WERE TESTING MEMORY MANAGEMENT'S STATUS REGISTER 0 (SRO). IN THE LISTING, THE TEST DESCRIPTION SAYS THAT THE ERROR BITS (BITS <15:13>) OF SRO WERE BEING SET AND CLEARED INDIVIDUALLY. THE ERROR REPORT SAYS WE TRIED TO SET BIT 14 BY WRITING '040000' TO SRO BUT WHEN WE READ IT BACK WE READ '060000'. IT APPEARS THAT BIT 13 IS STUCK AT '1' OR IT IS GETTING SET WHEN BIT 14 IS SET TO '1'. ERROR REPORTS BEFORE AND AFTER THIS ONE COULD TELL US WHICH IS THE CASE.

3.4 POWER MONITOR BIT ERRORS

WHEN THE POWER MONITOR BIT (BIT 0 OF THE CPU ERROR REGISTER) BECOMES SET DURING THE RUNNING OF THIS DIAGNOSTIC, THE \$SCOPE ROUTINE WILL CALL AN ERROR. IF THE BIT SHOULD BECOME SET AFTER THE \$SCOPE ROUTINE AND BEFORE AN ERROR, AND THE ERROR IS CALLED FOR ANY REASON, THE ERROR ROUTINE WILL CALL *TWO* ERRORS. THE FIRST ERROR WILL BE THE POWER MONITOR BIT ERROR CALL, THEN THE ERROR CALL ORIGINALLY CALLED WILL BE PRINTED. IN ANY CASE, LOOP-ON-ERROR IS DISABLED FOR THIS ERROR ONLY. IT IS RECOMMENDED THAT IF THIS ERROR SHOULD BE CALLED, THAT THE PROBLEM CAUSING THE BIT TO BE SET BE REPAIRED BEFORE RELYING ON THE RESULTS OF RUNNING THIS DIAGNOSTIC.

349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388

4.0 MISCELLANEOUS INFORMATION

4.1 ACT/APT/XXDP COMPATABILITY

THE PROGRAM IS FULLY ACT AND APT COMPATABLE
AND IS SUPPORTED UNDER THE XXDP PACKAGE.

4.2 END-OF-PASS MESSAGE

AT THE END OF EACH PASS OF THE PROGRAM THE PASS NUMBER
AND TOTAL NUMBER OF ERRORS SINCE THE LAST END-OF-PASS ARE
REPORTED IN THE END-OF-PASS MESSAGE. FOR EXAMPLE:

END OF PASS #2 TOTAL ERRORS SINCE LAST REPORT 0

THAT WOULD INDICATE THAT PASS TWO WAS JUST COMPLETED
AND NO ERRORS WERE DETECTED DURING THAT PASS. BOTH
THE PASS NUMBER AND NUMBER OF ERRORS ARE DECIMAL NUMBERS.

4.3 T-BIT TRAPPING


THE "T-BIT" (BIT 4) IN THE PROCESSOR STATUS WORD IS SET
BY AN "RTI" IN THE END-OF-PASS ROUTINE FOR EVERY OTHER PASS
BEGINNING WITH THE THIRD PASS (PASSES 3,5,7,9...). T-BIT
TRAPPING CAN BE INHIBITED BY SETTING BIT 12 = 1 IN THE SWITCH
REGISTER (SEE SECTION 2.4).

4.4 POWER FAILURE HANDLING

IF A POWER FAIL OCCURS (FOLLOWED BY A POWER UP), THE
MESSAGE "POWER FAILURE-RESTARTING" IS TYPED OUT AND
THE PROGRAM WILL RESTART EXECUTION AT "START:" (THE
VERY BEGINNING OF THE PROGRAM. IF THE SOFTWARE
SWITCH REGISTER IS BEING USED, ITS CONTENTS WILL BE
RESTORED.

4.5 PHYSICAL BUS ADDRESS CONSTRUCTION

BELOW IS A SIMPLIFIED DIAGRAM OF HOW THE MEMORY MANAGEMENT LOGIC CONSTRUCTS A PHYSICAL BUS ADDRESS USING THE VIRTUAL ADDRESS AND THE PAGE ADDRESS REGISTER. THE PAGE DESCRIPTOR REGISTER SELECTED WILL CONTAIN THE PAGE EXPANSION, LENGTH, AND ACCESS INFORMATION.



*= VBA BITS <15:13> SELECT THE APPROPRIATE PAR AND PDR
 **= PSW MODE BITS <15:14> SELECTS THE USER (=11), SUPERVISOR (=01) OR KERNEL (=00) SET OF PAR'S/PDR'S

389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419

420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453

5.0 PROGRAM DESCRIPTION

5.1 SUBROUTINES USED BY THIS PROGRAM

FOLLOWING IS A LIST OF THE SUBROUTINES AND HANDLERS USED BY THIS PROGRAM THAT ARE NOT PROVIDED BY THE 'SYSMAC PACKAGE'. DETAILS OF THE SUBROUTINES UNIQUE TO THIS PROGRAM MAY BE FOUND IN THE PROGRAM LISTING. REFER TO THE 'SYSMAC' DOCUMENT AND PROGRAM LISTING FOR THE OTHER ROUTINES.

1. TURN OFF T-BIT AND SAVE CURRENT PSW
2. TURN ON T-BIT AND RESTORE PREVIOUS PSW
3. SET ALL WRITEABLE BITS IN ALL PAR/PDR'S
4. CONVERT VIRTUAL ADDRESS TO PHYSICAL ADDRESS

NOTE ALSO THAT THE MACRO LIBRARY USED TO ASSEMBLE THIS PROGRAM HAS OTHER SPECIAL ROUTINES APPENDED TO THE SYSMAC MACRO PACKAGE; THIS LIBRARY MUST BE USED TO ASSEMBLE EITHER PART A OR PART B CORRECTLY.

5.2 PROGRAM LISTING

A TABLE OF CONTENTS APPEARS AT THE BEGINNING OF THE LISTING WHICH CONTAINS THE NAMES OF EACH SECTION, SUBTEST, AND ROUTINE AND THE LINE NUMBERS CORRESPONDING TO THE START OF EACH.

FOLLOWING THIS SECTION OF DOCUMENTATION IS THE ACTUAL PROGRAM LISTING COMPLETE WITH SUBTEST DESCRIPTIONS AND 'CODING COMMENTS'.

454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487

5.3 USING THE PROGRAM TO DIAGNOSE A FAULT

WHEN AN ERROR OCCURS, ONE OF THE THINGS THAT'S IMPORTANT TO NOTE IS WHAT PASS THE ERROR OCCURRED ON. IF THE PASS NUMBER IS ODD AND IS THREE OR GREATER, THE ERROR MIGHT BE T-BIT SENSITIVE. TRY RUNNING THE PROGRAM AGAIN WITH BIT 12 OF THE SWITCH REG. EQUAL TO '1' TO INHIBIT T-BIT TRAPPING. THIS SHOULD HELP YOU DETERMINE WHAT MAKES THE MACHINE FAIL AND WHEN.

IF YOU HAVE BEEN RUNNING WITH BIT 15 OF THE SWITCH REG. EQUAL TO '0', THEN YOU ARE ABLE TO LOOK AT ALL THE ERRORS THAT MAY BE RELATED TO THE FAULT YOU ARE DIAGNOSING. A FAULT IN AN EARLIER TEST MAY RESULT IN ERRORS DURING LATER TESTS WHICH MAY GIVE YOU MORE CLUES ABOUT THE NATURE OF THE FAULT. NOW USE THE METHOD OUTLINED IN SECTION 3.2 FOR EACH ERROR TO GATHER AS MUCH INFORMATION AS POSSIBLE.

NOW TO TEST YOUR IDEAS ON THE CAUSE OF THE FAILURE, YOU MAY WANT TO SCOPE THIS ERROR CONDITION. SET BIT 09 OF THE SWITCH REG. EQUAL TO '1' TO LOOP ON THE ERROR. FOR AN EVEN TIGHTER SCOPE LOOP THE ERROR CALL CAN BE REPLACED WITH A BRANCH (REFER TO COMMENTS BY ERROR CALLS IN THE PROGRAM LISTING).

OR YOU COULD LOOP ON THE TEST BY EITHER SETTING BIT 14 OF THE SWITCH REG. EQUAL TO '1' OF BY SETTING BIT 08 OF THE SWITCH REG. EQUAL TO '1' AND THEN SETTING THE TEST NUMBER IN BITS 07-00 OF THE SWITCH REG. YOU WILL PROBABLY WANT TO INHIBIT ERROR TYPEOUTS BY SETTING BIT 13 OF THE SWITCH REG. EQUAL TO '1'.

a

1194
1195

```
.TITLE CKKTBD0 11/44 MEM MGMT PRT B
;*COPYRIGHT (C) 1982
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;*
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C5), JAN, 1981.
;*

```

1196

```
.SBTTL OPERATIONAL SWITCH SETTINGS
;*
;* SWITCH USE
;* -----
;* 15 HALT ON ERROR
;* 14 LOOP ON TEST
;* 13 INHIBIT ERROR TYPEOUTS
;* 12 INHIBIT TRACE TRAP
;* 10 BELL ON ERROR
;* 9 LOOP ON ERROR
;* 8 LOOP ON TEST IN SWR<7:0>

```

1197

001100
104000
000004

```
.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100
ERROR=EMT
SCOPE=IOT

```

000011
000012
000015
000200
177776
177776
177774
177772
177570
177570

```
;*MISCELLANEOUS DEFINITIONS
HT= 11 ;;CODE FOR HORIZONTAL TAB
LF= 12 ;;CODE FOR LINE FEED
CR= 15 ;;CODE FOR CARRIAGE RETURN
CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776 ;;PROCESSOR STATUS WORD
PSW=PS
STKLMT= 177774 ;;STACK LIMIT REGISTER
PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
DSWR= 177570 ;;HARDWARE SWITCH REGISTER
DDISP= 177570 ;;HARDWARE DISPLAY REGISTER

```

000000
000001
000002
000003
000004
000005
000006
000007
000006
000007

```
;*GENERAL PURPOSE REGISTER DEFINITIONS
R0= %0 ;;GENERAL REGISTER
R1= %1 ;;GENERAL REGISTER
R2= %2 ;;GENERAL REGISTER
R3= %3 ;;GENERAL REGISTER
R4= %4 ;;GENERAL REGISTER
R5= %5 ;;GENERAL REGISTER
R6= %6 ;;GENERAL REGISTER
R7= %7 ;;GENERAL REGISTER
SP= %6 ;;STACK POINTER
PC= %7 ;;PROGRAM COUNTER

```

000000
000040
000100
000140
000200
000240
000300
000340

```
;*PRIORITY LEVEL DEFINITIONS
PR0= 0 ;;PRIORITY LEVEL 0
PR1= 40 ;;PRIORITY LEVEL 1
PR2= 100 ;;PRIORITY LEVEL 2
PR3= 140 ;;PRIORITY LEVEL 3
PR4= 200 ;;PRIORITY LEVEL 4
PR5= 240 ;;PRIORITY LEVEL 5
PR6= 300 ;;PRIORITY LEVEL 6
PR7= 340 ;;PRIORITY LEVEL 7

```

BASIC DEFINITIONS

```

: * "SWITCH REGISTER" SWITCH DEFINITIONS
100000 SW15= 100000
040000 SW14= 40000
020000 SW13= 20000
010000 SW12= 10000
004000 SW11= 4000
002000 SW10= 2000
001000 SW09= 1000
000400 SW08= 400
000200 SW07= 200
000100 SW06= 100
000040 SW05= 40
000020 SW04= 20
000010 SW03= 10
000004 SW02= 4
000002 SW01= 2
000001 SW00= 1
001000 SW9=SW09
000400 SW8=SW08
000200 SW7=SW07
000100 SW6=SW06
000040 SW5=SW05
000020 SW4=SW04
000010 SW3=SW03
000004 SW2=SW02
000002 SW1=SW01
000001 SW0=SW00

: * DATA BIT DEFINITIONS (BIT00 TO BIT15)
100000 BIT15= 100000
040000 BIT14= 40000
020000 BIT13= 20000
010000 BIT12= 10000
004000 BIT11= 4000
002000 BIT10= 2000
001000 BIT09= 1000
000400 BIT08= 400
000200 BIT07= 200
000100 BIT06= 100
000040 BIT05= 40
000020 BIT04= 20
000010 BIT03= 10
000004 BIT02= 4
000002 BIT01= 2
000001 BIT00= 1
001000 BIT9=BIT09
000400 BIT8=BIT08
000200 BIT7=BIT07
000100 BIT6=BIT06
000040 BIT5=BIT05
000020 BIT4=BIT04
000010 BIT3=BIT03
000004 BIT2=BIT02
000002 BIT1=BIT01
000001 BIT0=BIT00

: * BASIC "CPU" TRAP VECTOR ADDRESSES
000004 ERRVEC= 4 ;: TIME OUT AND OTHER ERRORS
000010 RESVEC= 10 ;: RESERVED AND ILLEGAL INSTRUCTIONS

```

1198

```
000014 TBITVEC=14 ;; 'T' BIT
000014 TRTVEC= 14 ;; TRACE TRAP
000014 BPTVEC= 14 ;; BREAKPOINT TRAP (BPT)
000020 IOTVEC= 20 ;; INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024 PWRVEC= 24 ;; POWER FAIL
000030 EMTVEC= 30 ;; EMULATOR TRAP (EMT) **ERROR**
000034 TRAPVEC=34 ;; 'TRAP' TRAP
000060 *KVEC= 60 ;; TTY KEYBOARD VECTOR
000064 TPVEC= 64 ;; TTY PRINTER VECTOR
000240 PIRQVEC=240 ;; PROGRAM INTERRUPT REQUEST VECTOR
.SBTTL MEMORY MANAGEMENT DEFINITIONS
;*KT11 VECTOR ADDRESS
000250 MMVEC= 250
;*KT11 STATUS REGISTER ADDRESSES
177572 SR0= 177572
177574 SR1= 177574
177576 SR2= 177576
172516 SR3= 172516
;*USER 'I' PAGE DESCRIPTOR REGISTERS
177600 UIPDR0= 177600
177602 UIPDR1= 177602
177604 UIPDR2= 177604
177606 UIPDR3= 177606
177610 UIPDR4= 177610
177612 UIPDR5= 177612
177614 UIPDR6= 177614
177616 UIPDR7= 177616
;*USER 'D' PAGE DESCRIPTOR REGISTERS
177620 UDPDR0= 177620
177622 UDPDR1= 177622
177624 UDPDR2= 177624
177626 UDPDR3= 177626
177630 UDPDR4= 177630
177632 UDPDR5= 177632
177634 UDPDR6= 177634
177636 UDPDR7= 177636
;*USER 'I' PAGE ADDRESS REGISTERS
177640 UIPAR0= 177640
177642 UIPAR1= 177642
177644 UIPAR2= 177644
177646 UIPAR3= 177646
177650 UIPAR4= 177650
177652 UIPAR5= 177652
177654 UIPAR6= 177654
177656 UIPAR7= 177656
;*USER 'D' PAGE ADDRESS REGISTERS
177660 UDPAR0= 177660
177662 UDPAR1= 177662
177664 UDPAR2= 177664
177666 UDPAR3= 177666
177670 UDPAR4= 177670
177672 UDPAR5= 177672
177674 UDPAR6= 177674
177676 UDPAR7= 177676
;*SUPERVISOR 'I' PAGE DESCRIPTOR REGISTERS
172200 SIPDR0= 172200
172202 SIPDR1= 172202
```



```
172204 SIPDR2= 172204
172206 SIPDR3= 172206
172210 SIPDR4= 172210
172212 SIPDR5= 172212
172214 SIPDR6= 172214
172216 SIPDR7= 172216
:*SUPERVISOR 'D' PAGE DESCRIPTOR REGISTERS
172220 SDPDR0= 172220
172222 SDPDR1= 172222
172224 SDPDR2= 172224
172226 SDPDR3= 172226
172230 SDPDR4= 172230
172232 SDPDR5= 172232
172234 SDPDR6= 172234
172236 SDPDR7= 172236
:*SUPERVISOR 'I' PAGE ADDRESS REGISTERS
172240 SIPAR0= 172240
172242 SIPAR1= 172242
172244 SIPAR2= 172244
172246 SIPAR3= 172246
172250 SIPAR4= 172250
172252 SIPAR5= 172252
172254 SIPAR6= 172254
172256 SIPAR7= 172256
:*SUPERVISOR 'D' PAGE ADDRESS REGISTERS
172260 SDPAR0= 172260
172262 SDPAR1= 172262
172264 SDPAR2= 172264
172266 SDPAR3= 172266
172270 SDPAR4= 172270
172272 SDPAR5= 172272
172274 SDPAR6= 172274
172276 SDPAR7= 172276
:*KERNEL 'I' PAGE DESCRIPTOR REGISTERS
172300 KIPDR0= 172300
172302 KIPDR1= 172302
172304 KIPDR2= 172304
172306 KIPDR3= 172306
172310 KIPDR4= 172310
172312 KIPDR5= 172312
172314 KIPDR6= 172314
172316 KIPDR7= 172316
:*KERNEL 'D' PAGE DESCRIPTOR REGISTERS
172320 KDPDR0= 172320
172322 KDPDR1= 172322
172324 KDPDR2= 172324
172326 KDPDR3= 172326
172330 KDPDR4= 172330
172332 KDPDR5= 172332
172334 KDPDR6= 172334
172336 KDPDR7= 172336
:*KERNEL 'I' PAGE ADDRESS REGISTERS
172340 KIPAR0= 172340
172342 KIPAR1= 172342
172344 KIPAR2= 172344
172346 KIPAR3= 172346
172350 KIPAR4= 172350
```

	172352	KIPAR5= 172352
	172354	KIPAR6= 172354
	172356	KIPAR7= 172356
		;*KERNEL 'D' PAGE ADDRESS REGISTERS
	172360	KDPAR0= 172360
	172362	KDPAR1= 172362
	172364	KDPAR2= 172364
	172366	KDPAR3= 172366
	172370	KDPAR4= 172370
	172372	KDPAR5= 172372
	172374	KDPAR6= 172374
	172376	KDPAR7= 172376
		;*ADDITIONAL DEFINITIONS
		;*
1199		
1200		
1201	177572	MMR0=SR0
1202	177574	MMR1=SR1
1203	177576	MMR2=SR2
1204	172516	MMR3=SR3
1205	000006	KSP=SP
1206	000006	SSP=SP
1207	000006	USP=SP
1208	000020	TBIT=BIT4
1209	000100	WBIT=BIT6
1210	177766	CPUERR=177766
1211	001100	KERSTK=STACK
1212	000700	SUPSTK=STACK-200
1213	000600	USESTK=STACK-300
1214		

1246
000000
000174 000174
000174 000000
000176 000000
000200 000137 020000

```
.SBTTL TRAP CATCHER
.=0
;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
.=174
DISPREG: .WORD 0          ;;SOFTWARE DISPLAY REGISTER
SWREG:   .WORD 0          ;;SOFTWARE SWITCH REGISTER
.SBTTL STARTING ADDRESS(ES)
JMP      @#START ;;JUMP TO STARTING ADDRESS OF PROGRAM
```

1247

.SBTTL ACT11 HOOKS

000046 000204
 000046
000052 036252
 000052
 000000
 000204

HOOKS REQUIRED BY ACT11
 \$SVPC= ;SAVE PC
 .=46
 \$ENDAD ;:1)SET LOC.46 TO ADDRESS OF \$ENDAD IN .SEOP
 .=52
 .WORD 0 ;:2)SET LOC.52 TO ZERO
 .=\$SVPC ;: RESTORE PC

1248

```
.SBTTL APT PARAMETER BLOCK
:*****
:SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
:*****
      . $X=      ;;SAVE CURRENT LOCATION
000024 000024  . =24      ;;SET POWER FAIL TO POINT TO START OF PROGRAM
      200      ;;FOR APT START UP
000044 000044  . =44      ;;POINT TO APT INDIRECT ADDRESS PNTR.
000044 000204  $APTHDR ;;POINT TO APT HEADER BLOCK
      000204  . =. $X      ;;RESET LOCATION COUNTER
:*****
:SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
:INTERFACE SPEC.
$APTHD:
$HIBTS: .WORD 0      ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
$MBADR: .WORD $MAIL  ;;ADDRESS OF APT MAILBOX (BITS 0-15)
$STMT:  .WORD 2      ;;RUN TIM OF LONGEST TEST
$PASTM: .WORD 5      ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
$UNITM: .WORD 5      ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
      .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)
```

1249

.SBTTL COMMON TAGS

*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.

```

001100      001100      .SCMTAG:      .=1100      ;;START OF COMMON TAGS
001100      000000      $STNM:      .BYTE      0      ;;CONTAINS THE TEST NUMBER
001102      000      $ERFLG:     .BYTE      0      ;;CONTAINS ERROR FLAG
001103      000      $ICNT:      .WORD      0      ;;CONTAINS SUBTEST ITERATION COUNT
001104      000000      $LPADR:     .WORD      0      ;;CONTAINS SCOPE LOOP ADDRESS
001106      000000      $LPERR:     .WORD      0      ;;CONTAINS SCOPE RETURN FOR ERRORS
001110      000000      $ERTL:      .WORD      0      ;;CONTAINS TOTAL ERRORS DETECTED
001112      000000      $ITEMB:     .BYTE      0      ;;CONTAINS ITEM CONTROL BYTE
001114      000      $ERMAX:     .BYTE      1      ;;CONTAINS MAX. ERRORS PER TEST
001115      001      $ERRPC:     .WORD      0      ;;CONTAINS PC OF LAST ERROR INSTRUCTION
001116      000000      $GDADR:     .WORD      0      ;;CONTAINS ADDRESS OF 'GOOD' DATA
001120      000000      $BDADR:     .WORD      0      ;;CONTAINS ADDRESS OF 'BAD' DATA
001122      000000      $GDDAT:     .WORD      0      ;;CONTAINS 'GOOD' DATA
001124      000000      $BDDAT:     .WORD      0      ;;CONTAINS 'BAD' DATA
001126      000000      .WORD      0      ;;RESERVED--NOT TO BE USED
001130      000000      .WORD      0
001132      000000      .WORD      0
001134      000      $AUTOB:     .BYTE      0      ;;AUTOMATIC MODE INDICATOR
001135      000      $INTAG:     .BYTE      0      ;;INTERRUPT MODE INDICATOR
001136      000000      .WORD      0
001140      177570      SWR:        .WORD      DSWR      ;;ADDRESS OF SWITCH REGISTER
001142      177570      DISPLAY:    .WORD      DDISP      ;;ADDRESS OF DISPLAY REGISTER
001144      177560      $TKS:       177560      ;;TTY KBD STATUS
001146      177562      $TKB:       177562      ;;TTY KBD BUFFER
001150      177564      $TPS:       177564      ;;TTY PRINTER STATUS REG. ADDRESS
001152      177566      $TPB:       177566      ;;TTY PRINTER BUFFER REG. ADDRESS
001154      000      $NULL:      .BYTE      0      ;;CONTAINS NULL CHARACTER FOR FILLS
001155      002      $FILLS:     .BYTE      2      ;;CONTAINS # OF FILLER CHARACTERS REQUIRED
001156      012      $FILLC:     .BYTE      12      ;;INSERT FILL CHARS. AFTER A 'LINE FEED'
001157      000      $TPFLG:     .BYTE      0      ;;'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
001160      000000      $REGAD:     .WORD      0      ;;CONTAINS THE ADDRESS FROM WHICH ($REG0) WAS OBTAINED

001162      000006      .REPT      $CM3
001164      000000      $REG0:     .WORD      0      ;;CONTAINS (($REGAD)+0)
001166      000000      $REG1:     .WORD      0      ;;CONTAINS (($REGAD)+2)
001170      000000      $REG2:     .WORD      0      ;;CONTAINS (($REGAD)+4)
001172      000000      $REG3:     .WORD      0      ;;CONTAINS (($REGAD)+6)
001174      000000      $REG4:     .WORD      0      ;;CONTAINS (($REGAD)+10)
001174      000000      $REG5:     .WORD      0      ;;CONTAINS (($REGAD)+12)
001176      000006      .REPT      6
001200      000000      $TMP0:     .WORD      0      ;;USER DEFINED
001202      000000      $TMP1:     .WORD      0      ;;USER DEFINED
001204      000000      $TMP2:     .WORD      0      ;;USER DEFINED
001206      000000      $TMP3:     .WORD      0      ;;USER DEFINED
001210      000000      $TMP4:     .WORD      0      ;;USER DEFINED
001212      000000      $TMP5:     .WORD      0      ;;USER DEFINED
001214      207      377      377      $ESCAPE:    0      ;;ESCAPE ON ERROR ADDRESS
001217      000      $BELL:      .ASCIIZ    <207><377><377> ;;CODE FOR BELL
001220      077      $QUES:      .ASCII     /?/      ;;QUESTION MARK
001221      015      $CRLF:      .ASCII     <15>      ;;CARRIAGE RETURN
001222      012      000      $LF:        .ASCIIZ    <12>      ;;LINE FEED
    
```

```
*****  
:SBTTL APT MAILBOX-ETABLE  
*****  
.EVEN  
001224 $MAIL: ;:APT MAILBOX  
001224 000000 $MSGTY: .WORD AMSGTY ;:MESSAGE TYPE CODE  
001226 000000 $FATAL: .WORD AFATAL ;:FATAL ERROR NUMBER  
001230 000000 $TESTN: .WORD ATESTN ;:TEST NUMBER  
001232 000000 $PASS: .WORD APASS ;:PASS COUNT  
001234 000000 $DEVCT: .WORD ADEVCT ;:DEVICE COUNT  
001236 000000 $UNIT: .WORD AUNIT ;:I/O UNIT NUMBER  
001240 000000 $MSGAD: .WORD AMSGAD ;:MESSAGE ADDRESS  
001242 000000 $MSGLG: .WORD AMSGLG ;:MESSAGE LENGTH  
001244 $ETABLE: ;:APT ENVIRONMENT TABLE  
001244 000 $ENV: .BYTE AENV ;:ENVIRONMENT BYTE  
001245 000 $ENVM: .BYTE AENVM ;:ENVIRONMENT MODE BITS  
001246 000000 $SWREG: .WORD ASWREG ;:APT SWITCH REGISTER  
001250 000000 $USWR: .WORD AUSWR ;:USER SWITCHES  
001252 000000 $CPUOP: .WORD ACPUOP ;:CPU TYPE,OPTIONS  
* ;BITS 15-11=CPU TYPE  
* ; 11/04=01,11/05=02,11/20=03,11/40=04,11/45=05  
* ; 11/70=06,PDQ=07,Q=10  
* ;BIT 10=REAL TIME CLOCK  
* ;BIT 9=FLOATING POINT PROCESSOR  
* ;BIT 8=MEMORY MANAGEMENT  
  
001254 $ETEND:  
.MEXIT  
  
001254 000000 TESTNO: .WORD 0 ;HOLDS TEST NUMBER FOR TYPEOUTS  
001256 000000 WASR6: .WORD 0 ;USED TO STORE THE STACK POINTER AFTER A TRAP  
001260 000000 TRAPPC: .WORD 0 ;USED TO STORE THE PC OF A TRAP OR ABORT  
001262 000000 TRAPPS: .WORD 0 ;USED TO STORE THE PS OF A TRAP OR ABORT  
001264 000000 WASSR0: .WORD 0 ;USED TO STORE CONTENTS OF SR0  
001266 000000 WASSR1: .WORD 0 ;USED TO STORE CONTENTS OF SR1  
001270 000000 WASSR2: .WORD 0 ;USED TO STORE CONTENTS OF SR2  
001272 000000 WASSR3: .WORD 0 ;USED TO STORE CONTENTS OF SR3  
001274 000000 TBITPS: .WORD 0 ;SAVES THE PSW THAT MAY HAVE ITS T-BIT ON  
001276 000000 VIRT1: .WORD 0 ;HOLDS VIRTUAL ADDRESS TO BE CONVERTED  
001300 000000 PBALO: .WORD 0 ;HOLDS BITS <15:00> OF PHYSICAL ADDRESS  
001302 000000 PBAHI: .WORD 0 ;HOLDS BITS <21:16> OF PHYSICAL ADDRESS  
001304 000000 BADPC: .WORD 0 ;HOLDS PC FROM ABORT OR TRAP  
001306 000200 $MXCNT: .WORD 200 ;HOLD MAX. NUMBER OF LOOP ITERATIONS  
001310 000000 $TBIT: .WORD 0 ;'T' BIT STATE INDICATOR  
001312 136 103 015 $CNTLC: .ASCIZ /*C/<15><12> ;CONTROL C  
001315 012 000  
  
.EVEN
```

.SBTTL ERROR POINTER TABLE

.*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
 .*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
 .*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
 .*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
 .*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
 .* EM ::POINTS TO THE ERROR MESSAGE
 .* DH ::POINTS TO THE DATA HEADER
 .* DT ::POINTS TO THE DATA
 .* DF ::POINTS TO THE DATA FORMAT

001320			\$ERRTB:		
1250			.*ITEM 1		
1251	001320	007522	EM1		:UNEXPECTED CPU TRAP TO LOC. 004
1252	001322	012672	DH1		:OLD PC OLD PSW R6 WAS CPUERR TESTNO ERRORPC
1253	001324	015306	DT1		:TRAPPC,TRAPPS,WASR6,CPUERR,TESTNO,\$ERRPC,0
1254	001326	016057	DF12		:0,0,0,0,0,0
1255					
1256			.*ITEM 2		
1257	001330	007562	EM2		:UNEXPECTED MEM. MGMT. TRAP TO LOC. 250
1258	001332	012752	DH2		:OLD PC OLD PSW R6 WAS SRO SR2 TESTNO ERRORPC
1259	001334	015324	DT2		:TRAPPC,TRAPPS,WASR6,WASSRO,WASSR2,TESTNO,\$ERRPC,0
1260	001336	016041	DF2		:0,0,0,0,0,0
1261					
1262			.*ITEM 3		
1263	001340	007631	EM10		:MEMORY MGMT. ACCESS ABORT DID NOT OCCUR
1264	001342	013042	DH10		:PDR 4 PSW TESTNO ERRORPC
1265	001344	015344	DT10		:\$REG2,\$TMPO,TESTNO,\$ERRPC,0
1266	001346	016050	DF3		:0,0,0,0
1267					
1268			.*ITEM 4		
1269	001350	007701	EM11		:ACCESS ERROR DID NOT ABORT INSTRUCTION
1270	001352	013042	DH10		:PDR 4 PSW TESTNO ERRORPC
1271	001354	015344	DT10		:\$REG2,\$TMPO,TESTNO,\$ERRPC,0
1272	001356	016050	DF3		:0,0,0,0
1273					
1274			.*ITEM 5		
1275	001360	007750	EM12		:SRO DID NOT REPORT ACCESS ERROR CORRECTLY
1276	001362	013102	DH12		:SRO WAS EXPECTD PDR 4 PSW TESTNO ERRORPC
1277	001364	015356	DT12		:WASSRO,\$REG3,\$REG2,\$TMPO,TESTNO,\$ERRPC,0
1278	001366	016057	DF12		:0,0,0,0,0,0
1279					
1280			.*ITEM 6		
1281	001370	010022	EM13		:SR2 DID NOT LOCKUP CORRECT VIRTUAL ADDR.
1282	001372	013162	DH13		:SR2 WAS EXPECTD PDR 4 PSW TESTNO ERRORPC
1283	001374	015374	DT13		:WASSR2,\$REG4,\$REG2,\$TMPO,TESTNO,\$ERRPC,0
1284	001376	016057	DF12		:0,0,0,0,0,0
1285					
1286			.*ITEM 7		
1287	001400	010073	EM14		:PAGE LGTH. ABORT OCCURRED WHEN IT SHOULDN'T HAVE
1288	001402	013242	DH14		:V.B.A. KIPDR4 SRO WAS SR2 WAS TESTNO ERRORPC
1289	001404	015412	DT14		:\$REG0,\$REG4,WASSRO,WASSR2,TESTNO,\$ERRPC,0
1290	001406	016057	DF12		:0,0,0,0,0,0

1291			:*ITEM 10	
1292	001410	010154	EM15	:PAGE LGTH. ABORT DID NOT OCCUR WHEN IT SHOULD HAVE
1293	001412	013322	DH15	:V.B.A. KIPDR4 TESTNO ERRORPC
1294	001414	015430	DT15	:\$REG0,\$REG4,TESTNO,\$ERRPC,0
1295	001416	016050	DF3	:0,0,0,0
1296				
1297			:*ITEM 11	
1298	001420	010237	EM16	:SRO DID NOT REPORT PAGE LGTH. ABORT CORRECTLY
1299	001422	013362	DH16	:V.B.A. KIPDR4 SRO WAS EXPECTD TESTNO ERRORPC
1300	001424	015442	DT16	:\$REG0,\$REG4,WASSRO,\$REG2,TESTNO,\$ERRPC,0
1301	001426	016057	DF12	:0,0,0,0,0,0
1302				
1303			:*ITEM 12	
1304	001430	010022	EM13	:SR2 DID NOT LOCKUP CORRECT VIRUAL ADDR.
1305	001432	013442	DH17	:V.B.A. KIPDR4 SR2 WAS EXPECTD TESTNO ERRORPC
1306	001434	015460	DT17	:\$REG0,\$REG4,WASSR2,\$REG3,TESTNO,\$ERRPC,0
1307	001436	016057	DF12	:0,0,0,0,0,0
1308				
1309			:*ITEM 13	
1310	001440	010022	EM13	:SR2 DID NOT LOCKUP CORRECT VIRUAL ADDR.
1311	001442	013522	DH20	:SR2 WAS EXPECTD TESTNO ERRORPC
1312	001444	015476	DT20	:WASSR2,\$REG1,TESTNO,\$ERRPC,0
1313	001446	016050	DF3	:0,0,0,0
1314				
1315			:*ITEM 14	
1316	001450	010315	EM21	:SRO OR SR2 CHANGED BY A SECOND ABORT
1317	001452	013562	DH21	:FIRST ABORT SECOND ABORT
1318				:SRO WAS SR2 WAS SRO WAS SR2 WAS TESTNO ERRORPC
1319	001454	015510	DT21	:\$TMP0,\$TMP2,WASSRO,WASSR2,TESTNO,\$ERRPC,0
1320	001456	016057	DF12	:0,0,0,0,0,0
1321				
1322			:*ITEM 15	
1323	001460	010362	EM22	:SRO OR SR2 WAS NOT 'RESET' BY A RESET
1324	001462	013677	DH22	:SRO WAS SR2 WAS TESTNO ERRORPC
1325	001464	015526	DT22	:WASSRO,WASSR2,TESTNO,\$ERRPC,0
1326	001466	016050	DF3	:0,0,0,0
1327				
1328			:*ITEM 16	
1329	001470	010431	EM23	:SR2 NOT TRACKING CORRECTLY
1330	001472	013522	DH20	:SR2 WAS EXPECTD TESTNO ERROPC
1331	001474	015476	DT20	:WASSR2,\$REG1,TESTNO,\$ERRPC,0
1332	001476	016050	DF3	:0,0,0,0
1333				
1334			:*ITEM 17	
1335	001500	010464	EM24	:DID NOT TRAP THRU KERNEL SPACE
1336	001502	013737	DH24	:PSW WAS R6 WAS TESTNO ERRORPC
1337	001504	015540	DT24	:\$REG1,\$REG2,TESTNO,\$ERRPC,0
1338	001506	016050	DF3	:0,0,0,0

1339			:*ITEM 20		
1340	001510	010523		EM25	:KT ERROR SERVICED ON ODD ADDR. ERROR
1341	001512	013522		DH20	:PDR TESTNO ERRORPC
1342	001514	015476		DT20	:\$REG5,TESTNO,\$ERRPC,0
1343	001516	016054		DF5	:0,0,0
1344					
1345			:*ITEM 21		
1346	001520	010570		EM26	:SRO OR SR2 CHANGED BY ODD ADDR. ERROR
1347	001522	013777		DH26	:EXPECTED RECEIVED
1348					:SRO SR2 SRO WAS SR2 WAS TESTNO ERRORPC
1349	001524	015552		DT26	:\$REG0,\$REG1,WASSRO,WASSR2,TESTNO,\$ERRPC,0
1350	001526	016057		DF12	:0,0,0,0,0,0
1351					
1352			:*ITEM 22		
1353	001530	010636		EM27	:ERROR DURING 'DOUBLE ERROR' (KT & ODD ADDR.)
1354	001532	014111		DH27	:EXPECTED:
1355					:PSW PC SRO SR2
1356					:170017 (3\$+4) 020147 (3\$)
1357					:RECEIVED
1358					:PSW PC SRO SR2 TESTNO ERRORPC
1359	001534	015570		DT27	:\$REG1,\$REG3,WASSRO,WASSR2,TESTNO,\$ERRPC,0
1360	001536	016057		DF12	:0,0,0,0,0,0
1361					
1362			:*ITEM 23		
1363	001540	010713		EM30	:MFPI INSTRUCTION PUSHED WRONG DATA
1364	001542	014306		DH30	:DATA DATA
1365					:EXPECTD RECEIVD TESTNO ERRORPC
1366	001544	015606		DT30	:\$REG0,\$REG1,TESTNO,\$ERRPC,0
1367	001546	016050		DF3	:0,0,0,0
1368					
1369			:*ITEM 24		
1370	001550	010756		EM31	:MTPI INSTRUCTION LOADED WRONG DATA
1371	001552	014306		DH30	:DATA DATA
1372					:EXPECTD RECEIVD TESTNO ERRORPC
1373	001554	015606		DT30	:\$REG0,\$REG1,TESTNO,\$ERRPC,0
1374	001556	016050		DF3	:0,0,0,0
1375					
1376			:*ITEM 25		
1377	001560	011021		EM32	:STACK NOT PUSHED BY MFPI-MTPI
1378	001562	014362		DH32	:TESTNO ERRORPC
1379	001564	015620		DT32	:TESTNO,\$ERRPC,0
1380	001566	016065		DF32	:0,0
1381					
1382			:*ITEM 26		
1383	001570	011057		EM33	:KERNEL PAGE ACCESSED INSTEAD OF USER: MFPI-MTPI
1384	001572	014401		DH33	:SRO WAS SR2 WAS TESTNO ERRORPC
1385	001574	015526		DT22	:WASSRO,WASSR2,TESTNO,\$ERRPC,0
1386	001576	016050		DF3	:0,0,0,0
1387					
1388			:*ITEM 27		
1389	001600	011135		EM34	:M.M. ABORT IN KERNAL D-SPACE HAD WRONG CONDITION
1390	001602	014441		DH34	:(MMR0) (MMR1) (MMR2) TESTNO ERRORPC EXPECTING 020031
1391	001604	015626		DT34	:\$REG1,\$REG2,\$REG3,TESTNO,\$ERRPC,0
1392	001606	016034		DF1	:0,0,0,0,0
1393					
1394			:*ITEM 30		
1395	001610	011216		EM35	:ILLEGAL MODE 10 NOT ABORTED

ERROR POINTER TABLE

1396	001612	014362
1397	001614	015620
1398	001616	016065

DH32
DT32
DF32

:TESTNO ERRORPC
:TESTNO,SERRPC,0
:0.0

1399			:*ITEM 31		
1400	001620	011252	EM36		:SRO DID NOT REPORT ILLEGAL MODE 10 CORRECTLY
1401	001622	014532	DH36		:SRO WAS EXPECTD TESTNO ERRORPC
1402	001624	015642	DT36		:WASSRO,\$REG1,TESTNO,\$ERRPC,0
1403	001626	016050	DF3		:0,0,0,0
1404					
1405			:*ITEM 32		
1406	001630	011327	EM37		:PSW CHANGED BY AN RTI IN USER MODE
1407	001632	014572	DH37		:PSW WAS EXPECTD TESTNO ERRORPC
1408	001634	015540	DT24		:\$REG1,\$REG2,TESTNO,\$ERRPC,0
1409	001636	016050	DF3		:0,0,0,0
1410					
1411			:*ITEM 33		
1412	001640	011372	EM40		:ABORT IN KERNAL D-SPACE PICKED UP VECTOR FROM I-SPACE
1413	001642	014632	DH40		:(PSW) TESTNO ERRORPC EXPECTING XXX340
1414	001644	015654	DT40		:\$REG0,TESTNO,\$ERRPC,0
1415	001646	016054	DF5		:0,0,0
1416					
1417			:*ITEM 34		
1418	001650	011457	EM41		:D SPACE ENABLE CIRCUITRY HAS FAILED
1419	001652	014703	DH41		:ERROR AUTOI/D VIRTUAL
1420					:REGISTR REGISTR ADDRESS TESTNO PC AT ABORT
1421	001654	015664	DT41		:WASSRO,WASSR1,WASSR2,TESTNO,BADPC,0
1422	001656	016034	DF1		:0,0,0,0,0
1423					
1424			:*ITEM 35		
1425	001660	011523	EM42		:INCORRECT STORE BY MTP INSTRUCTION
1426	001662	015007	DH42		:GDDATA STORED TESTNO ERRORPC
1427	001664	015700	DT42		:\$REG3,\$REG4,TESTNO,\$ERRPC,0
1428	001666	016050	DF3		:0,0,0,0
1429					
1430			:*ITEM 36		
1431	001670	011566	EM43		:TRIED TO REFERENCE NON-RESIDENT PAGE
1432	001672	015047	DH43		:(MMR0) (MMR1) (MMR2) TESTNO ERRORPC
1433	001674	015712	DT43		:\$REG0,\$REG1,\$REG2,TESTNO,\$ERRPC,0
1434	001676	016034	DF1		
1435					
1436			:*ITEM 37		
1437	001700	011633	EM44		:WRONG DATA FETCHED BY MFP INSTRUCTION
1438	001702	014306	DH30		:DATA DATA
1439					:EXPECTD RECEIVD TESTNO ERRORPC
1440	001704	015606	DT30		:\$REG0,\$REG1,TESTNO,\$ERRPC,0
1441	001706	016050	DF3		:0,0,0,0
1442					
1443			:*ITEM 40		
1444	001710	011566	EM43		:TRIED TO REFERENCE NON-RESIDENT PAGE
1445	001712	015047	DH43		:(MMR0) (MMR1) (MMR2) TESTNO ERRORPC
1446	001714	015726	DT45		:WASSRO,WASSR1,WASSR2,TESTNO,\$ERRPC,0
1447	001716	016034	DF1		:0,0,0,0,0
1448					
1449			:*ITEM 41		
1450	001720	011701	EM45		:ILLEGAL CSM DID NOT TRAP TO 10
1451	001722	014362	DH32		:TESTNO ERRORPC
1452	001724	015620	DT32		:TESTNO,\$ERRPC,0
1453	001726	016041	DF2		:0,0

1454			:*ITEM 42		
1455	001730	011740	EM46	:CSM DID NOT ENTER SUPERVISOR MODE	
1456	001732	015117	DH44	: EXPECTD (PSW) TESTNO ERR PC	
1457	001734	015742	DT46	: \$REG3,ACSMPS,TESTNO,\$ERRPC,0	
1458	001736	016034	DF1	:0,0,0,0,0	
1459					
1460			:*ITEM 43		
1461	001740	012002	EM47	:CSM SET UP WRONG PREVIOUS MODE	
1462	001742	015117	DH44	: EXPECTD (PSW) TESTNO ERR PC	
1463	001744	015742	DT46	: \$REG3,ACSMPS,TESTNO,\$ERRPC,0	
1464	001746	016034	DF1	:0,0,0,0,0	
1465					
1466			:*ITEM 44		
1467	001750	012041	EM50	:CSM SET UP STACK WRONG	
1468	001752	014306	DH30	:DATA DATA	
1469				: EXPECTD RECEIVD TESTNO ERR PC	
1470	001754	015606	DT30	:ACSMSP,\$TMPO,TESTNO,\$ERRPC,0	
1471	001756	016034	DF1	:0,0,0,0,0	
1472					
1473			:*ITEM 45		
1474	001760	012070	EM51	:CSM PUSHED INCORRECT ARGUMENT	
1475	001762	014306	DH30	:DATA DATA	
1476				: EXPECTD RECEIVD TESTNO ERR PC	
1477	001764	015754	DT47	: \$REG0,CSM1ST,TESTNO,\$ERRPC,0	
1478	001766	016034	DF1	:0,0,0,0,0	
1479					
1480			:*ITEM 46		
1481	001770	012126	EM52	:CSM PUSHED WRONG PC	
1482	001772	014306	DH30	:DATA DATA	
1483				: EXPECTD RECEIVD TESTNO ERR PC	
1484	001774	015766	DT50	: \$TMPO,CSM2ND,TESTNO,\$ERRPC,0	
1485	001776	016034	DF1	:0,0,0,0,0	
1486					
1487			:*ITEM 47		
1488	002000	012152	EM53	:CSM DID NOT CLEAR OLD PSW BITS <3:0>	
1489	002002	015117	DH44	:OLDPSW TESTNO ERR PC	
1490	002004	016000	DT52	:CSM3RD,TESTNO,\$ERRPC,0	
1491	002006	016050	DF3	:0,0,0,0	
1492					
1493			:*ITEM 50		
1494	002010	012217	EM54	:CSM ACCESSED WRONG SUPERVISOR SPACE	
1495	002012	014362	DH32	:TESTNO ERR PC	
1496	002014	015620	DT32	:TESTNO,\$ERRPC,0	
1497	002016	016054	DF5	:0,0,0	
1498					
1499			:*ITEM 51		
1500	002020	012263	EM55	:CSM ABORTED WHEN IT SHOULD NOT HAVE	
1501	002022	014362	DH32	:TESTNO ERR PC	
1502	002024	015620	DT32	:TESTNO,\$ERRPC,0	
1503	002026	016054	DF5	:0,0,0	
1504					
1505			:*ITEM 52		
1506	002030	012327	EM56	:CSM FAILED TO INCRFMENT/DECREMENT REGISTER PROPERLY	
1507	002032	015207	DH55	:TESTNO ERR PC RO EXP RO RCV	
1508	002034	016010	DT55	:TESTNO,\$ERRPC,\$TMPO,\$REG0,0	
1509	002036	016050	DF3	:0,0,0,0	

1510
1511 002040 012413
1512 002042 015246
1513 002044 016022
1514 002046 016050
1515
1516
1517 002050 012466
1518
1519
1520 002052 013522
1521 002054 015476
1522 002056 016050

;*ITEM 53

EM57
DH57
DT57
DF3

:CSM FAILED TO PUT PROPER ARGUMENT ON STACK
:TESTNO ERR PC ARGEXP ARGRCV
:TESTNO,\$ERRPC,\$TMP1,\$TMP2,0
:0,0,0,0

;*ITEM 54

EM58

DH20
DT20
DF3

:SR2 LOCKED UP AN 11/34 COMPATIBLE ADDRESS THAT
:DOES NOT MAKE IT COMPATIBLE WITH AN 11/70 SINCE
:THE OPTIONAL M7095 ECO #8 IS MISSING
:SR2 WAS EXPECTD TESTNO ERRORPC
:WASSR2,\$REG1,TESTNO,\$ERRPC,0
:0,0,0,0

1523
 1524
 1525
 1526
 1527
 1528
 1529
 1530
 1531
 1532 002060
 1533 002060 012700 077406
 1534
 1535 002064 012702 172300
 1536 002070 012701 000020
 1537 002074 010022
 1538 002076 077102
 1539 002100 020227 172340
 1540 002104 001003
 1541 002106 012702 172200
 1542 002112 000766
 1543 002114 020227 172240
 1544 002120 001003
 1545 002122 012702 177600
 1546 002126 000760
 1547 002130 012701 172340
 1548 002134 012702 172360
 1549 002140 012703 000007
 1550 002144 005000
 1551 002146 010021
 1552 002150 010022
 1553 002152 062700 000200
 1554 002156 077305
 1555 002160 012711 177600
 1556 002164 012712 177600
 1557 002170 020127 172356
 1558 002174 001005
 1559 002176 012701 172240
 1560 002202 012702 172260
 1561 002206 000754
 1562 002210 020127 172256
 1563 002214 001401
 1564 002216 000207
 1565 002220 012701 177640
 1566 002224 012702 177660
 1567 002230 000743

```

.SBTTL INITIALIZE ALL PAR'S AND PDR'S
:* ***** SUBROUTINES UNIQUE TO THIS PROGRAM *****
:* *****
:* THIS ROUTINE WILL INITIALIZE ALL KERNAL, SUPERVISOR, AND
:* USER PAR'S AND PDR'S TO THEIR USUAL INITIAL VALUE
:* *****
APRINIT:
MOV #77406,R0 ;MAKE ALL PDR'S 4K, READ/WRITE, UPWARDS
;EXPANDING, 200 BLOCKS
MOV #KIPDR0,R2 ;LOAD THE ADDRESS OF THE FIRST KERNAL PDR
1$: MOV #20,R1 ;LOAD R1 WITH 16
2$: MOV R0,(R2)+ ;LOAD EACH PDR IN TURN
SOB R1,2$ ;LOOP UNTIL ALL ARE LOADED
CMP R2,#KDPDR7+2 ;HAVE WE LOADED ALL KERNAL PDR'S
BNE 3$ ;BRANCH IF KERNAL & SUPER HAVE BEEN LOADED
MOV #SIPDR0,R2 ;LOAD ALL SUPERVISOR PDR'S
BR 1$ ;BRANCH TO LOOP
3$: CMP R2,#SDPDR7+2 ;HAVE USER PDR'S BEEN DONE
BNE 4$ ;BRANCH IF THEY HAVE
MOV #UIPDR0,R2 ;LOAD ALL USER PDR'S
BR 1$ ;BRANCH TO LOOP
4$: MOV #KIPAR0,R1 ;LOAD R1 WITH ADDRESS OF KIPAR0
MOV #KDPAR0,R2 ;LOAD R2 WITH ADDRESS OF KDPAR0
5$: MOV #7,R3 ;LOAD LOOP COUNTER WITH 7
CLR R0 ;CLEAR PAR VALUE REGISTER
6$: MOV R0,(R1)+ ;LOAD AN I-SPACE PAR
MOV R0,(R2)+ ;LOAD A D-SPACE PAR
ADD #200,R0 ;INCREASE THE PAR VALUE BY 200
SOB R3,6$ ;LOOP UNTIL 7 PAR'S ARE LOADED
MOV #177600,(R1) ;MAP I-SPACE PAR7 TO I/O PAGE
MOV #177600,(R2) ;MAP D-SPACE PAR7 TO I/O PAGE
1557: CMP R1,#KIPAR7
BNE 7$
MOV #SIPAR0,R1
MOV #SDPAR0,R2
BR 5$
7$: CMP R1,#SIPAR7
BEQ 8$ ;BRANCH TO USER LOAD ROUTINE
RTS PC ;RETURN TO CALLING ROUTINE
8$: MOV #UIPAR0,R1
MOV #UDPAR0,R2
BR 5$
  
```

```

1568 .SBTTL D-SPACE TESTS MEMORY MANAGEMENT ABORT SERVICE ROUTINE
1569 *****
1570 * THIS ROUTINE WILL BE ENTERED IF A MEMORY MANAGEMENT ABORT OCCURS
1571 * DURING THE D-SPACE ENABLE TESTS. IF THE ABORT IS A NON-RESIDENT
1572 * ABORT, THE PROBLEM IS PROBABLY IN THE D-SPACE ENABLE LOGIC. IN
1573 * ALL OF THE D-SPACE ENABLE TESTS, D-SPACE PAGES 1 & 3 ARE MAPPED
1574 * NON-RESIDENT AND I-SPACE PAGE 3 IS MAPPED NON-RESIDENT. ALL
1575 * OTHER PAGES ARE MAPPED RESIDENT, 4K, READ/WRITE. THEREFORE, IF
1576 * THE NON-RESIDENT PAGE IS 1 OR 3 YOU ARE NOT FORCING I-SPACE WHEN
1577 * YOU SHOULD. IF THE NON-RESIDENT PAGE IS 3, AND YOU ARE IN TEST
1578 * 15, YOU ARE PROBABLY FORCING I-SPACE WHEN YOU SHOULD BE ALLOWING
1579 * D-SPACE.
1580 *****
1581 002232 NODSPAC: ;STARTING ADDRESS FOR ABORT SERVICE ROUTINE
1582 002232 042737 000004 172516 BIC #BIT2,MMR3 ;TURN OFF D-SPACE BEFORE DOING ROUTINE
1583 002240 005227 INC (PC)+ ;MAKE FLAG ZERO IF THE FIRST TIME
1584 002242 177777 NDFLAG: .WORD -1 ;FLAG SHOULD BE -1
1585 002244 001401 BEQ 10$ ;BRANCH IF FIRST TIME IN ROUTINE
1586 002246 000000 HALT ;I HAVE ENTERED THIS ROUTINE BEFORE
1587 ;THE FIRST ERROR IS REPORTED; THE SECOND
1588 ;ENTRY ADDRESS IS ON THE STACK, AND THE
1589 ;FIRST ERROR CONDITION IS PROBABLY STILL
1590 ;LOCKED UP.
1591 002250 011637 001304 10$: MOV (KSP),BADPC ;SAVE PC AT TIME OF ABORT OR TRAP
1592 002254 012637 001260 MOV (KSP)+,TRAPPC ;SAVE RETURN ADDRESS IN CASE OF LOOP
1593 002260 012637 001262 MOV (KSP)+,TRAPPS ;SAVE OLD PSW IN CASE OF LOOP
1594 002264 013737 177572 001264 MOV MMRO,WASSRO ;SAVE STATUS REGISTER
1595 002272 013737 177574 001266 MOV MMR1,WASSR1 ;SAVE AUTO INCR/DECR REGISTER
1596 002300 013737 177576 001270 MOV MMR2,WASSR2 ;SAVE VIRTUAL ADDRESS REGISTER
1597 002306 005737 001264 TST WASSRO ;WAS ABORT NON-RESIDENT?
1598 002312 100002 BPL 1$ ;BRANCH IF ABORT NOT EXPECTED
1599 002314 104034 ERROR +34 ;D-SPACE ENABLE FAULTY
1600 002316 000401 BR 2$ ;BRANCH TO EXIT
1601 002320 104002 1$: ERROR +2 ;UNEXPECTED M.M. ABORT
1602 002322 042737 177376 177572 2$: BIC #177376,MMRO ;CLEAR ALL BITS EXCEPT 0 AND 8
1603 002330 012737 177777 002242 MOV #-1,NDFLAG ;MOVE A -1 TO THE FLAG
1604 002336 013746 001262 MOV TRAPPS,-(KSP) ;PUSH OLD PSW ONTO STACK
1605 002342 013746 001260 MOV TRAPPC,-(KSP) ;PUSH OLD PC ONTO STACK
1606 002346 052737 000004 172516 BIS #BIT2,MMR3 ;TURN D-SPACE BACK ON
1607 002354 000006 RTT ;RETURN TO MAIN PROGRAM

```



```

1608 .SBTTL TURN OFF T-BIT AND SAVE CURRENT PSW
1609 :*****
1610 :*
1611 :* THIS SUBROUTINE IS USED TO TURN OFF THE TRACE TRAP BIT IN
1612 :* THE PSW IF IT IS ON. THE PROCESSOR STATUS IS SAVED IN
1613 :* 'TBITPS' SO THAT THE PSW CAN BE RESTORED TO ITS PREVIOUS
1614 :* CONDITION WHEN CONDITIONS WARRANT T-BIT TRAPPING.
1615 :*
1616 :*****
1617 002356 033727 177776 000020 TOFF: BIT PSW,#TBIT ;IS THE T-BIT SET IN THE PSW?
1618 002364 001411 BEQ 1$ ;EXIT IF NO
1619 002366 013746 177776 MOV PSW,-(SP) ;PUSH PRESENT PSW ON THE STACK
1620 002372 011637 001274 MOV (SP),TBITPS ;ALSO SAVE IT IN 'TBITPS' FOR
1621 ;RESTORING LATER
1622 002376 042716 000020 BIC #TBIT,(SP) ;CLEAR THE T-BIT (BIT 4) IN THE PSW
1623 002402 012746 002410 MOV #1$,-(SP) ;PUSH PC OF 'RTS' ON STACK
1624 002406 000006 RTT ;'RETURN' TO 1$ WITH T-BIT OFF
1625 002410 000207 1$: RTS PC ;RETURN TO PROGRAM
    
```

```

1626 .SBTTL TURN ON T-BIT AND RESTORE PREVIOUS PSW
1627 :*****
1628 :*
1629 :* THIS SUBROUTINE IS USED TO RESTORE THE PROCESSOR STATUS
1630 :* TO ITS PREVIOUS CONDITION BY RESTORING THE "T-BIT PSW"
1631 :* SAVED BY THE "TOFF" SUBROUTINE IN THE "TBITPS" LOCATION.
1632 :*
1633 :*****
1634 002412 033727 001274 000020 TON: BIT TBITPS,#TBIT ;WAS T-BIT ON IN THE PREVIOUS PSW?
1635 002420 001410 BEQ 1$ ;EXIT IF NO
1636 002422 013746 001274 MOV TBITPS,-(SP) ;PUSH PREVIOUS PSW ON THE STACK
1637 002426 012737 000340 001274 MOV #340,TBITPS ;RESET THE "TBITPS" LOCATION
1638 002434 012746 002442 MOV #1$,-(SP) ;PUSH PC OF "RTS" ON STACK
1639 002440 000006 RTT ;"RETURN" TO 1$ WITH T-BIT RESTORED
1640 002442 000207 1$: RTS PC ;RETURN TO PROGRAM
    
```

1641
 1642
 1643
 1644
 1645
 1646
 1647
 1648
 1649
 1650
 1651
 1652
 1653
 1654 002444 005726
 1655 002446 012737 000001 002624
 1656 002454 011646
 1657 002456 162716 000004
 1658 002462 000207

```

.SBTTL SUBROUTINE TO PREPARE ERLOOP, THE STACK AND EXIT TO ERROR
*****
:
:
: THIS SUBROUTINE IS USED BY THE THREE SUBROUTINES MFPITS, MTPITS AND
: MFPDTS WHEN AN ERROR IS CALLED. THE RETURN ADDRESS IS POPPED AS
: RETURN IS NOT BACK TO THE SUBROUTINE, BUT TO THE TEST ERROR CALL. THIS
: ROUTINE SETS LOCATION ERLOOP, DUPLICATES THE RETURN ADDRESS ON THE
: STACK FOR POSSIBLE LOOP ON ERROR, AND CORRECTS THE RETURN ADDRESS TO
: POINT TO THE ERROR CALL 4 LOCATIONS BACK FROM THE 'TEST PASSED' LOCA-
: TION DUPLICATED. NOTE THE 'TEST PASSED' RETURN ON THE STACK IS NOT
: TOUCHED FOR PROBABLE LATER USE WHEN LOOPING IS NO LONGER ENABLED.
:
:
*****
ERPREP: TST (SP)+ ;POP RETURN OF THIS ROUTINE - NOT USED
        MOV #1,ERLOOP ;SET ERROR LOOPING FLAG INDICATING AN ERROR
        MOV (SP),-(SP) ;DUPLICATE RETURN PC AND
        SUB #4,(SP) ;FUDGE FOR ERROR RETURN
        RTS PC ;RETURN TO THE ERROR CALL IN THE TEST
  
```

1659
 1660
 1661
 1662
 1663
 1664
 1665
 1666
 1667
 1668
 1669
 1670
 1671
 1672
 1673
 1674
 1675
 1676 002464 005037 002624
 1677 002470 011605
 1678 002472 012537 002532
 1679 002476 012537 002534
 1680 002502 062716 000010
 1681 002506 010637 001176
 1682 002512 011637 001200
 1683 002516 012737
 1684 002520 000000
 1685 002522 177776
 1686 002524 017737 000072 000250
 1687 002532 000000 000000
 1688 002536 012737 016142 000250
 1689 002544 012601
 1690 002546 020001
 1691 002550 001411
 1692 002552 012737 000340 177776
 1693 002560 013706 001176
 1694 002564 013716 001200
 1695 002570 004737 002444
 1696
 1697 002574 005737 002624
 1698 002600 001346
 1699 002602 012737 000340 177776
 1700 002610 013706 001176
 1701 002614 013716 001200
 1702 002620 000207
 1703 002622 000000
 1704 002624 000000

```

.SBTTL SUBROUTINE TO TEST MFPI INSTRUCTION
*****
*
*   USAGE OF THE SUBROUTINE BELOW IS AS FOLLOWS:
*
*   MOV    #MFPILP,$LPERR ;PUT ADDRESS OF LOOPING LOCATION IN $LPERR
*   MOV    #(NUMB),MFPIPS ;PUT PS PREVIOUS/CURRENT MODE VALUE IN THIS LOCATION
*   MOV    #TRAPRTN,MFPIVC ;LOAD THE TEST EXCLUSIVE TRAP ROUTINE TO MFPIVC
*   MOV    #(NUMB),R2      ;SETUP ADDRESS IN R2
*   (IT IS ASSUMED THAT ALL PDR'S/PAR'S WILL ALSO BE SET UP PROPERLY)
*   JSR    PC,MFPITS      ;GO DO THE TEST
*   MFPI   (MODE)        ;MFPI INSTRUCTION TO TEST IS PUT HERE
*   NOP    ;NEEDED FOR MODES 1,2,4, & 5 *ONLY*
*   ERROR  +(NUMB)       ;RETURN IS HERE FOR ERROR CALLS
*   TST    (SP)+         ;POP STACK - EXTRA RETURN INSTALLED BY SUBRTN NOT NEEDED
*
*****
MFPITS: CLR    ERLOOP      ;CLEAR ERROR LOOPING FLAG
        MOV    (SP),R5     ;MOVE STACK POINTER TO R5 FOR SUBROUTINE LOADING
        MOV    (R5)+,MFPILD ;MOVE MFPI INSTRUCTION TO LOCATION
        MOV    (R5)+,MFPILD+2 ;MOVE NEXT WORD TO LOCATION
        ADD    #10,(SP)    ;FUDGE RETURN TO "TEST PASSED" LOCATION
        MOV    SP,$TMP0    ;SAVE THE STACK POINTER AND
        MOV    (SP),$TMP1   ;SAVE THE RETURN ADDRESS
MFPILP: MOV    (PC)+,@(PC)+ ;SETUP PSW AS DEFINED BY LOADED VALUE IN PRVMD1
MFPIPS: .WORD  0           ;LOCATION TO HOLD SUPER/USER PREVIOUS MODE
        .WORD  PSW         ;LOAD THE PSW
        MOV    @MFPIVC,MMVEC ;SET M.M. VECTOR TO MFPIV1
MFPILD: .WORD  0,0        ;LOCATIONS TO HOLD MFPI INSTRUCTION UNDER TEST
        MOV    #MGMERR,MMVEC ;SET M.M. VECTOR TO NORMAL ROUTINE
        MOV    (SP)+,R1     ;POP SUPERVISOR/USER/KERNEL STACK INTO R1
        CMP    R0,R1       ;WAS DATA FETCHED SAME AS STORED
        BEQ    1$          ;BRANCH IF CORRECT DATA WAS FETCHED
        MOV    #340,PSW    ;GO TO KERNEL MODE
        MOV    $TMP0,SP    ;RESET SP
        MOV    $TMP1,(SP)  ;RESET RETURN ADDRESS
        JSR    PC,ERPREP   ;GO PREPARE LOCATION ERLOOP, RETURN PC & EXIT TO ERROR
;FOR TIGHTER SCOPE LOOP, REPLACE 'JSR PC,ERPREP' WITH 'BR MFPILP' = 000767
1$:     TST    ERLOOP      ;CHECK TO SEE IF THIS 'PASSED' IS IN AN ERROR LOOP
        BNE    MFPILP     ;BRANCH BACK IF SO
        MOV    #340,PSW    ;GET BACK TO KERNEL MODE
        MOV    $TMP0,SP    ;RESET SP
        MOV    $TMP1,(SP)  ;RESET RETURN ADDRESS
        RTS    PC         ;EXIT - TEST PASSED
MFPIVC: .WORD  0           ;LOCATION TO HOLD ADDRESS OF MM TRAP CATCHER
ERLOOP: .WORD  0           ;LOCATION USED TO FLAG AN ERROR CONDITION
    
```

1705
 1706
 1707
 1708
 1709
 1710
 1711
 1712
 1713
 1714
 1715
 1716
 1717
 1718
 1719
 1720
 1721
 1722 002626 005037 002624
 1723 002632 011605
 1724 002634 012537 002676
 1725 002640 012537 002700
 1726 002644 012537 002720
 1727 002650 062716 000012
 1728 002654 012737
 1729 002656 000000
 1730 002660 000000
 1731 002662 010046
 1732 002664 105037 172310
 1733 002670 017737 000050 000250
 1734 002676 000000 000000
 1735 002702 012737 016142 000250
 1736 002710 112737 000006 172310
 1737 002716 062702
 1738 002720 000000
 1739 002722 011201
 1740 002724 020001
 1741 002726 001402
 1742 002730 004737 002444
 1743
 1744 002734 005737 002624
 1745 002740 001345
 1746 002742 000207
 1747 002744 000000

```

.SBTTL SUBROUTINE TO CHECK THE MTPI INSTRUCTION
*****
      USAGE OF THE SUBROUTINE BELOW IS AS FOLLOWS:
      MOV      #MTPILP,$LPERR ;PUT ADDRESS OF LOOPING LOCATION IN $LPERR
      MOV      #(NUMB),MTPIPS ;PUT PS PREVIOUS/CURRENT MODE VALUE IN THIS LOCATION
      MOV      #TRAPRTN,MTPIVC ;LOAD THE TEST EXCLUSIVE TRAP ROUTINE TO MTPIVC
      MOV      #(NUMB),R2     ;SETUP ADDRESS IN R2
      (IT IS ASSUMED THAT ALL PDR'S/PAR'S WILL ALSO BE SET UP PROPERLY)
      JSR      PC,MTPITS      ;GO DO THE TEST
      MTPI     (MODE)         ;MTPI INSTRUCTION TO TEST IS PUT HERE
      NOP      ;NEEDED FOR MODES 1,2,4, & 5 *ONLY*
      ERROR   +(NUMB)        ;RETURN IS HERE FOR ERROR CALLS
      TST     (SP)+          ;POP STACK - EXTRA RETURN INSTALLED BY SUBRTN NOT NEEDED
*****
MTPITS: CLR      ERLOOP      ;CLEAR ERROR LOOPING FLAG
        MOV      (SP),R5     ;MOVE STACK POINTER TO R5 FOR LOADING
        MOV      (R5)+,MTPILD ;MOVE MTPI TO LOCATION
        MOV      (R5)+,MTPILD+2 ;MOVE NEXT WORD TO LOCATION
        MOV      (R5)+,MTPITA ;MOVE NUMBER TO ADD TO R2 TO LOCATION
        ADD     #12,(SP)     ;FUDGE RETURN TO 'TEST PASSED' LOCATION
MTPILP: MOV      (PC)+,@(PC)+ ;MAKE PREVIOUS MODE USER/SUPERVISOR
MTPIPM: .WORD   0           ;LOCATION TO HOLD PREVIOUS MODE USER OR SUPER
        .WORD   PSW         ;LOAD THE PSW
        MOV      R0,-(KSP)  ;PUSH TEST DATA ON KERNEL STACK
        CLR     KIPDR4     ;MAKE KERNEL I PAGE 4 NON-RESIDENT
        MOV     @MTPIVC,MMVEC ;SET MM TO VECTOR IN MTPIVC
MTPILD: .WORD   0,0        ;LOCATIONS USED TO PLACE THE MPTI INSTRUCTION
        MOV     #MGERR,MMVEC ;RESTORE MM VECTOR TO NORMAL ROUTINE
        MOV     #006,KIPDR4 ;MAKE KERNEL PAGE 4 RESIDENT
        ADD     (PC)+,R2    ;ADD NUMBER TO R2 TO UNDO INCREMENT/DECREMENT
MTPITA: .WORD   0         ;LOCATION TO HOLD -2, 0, +2 OR 10000
        MOV     (R2),R1    ;READ FROM ADDRESS 60000
        CMP     R0,R1     ;SEE IF DATA WAS STORED AT CORRECT PLACE
        BEQ    1$        ;BRANCH IF IT WAS
        JSR    PC,ERPREP  ;GO PREPARE LOCATION ERLOOP, RETURN PC & EXIT TO ERROR
;FOR TIGHTER ERROR LOOP, REPLACE "JSR PC,ERPREP" WITH "BR MTPILP" = 000754
1$:     TST     ERLOOP    ;SEE IF THIS 'PASSED' WAS IN AN ERROR LOOP
        BNE   MTPILP    ;BRANCH BACK IF SO
        RTS    PC       ;EXIT - TEST PASSED
MTPIVC: .WORD   0       ;LOCATION TO HOLD MM VECTOR TO LOAD
    
```

1748
 1749
 1750
 1751
 1752
 1753
 1754
 1755
 1756
 1757
 1758
 1759
 1760
 1761
 1762
 1763
 1764
 1765 002746 005037 002624
 1766 002752 011605
 1767 002754 012537 003004
 1768 002760 012537 003006
 1769 002764 062716 000010
 1770 002770 012737
 1771 002772 000000
 1772 002774 177776
 1773 002776 017737 000036 000250
 1774 003004 000000 000000
 1775 003010 012737 016142 000250
 1776 003016 012601
 1777 003020 020001
 1778 003022 001402
 1779 003024 004737 002444
 1780 003030 005737 002624
 1781 003034 001355
 1782 003036 000207
 1783 003040 000000

```

.SBTTL SUBROUTINE TO CHECK THE MFPD INSTRUCTION
*****
:
:
:      USAGE OF THE SUBROUTINE BELOW IS AS FOLLOWS:
:
:      MOV      #MFPDLP,$LPERR ;PUT ADDRESS OF LOOPING LOCATION IN $LPERR
:      MOV      #(NUMB),MFPDPS ;PUT PS PREVIOUS/CURRENT MODE VALUE IN THIS LOCATION
:      MOV      #TRAPRTN,MFPDVC ;LOAD THE TEST EXCLUSIVE TRAP ROUTINE TO MFPDVC
:      MOV      #(NUMB),R2      ;SETUP ADDRESS IN R2
:      (IT IS ASSUMED THAT ALL PDR'S/PAR'S WILL ALSO BE SET UP PROPERLY)
:      JSR      PC,MFPDTS      ;GO DO THE TEST
:      MFPD     (MODE)         ;MFPD INSTRUCTION TO TEST IS PUT HERE
:      NOP                                     ;NEEDED FOR MODES 1,2,4, & 5 *ONLY*
:      ERROR    +(NUMB)         ;RETURN IS HERE FOR ERROR CALLS
:      TST      (SP)+           ;POP STACK - EXTRA RETURN INSTALLED BY SUBRTN NOT NEEDED
:
:*****
MFPDTS: CLR      ERLOOP          ;CLEAR THE ERROR LOOPING FLAG
:      MOV      (SP),R5         ;MOVE RETURN ADDRESS TO R5 FOR LOADING
:      MOV      (R5)+,MFPDLD    ;MOVE MFPD INSTRUCTION TO THE LOCATION BELOW
:      MOV      (R5)+,MFPDLD+2  ;MOVE NEXT WORD TO THE NEXT LOCATION
:      ADD      #10,(SP)        ;FUDGE RETURN TO THE "TEST PASSED" LOCATION
MFPDLP: MOV      (PC)+,@(PC)+   ;SET UP PSW AS LOADED BY TEST RUNNING THIS SUBROUTINE
MFPDPS: .WORD    0              ;LOCATION TO HOLD NUMBER TO LOAD THE PSW
:      .WORD    PSW             ;LOAD THE PSW
:      MOV      @MFPDVC,MMVEC   ;SET M.M. VECTOR TO TRAP CATCHER OF THE TEST
MFPDLD: .WORD    0,0           ;LOCATIONS TO HOLD THE MFPD INSTRUCTION
:      MOV      #MMGMERR,MMVEC  ;RESTORE MM VECTOR TO NORMAL ROUTINE
:      MOV      (SP)+,R1        ;POP K/S/U STACK INTO R1
:      CMP      R0,R1           ;WAS DATA FETCHED SAME AS DATA STORED
:      BEQ      1$              ;BRANCH IF CORRECT DATA WAS FETCHED
:      JSR      PC,ERPREP      ;GO PREPARE ERLOOP, STACK AND EXIT TO ERROR CALL
1$:     TST      ERLOOP         ;SEE IF THIS "PASSED" IS IN AN ERROR LOOP
:      BNE      MFPDLP         ;BRANCH BACK IF SO
:      RTS      PC              ;EXIT - TEST PASSED
MFPDVC: .WORD    0              ;LOCATION TO HOLD MM VECTOR OF TEST
  
```

1785

.SBTTL SCOPE HANDLER ROUTINE

```

*****
*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
*AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW14=1      LOOP ON TEST
*SW09=1      LOOP ON ERROR
*SW08=1      LOOP ON TEST IN SWR<7:0>
*CALL
*           SCOPE           ;;SCOPE=10T
    
```

```

003042          $SCOPE:
003042 104410          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
003044 032777 040000 176066 1$: BIT #BIT14,@SWR          ;;LOOP ON PRESENT TEST?
003052 001077          BNE $OVER          ;;YES IF SW14=1
          ;#####START OF CODE FOR THE XOR TESTER#####
003054 000416          $XTSTR: BR 6$          ;;IF RUNNING ON THE 'XOR' TESTER CHANGE
          ;;THIS INSTRUCTION TO A 'NOP' (NOP=240)
003056 013746 000004          MOV @#ERRVEC,-(SP)          ;;SAVE THE CONTENTS OF THE ERROR VECTOR
003062 012737 003102 000004          MOV #5$,@#ERRVEC          ;;SET FOR TIMEOUT
003070 005737 177060          TST @#177060          ;;TIME OUT ON XOR?
003074 012637 000004          MCV (SP)+,@#ERRVEC          ;;RESTORE THE ERROR VECTOR
003100 000446          BR $SVLAD          ;;GO TO THE NEXT TEST
003102 022626          5$: CMP (SP)+,(SP)+          ;;CLEAR THE STACK AFTER A TIME OUT
003104 012637 000004          MOV (SP)+,@#ERRVEC          ;;RESTORE THE ERROR VECTOR
003110 000434          BR 7$          ;;LOOP ON THE PRESENT TEST
003112          6$:;#####END OF CODE FOR THE XOR TESTER#####
003112 032777 000400 176020          BIT #BIT08,@SWR          ;;LOOP ON SPEC. TEST?
003120 001404          BEQ 2$          ;;BR IF NO
003122 127737 176012 001102          CMPB @SWR,$STNM          ;;ON THE RIGHT TEST? SWR<7:0>
003130 001450          BEQ $OVER          ;;BR IF YES
003132 013737 177766 003266 2$: MOV 177766,CPSAVE          ;;MOVE CPU ERR REG VALUE TO LOC FOR TST ;DPM001
003140 032737 000001 003266          BIT #BIT00,CPSAVE          ;;SEE IF THE POWER MONITOR BIT IS ON ;DPM001
003146 001406          BEQ 2000$          ;;BRANCH TO CONTINUE ROUTINE IF CLEAR ;DPM001
003150 042737 000001 177766          BIC #BIT00,177766          ;;CLEAR THE BIT FOUND TO BE SET ;DPM001
003156 104177          EMT +177          ;;CALL SPECIAL POWER FAIL BIT ERROR CALL ;DPM001
003160 105037 001103          CLRB $ERFLG          ;;CLEAR THE ERROR FLAG ;DPM001
003164 105737 001103          2000$: TSTB $ERFLG          ;;HAS AN ERROR OCCURRED?
003170 001412          BEQ $SVLAD          ;;BR IF NO
003172 032777 001000 175740          BIT #BIT09,@SWR          ;;LOOP ON ERROR?
003200 001404          BEQ 4$          ;;BR IF NO
003202 013737 001110 001106 7$: MOV $LPERR,$LPADR          ;;SET LOOP ADDRESS TO LAST SCOPE
003210 000420          BR $OVER
003212 105037 001103          4$: CLRB $ERFLG          ;;ZERO THE ERROR FLAG
003216 105237 001102          $SVLAD: INCB $STNM          ;;COUNT TEST NUMBERS
003222 113737 001102 001230          MOVB $STNM,$TESTN          ;;SET TEST NUMBER IN APT MAILBOX
003230 011637 001106          MOV (SP),$LPADR          ;;SAVE SCOPE LOOP ADDRESS
003234 011637 001110          MOV (SP),$LPERR          ;;SAVE ERROR LOOP ADDRESS
003240 005037 001212          CLR $ESCAPE          ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
003244 112737 000001 001115          MOVB #1,$ERMAX          ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
003252 013777 001102 175662 $OVER: MOV $STNM,@DISPLAY          ;;DISPLAY TEST NUMBER
003260 013716 001106          MOV $LPADR,(SP)          ;;FUDGE RETURN ADDRESS
003264 000002          RTI          ;;FIXES PS
003266 000000          CPSAVE: .WORD 0          ;;LOCATION TO SAVE CPU ERR REG CONTENTS ;DPM001
    
```

1787

.SBTTL ERROR HANDLER ROUTINE

```

:*****
:*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
:*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
:*AND GO TO ERRTP ON ERROR
:*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
:*SW15=1      HALT ON ERROR
:*SW13=1      INHIBIT ERROR TYPEOUTS
:*SW10=1      BELL ON ERROR
:*SW09=1      LOOP ON ERROR
:*CALL
:*          ERROR  N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
  
```

```

003270 105037 003646 $ERROR: CLRB IBSAVE ;CLEAR THE ITEM BYTE SAVE LOCATION ;DPM001
003274 104410 CKSWR ;TEST FOR CHANGE IN SOFT-SWR
003276 010037 001162 MOV R0,$REG0 ;SAVE THE CONTENTS OF R0
003302 010137 001164 MOV R1,$REG1 ;SAVE THE CONTENTS OF R1
003306 010237 001166 MOV R2,$REG2 ;SAVE THE CONTENTS OF R2
003312 010337 001170 MOV R3,$REG3 ;SAVE THE CONTENTS OF R3
003316 010437 001172 MOV R4,$REG4 ;SAVE THE CONTENTS OF R4
003322 010537 001174 MOV R5,$REG5 ;SAVE THE CONTENTS OF R5
003326 113737 001102 001254 MOVB $STNM,TESTNO ;SAVE THE TEST NUMBER
003334 105237 001103 7$: INCB $ERFLG ;SET THE ERROR FLAG
003340 001775 BEQ 7$ ;DON'T LET THE FLAG GO TO ZERO
003342 013777 001102 175572 MOV $STNM,@DISPLAY ;DISPLAY TEST NUMBER AND ERROR FLAG
003350 032777 002000 175562 BIT #BIT10,@SWR ;BELL ON ERROR?
003356 001402 BEQ 1$ ;NO - SKIP
003360 104401 001214 TYPE $BELL ;RING BELL
003364 005237 001112 1$: INC $ERTTL ;COUNT THE NUMBER OF ERRORS
003370 011637 001116 MOV (SP),$ERRPC ;GET ADDRESS OF ERROR INSTRUCTION
003374 162737 000002 001116 SUB #2,$ERRPC
003402 117737 175510 001114 MOVB @ERRPC,$ITEMB ;STRIP AND SAVE THE ERROR ITEM CODE
003410 122737 000177 001114 CMPB #177,$ITEMB ;SEE IF THIS IS THE POWER FAIL CALL ;DPM001
003416 001426 BEQ 1001$ ;BRANCH AROUND ROUTINE IF IT IS ;DPM001
003420 105737 003646 TSTB IBSAVE ;SEE IF THIS IS THE 2ND ERROR CALL ;DPM001
003424 001021 BNE 1000$ ;BRANCH IF SO ;DPM001
003426 013737 177766 003266 MOV 177766,CPSAVE ;MOVE CPU ERR REG TO CPSAVE FOR TEST ;DPM001
003434 032737 000001 003266 BIT #BIT00,CPSAVE ;SEE IF POWER MONITOR BIT IS SET ;DPM001
003442 001414 BEQ 1001$ ;BRANCH IF OK ;DPM001
003444 042737 000001 177766 BIC #BIT00,177766 ;CLEAR THE BIT FOUND SET ;DPM001
003452 113737 001114 003646 MOVB $ITEMB,IBSAVE ;MAKE IBSAVE NON-ZERO FOR DUAL CALL ;DPM001
003460 112737 000177 001114 MOVB #177,$ITEMB ;SET $ITEMB TO SPECIAL POWER FAIL PNTR ;DPM001
003466 000402 BR 1001$ ;BRANCH OVER IBSAVE CLEARING ;DPM001
003470 105037 003646 1000$: CLRB IBSAVE ;CLEAR IBSAVE SO AFTER 2ND ERROR, EXIT ;DPM001
003474 1001$:
003474 032777 020000 175436 BIT #BIT13,@SWR ;SKIP TYPEOUT IF SET
003502 001004 BNE 20$ ;SKIP TYPEOUTS
003504 004737 003650 JSR PC,ERRTYP ;GO TO USER ERROR ROUTINE
003510 104401 001221 TYPE $CRLF
003514 20$:
003514 122737 000001 001244 CMPB #APTENV,$ENV ;RUNNING IN APT MODE
003522 001007 BNE 2$ ;NO,SKIP APT ERROR REPORT
003524 113737 001114 003536 MOVB $ITEMB,21$ ;SET ITEM NUMBER AS ERROR NUMBER
003532 004737 006014 JSR PC,$ATY4 ;REPORT FATAL ERROR TO APT
003536 000 21$: .BYTE 0
003537 000 .BYTE 0
  
```



```

003540 000777          22$: BR      22$      ;;APT ERROR LOOP
003542 105737 003646  2$:  TSTB   IBSAVE  ;;SEE IF POWER FAIL ERROR CALL      ;DPM001
003546 001005          3$:  BNE     3$      ;;BRANCH IF NOT - HALT NOT ALLOWED  ;DPM001
003550 005777 175364   TST     @SWR   ;;HALT ON ERROR
003554 100002          BPL     3$      ;;SKIP IF CONTINUE
003556 000000          HALT                    ;;HALT ON ERROR.
003560 104410          CKSWR                    ;;TEST FOR CHANGE IN SOFT-SWR
003562 032777 001000 175350 3$: BIT     #BIT09,@SWR ;;LOOP ON ERROR SWITCH SET?
003570 001405          BEQ     4$      ;;BR IF NO
003572 105737 003646   TSTB   IBSAVE  ;;SEE IF THIS IS THE PWR MNTR BIT ERROR ;DPM001
003576 001256          BNE     7$      ;;BRANCH BACK IF SO - FUDGING NOT ALLOWED;DPM001
003600 013716 001110   MOV     $LPERR,(SP) ;;FUDGE RETURN FOR LOOPING
003604 005737 001212   4$:  TST     $ESCAPE ;;CHECK FOR AN ESCAPE ADDRESS
003610 001405          BEQ     5$      ;;BR IF NONE
003612 105737 003646   TSTB   IBSAVE  ;;SEE IF THIS IS THE PWR MNTR BIT ERROR ;DPM001
003616 001246          BNE     7$      ;;BRANCH BACK IF SO - FUDGING NOT ALLOWED;DPM001
003620 013716 001212   MOV     $ESCAPE,(SP) ;;FUDGE RETURN ADDRESS FOR ESCAPE
003624          5$:  CMP     #$ENDAD,@#42 ;;ACT-11 AUTO-ACCEPT?
003624 022737 036252 000042 BNE     6$      ;;BRANCH IF NO
003632 001001          HALT                    ;;YES
003634 000000          6$:  TSTB   IBSAVE  ;;SEE IF THIS IS THE PWR FAIL ERROR CALL ;DPM001
003636 105737 003646   BNE     7$      ;;BRANCH BACK TO CALL ORIGINAL ERR IF SO ;DPM001
003642 001234          RTI                    ;;RETURN
003644 000002          IBSAVE: .WORD 0 ;;LOC'N TO HOLD $ITEMB DURING DUAL ERR ;DPM001
003646 000000
  
```

```

1789 003650 104401 001221  ERRRTYP: TYPE , $CRLF ;TYPE <CRLF>
1790 003654 010046          MOV R0,-(KSP) ;SAVE R0.
1791 003656 005000          CLR R0 ;PICKUP THE ITEM INDEX
1792 003660 153700 001114  BISB @#$ITEMB,R0
1793 003664 001004          BNE 1$ ;IF ITEM NUMBER IS ZERO, JUST
1794                                     ;TYPE THE PC OF THE ERROR
1795 003666 013746 001116  MOV $ERRPC,-(SP) ;:SAVE $ERRPC FOR TYPEOUT
1796                                     ;:ERROR ADDRESS
1797 003672 104402          TYPDC ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
1798 003674 000530          BR 13$ ;GET OUT
1799 003676 122700 000177  1$: CMPB #177,R0 ;SEE IF THIS ERROR CALL IS THE POWER MONITOR BIT CALL
1800 003702 001003          BNE 100$ ;BRANCH IF NOT
1801 003704 012700 004172  MOV #PFECWS,R0 ;MOVE ADDRESS OF POWER MONITOR BIT ERROR TO R0
1802 003710 000406          BR 110$ ;BRANCH TO CALL THE ERROR
1803 003712 005300          100$: DEC R0 ;ADJUST THE INDEX SO THAT IT WILL
1804 003714 006300          ASL R0 ;WORK FOR THE ERROR TABLE.
1805 003716 006300          ASL R0
1806 003720 006300          ASL R0
1807 003722 062700 001320  ADD #$ERRTB,R0 ;FORM TABLE POINTER
1808 003726 012037 003736  110$: MOV (R0)+,2$ ;PICKUP 'ERROR MESSAGE' POINTER
1809 003732 001404          BEQ 3$ ;SKIP TYPEOUT IF NO POINTER
1810 003734 104401          TYPE ;TYPE THE 'ERROR MESSAGE'
1811 003736 000000          2$: .WORD 0 ;'ERROR MESSAGE' POINTER GOES HERE
1812 003740 104401 001221  TYPE , $CRLF ;'CARRIAGE RETURN' & 'LINE FEED'
1813 003744 012037 003754  3$: MOV (R0)+,4$ ;PICKUP 'DATA HEADER' POINTER
1814 003750 001404          BEQ 5$ ;SKIP TYPEOUT IF 0
1815 003752 104401          TYPE ;TYPE THE 'DATA HEADER'
1816 003754 000000          4$: .WORD 0 ;'DATA HEADER' POINTER GOES HERE
1817 003756 104401 001221  TYPE , $CRLF ;'CARRIAGE RETURN' & 'LINE FEED'
1818 003762 010146          5$: MOV R1,-(KSP) ;SAVE R1
1819 003764 012001          MOV (R0)+,R1 ;PICKUP 'DATA TABLE' POINTER
1820 003766 001472          BEQ 12$ ;BR IF NO DATA TO BE TYPED
1821 003770 012000          MOV (R0)+,R0 ;PICKUP 'DATA FORMAT' POINTER
1822 003772 105710          6$: TSTB (R0) ;IS IT FORMAT 0?
1823 003774 001003          BNE 7$ ;BR IF NO
1824                                     ;*THIS CODE IS FOR OCTAL (16-BIT) FORMAT (DF=0)
1825 003776 013146          MOV @ (R1)+,-(SP) ;:SAVE @ (R1)+ FOR TYPEOUT
1826 004000 104402          TYPDC ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
1827 004002 000456          BR 11$
1828                                     ;*THIS CODE IS FOR DECIMAL FORMAT (DF=1)
1829 004004 121027 000001  7$: CMPB (R0),#1 ;IS IT FORMAT 1?
1830 004010 001003          BNE 8$ ;BRANCH IF NO
1831 004012 013146          MOV @ (R1)+,-(SP) ;:SAVE @ (R1)+ FOR TYPEOUT
1832 004014 104405          TYPDS ;:GO TYPE--DECIMAL ASCII WITH SIGN
1833 004016 000450          BR 11$
1834                                     ;*THIS CODE IS FOR BINARY FORMAT (DF=2)
1835 004020 121027 000002  8$: CMPB (R0),#2 ;IS IT FORMAT 2
1836 004024 001003          BNE 9$ ;BRANCH IF NO
1837 004026 013146          MOV @ (R1)+,-(SP) ;:SAVE @ (R1)+ FOR TYPEOUT
1838 004030 104406          TYPBN ;:GO TYPE--BINARY ASCII
1839 004032 000442          BR 11$
1840                                     ;*THIS CODE IS FOR OCTAL (22-BIT) FORMAT (DF=3)
1841 004034 121027 000003  9$: CMPB (R0),#3 ;IS IT FORMAT 3?
1842 004040 001011          BNE 15$ ;BRANCH IF NO
1843 004042 012146          MOV (R1)+,-(KSP) ;PUT ADDRESS OF FIRST LOC. ON STACK
1844 004044 004737 007066  JSR PC,$DB20 ;CONVERT TWO LOCS. TO AN ASCII STRING
1845 004050 062716 000003  ADD #3,(KSP) ;ONLY NEED 8 CHARACTERS NOT 11
    
```

```

1846 004054 012637 004062      MOV      (KSP)+,10$      ;PUT ADDRESS OF ASCII CHARS. AT 10$
1847 004060 104401              TYPE                    ;TYPE OCTAL VALUE OF 22-BIT BINARY NO.
1848 004062 000000      10$: .WORD      0
1849                                ;*THIS CODE IS FOR OCTAL (22-BIT) FORMAT FOR A PAR LEFT SHIFTED 6 (DF=4)
1850 004064 010246      15$: MOV      R2,-(KSP)      ;SAVE R2 ON STACK
1851 004066 010346      MOV      R3,-(KSP)      ;SAVE R3 ON STACK
1852 004070 013103      MOV      @(R1)+,R3      ;LOAD DATA WORD INTO R3
1853 004072 005002      CLR      R2              ;R2 HOLDS UPPER SIX BITS OF NUMBER
1854 004074 073227 000006      ASHC     #6,R2          ;SHIFT VALUE LEFT 6 TIMES
1855 004100 010237 001206      MOV      R2,$TMP4      ;HOLDS LOWER 16 BITS OF ADDRESS
1856 004104 010337 001210      MOV      R3,$TMP5      ;HOLDS UPPER 6 BITS OF ADDRESS
1857 004110 012746 001206      MOV      #$TMP4,-(KSP)  ;PUT ADDRESS OF LOWER BITS ONTO STACK
1858 004114 004737 007066      JSR      PC,$DB20      ;CONVERT TWO LOCS. TO AN ASCII STRING
1859 004120 062716 000003      ADD      #3,(KSP)      ;ONLY NEED 8 CHARACTERS NOT 11
1860 004124 012637 004132      MOV      (KSP)+,16$     ;PUT ADDRESS OF ASCII CHARS. AT 16$
1861 004130 104401              TYPE                    ;TYPE OCTAL VALUE OF 22-BIT BINARY NO.
1862 004132 000000      16$: .WORD      0
1863 004134 012603      MOV      (KSP)+,R3      ;RESTORE R3
1864 004136 012602      MOV      (KSP)+,R2      ;RESTORE R2
1865 004140 005711      11$: TST      (R1)        ;IS THERE ANOTHER NUMBER?
1866 004142 001404      BEQ      12$            ;BR IF NO
1867 004144 104401 004166      TYPE     ,14$          ;TYPE TWO(2) SPACES
1868 004150 105720      TSTB    (R0)+          ;POINT TO NEW 'DATA FORMAT'
1869 004152 000707      BR      6$             ;LOOP
1870 004154 012601      12$: MOV      (KSP)+,R1      ;RESTORE R1
1871 004156 012600      13$: MOV      (KSP)+,R0      ;RESTORE R0
1872 004160 104401 001221      TYPE     , $CRLF       ;'CARRIAGE RETURN' & 'LINE FEED'
1873 004164 000207      RTS     PC              ;RETURN
1874 004166      040      000      14$: .ASCIZ  / /          ;TWO(2) SPACES
1875 004171      000
1876 004172 004202 004242 004272 PFECWS: .WORD  PFECM,PFECDH,PFECDT,PFECDF
1877 004202 004302      PFECM: .ASCIZ  ?POWER MONITOR BIT WAS FOUND SET?
1878 004202 120      117      127
1879 004205 105      122      040
1880 004210 115      117      116
1881 004213 111      124      117
1882 004216 122      040      102
1883 004221 111      124      040
1884 004224 127      101      123
1885 004227 040      106      117
1886 004232 125      116      104
1887 004235 040      123      105
1888 004240 124      000
1889 004242 124      105      123 PFECDH: .ASCIZ  ?TESTNO ERR PC CPUERR?
1890 004245 124      116      117
1891 004250 040      040      105
1892 004253 122      122      040
1893 004256 120      103      040
1894 004261 040      103      120
1895 004264 125      105      122
1896 004267 122      000
1879 004272 001230 001116 003266 PFECDT: .EVEN .WORD  $TESTN,$ERRPC,$CPSAVE,0
1880 004300 000000
1881 004302 000      000      000 PFECDF: .BYTE  0,0,0,0
1882 004305 000

```

1882

```

.SBTTL TTY INPUT ROUTINE
:*****
:ENABL LSB
:*****
:SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
:ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
:SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
:WHEN OPERATING IN TTY FLAG MODE.
$CKSWR: CMP #SWREG,SWR ;; IS THE SOFT-SWR SELECTED?
        BNE 15$ ;; BRANCH IF NO
        TSTB @STKS ;; CHAR THERE?
        BPL 15$ ;; IF NO, DON'T WAIT AROUND
        MOVB @STKB,-(SP) ;; SAVE THE CHAR
        BIC #^C17?,(SP) ;; STRIP-OFF THE ASCII
        CMP #7,(SP)+ ;; IS IT A CONTROL G?
        BNE 15$ ;; NO, RETURN TO USER
        CMPB $AUTOB,#1 ;; ARE WE RUNNING IN AUTO-MODE?
        BEQ 15$ ;; BRANCH IF YES
        TYPE ,SCNTLG ;; ECHO THE CONTROL-G (^G)
$GTSWR: TYPE ,SMSWR ;; TYPE CURRENT CONTENTS
        MOV SWREG,-(SP) ;; SAVE SWREG FOR TYPEOUT
        TYPOC ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
        TYPE ,SMNEW ;; PROMPT FOR NEW SWR
19$: CLR -(SP) ;; CLEAR COUNTER
        CLR -(SP) ;; THE NEW SWR
7$: TSTB @STKS ;; CHAR THERE?
        BPL 7$ ;; IF NOT TRY AGAIN
        MOVB @STKB,-(SP) ;; PICK UP CHAR
        BIC #^C17?,(SP) ;; MAKE IT 7-BIT ASCII
        CMP (SP),#3 ;; IS IT A CONTROL-C?
        BNE 9$ ;; BRANCH IF NOT
        TYPE ,SCNTLC ;; YES, ECHO CONTROL-C (^C)
        ADD #6,SP ;; CLEAN UP STACK
        CMPB $INTAG,#1 ;; REENABLE TTY KEYBOARD INTERRUPTS?
        BNE 8$ ;; BRANCH IF NO
        MOV #100,@STKS ;; ALLOW TTY KEYBOARD INTERRUPTS
8$: JMP CNTRLC ;; CONTROL-C RESTART
9$: CMP (SP),#25 ;; IS IT A CONTROL-U?
        BNE 10$ ;; BRANCH IF NOT
        TYPE ,SCNTLU ;; YES, ECHO CONTROL-U (^U)
20$: ADD #6,SP ;; IGNORE PREVIOUS INPUT
        BR 19$ ;; LET'S TRY IT AGAIN
10$: CMP (SP),#15 ;; IS IT A <CR>?
        BNE 16$ ;; BRANCH IF NO
        TST 4(SP) ;; YES, IS IT THE FIRST CHAR?
        BEQ 11$ ;; BRANCH IF YES
        MOV 2(SP),@SWR ;; SAVE NEW SWR
11$: ADD #6,SP ;; CLEAN UP STACK
14$: TYPE ,SCRLF ;; ECHO <CR> AND <LF>
        CMPB $INTAG,#1 ;; RE-ENABLE TTY KBD INTERRUPTS?
        BNE 15$ ;; BRANCH IF NOT
        MOV #100,@STKS ;; RE-ENABLE TTY KBD INTERRUPTS
15$: RTI ;; RETURN
16$: JSR PC,$TYPEC ;; ECHO CHAR
        CMP (SP),#60 ;; CHAR < 0?
        BLT 18$ ;; BRANCH IF YES
        CMP (SP),#67 ;; CHAR > 7?

```

004306	022737	000176	001140
004314	001114		
004316	105777	174622	
004322	100111		
004324	117746	174616	
004330	042716	177600	
004334	022726	000007	
004340	001102		
004342	123727	001134	000001
004350	001476		
004352	104401	005253	
004356	104401	005260	
004362	013746	000176	
004366	104402		
004370	104401	005271	
004374	005046		
004376	005046		
004400	105777	174540	
004404	100375		
004406	117746	174534	
004412	042716	177600	
004416	021627	000003	
004422	001015		
004424	104401	001312	
004430	062706	000006	
004434	123727	001135	000001
004442	001003		
004444	012777	000100	174472
004452	000137	005302	
004456	021627	000025	
004462	001005		
004464	104401	005246	
004470	062706	000006	
004474	000737		
004476	021627	000015	
004502	001022		
004504	005766	000004	
004510	001403		
004512	016677	000002	174420
004520	062706	000006	
004524	104401	001221	
004530	123727	001135	000001
004536	001003		
004540	012777	000100	174376
004546	000002		
004550	004737	005644	
004554	021627	000060	
004560	002420		
004562	021627	000067	

```

004566 003015          BGT      18$          ;;BRANCH IF YES
004570 042726 000060  BIC      #60,(SP)+    ;;STRIP-OFF ASCII
004574 005766 000002  TST      2(SP)        ;;IS THIS THE FIRST CHAR
004600 001403          BEQ      17$          ;;BRANCH IF YES
004602 006316          ASL      (SP)         ;;NO, SHIFT PRESENT
004604 006316          ASL      (SP)         ;;CHAR OVER TO MAKE
004606 006316          ASL      (SP)         ;;ROOM FOR NEW ONE.
004610 005266 000002  17$: INC      2(SP)        ;;KEEP COUNT OF CHAR
004614 056616 177776  BIS      -2(SP),(SP)  ;;SET IN NEW CHAR
004620 000667          BR       7$          ;;GET THE NEXT ONE
004622 104401 001220  18$: TYPE   $QUES     ;;TYPE ?<CR><LF>
004626 000720          BR       20$         ;;SIMULATE CONTROL-U
.DSABL  LSB
;*****
;THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
;CALL:
;*      RDCHR          ;;INPUT A SINGLE CHARACTER FROM THE TTY
;*      RETURN HERE    ;;CHARACTER IS ON THE STACK
;*                      ;;WITH PARITY BIT STRIPPED OFF
004630 011646          $RDCHR: MOV      (SP),-(SP)  ;;PUSH DOWN THE PC
004632 016666 000004 000002  MOV      4(SP),2(SP)  ;;SAVE THE PS
004640 105777 174300  1$: TSTB   @STKS      ;;WAIT FOR
004644 100375          BPL      1$          ;;A CHARACTER
004646 117766 174274 000004  MOVB    @STKB,4(SP)   ;;READ THE TTY
004654 042766 177600 000004  BIC     #^C<177>,4(SP) ;;GET RID OF JUNK IF ANY
004662 026627 000004 000023  CMP     4(SP),#23     ;;IS IT A CONTROL-S?
004670 001013          BNE     3$          ;;BRANCH IF NO
004672 105777 174246  2$: TSTB   @STKS      ;;WAIT FOR A CHARACTER
004676 100375          BPL     2$          ;;LOOP UNTIL ITS THERE
004700 117746 174242  MOVB    @STKB,-(SP)   ;;GET CHARACTER
004704 042716 177600  BIC     #^C177,(SP)  ;;MAKE IT 7-BIT ASCII
004710 022627 000021  CMP     (SP)+,#21     ;;IS IT A CONTROL-Q?
004714 001366          BNE     2$          ;;IF NOT DISCARD IT
004716 000750          BR      1$          ;;YES, RESUME
004720 026627 000004 000021  3$: CMP     4(SP),#$XON ;;IS IT A RANDOM XON?
004726 001744          BEQ     1$          ;;BRANCH IF YES
004730 026627 000004 000140  CMP     4(SP),#140    ;;IS IT UPPER CASE?
004736 002407          BLT     4$          ;;BRANCH IF YES
004740 026627 000004 000175  CMP     4(SP),#175    ;;IS IT A SPECIAL CHAR?
004746 003003          BGT     4$          ;;BRANCH IF YES
004750 042766 000040 000004  BIC     #40,4(SP)     ;;MAKE IT UPPER CASE
004756 000002          RTI          ;;GO BACK TO USER
;*****
;THIS ROUTINE WILL INPUT A STRING FROM THE TTY
;CALL:
;*      RDLIN          ;;INPUT A STRING FROM THE TTY
;*      RETURN HERE    ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
;*                      ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
004760 010346          $RDLIN: MOV     R3,-(SP)  ;;SAVE R3
004762 005046          CLR     -(SP)        ;;CLEAR THE RUBOUT KEY
004764 012703 005236  1$: MOV     #$TTYIN,R3  ;;GET ADDRESS
004770 022703 005246  2$: CMP     #$TTYIN+8.,R3 ;;BUFFER FULL?
004774 101467          BLOS   4$          ;;BR IF YES
004776 104411          RDCHR   ;;GO READ ONE CHARACTER FROM THE TTY
005000 112613          MOVB   (SP)+,(R3)    ;;GET CHARACTER
005002 122713 000003  CMPB   #3,(R3)       ;;IS IT A CONTROL-C?

```

005006	001006			BNE	10\$::BRANCH IF NO
005010	104401	001312		TYPE	,\$CNTLC	::TYPE A CONTROL-C (^C)
005014	005726			TST	(SP)+	::CLEAN RUBOUT KEY OFF OF THE STACK
005016	012603			MOV	(SP)+,R3	::RESTORE R3
005020	000137	005302		JMP	CNTRLC	::GOTO CONTROL-C RESTART
005024	122713	000177	10\$:	CMPB	#177,(R3)	::IS IT A RUBOUT
005030	001022			BNE	5\$::BR IF NO
005032	005716			TST	(SP)	::IS THIS THE FIRST RUBOUT?
005034	001007			BNE	6\$::BR IF NO
005036	112737	000134	005234	MOVB	#'\,9\$::TYPE A BACK SLASH
005044	104401	005234		TYPE	,9\$	
005050	012716	177777		MOV	#-1,(SP)	::SET THE RUBOUT KEY
005054	005303		6\$:	DEC	R3	::BACKUP BY ONE
005056	020327	005236		CMP	R3,\$TTYIN	::STACK EMPTY?
005062	103434			BLO	4\$::BR IF YES
005064	111337	005234		MOVB	(R3),9\$::SETUP TO TYPEOUT THE DELETED CHAR.
005070	104401	005234		TYPE	,9\$::GO TYPE
005074	000735			BR	2\$::GO READ ANOTHER CHAR.
005076	005716		5\$:	TST	(SP)	::RUBOUT KEY SET?
005100	001406			BEQ	7\$::BR IF NO
005102	112737	000134	005234	MOVB	#'\,9\$::TYPE A BACK SLASH
005110	104401	005234		TYPE	,9\$	
005114	005016			CLR	(SP)	::CLEAR THE RUBOUT KEY
005116	122713	000025	7\$:	CMPB	#25,(R3)	::IS CHARACTER A CTRL U?
005122	001003			BNE	8\$::BR IF NO
005124	104401	005246		TYPE	,\$CNTLU	::TYPE A CONTROL 'U'
005130	000715			BR	1\$::GO START OVER
005132	122713	000022	8\$:	CMPB	#22,(R3)	::IS CHARACTER A '^R'?
005136	001011			BNE	3\$::BRANCH IF NO
005140	105013			CLRB	(R3)	::CLEAR THE CHARACTER
005142	104401	001221		TYPE	,\$CRLF	::TYPE A 'CR' & 'LF'
005146	104401	005236		TYPE	,\$TTYIN	::TYPE THE INPUT STRING
005152	000706			BR	2\$::GO PICKUP ANOTHER CHACTER
005154	104401	001220	4\$:	TYPE	,\$QUES	::TYPE A '?'
005160	000701			BR	1\$::CLEAR THE BUFFER AND LOOP
005162	111337	005234	3\$:	MOVB	(R3),9\$::ECHO THE CHARACTER
005166	104401	005234		TYPE	,9\$	
005172	122723	000015		CMPB	#15,(R3)+	::CHECK FOR RETURN
005176	001274			BNE	2\$::LOOP IF NOT RETURN
005200	105063	177777		CLRB	-1(R3)	::CLEAR RETURN (THE 15)
005204	104401	001222		TYPE	,\$LF	::TYPE A LINE FEED
005210	005726			TST	(SP)+	::CLEAN RUBOUT KEY FROM THE STACK
005212	012603			MOV	(SP)+,R3	::RESTORE R3
005214	011646			MOV	(SP)-,(SP)	::ADJUST THE STACK AND PUT ADDRESS OF THE
005216	016666	000004	000002	MOV	4(SP),2(SP)	::
005224	012766	005236	000004	MOV	,\$TTYIN,4(SP)	:: FIRST ASCII CHARACTER ON IT
005232	000002			RTI		::RETURN
005234	000		9\$:	.BYTE	0	::STORAGE FOR ASCII CHAR. TO TYPE
005235	000			.BYTE	0	::TERMINATOR
005236				STTYIN:	.BLKB	8.
005246	136	125	015	\$CNTLU:	.ASCIZ	/'^U/<15><12>
005251	012	000				::CONTROL 'U'
005253	136	107	015	\$CNTLG:	.ASCIZ	/'^G/<15><12>
005256	012	000				::CONTROL 'G'
005260	015	012	123	\$MSWR:	.ASCIZ	<15><12>/SWR = /
005263	127	122	040			
005266	075	040	000			

005271	040	040	116	SMNEW: .ASCIZ / NEW = /
005274	105	127	040	
005277	075	040	000	

```

1884          .SBTTL CONTROL-C SERVICING ROUTINE
1885
1886 005302 013737 001232 001210 CNTRLC: MOV $PASS,$TMP5 ;GET THE VALUE OF '$PASS'
1887 005310 005237 001210          INC $TMP5 ;FORM CURRENT PASS #
1888 005314 104401 005361          TYPE ,CMMSG ;TYPE THE TEST STOPS HERE
1889 005320 113737 001102 005354 MOV $STNM,1$ ;SAVE TEST NUMBER
1890 005326 013746 005354          MOV 1$,-(SP) ;SAVE 1$ FO TYPEOUT
1891 005332 104402          TYPDC
1892 005334 104401 005356          TYPE ,2$
1893 005340 013746 001210          MOV $TMP5,-(SP) ;SAVE $TMP5 FOR TYPEOUT
1894 005344 104405          TYPDS ;TYPE ASCII DECIMAL WITH SIGN
1895 005346 104407          GTSWR ;ASK FOR NEW SWR VALUE
1896 005350 000137 036026          JMP $EOP+2 ;JUMP TO END OF PASS + 2
1897 005354 000000          1$: .WORD 0 ;TEST # BUFFER
1898 005356          2$: .ASCIZ / / ;2 SPACES & STOP MESSAGE
1899 005361          CMMSG: .ASCII /JUMPING TO END OF PASS/<15><12>
          005364          112 125 115
          005367          107 040 124
          005372          117 040 105
          005375          116 104 040
          005400          117 106 040
          005403          120 101 123
          005406          123 015 012
1900 005411          124 105 123 .ASCIZ /TESTNO PASSNO/<15><12>
          005414          124 116 117
          005417          011 120 101
          005422          123 123 116
          005425          117 015 012
          005430          000
1901          .EVEN
    
```


1903

.SBTTL TYPE ROUTINE

 *ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
 *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
 *NOTE1: \$NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
 *NOTE2: \$FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
 *NOTE3: \$FILLC CONTAINS THE CHARACTER TO FILL AFTER.
 *

*CALL:
 *1) USING A TRAP INSTRUCTION
 * TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING

*OR
 * TYPE
 * MESADR

005432	105737	001157	\$TYPE:	TSTB	\$TPFLG	::IS THERE A TERMINAL?
005436	100002			BPL	1\$::BR IF YES
005440	000000			HALT		::HALT HERE IF NO TERMINAL
005442	000430			BR	3\$::LEAVE
005444	010046		1\$:	MOV	RO,-(SP)	::SAVE RO
005446	017600	000002		MOV	@2(SP),RO	::GET ADDRESS OF ASCIZ STRING
005452	122737	000001	001244	CMPB	#APTENV,\$ENV	::RUNNING IN APT MODE
005460	001011			BNE	62\$::NO,GO CHECK FOR APT CONSOLE
005462	132737	000100	001245	BITB	#APTSPOOL,\$ENVM	::SPOOL MESSAGE TO APT
005470	001405			BEQ	62\$::NO,GO CHECK FOR CONSOLE
005472	010037	005502		MOV	RO,61\$::SETUP MESSAGE ADDRESS FOR APT
005476	004737	006004		JSR	PC,\$ATY3	::SPOOL MESSAGE TO APT
005502	000000			.WORD	0	::MESSAGE ADDRESS
005504	132737	000040	001245	61\$:	BITB	#APTCSUP,\$ENVM
005512	001003			62\$:	BNE	60\$
005514	112046			2\$:	MOVB	(RO)+,-(SP)
005516	001005				BNE	4\$
005520	005726				TST	(SP)+
005522	012600			60\$:	MOV	(SP)+,RO
005524	062716	000002		3\$:	ADD	#2,(SP)
005530	000002				RTI	
005532	122716	000011		4\$:	CMPB	#HT,(SP)
005536	001430				BEQ	8\$
005540	122716	000200			CMPB	#CRLF,(SP)
005544	001006				BNE	5\$
005546	005726				TST	(SP)+
005550	104401				TYPE	
005552	001221				\$CRLF	
005554	105037	005772			CLRB	\$CHARCNT
005560	000755				BR	2\$
005562	004737	005644		5\$:	JSR	PC,\$TYPEC
005566	123726	001156		6\$:	CMPB	\$FILLC,(SP)+
005572	001350				BNE	2\$
005574	013746	001154			MOV	\$NULL,-(SP)
005600	105366	000001		7\$:	DECB	1(SP)
005604	002770				BLT	6\$
005606	004737	005644			JSR	PC,\$TYPEC
005612	105337	005772			DECB	\$CHARCNT
005616	000770				BR	7\$
						::LOOP
005620	112716	000040		8\$:	MOV	#' ,(SP)
						::REPLACE TAB WITH SPACE

:HORIZONTAL TAB PROCESSOR

```

005624 004737 005644 9$: JSR PC,$TYPEC ;;TYPE A SPACE
005630 132737 000007 005772 BITB #7,$CHARCNT ;;BRANCH IF NOT AT
005636 001372 BNE 9$ ;;TAB STOP
005640 005726 TST (SP)+ ;;POP SPACE OFF STACK
005642 000724 BR 2$ ;;GET NEXT CHARACTER
005644 $TYPEC:
005644 105777 173274 TSTB @STKS ;;CHAR IN KYBD BUFFER? ;MJD001
005650 100022 BPL 10$ ;;BR IF NOT ;MJD001
005652 017746 173270 MOV @STKB,-(SP) ;;GET CHAR ;MJD001
005656 042716 177600 BIC #177600,(SP) ;;STRIP EXTRANEIOUS BITS ;MJD001
005662 122716 000023 CMPB #$XOFF,(SP) ;;WAS CHAR XOFF ;MJD001
005666 001012 BNE 102$ ;;BR IF NOT ;MJD001
005670 105777 173250 101$: TSTB @STKS ;;WAIT FOR CHAR ;MJD001
005674 100375 BPL 101$ ;MJD001
005676 117716 173244 MOVB @STKB,(SP) ;;GET CHAR ;MJD001
005702 042716 177600 BIC #177600,(SP) ;;STRIP IT ;MJD001
005706 122716 000021 CMPB #$XON,(SP) ;;WAS IT XON? ;MJD001
005712 001366 BNE 101$ ;;BR IF NOT ;MJD001
005714 102$: TST (SP)+ ;;FIX STACK ;MJD001
005716 105777 173226 10$: TSTB @STPS ;;WAIT UNTIL PRINTER IS READY ;MJD001
005722 100375 BPL 10$ ;MJD001
005724 126627 000002 000021 CMPB 2(SP),#$XON ;;IS CHARACTER A RANDOM XON? ;RAN001
005732 001420 BEQ $TYPEX ;;BRANCH IF YES ;RAN001
005734 116677 000002 173210 MOVB 2(SP),@STPB ;;LOAD CHAR TO BE TYPED INTO DATA REG.
005742 122766 000015 000002 CMPB #CR,2(SP) ;;IS CHARACTER A CARRIAGE RETURN?
005750 001003 BNE 1$ ;;BRANCH IF NO
005752 105037 005772 CLRB $CHARCNT ;;YES--CLEAR CHARACTER COUNT
005756 000406 BR $TYPEX ;;EXIT
005760 122766 000012 000002 1$: CMPB #LF,2(SP) ;;IS CHARACTER A LINE FEED?
005766 001402 BEQ $TYPEX ;;BRANCH IF YES
005770 105227 INCB (PC)+ ;;COUNT THE CHARACTER
005772 000000 $CHARCNT: .WORD 0 ;;CHARACTER COUNT STORAGE
005774 000207 $TYPEX: RTS PC

```

1904

.SBTTL APT COMMUNICATIONS ROUTINE

```

*****
005776 112737 000001 006242 $ATY1: MOVB #1,$FFLG ;;TO REPORT FATAL ERROR
006004 112737 000001 006240 $ATY3: MOVB #1,$MFLG ;;TO TYPE A MESSAGE
006012 000403
006014 112737 000001 006242 $ATY4: MOVB #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
006022 $ATYC:
006022 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
006024 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
006026 105737 006240 TSTB $MFLG ;;SHOULD TYPE A MESSAGE?
006032 001450 BEQ 5$ ;;IF NOT: BR
006034 122737 000001 001244 CMPB #APTENV,$ENV ;;OPERATING UNDER APT?
006042 001031 BNE 3$ ;;IF NOT: BR
006044 132737 000100 001245 BITB #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
006052 001425 BEQ 3$ ;;IF NOT: BR
006054 017600 000004 MOV @4(SP),R0 ;;GET MESSAGE ADDR.
006060 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
006066 005737 001224 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
006072 001375 BNE 1$ ;;IF NOT: WAIT
006074 010037 001240 MOV R0,$MSGAD ;;PUT ADDR IN MAILBOX
006100 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
006102 001376 BNE 2$
006104 163700 001240 SUB $MSGAD,R0 ;;SUB START OF MESSAGE
006110 006200 ASR R0 ;;GET MESSAGE LNGTH IN WORDS
006112 010037 001242 MOV R0,$MSGLGT ;;PUT LENGTH IN MAILBOX
006116 012737 000004 001224 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
006124 000413 BR 5$
006126 017637 000004 006152 3$: MOV @4(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
006134 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
006142 013746 177776 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
006146 004737 005432 JSR PC,$TYPE ;;CALL TYPE MACRO
006152 000000 4$: .WORD 0
006154 5$:
006154 105737 006242 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
006160 001416 BEQ 12$ ;;IF NOT: BR
006162 005737 001244 TST $ENV ;;RUNNING UNDER APT?
006166 001413 BEQ 12$ ;;IF NOT: BR
006170 005737 001224 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
006174 001375 BNE 11$ ;;IF NOT: WAIT
006176 017637 000004 001226 MOV @4(SP),$FATAL ;;GET ERROR #
006204 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
006212 005237 001224 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
006216 105037 006242 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
006222 105037 006241 CLRB $LFLG ;;CLEAR LOG FLAG
006226 105037 006240 CLRB $MFLG ;;CLEAR MESSAGE FLAG
006232 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
006234 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
006236 000207 RTS PC ;;RETURN
006240 000 $MFLG: .BYTE 0 ;;MESSG. FLAG
006241 000 $LFLG: .BYTE 0 ;;LOG FLAG
006242 000 $FFLG: .BYTE 0 ;;FATAL FLAG
.EVEN
000200 APTSIZE=200
000001 APTENV=001
000100 APTSPOOL=100
000040 APTCSUP=040

```

1905

```

.SBTTL BINARY TO ASCII AND TYPE ROUTINE
:*****
:*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 16-BIT
:*BINARY-ASCII NUMBER AND TYPE IT.
:*CALL:
:*
MOV     NUMBER,-(SP)    ;;NUMBER TO BE TYPED
TYPBN
$TYPBN: MOV     R1,-(SP)    ;;SAVE R1 ON THE STACK
MOV     6(SP),R1       ;;GET THE INPUT NUMBER
SEC     ;;SET 'C' SO CAN KEEP TRACK OF THE NUMBER OF BITS
1$:     MOVB    #'0,$BIN  ;;SET CHARACTER TO AN ASCII '0'.
ROL     R1             ;;GET THIS BIT
BEQ     2$            ;;DONE?
ADCB    $BIN          ;;NO--SET THE CHARACTER EQUAL TO THIS BIT
TYPE    .$BIN         ;;GO TYPE THIS BIT
CLC    ;;CLEAR 'C' SO CAN KEEP TRACK OF BITS
BR     1$            ;;GO DO THE NEXT BIT
2$:     MOV     (SP)+,R1  ;;POP THE STACK INTO R1
MOV     2(SP),4(SP)   ;;ADJUST THE STACK
MOV     (SP)+,(SP)
RTI    ;;RETURN TO USER
$BIN:   .BYTE    0,0  ;;STORAGE FOR ASCII CHAR. AND TERMINATOR
    
```

1906

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE
*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*      MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOS   TYPOS        ;;CALL FOR TYPEOUT
*      .BYTE   N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*      .BYTE   M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS
*
*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*      MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPON   TYPON        ;;CALL FOR TYPEOUT
*
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*      MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOC   TYPOC        ;;CALL FOR TYPEOUT
*$TYPOS:
*      MOV     @ (SP),-(SP)    ;;PICKUP THE MODE
*      MOV     1(SP), $OFILL   ;;LOAD ZERO FILL SWITCH
*      MOV     (SP)+, $OMODE+1 ;;NUMBER OF DIGITS TO TYPE
*      ADD     #2,(SP)        ;;ADJUST RETURN ADDRESS
*      BR     $TYPON
*
*$TYPOC:
*      MOV     #1,$OFILL      ;;SET THE ZERO FILL SWITCH
*      MOV     #6,$OMODE+1    ;;SET FOR SIX(6) DIGITS
*$TYPON:
*      MOV     #5,$OCNT      ;;SET THE ITERATION COUNT
*      MOV     R3,-(SP)      ;;SAVE R3
*      MOV     R4,-(SP)      ;;SAVE R4
*      MOV     R5,-(SP)      ;;SAVE R5
*      MOV     $OMODE+1,R4   ;;GET THE NUMBER OF DIGITS TO TYPE
*      NEG     R4
*      ADD     #6,R4         ;;SUBTRACT IT FOR MAX. ALLOWED
*      MOV     R4,$OMODE     ;;SAVE IT FOR USE
*      MOV     $OFILL,R4     ;;GET THE ZERO FILL SWITCH
*      MOV     12(SP),R5     ;;PICKUP THE INPUT NUMBER
*      CLR     R3            ;;CLEAR THE OUTPUT WORD
*      ROL     R5            ;;ROTATE MSB INTO 'C'
*      BR     3$           ;;GO DO MSB
*
*2$:
*      ROL     R5            ;;FORM THIS DIGIT
*      ROL     R5
*      MOV     R5,R3
*
*3$:
*      ROL     R3            ;;GET LSB OF THIS DIGIT
*      DECB   $OMODE        ;;TYPE THIS DIGIT?
*      BPL     7$           ;;BR IF NO
*      BIC     #177770,R3   ;;GET RID OF JUNK
*      BNE     4$           ;;TEST FOR 0
*      TST     R4           ;;SUPPRESS THIS 0?
*      BEQ     5$           ;;BR IF YES
*
*4$:
*      INC     R4           ;;DON'T SUPPRESS ANYMORE 0'S
*      BIS     #'0,R3      ;;MAKE THIS DIGIT ASCII
*
*5$:
*      BIS     #' ,R3      ;;MAKE ASCII If NOT ALREADY
  
```

006320	017646	000000	
006324	116637	000001	006543
006332	112637	006545	
006336	062716	000002	
006342	000406		
006344	112737	000001	006543
006352	112737	000006	006545
006360	112737	000005	006542
006366	010346		
006370	010446		
006372	010546		
006374	113704	006545	
006400	005404		
006402	062704	000006	
006406	110437	006544	
006412	113704	006543	
006416	016605	000012	
006422	005003		
006424	006105		1\$:
006426	000404		
006430	006105		2\$:
006432	006105		
006434	006105		
006436	010503		
006440	006103		3\$:
006442	105337	006544	
006446	100016		
006450	042703	177770	
006454	001002		
006456	005704		
006460	001403		
006462	005204		4\$:
006464	052703	000060	
006470	052703	000040	5\$:

006474	110337	006540		MOVB	R3,8\$::SAVE FOR TYPING
006500	104401	006540		TYPE	.8\$::GO TYPE THIS DIGIT
006504	105337	006542	7\$:	DECB	\$OCNT	::COUNT BY 1
006510	003347			BGT	2\$::BR IF MORE TO DO
006512	002402			FLT	6\$::BR IF DONE
006514	005204			INC	R4	::INSURE LAST DIGIT ISN'T A BLANK
006516	000744			BR	2\$::GO DO THE LAST DIGIT
006520	012605		6\$:	MOV	(SP)+,R5	::RESTORE R5
006522	012604			MOV	(SP)+,R4	::RESTORE R4
006524	012603			MOV	(SP)+,R3	::RESTORE R3
006526	016666	000002 000004		MOV	2(SP),4(SP)	::SET THE STACK FOR RETURNING
006534	012616			MOV	(SP)+,(SP)	
006536	000002			RTI		::RETURN
006540	000		8\$:	.BYTE	0	::STORAGE FOR ASCII DIGIT
006541	000			.BYTE	0	::TERMINATOR FOR TYPE ROUTINE
006542	000			\$OCNT:	.BYTE 0	::OCTAL DIGIT COUNTER
006543	000			\$OFILL:	.BYTE 0	::ZERO FILL SWITCH
006544	000000			\$OMODE:	.WORD 0	::NUMBER OF DIGITS TO TYPE

1907

```

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
:*****
:THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
:SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
:NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
:BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
:REPLACED WITH SPACES.
:CALL:
:*
:*      MOV      NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
:*      TYPDS                    ;;GO TO THE ROUTINE
$TYPDS:
MOV      R0,-(SP)      ;;PUSH R0 ON STACK
MOV      R1,-(SP)      ;;PUSH R1 ON STACK
MOV      R2,-(SP)      ;;PUSH R2 ON STACK
MOV      R3,-(SP)      ;;PUSH R3 ON STACK
MOV      R5,-(SP)      ;;PUSH R5 ON STACK
MOV      #20200,-(SP)    ;;SET BLANK SWITCH AND SIGN
MOV      20(SP),R5      ;;GET THE INPUT NUMBER
BPL      1$            ;;BR IF INPUT IS POS.
NEG      R5            ;;MAKE THE BINARY NUMBER POS.
MOVB     #'-,1(SP)     ;;MAKE THE ASCII NUMBER NEG.
CLR      R0            ;;ZERO THE CONSTANTS INDEX
MOV      #$DBLK,R3     ;;SETUP THE OUTPUT POINTER
MOVB     #' ,(R3)+     ;;SET THE FIRST CHARACTER TO A BLANK
2$:      CLR      R2            ;;CLEAR THE BCD NUMBER
MOV      $DTBL(R0),R1  ;;GET THE CONSTANT
3$:      SUB      R1,R5        ;;FORM THIS BCD DIGIT
BLT      4$            ;;BR IF DONE
INC      R2            ;;INCREASE THE BCD DIGIT BY 1
BR       3$
4$:      ADD      R1,R5        ;;ADD BACK THE CONSTANT
TST      R2            ;;CHECK IF BCD DIGIT=0
BNE      5$            ;;FALL THROUGH IF 0
TSTB     (SP)          ;;STILL DOING LEADING 0'S?
BMI      7$            ;;BR IF YES
5$:      ASLB     (SP)          ;;MSD?
BCC      6$            ;;BR IF NO
MOVB     1(SP),-1(R3)  ;;YES--SET THE SIGN
6$:      BIS      #'0,R2      ;;MAKE THE BCD DIGIT ASCII
7$:      BIS      #' ,R2      ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOVB     R2,(R3)+     ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
TST      (R0)+        ;;JUST INCREMENTING
CMP      R0,#10       ;;CHECK THE TABLE INDEX
BLT      2$            ;;GO DO THE NEXT DIGIT
BGT      8$            ;;GO TO EXIT
MOV      R5,R2        ;;GET THE LSD
BR       6$            ;;GO CHANGE TO ASCII
8$:      TSTB     (SP)+      ;;WAS THE LSD THE FIRST NON-ZERO?
BPL      9$            ;;BR IF NO
9$:      MOVB     -1(SP),-2(R3) ;;YES--SET THE SIGN FOR TYPING
CLRB     (R3)          ;;SET THE TERMINATOR
MOV      (SP)+,R5     ;;POP STACK INTO R5
MOV      (SP)+,R3     ;;POP STACK INTO R3
MOV      (SP)+,R2     ;;POP STACK INTO R2
MOV      (SP)+,R1     ;;POP STACK INTO R1
MOV      (SP)+,R0     ;;POP STACK INTO R0
TYPE     , $DBLK      ;;NOW TYPE THE NUMBER

```

```

006546
006546 010046
006550 010146
006552 010246
006554 010346
006556 010546
006560 012746 020200
006564 016605 000020
006570 100004
006572 005405
006574 112766 000055 000001
006602 005000 1$:
006604 012703 006762
006610 112723 000040
006614 005002 2$:
006616 016001 006752
006622 160105 3$:
006624 002402
006626 005202
006630 000774
006632 060105 4$:
006634 005702
006636 001002
006640 105716
006642 100407
006644 106316 5$:
006646 103003
006650 116663 000001 177777
006656 052702 000060 6$:
006662 052702 000040 7$:
006666 110223
006670 005720
006672 020027 000010
006676 002746
006700 003002
006702 010502
006704 000764
006706 105726 8$:
006710 100003
006712 116663 177777 177776
006720 105013 9$:
006722 012605
006724 012603
006726 012602
006730 012601
006732 012600
006734 104401 006762

```

```
006740 016666 000002 000004      MOV      2(SP),4(SP)      ;;ADJUST THE STACK
006746 012616                      MOV      (SP)+,(SP)
006750 000002                      RTI                          ;;RETURN TO USER
006752 023420      $DTBL: 10000.
006754 001750                      1000.
006756 000144                      100.
006760 000012                      10.
006762                      $DBLK: .BLKW 4
```


1908

..SBTTL SAVE AND RESTORE RO-R5 ROUTINES
 ..*****

..*SAVE RO-R5
 ..*CALL:
 ..* SAVREG
 ..*UPON RETURN FROM \$SAVREG THE STACK WILL LOOK LIKE:
 ..*
 ..*TOP---(+16)
 ..* +2---(+18)
 ..* +4---R5
 ..* +6---R4
 ..* +8---R3
 ..*+10---R2
 ..*+12---R1
 ..*+14---R0

..\$SAVREG:
 ..MOV R0,-(SP) ;;PUSH R0 ON STACK
 ..MOV R1,-(SP) ;;PUSH R1 ON STACK
 ..MOV R2,-(SP) ;;PUSH R2 ON STACK
 ..MOV R3,-(SP) ;;PUSH R3 ON STACK
 ..MOV R4,-(SP) ;;PUSH R4 ON STACK
 ..MOV R5,-(SP) ;;PUSH R5 ON STACK
 ..MOV 22(SP),-(SP) ;;SAVE PS OF MAIN FLOW
 ..MOV 22(SP),-(SP) ;;SAVE PC OF MAIN FLOW
 ..MOV 22(SP),-(SP) ;;SAVE PS OF CALL
 ..MOV 22(SP),-(SP) ;;SAVE PC OF CALL
 ..RTI

..*RESTORE RO-R5
 ..*CALL:
 ..* RESREG

..\$RESREG:
 ..MOV (SP)+,22(SP) ;;RESTORE PC OF CALL
 ..MOV (SP)+,22(SP) ;;RESTORE PS OF CALL
 ..MOV (SP)+,22(SP) ;;RESTORE PC OF MAIN FLOW
 ..MOV (SP)+,22(SP) ;;RESTORE PS OF MAIN FLOW
 ..MOV (SP)+,R5 ;;POP STACK INTO R5
 ..MOV (SP)+,R4 ;;POP STACK INTO R4
 ..MOV (SP)+,R3 ;;POP STACK INTO R3
 ..MOV (SP)+,R2 ;;POP STACK INTO R2
 ..MOV (SP)+,R1 ;;POP STACK INTO R1
 ..MOV (SP)+,R0 ;;POP STACK INTO R0
 ..RTI

006772
 006772 010046
 006774 010146
 006776 010246
 007000 010346
 007002 010446
 007004 010546
 007006 016646 000022
 007012 016646 000022
 007016 016646 000022
 007022 016646 000022
 007026 000002

007030
 007030 012666 000022
 007034 012666 000022
 007040 012666 000022
 007044 012666 000022
 007050 012605
 007052 012604
 007054 012603
 007056 012602
 007060 012601
 007062 012600
 007064 000002

```

1909          .SBTTL  DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE
              :*****
              :*THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
              :*UNSIGNED OCTAL ASCII NUMBER.
              :*CALL
              :*
              :*   MOV     #PNTR,-(SP)      ;; POINTER TO LOW WORD OF BINARY NUMBER
              :*   JSR     PC,@#$DB20    ;; CALL THE ROUTINE
              :*   RETURN                    ;; THE ADDRESS OF THE FIRST ASCII CHAR. IS ON THE STACK
              $DB20: SAVREG                ;; SAVE ALL REGISTERS
              :*   MOV     2(SP),R1      ;; PICKUP THE POINTER TO LOW WORD
              :*   MOV     #$OCTVL+13.,R5 ;; POINTER TO DATA TABLE
              :*   MOV     #12.,R4       ;; DO ELEVEN CHARACTERS
              :*   MOV     #^C7,R3      ;; MASK
              :*   MOV     (R1)+,R0      ;; LOWER WORD
              :*   MOV     (R1)+,R1      ;; HIGH WORD
              :*   CLR     R2           ;; TERMINATOR
              1$:  MOVB    R2,-(R5)      ;; PUT CHARACTER IN DATA TABLE
              :*   MOV     R0,R2        ;; GET THIS DIGIT
              :*   DEC     R4           ;; COUNT THIS CHARACTER
              :*   BGT     3$           ;; BR IF NOT THE LAST DIGIT
              :*   BEQ     2$           ;; BR IF IT IS THE LAST DIGIT
              :*   INC     R5           ;; ALL DIGITS DONE-ADJUST POINTER FOR FIRST
              :*   MOV     R5,2(SP)     ;; ASCII CHAR. & PUT IT ON THE STACK
              :*   RESREG                ;; RESTORE ALL REGISTERS
              :*   RTS     PC           ;; RETURN TO USER
              2$:  ASR     R3           ;; POSITION THE MASK FOR THE LAST DIGIT
              3$:  ROR     R1           ;; POSITION THE BINARY NUMBER FOR
              :*   ROR     R0           ;; THE NEXT OCTAL DIGIT
              :*   ROR     R1
              :*   ROR     R0
              :*   ROR     R1
              :*   ROR     R0
              :*   BIC     R3,R2       ;; MASK OUT ALL JUNK
              :*   ADD     #'0,R2      ;; MAKE THIS CHAR. ASCII
              :*   BR     1$           ;; GO PUT IT IN THE DATA TABLE
              $OCTVL: .BLKB 14.        ;; RESERVE DATA TABLE
    007066 104413
    007070 016601 000002
    007074 012705 007205
    007100 012704 000014
    007104 012703 177770
    007110 012100
    007112 012101
    007114 005002
    007116 110245
    007120 010002
    007122 005304
    007124 003007
    007126 001405
    007130 005205
    007132 010566 000002
    007136 104414
    007140 000207
    007142 006203
    007144 006001
    007146 006000
    007150 006001
    007152 006000
    007154 006001
    007156 006000
    007160 040302
    007162 062702 000060
    007166 000753
    007170
    
```

1910

.SBTTL TRAP DECODER

 *THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE 'TRAP' INSTRUCTION
 *AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
 *OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
 *GO TO THAT ROUTINE.

007206 010046
 007210 016600 000002
 007214 005740
 007216 111000
 007220 006300
 007222 016000 007242
 007226 000200

```
$TRAP:  MOV    R0,-(SP)      ;;SAVE R0
        MOV    2(SP),R0     ;;GET TRAP ADDRESS
        TST   -(R0)        ;;BACKUP BY 2
        MOVB  (R0),R0       ;;GET RIGHT BYTE OF TRAP
        ASL   R0            ;;POSITION FOR INDEXING
        MOV   $TRPAD(R0),R0 ;;INDEX TO TABLE
        RTS   R0            ;;GO TO ROUTINE
```

;;THIS IS USE TO HANDLE THE 'GETPRI' MACRO

007230 011646
 007232 016666 000004 000002
 007240 000002

```
$TRAP2: MOV   (SP),-(SP)    ;;MOVE THE PC DOWN
        MOV   4(SP),2(SP)  ;;MOVE THE PSW DOWN
        RTI                    ;;RESTORE THE PSW
```

.SBTTL TRAP TABLE

*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
 *BY THE 'TRAP' INSTRUCTION.

ROUTINE

007242 007230
 007244 005432
 007246 006344
 007250 006320
 007252 006360
 007254 006546
 007256 006244
 007260 004356
 007262 004306
 007264 004630
 007266 004760
 007270 006772
 007272 007030

```
$TRPAD: .WORD  $TRAP2
        $TYPE  ;;CALL=TYPE      TRAP+1(104401) TTY TYPEOUT ROUTINE
        $TYPOC ;;CALL=TYPOC    TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
        $TYPOS ;;CALL=TYPOS    TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
        $TYPON ;;CALL=TYPON    TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
        $TYPDS ;;CALL=TYPDS    TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
        $TYPBN ;;CALL=TYPBN    TRAP+6(104406) TYPE BINARY (ASCII) NUMBER
        $GTSWR ;;CALL=GTSWR    TRAP+7(104407) GET SOFT-SWR SETTING
        $CKSWR ;;CALL=CKSWR    TRAP+10(104410) TEST FOR CHANGE IN SOFT-SWR
        $RDCHR ;;CALL=RDCHR    TRAP+11(104411) TTY TYPEIN CHARACTER ROUTINE
        $RDLIN ;;CALL=RDLIN    TRAP+12(104412) TTY TYPEIN STRING ROUTINE
        $$AVREG ;;CALL=SAVREG  TRAP+13(104413) SAVE R0-R5 ROUTINE
        $RESREG ;;CALL=RESREG  TRAP+14(104414) RESTORE R0-R5 ROUTINE
```

1911

.SBTTL POWER DOWN AND UP ROUTINES

:POWER DOWN ROUTINE

007274	012737	007452	000024	\$PWRDN: MOV	#\$ILLUP,@#PWRVEC	::SET FOR FAST UP
007302	012737	000340	000026	MOV	#340,@#PWRVEC+2	::PRIO:7
007310	010046			MOV	R0,-(SP)	::PUSH R0 ON STACK
007312	010146			MOV	R1,-(SP)	::PUSH R1 ON STACK
007314	010246			MOV	R2,-(SP)	::PUSH R2 ON STACK
007316	010346			MOV	R3,-(SP)	::PUSH R3 ON STACK
007320	010446			MOV	R4,-(SP)	::PUSH R4 ON STACK
007322	010546			MOV	R5,-(SP)	::PUSH R5 ON STACK
007324	017746	171610		MOV	@SWR,-(SP)	::PUSH @SWR ON STACK
007330	010637	007456		MOV	SP,\$SAVR6	::SAVE SP
007334	012737	007346	000024	MOV	#SPWRUP,@#PWRVEC	::SET UP VECTOR
007342	000000			HALT		
007344	000776			BR	.-2	::HANG UP

:POWER UP ROUTINE

007346	012737	007452	000024	\$PWRUP: MOV	#\$ILLUP,@#PWRVEC	::SET FOR FAST DOWN
007354	013706	007456		MOV	\$SAVR6,SP	::GET SP
007360	005037	007456		CLR	\$SAVR6	::WAIT LOOP FOR THE TTY
007364	005237	007456		1\$: INC	\$SAVR6	::WAIT FOR THE INC
007370	001375			BNE	1\$::OF WORD
007372	012677	171542		MOV	(SP)+,@SWR	::POP STACK INTO @SWR
007376	012605			MOV	(SP)+,R5	::POP STACK INTO R5
007400	012604			MOV	(SP)+,R4	::POP STACK INTO R4
007402	012603			MOV	(SP)+,R3	::POP STACK INTO R3
007404	012602			MOV	(SP)+,R2	::POP STACK INTO R2
007406	012601			MOV	(SP)+,R1	::POP STACK INTO R1
007410	012600			MOV	(SP)+,R0	::POP STACK INTO R0
007412	012737	007274	000024	MOV	#SPWRDN,@#PWRVEC	::SET UP THE POWER DOWN VECTOR
007420	012737	000340	000026	MOV	#340,@#PWRVEC+2	::PRIO:7
007426	104401			TYPE		::REPORT THE POWER FAILURE
007430	007460			\$PWRMG: .WORD	PWRMSG	::POWER FAIL MESSAGE POINTER
007432	012716			MOV	(PC)+,(SP)	::RESTART AT START
007434	020000			\$PWRAD: .WORD	START	::RESTART ADDRESS
007436	042766	000020	000002	BIC	#20,2(SP)	::CLEAR 'T' BIT
007444	005037	001310		CLR	\$TBIT	::CLEAR THE 'T' BIT FLAG
007450	000002			RTI		
007452	000000			\$ILLUP: HALT		::THE POWER UP SEQUENCE WAS STARTED
007454	000776			BR	.-2	:: BEFORE THE POWER DOWN WAS COMPLETE
007456	000000			\$SAVR6: 0		::PUT THE SP HERE
1912	007460	012	015	040	PWRMSG: .ASCIZ	<12><15>? POWER FAILURE - RESTARTING ?<12><15>
	007463	120	117	127		
	007466	105	122	040		
	007471	106	101	111		
	007474	114	125	122		
	007477	105	040	055		
	007502	040	122	105		
	007505	123	124	101		
	007510	122	124	111		
	007513	116	107	040		
	007516	012	015	000		

1913

.EVEN

```

1915          .SBTTL  ERROR MESSAGES, DATA HEADERS-TABLES & FORMATS
1916          .NLIST  BEX
1917 007522      125      116      105  EM1:  .ASCIZ  /UNEXPECTED CPU TRAP TO LOC. 004/
1918 007562      125      116      105  EM2:  .ASCIZ  /UNEXPECTED MEM. MGMT. TRAP TO LOC. 250/
1919 007631      115      105      115  EM10: .ASCIZ  /MEMORY MGMT. ACCESS ABORT DID NOT OCCUR/
1920 007701      101      103      103  EM11: .ASCIZ  /ACCESS ERROR DID NOT ABORT INSTRUCTION/
1921 007750      123      122      060  EM12: .ASCIZ  /SR0 DID NOT REPORT ACCESS ERROR CORRECTLY/
1922 010022      123      122      062  EM13: .ASCIZ  /SR2 DID NOT LOCKUP CORRECT VIRTUAL ADDR./
1923 010073      120      101      107  EM14: .ASCIZ  /PAGE LGTH. ABORT OCCURRED WHEN IT SHOULDN'T HAVE/
1924 010154      120      101      107  EM15: .ASCIZ  /PAGE LGTH. ABORT DID NOT OCCUR WHEN IT SHOULD HAVE/
1925 010237      123      122      060  EM16: .ASCIZ  /SR0 DID NOT REPORT PAGE LGTH. ABORT CORRECTLY/
1926 010315      123      122      060  EM21: .ASCIZ  /SR0 OR SR2 CHANGED BY A SECOND ABORT/
1927 010362      123      122      060  EM22: .ASCIZ  /SR0 OR SR2 WERE NOT 'RESET' BY A RESET/
1928 010431      123      122      062  EM23: .ASCIZ  /SR2 NOT TRACKING CORRECTLY/
1929 010464      104      111      104  EM24: .ASCIZ  /DID NOT TRAP THRU KERNEL SPACE/
1930 010523      113      124      040  EM25: .ASCIZ  /KT ERROR SERVICED ON ODD ADDR. ERROR/
1931 010570      123      122      060  EM26: .ASCIZ  /SR0 OR SR2 CHANGED BY ODD ADDR. ERROR/
1932 010636      105      122      122  EM27: .ASCIZ  /ERROR DURING 'DOUBLE ERROR' (KT & ODD ADDR.)/
1933 010713      115      106      120  EM30: .ASCIZ  /MFPI INSTRUCTION PUSHED WRONG DATA/
1934 010756      115      124      120  EM31: .ASCIZ  /MTPI INSTRUCTION LOADED WRONG DATA/
1935 011021      123      124      101  EM32: .ASCIZ  /STACK NOT PUSHED BY MFPI-MTPI/
1936 011057      113      105      122  EM33: .ASCIZ  /KERNEL PAGE ACCESS INSTEAD OF USER: MFPI-MTPI/
1937 011135      115      056      115  EM34: .ASCIZ  /M.M. ABORT IN KERNAL D-SPACE HAD WRONG CONDITION/
1938 011216      111      114      114  EM35: .ASCIZ  /ILLEGAL MODE 10 NOT ABORTED/
1939 011252      123      122      060  EM36: .ASCIZ  /SR0 DID NOT REPORT ILLEGAL MODE 10 CORRECTLY/
1940 011327      120      123      127  EM37: .ASCIZ  /PSW CHANGED BY AN RTI IN USER MODE/
1941 011372      101      102      117  EM40: .ASCIZ  /ABORT I KERNAL D-SPACE PICKED UP VECTOR FROM I-SPACE/
1942 011457      104      040      123  EM41: .ASCIZ  /D SPACE ENABLE CIRCUITRY HAS FAILED/
1943 011523      111      116      103  EM42: .ASCIZ  /INCORRECT STORE BY MTP INSTRUCTION/
1944 011566      124      122      111  EM43: .ASCIZ  /TRIED TO REFERENCE NON-RESIDENT PAGE/
1945 011633      127      122      117  EM44: .ASCIZ  /WRONG DATA FETCHED BY MFP INSTRUCTION/
1946 011701      111      114      114  EM45: .ASCIZ  /ILLEGAL CSM DID NOT TRAP TO 10/
1947 011740      103      123      115  EM46: .ASCIZ  /CSM DID NOT ENTER SUPERVISOR MODE/
1948 012002      103      123      115  EM47: .ASCIZ  /CSM SET UP WRONG PREVIOUS MODE/
1949 012041      103      123      115  EM50: .ASCIZ  /CSM SET UP STACK WRONG/
1950 012070      103      123      115  EM51: .ASCIZ  /CSM PUSHED INCORRECT ARGUMENT/
1951 012126      103      123      115  EM52: .ASCIZ  /CSM PUSHED WRONG PC/
1952 012152      103      123      115  EM53: .ASCIZ  /CSM DID NOT CLEAR OLD PSW BITS <3:0>/
1953 012217      103      123      115  EM54: .ASCIZ  /CSM ACCESSED WRONG SUPERVISOR SPACE/
1954 012263      103      123      115  EM55: .ASCIZ  /CSM ABORTED WHEN IT SHOULD NOT HAVE/
1955 012327      103      123      115  EM56: .ASCIZ  ?CSM FAILED TO INCREMENT/DECREMENT REGISTER PROPERLY?
1956 012413      103      123      115  EM57: .ASCIZ  /CSM FAILED TO PUT PROPER ARGUMENT ON STACK/
1957 012466      123      122      062  EM58: .ASCII  !SR2 LOCKED UP AN 11/34 COMPATIBLE ADDRESS THAT:<CRLF>
1958 012545      104      117      105  .ASCII  !DOES NOT MAKE IT COMPATIBLE WITH AN 11/70 SINCE:<CRLF>
1959 012625      124      110      105  .ASCII  !THE OPTIONAL M7095 ECO #8 IS MISSING;
1960          .EVEN

```

1962						.SBTTL	DATA HEADERS						
1963	012672	117	114	104	DH1:	.ASCIZ	/OLD PC OLD PSW R6 WAS CPUERR TESTNO ERRORPC/						
1964	012752	117	114	104	DH2:	.ASCIZ	/OLD PC OLD PSW R6 WAS SRO SR2 TESTNO ERRORPC/						
1965	013042	120	104	122	DH10:	.ASCIZ	/PDR 4 PSW TESTNO ERRORPC/						
1966	013102	123	122	060	DH12:	.ASCIZ	/SRO WAS EXPECTD PDR 4 PSW TESTNO ERRORPC/						
1967	013162	123	122	062	DH13:	.ASCIZ	/SR2 WAS EXPECTD PDR 4 PSW TESTNO ERRORPC/						
1968	013242	126	056	102	DH14:	.ASCIZ	/V.B.A. KIPDR4 SRO WAS SR2 WAS TESTNO ERRORPC/						
1969	013322	126	056	102	DH15:	.ASCIZ	/V.B.A. KIPDR4 TESTNO ERRORPC/						
1970	013362	126	056	102	DH16:	.ASCIZ	/V.B.A. KIPDR4 SRO WAS EXPECTD TESTNO ERRORPC/						
1971	013442	126	056	102	DH17:	.ASCIZ	/V.B.A. KIPDR4 SR2 WAS EXPECTD TESTNO ERRORPC/						
1972	013522	123	122	062	DH20:	.ASCIZ	/SR2 WAS EXPECTD TESTNO ERRORPC/						
1973	013562	106	111	122	DH21:	.ASCII	/FIRST ABORT SECOND ABORT/<CRLF>						
1974	013617	123	122	060		.ASCIZ	/SRO WAS SR2 WAS SRO WAS SR2 WAS TESTNO ERRORPC/						
1975	013677	123	122	060	DH22:	.ASCIZ	/SRO WAS SR2 WAS TESTNO ERRORPC/						
1976	013737	120	123	127	DH24:	.ASCIZ	/PSW WAS R6 WAS TESTNO ERRORPC/						
1977	013777	105	130	120	DH26:	.ASCII	/EXPECTED RECEIVED/<CRLF>						
1978	014031	123	122	060		.ASCIZ	/SRO SR2 SRO WAS SR2 WAS TESTNO ERRORPC/						
1979	014111	105	130	120	DH27:	.ASCII	/EXPECTED:/<CRLF>						
1980	014123	120	123	127		.ASCII	/PSW PC SRO SR2/<CRLF>						
1981	014157	061	067	060		.ASCII	/170017 (3\$+4) 020147 (3\$)/<CRLF>						
1982	014214	122	105	103		.ASCII	/RECEIVED:/<CRLF>						
1983	014226	120	123	127		.ASCIZ	/PSW PC SRO SR2 TESTNO ERRORPC/						
1984	014306	104	101	124	DH30:	.ASCII	/DATA DATA/<CRLF>						
1985	014323	105	130	120		.ASCIZ	/EXPECTD RECEIVD TESTNO ERR PC/						
1986	014362	124	105	123	DH32:	.ASCIZ	/TESTNO ERR PC/						
1987	014401	123	122	060	DH33:	.ASCIZ	/SRO WAS SR2 WAS TESTNO ERRORPC/						
1988	014441	050	115	115	DH34:	.ASCIZ	/(MMR0) (MMR1) (MMR2) TESTNO ERRORPC EXPECTING 020031/						
1989	014532	123	122	060	DH36:	.ASCIZ	/SRO WAS EXPECTD TESTNO ERRORPC/						
1990	014572	120	123	127	DH37:	.ASCIZ	/PSW WAS EXPECTD TESTNO ERRORPC/						
1991	014632	050	120	123	DH40:	.ASCIZ	/(PSW) TESTNO ERRORPC EXPECTING xxx340/						
1992	014703	105	122	122	DH41:	.ASCII	/ERROR AUTOI-D VIRTUAL/<CRLF>						
1993	014733	122	105	107		.ASCIZ	/REGISTR REGISTR ADDRESS TESTNO PC AT ABORT/						
1994	015007	107	104	104	DH42:	.ASCIZ	/GDDATA STORED TESTNO ERRORPC/						
1995	015047	050	115	115	DH43:	.ASCIZ	/(MMR0) (MMR1) (MMR2) TESTNO ERRORPC/						
1996	015117	105	130	120	DH44:	.ASCIZ	/EXPECTD (PSW) TESTNO ERRORPC/						
1997	015157	117	114	104	DH45:	.ASCIZ	/OLDPSW TESTNO ERRORPC/						
1998	015207	124	105	123	DH55:	.ASCIZ	/TESTNO ERR PC RO EXP RO RCV/						
1999	015246	124	105	123	DH57:	.ASCIZ	/TESTNO ERR PC ARGEXP ARGRCV/						
2000							.EVEN						

Year	Code	Code	Code	Code	DT	Label	Parameters
2002						.SBTTL	DATA TABLES
2003	015306	001260	001262	001256	DT1:	.WORD	TRAPPC, TRAPPS, WASR6, CPUERR, TESTNO, \$ERRPC, 0
2004	015324	001260	001262	001256	DT2:	.WORD	TRAPPC, TRAPPS, WASR6, WASSR0, WASSR2, TESTNO, \$ERRPC, 0
2005	015344	001166	001176	001254	DT10:	.WORD	\$REG2, \$TMP0, TESTNO, \$ERRPC, 0
2006	015356	001264	001170	001166	DT12:	.WORD	WASSR0, \$REG3, \$REG2, \$TMP0, TESTNO, \$ERRPC, 0
2007	015374	001270	001172	001166	DT13:	.WORD	WASSR2, \$REG4, \$REG2, \$TMP0, TESTNO, \$ERRPC, 0
2008	015412	001162	001172	001264	DT14:	.WORD	\$REG0, \$REG4, WASSR0, WASSR2, TESTNO, \$ERRPC, 0
2009	015430	001162	001172	001254	DT15:	.WORD	\$REG0, \$REG4, TESTNO, \$ERRPC, 0
2010	015442	001162	001172	001264	DT16:	.WORD	\$REG0, \$REG4, WASSR0, \$REG2, TESTNO, \$ERRPC, 0
2011	015460	001162	001172	001270	DT17:	.WORD	\$REG0, \$REG4, WASSR2, \$REG3, TESTNO, \$ERRPC, 0
2012	015476	001270	001164	001254	DT20:	.WORD	WASSR2, \$REG1, TESTNO, \$ERRPC, 0
2013	015510	001176	001202	001264	DT21:	.WORD	\$TMP0, \$TMP2, WASSR0, WASSR2, TESTNO, \$ERRPC, 0
2014	015526	001264	001270	001254	DT22:	.WORD	WASSR0, WASSR2, TESTNO, \$ERRPC, 0
2015	015540	001164	001166	001254	DT24:	.WORD	\$REG1, \$REG2, TESTNO, \$ERRPC, 0
2016	015552	001162	001164	001264	DT26:	.WORD	\$REG0, \$REG1, WASSR0, WASSR2, TESTNO, \$ERRPC, 0
2017	015570	001164	001170	001264	DT27:	.WORD	\$REG1, \$REG3, WASSR0, WASSR2, TESTNO, \$ERRPC, 0
2018	015606	035336	001176	001254	DT30:	.WORD	ACSMSP, \$TMP0, TESTNO, \$ERRPC, 0
2019	015620	001254	001116	000000	DT32:	.WORD	TESTNO, \$ERRPC, 0
2020	015626	001164	001166	001170	DT34:	.WORD	\$REG1, \$REG2, \$REG3, TESTNO, \$ERRPC, 0
2021	015642	001264	001164	001254	DT36:	.WORD	WASSR0, \$REG1, TESTNO, \$ERRPC, 0
2022	015654	001162	001254	001116	DT40:	.WORD	\$REG0, TESTNO, \$ERRPC, 0
2023	015664	001264	001266	001270	DT41:	.WORD	WASSR0, WASSR1, WASSR2, TESTNO, BADPC, 0
2024	015700	001162	001164	001254	DT42:	.WORD	\$REG0, \$REG1, TESTNO, \$ERRPC, 0
2025	015712	001162	001164	001166	DT43:	.WORD	\$REG0, \$REG1, \$REG2, TESTNO, \$ERRPC, 0
2026	015726	001264	001266	001270	DT45:	.WORD	WASSR0, WASSR1, WASSR2, TESTNO, \$ERRPC, 0
2027	015742	001170	035334	001254	DT46:	.WORD	\$REG3, ACSMPS, TESTNO, \$ERRPC, 0
2028	015754	001162	035326	001254	DT47:	.WORD	\$REG0, CSM1ST, TESTNO, \$ERRPC, 0
2029	015766	001176	035330	001254	DT50:	.WORD	\$TMP0, CSM2ND, TESTNO, \$ERRPC, 0
2030	016000	035332	001254	001116	DT52:	.WORD	CSM3RD, TESTNO, \$ERRPC, 0
2031	016010	001254	001116	001176	DT55:	.WORD	TESTNO, \$ERRPC, \$TMP0, \$REG0, 0
2032	016022	001254	001116	001176	DT57:	.WORD	TESTNO, \$ERRPC, \$TMP0, \$TMP1, 0

						.SBTTL	DATA FORMAT BYTE STRINGS
2034						.BYTE	0.0.0.0.0
2035	016074	000	000	000	DF1:	.BYTE	0.0.0.0.0.0.0
2036	016041	000	000	000	DF2:	.BYTE	0.0.0.0
2037	016050	000	000	000	DF3:	.BYTE	0.0.0.0
2038	016054	000	000	000	DF5:	.BYTE	0.0.0
2039	016057	000	000	000	DF12:	.BYTE	0.0.0.0.0.0
2040	016065	000	000		DF32:	.BYTE	0.0
2041						.EVEN	

.SBTTL ***** TRAP HANDLING ROUTINES *****

.SBTTL CPU TRAP HANDLER ROUTINE

```

:*****
:*
:* THIS SUBROUTINE WILL HANDLE ALL CPU TRAPS AND ABORTS THRU
:* 'ERRVEC' (LOC. 004). IF THIS SUBROUTINE IS ENTERED BY A
:* SECOND TRAP BEFORE THE FIRST HAS BEEN SERVICED, A HALT IS
:* EXECUTED.
:*
:*****

```

2042					
2043					
2044					
2045					
2046					
2047					
2048					
2049					
2050					
2051					
2052					
2053	016070	005227			
2054	016072	177777			
2055	016074	001401			
2056	016076	000000			
2057					
2058					
2059					
2060					
2061	016100	012637	001260		
2062	016104	012637	001262		
2063	016110	010637	001256		
2064	016114	104001			
2065	016116	012737	177777	016072	
2066	016124	005037	177766		
2067	016130	013746	001262		
2068	016134	013746	001260		
2069	016140	000006			

```

TIMERR: INC      (PC)+      ;MAKE FLAG ZERO IF FIRST TIME THRU
TIMFLG: .WORD   -1        ;NEGATIVE ONE FOR 'HAVE ENTERED' FLAG
        BEQ     1$        ;BRANCH IF FIRST TIME IN
        HALT                ;STOP! - I'VE ENTERED THIS ROUTINE
                                ;A SECOND TIME BEFORE I FINISHED
                                ;REPORTING THE FIRST ERROR. THE
                                ;SECOND ENTRY ADDRESS SHOULD BE ON
                                ;THE KERNEL STACK.
1$:     MOV     (KSP)+,TRAPPC ;SAVE PC+2 AT TIME OF ABORT
        MOV     (KSP)+,TRAPPS ;SAVE PS AT TIME OF ABORT
        MOV     KSP,WASR6    ;SAVE STACK POINTER VALUE
        ERROR  +1          ;UNEXPECTED TRAP OR ABORT TO LOC. 4
        MOV     #-1,TIMFLG  ;MAKE FLAG NEGATIVE ONE FOR NEXT TIME
        CLR     CPUERR      ;CLEAR THE CPU ERROR REGISTER
        MOV     TRAPPS,-(KSP);PUT PC & PS OF TRAP ON STACK
        MOV     TRAPPC,-(KSP)
        RTT                ;RETURN FROM INTERRUPT OR ABORT

```


2102
 2103
 2104
 2105
 2106

020000

```

    :*      ***** STARTING POINT OF TEST *****
    :*      ***** STARTING ADDRESS OF 200 *****
    .=20000
    
```

```

020000 012706 001100
020004 005026
020006 022706 001140
020012 001374
020014 012706 001100

020020 012737 003042 000020
020026 012737 000340 000022
020034 012737 003270 000030
020042 012737 000340 000032
020050 012737 007206 000034
020056 012737 000340 000036
020064 012737 007274 000024
020072 012737 000340 000026
020100 013737 036054 036046
020106 005037 001212
020112 112737 000001 001115

020120 012737 036316 000014
020126 012737 000340 000016
020134 012737 000002 036316
020142 012737 020170 000010
020150 005046
020152 012746 020160
020156 000006
020160 012737 000006 036316 64$
020166 000402
020170 062706 000010 65$
020174 012737 000012 000010 66$
020202 005037 001310
020206 012737 020206 001106
020214 012737 020214 001110

020222 013746 000004
020226 012737 020262 000004
020234 012737 177570 001140
020242 012737 177570 001142
020250 022777 177777 160662
020256 001012

020260 000403
020262 012716 020270 67$
020266 000002
020270 012737 000176 001140 68$
020276 012737 000174 001142
020304 012637 000004 69$
020310 005037 001232
020314 132737 000200 001245
    
```

```

START:
.SBTTL INITIALIZE THE COMMON TAGS
::CLEAR THE COMMON TAGS ($CMTAG) AREA
MOV # $CMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
CLR (R6)+ ;;CLEAR MEMORY LOCATION
CMP #SWR,R6 ;;DONE?
BNE -6 ;;LOOP BACK IF NO
MOV #STACK,SP ;;SETUP THE STACK POINTER
::INITIALIZE A FEW VECTORS
MOV # $SCOPE,@#IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
MOV #340,@#IOTVEC+2 ;;LEVEL 7
MOV # $ERROR,@#EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
MOV #340,@#EMTVEC+2 ;;LEVEL 7
MOV # $TRAP,@#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
MOV #340,@#TRAPVEC+2 ;;LEVEL 7
MOV # $PWRDN,@#PWRVEC ;;POWER FAILURE VECTOR
MOV #340,@#PWRVEC+2 ;;LEVEL 7
MOV $ENDCT,$EOPCT ;;SETUP END-OF-PROGRAM COUNTER
CLR $ESCAPE ;;CLEAR THE ESCAPE ON ERROR ADDRESS
MOVB #1,$ERMAX ;;ALLOW ONE ERROR PER TEST
::INITIALIZE THE 'T-BIT' TRAP VECTOR. THEN LOAD LOCATION '$RTRN', IN
::THE 'END-OF-PASS' ($EOP) ROUTINE, WITH A 'RTI' OR 'RTT'.
MOV # $RTRN,@#TBITVEC ;;SET 'T' BIT VECTOR TO $RTRN
MOV #340,@#TBITVEC+2 ;;LEVEL 7
MOV #RTI,$RTRN ;;SET $RTRN TO A RTI
MOV #65$,@#RESVEC ;;TRY TO DO A RTT
CLR -(SP) ;;DUMMY PS
MOV #64$,-(SP) ;;AND PC
RTT ;;TRY THE RTT
MOV #RTT,$RTRN ;;RTT IS LEGAL--SET $RTRN TO A RTT
BR 66$
65$: ADD #10,SP ;;RTT ILLEGAL--CLEAN OFF THE STACK
66$: MOV #RESVEC+2,@#RESVEC ;;RESTORE TRAP CATCHER
CLR $TBIT ;;CLEAR 'T' BIT SWITCH
MOV #.,$LPADR ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
MOV #.,$LPERR ;;SETUP THE ERROR LOOP ADDRESS
::SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
::EQUAL TO A '-1', SETUP FOR A SOFTWARE SWITCH REGISTER.
MOV @#ERRVEC,-(SP) ;;SAVE ERROR VECTOR
MOV #67$,@#ERRVEC ;;SET UP ERROR VECTOR
MOV #DSWR,$SWR ;;SETUP FOR A HARDWARE SWICH REGISTER
MOV #DDISP,$DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
CMP #-1,@$SWR ;;TRY TO REFERENCE HARDWARE SWR
BNE 69$ ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
;;AND THE HARDWARE SWR IS NOT = -1
BR 68$ ;;BRANCH IF NO TIMEOUT
MOV #68$,(SP) ;;SET UP FOR TRAP RETURN
RTI
68$: MOV #SWREG,$SWR ;;POINT TO SOFTWARE SWR
MOV #DISPREG,$DISPLAY
69$: MOV (SP)+,@#ERRVEC ;;RESTORE ERROR VECTOR
CLR $PASS ;;CLEAR PASS COUNT
BITB #APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT
    
```

```

020322 001403      BEQ    70$      ::YES,USE NON-APT SWITCH
020324 012737 001246 001140  MOV    #$$SWREG,SWR  ::NO,USE APT SWITCH REGISTER
020332
2107 70$:
.SBTTL TYPE PROGRAM NAME
::TYPE THE NAME OF THE PROGRAM IF FIRST PASS
020332 005227 177777      INC    #-1      ::FIRST TIME?
020336 001047      BNE    71$      ::BRANCH IF NO
020340 022737 036252 000042  CMP    #SENDAD,@#42  ::ACT-11?
020346 001443      BEQ    71$      ::BRANCH IF YES
020350 104401 020416      TYPE    ,72$     ::TYPE ASCIZ STRING
.SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
020354 005737 000042      TST    @#42     ::ARE WE RUNNING UNDER XXDP/ACT?
020360 001012      BNE    73$      ::BRANCH IF YES
020362 123727 001244 000001  CMPB   $ENV,#1    ::ARE WE RUNNING UNDER APT?
020370 001406      BEQ    73$      ::BRANCH IF YES
020372 023727 001140 000176  CMP    SWR,#SWREG  ::SOFTWARE SWITCH REG SELECTED?
020400 001005      BNE    74$      ::BRANCH IF NO
020402 104407      GTSWR          ::GET SOFT-SWR SETTINGS
020404 000403      BR     74$
020406 112737 000001 001134 73$:  MOVB   #1,$AUTOB  ::SET AUTO-MODE INDICATOR
020414 74$:
020414 000420      BR     71$      ::GET OVER THE ASCIZ
020456 71$:
2108 020456 104401 020464      .ASCIZ <CRLF>#CKKTBD0 11/44 MEM MGMT PRT B#<CRLF>
020462 000436      TYPE    ,76$     ::TYPE ASCIZ STRING
75$:  BR     75$      ::GET OVER THE ASCIZ
::76$: .ASCIZ #EOP MESSAGES WILL PRINT EVERY 64 PASSES OR ABOUT 11 SECONDS#
2109 020560 75$:
LOOP:
2110 020560 012706 001100      MOV    #STACK,KSP  ;INITIALIZE THE STACK POINTER
2111 020564 012737 040000 177776  MOV    #40000,PSW  ;TURN ON SUPERVISOR MODE
2112 020572 012706 000700      MOV    #SUPSTK,SSP ;INITIALIZE SUPER. STACK POINTER
2113 020576 012737 140000 177776  MOV    #140000,PSW ;TURN ON USER MODE
2114 020604 012706 000600      MOV    #USESTK,USP ;INITIALIZE USER STACK POINTER
2115 020610 005037 177776      CLR    PSW        ;RETURN TO KERNAL MODE
2116 020614 012737 016070 000004  MOV    #TIMERR,ERRVEC ;LOAD CPU SERVICE ROUTINE INTO TRAP VECTOR
2117 020622 012737 000340 000006  MOV    #340,ERRVEC+2 ;SET NEW PS TO PRIORITY LEVEL 7-KERNEL
2118 020630 012737 016142 000250  MOV    #MGMERR,MMVEC ;LOAD MEMORY MANAGENT ROUTINE INTO VECTOR
2119 020636 012737 000340 000252  MOV    #340,MMVEC+2 ;SET NEW PS TO PRIORITY LEVEL 7-KERNEL
2120 020644 012700 177777      MOV    #-1,R0     ;PUT -1 INTO R0 TO INITIALIZE FLAGS
2121 020650 010037 016072      MOV    R0,TIMFLG  ;INITIALIZE CPU ERROR FLAG
2122 020654 010037 016144      MOV    R0,MGMFLG  ;INITIALIZE MEMORY MANAGEMENT ERROR FLAG
2123 020660 012737 000340 001274  MOV    #340,TBITPS ;INITIALIZE LOG THAT HOLDS T-BIT PSW
2124 020666 005037 177572      MMR0          ;BE SURE MEM. MGMT IS OFF TO START WITH,
2125 020672 012737 000020 172516  MOV    #BIT4,MMR3 ;BUT TURN ON 22-BIT ADDRESSING MODE
2126 020700 004737 002060      JSR    PC,APRINIT ;JUMP TO PAR/PDR INIT ROUTINE

```


2150

```
.SBTTL TEST # 1 - NON-RESIDENT ABORT TEST (ACF=0B4)
:*****
:*TEST 1      NON-RESIDENT ABORT TEST (ACF=0B4)
:*
:*      THIS TEST CHECKS THE ACCESS CONTROL FIELD (ACF) COMPARATOR
:*      LOGIC BY CAUSING NON-RESIDENT ABORTS IN KERNEL, SUPERVISOR
:*      AND USER MODES. PDR 4 IS LOADED WITH ACF'S = 0B4 AND
:*      THEN PHYSICAL ADDR. 60000 IS ACCESSED TO CAUSE THE ABORT.
:*
:*****
```

```
TST1:  SCOPE
1$:    MOV      #600,R0          ;LOAD DATA FOR PAR'S INTO R0
        MOV      R0,KIPAR3      ;MAP KERNEL PAR'S 3B4 TO 12-16K
        MOV      R0,KIPAR4
        MOV      R0,SIPAR3      ;MAP SUPERVISOR PAR'S 3B4 TO 12-16K
        MOV      R0,SIPAR4
        MOV      R0,UIPAR3      ;MAP USER PAR'S 3B4 TO 12-16K
        MOV      R0,UIPAR4
        MOV      #60000,R0      ;LOAD VIRTUAL ADDR. TO REFERENCE PDR3 INTO R0
        MOV      #100000,R1     ;LOAD VIRTUAL ADDR. TO REFERENCE PDR4 INTO R1
        MOV      #100011,R3     ;LOAD R3 WITH WHAT SRO SHOULD READ - N.R. KERNEL, PG.4
        MOV      #77400,R2     ;LOAD ACF=0 (NON-RESIDENT) PDR VALUE IN R2
        MOV      #5$,MMVEC     ;POINT MEM. MGMT. TRAP VECTOR TO 5$ BELOW
        MOV      R2,KIPDR4      ;LOAD ACF TEST VALUE INTO KIPDR4
        MOV      R2,SIPDR4      ;LOAD ACF TEST VALUE INTO SIPDR4
        MOV      R2,UIPDR4      ;LOAD ACF TEST VALUE INTO UIPDR4
        MOV      #3$,SLPERR     ;SET LOOP ON ERROR POINTER TO 3$
        MOV      #1,MMRO       ;TURN ON MEMORY MANAGEMENT
        CLR      (R0)           ;CLEAR PHYS. LOC. 60000 USING PDR3
        MOV      PSW,$TMP0      ;SAVE PSW IN CASE OF ERROR
        INC      (R1)           ;TRY TO REF. IT USING PDR4 - SHOULD TRAP TO 5$
        ERROR   +3             ;MEM. MGMT. ABORT DID NOT OCCUR
        ;FOR TIGHTER SCOPE LOOP
        ;REPLACE ERROR CALL WITH
        ;'BR 3$' = 000772
        BR      8$             ;BRANCH AROUND STATUS REG. CHECKS IF NO ABORT
        ADD      #4,SP          ;RESTORE STACK POINTER
        TST      (R0)           ;DID INSTRUCTION GET ABORTED & NOT EXECUTE
        BEQ      6$             ;BRANCH IF YES
        ERROR   +4             ;INSTRUCTION WAS NOT ABORTED, LOC. GOT CHANGED
        ;FOR TIGHTER SCOPE LOOP
        ;REPLACE ERROR CALL WITH
        ;'BR 3$' = 000764
        MOV      SRO,WASSRO     ;READ STATUS REGISTER 0
        MOV      SR2,WASSR2     ;READ STATUS REGISTER 2
        CMP      R3,WASSRO      ;DID SRO REPORT NON-RESIDENT ERROR CORRECTLY?
        BEQ      7$             ;BRANCH IF YES
        ERROR   +5             ;SRO DID NOT REPORT NON-RES. ERROR CORRECTLY
        ;FOR TIGHTER SCOPE LOOP
        ;REPLACE ERROR CALL WITH
        ;'BR 3$' = 000752
        MOV      #4$,R4         ;LOAD R4 WITH WHAT SR2 SHOULD READ
        CMP      R4,WASSR2     ;DID SR2 LOCKUP RIGHT VIRTUAL ADDR. (=4$)?
        BEQ      8$             ;BRANCH IF YES
        ERROR   +6             ;SR2 DID NOT LOCK VIRTUAL ADDR. OF NON-RES. ERROR
        ;FOR TIGHTER SCOPE LOOP
        ;REPLACE ERROR CALL WITH
```


2226

```
.SBTTL TEST # 2 - READ-ONLY ABORT TEST (ACF=2)
*****
*TEST 2 READ-ONLY ABORT TEST (ACF=2)
*
* THIS TEST CHECKS THE ACCESS CONTROL FIELD (ACF) COMPARATOR
* LOGIC BY CAUSING READ-ONLY ABORTS IN KERNEL, SUPERVISOR AND
* USER MODES. PDR 4 IS LOAD WITH ACF=2 AND THEN
* PHYSICAL ADDR. 60000 IS WRITTEN TO CAUSE THE ABORT.
*****
```

```

021222 000004
2227 021224
2228
2229 021224 012700 060000      MOV      #60000,R0      ;KERNEL, SUPERVISOR AND USER PAR'S 3 & 4,
2230 021230 012701 100000      MOV      #100000,R1     ;AND PDR 3 ARE SETUP FROM LAST TEST
2231 021234 012703 020011      MOV      #20011,R3     ;LOAD VIRTUAL ADDR. TO REFERENCE PDR3 INTO R0
2232 021240 012702 077402      MOV      #77402,R2     ;LOAD VIRTUAL ADDR. TO REFERENCE PDR4 INTO R1
2233 021244 012737 021316 000250 2$:  MOV      #5$,MMVEC     ;LOAD R3 WITH WHAT SRO SHOULD READ - R/O, KERNEL, PG.4
2234 021252 010237 172310      MOV      R2,KIPDR4     ;LOAD ACF=2 (READ-ONLY) PDR VALUE IN R2
2235 021256 010237 172210      MOV      R2,SIPDR4     ;POINT MEM. MGMT. TRAP VECTOR TO 5$ BELOW
2236 021262 010237 177610      MOV      R2,UIPDR4     ;LOAD ACF=2 INTO KIPDR4
2237 021266 012737 021300 001110      MOV      #3$,SLPERR    ;LOAD ACF=2 INTO SIPDR4
2238 021274 005237 177572      INC      MMRO           ;LOAD ACF=2 INTO UIPDR4
2239 021300 005010              CLR      (R0)           ;SET LOOP ON ERROR POINTER TO 3$
2240 021302 013737 177776 001176 3$:  MOV      PSW,$TMP0     ;TURN ON MEMORY MANAGEMENT
2241 021310 005211              INC      (R1)           ;CLEAR PHYS. LOC. 60000 USING PDR3
2242 021312 104003              ERROR   +3             ;SAVE PSW IN CASE OF ERROR
2243
2244
2245
2246 021314 000425              BR      8$             ;TRY TO WRITE USING PDR4 - SHOULD TRAP TO 5$
2247 021316 062706 000004 5$:  ADD      #4,$SP         ;MEM. MGMT. ABORT DID NOT OCCUR
2248 021322 005710              TST     (R0)           ;FOR TIGHTER SCOPE LOOP
2249 021324 001401              BEQ    6$             ;REPLACE ERROR CALL WITH
2250 021326 104004              ERROR   +4             ;'BR 3$' = 000772
2251
2252
2253
2254 021330 013737 177572 001264 6$:  MOV      SRO,WASSR0     ;BRANCH AROUND STATUS REG. CHECKS IF NO ABORT
2255 021336 013737 177576 001270      MOV      SR2,WASSR2     ;RESTORE STACK POINTER
2256 021344 020337 001264      CMP     R3,WASSR0     ;DID INSTRUCTION GET ABORTED & NOT EXECUTE
2257 021350 001401              BEQ    7$             ;BRANCH IF YES
2258 021352 104005              ERROR   +5             ;INSTRUCTION WAS NOT ABORTED, LOC. GOT CHANGED
2259
2260
2261
2262 021354 012704 021310 7$:  MOV      #4$,R4         ;FOR TIGHTER SCOPE LOOP
2263 021360 020437 001270      CMP     R4,WASSR2     ;REPLACE ERROR CALL WITH
2264 021364 001401              BEQ    8$             ;'BR 3$' = 000764
2265 021366 104006              ERROR   +6             ;READ STATUS REG. 0
2266
2267
2268
2269 021370 005037 177572 8$:  CLR      MMRO           ;READ STATUS REG. 2
2270 021374 032737 140000 001176      BIT     #140000,$TMP0  ;DID SRO REPORT READ-ONLY ERROR CORRECTLY?
2271 021402 001006              BNE   11$             ;BRANCH IF YES
2272 021404 012703 020151      MOV     #20151,R3     ;SRO DID NOT REPORT R/O ERROR CORRECTLY
                                     ;FOR TIGHTER SCOPE LOOP
                                     ;REPLACE ERROR CALL WITH
                                     ;'BR 3$' = 000752
                                     ;LOAD R4 WITH WHAT SR2 SHOULD READ
                                     ;DID SR2 LOCKUP RIGHT VIRTUAL ADDR. (=4$)?
                                     ;BRANCH IF YES
                                     ;SR2 DID NOT LOCKUP VIRTUAL ADDR. OF R/O ERROR
                                     ;FOR TIGHTER SCOPE LOOP
                                     ;REPLACE ERROR CALL WITH
                                     ;'BR 3$' = 000744
                                     ;TURN OFF MEMORY MANAGEMENT
                                     ;HAS ACF=2 BEEN TESTED IN USER MODE?
                                     ;BRANCH IF YES
                                     ;LOAD R3 WITH WHAT SRO SHOULD READ-R/O, USER, PG.4

```


2273	021410	012737	140000	177776		MOV	#140000,PSW	:GO TO USER MODE
2274	021416	000712				BR	2\$:REPEAT TEST IN USER MODE
2275	021420	022737	040000	001176	11\$:	CMP	#40000,\$TMPO	:HAS ACF=2 BEEN TESTED IN SUPERVISOR MODE?
2276	021426	001006				BNE	9\$:BRANCH IF YES
2277	021430	012703	020051			MOV	#20051,R3	:LOAD R3 WITH WHAT SRO SHOULD READ-R/O, SUPERVISOR, PG.4
2278	021434	012737	040000	177776		MOV	#40000,PSW	:GO TO SUPERVISOR MODE
2279	021442	000700				BR	2\$:REPEAT TEST IN SUPERVISOR MODE
2280	021444	005037	177776		9\$:	CLR	PSW	:GO BACK TO KERNEL MODE BEFORE LEAVING
2281	021450	012737	016142	000250		MOV	#MGMERR,MMVEC	:RESTORE ADDRESS OF NORMAL MEMORY
2282								:MANAGEMENT ERROR ROUTINE TO MMVEC.

2294

```

.SBTTL TEST # 3 - TEST ILLEGAL MODE '10'
*****
*TEST 3 TEST ILLEGAL MODE '10'
*
* THIS TEST CHECKS TO SEE THAT A 10 IN THE CURRENT MODE BITS OF THE
* PSW WHILE MEMORY MANAGEMENT IS ON IS ILLEGAL. A
* MEMORY MANAGEMENT ABORT SHOULD OCCUR AND STATUS REGISTER 0
* SHOULD REPORT NON-RESIDENT ABORT, MODE = 10, PAGE = 1 (100103). STATUS
* REGISTER 2 SHOULD LOCKUP THE ADDRESS OF THE INSTRUCTION
* THAT LOADED THE PSW IF M7095 ECO #8 IS MISSIGN. IF THE ECO IS
* INSTALLED, THE ADDRESS LOCKED UP WILL BE THAT OF THE UPDATED PC.
*
*****

```

```

TST3: SCOPE
2295 021456 000004 021502 001110 1$: MOV #10$, $LPERR ;SET LOOP ON ERROR POINTER TO 10$
2296 021460 012737 021522 000250 MOV #3$, MMVEC ;LOAD MEM. MGMT. TRAP VECTOR WITH 3$
2297 021474 012737 000001 177572 MOV #1, MMRO ;TURN ON MEMORY MANAGEMENT
2298 021502 012737 100000 177776 10$: MOV #100000, PSW ;SET 10 IN PSW CURRENT MODE BITS
2299 021510 104030 2$: ERROR +30 ;ILLEGAL MODE 10 NOT ABORTED
2300 ;FOR A TIGHTER SCOPE LOOP, REPLACE ERROR CALL WITH 'BR 10$' = 000774
2301 021512 012737 016142 000250 MOV #MMGMERR, MMVEC ;RESTORE MEM. MGMT. ABORT VECTOR
2302 021520 000441 BR 5$ ;BRANCH AROUND SRO & SR2 CHECKS
2303 021522 013737 177576 001270 3$: MOV SR2, WASSR2 ;READ CONTENTS OF SR2
2304 021530 012737 016142 000250 MOV #MMGMERR, MMVEC ;RESTORE MEM. MGMT. ABORT VECTOR
2305 021536 012706 001100 MOV #KERSTK, SP ;RESTORE STACK POINTER
2306 021542 022737 100103 177572 CMP #100103, SRO ;DID SRO REPORT ILLEGAL MODE CORRECTLY?
2307 021550 001406 BEQ 4$ ;BRANCH IF YES
2308 021552 012701 100103 MOV #100103, R1 ;LOAD EXPECTED CONTENTS OR SRO INTO R1
2309 021556 013737 177572 001264 MOV SRO, WASSR0 ;READ CONTENTS OF SRO
2310 021564 104031 ERROR +31 ;SRO DID NOT REPORT NR ABORT, PG=1, MODE=10
2311 ;FOR TIGHTER SCOPE LOOP, REPLACE ERROR CALL WITH 'BR 10$' = 000746
2312 021566 022737 021502 001270 4$: CMP #10$, WASSR2 ;DID SR2 LOCKUP VIRT. ADDR OF ABORT ;DPM002
2313 021574 001410 BEQ 45$ ;BRANCH IF OK BUT NOT FOR ECO #8 ;DPM002
2314 021576 022737 021510 001270 CMP #2$, WASSR2 ;DID SR2 LOCKUP VIRT. ADDR OF ABORT ;DPM002
2315 021604 001407 BEQ 5$ ;BRANCH IF ANSWER IS OK ;DPM002
2316 021606 012701 021510 MOV #2$, R1 ;MOVE ERROR ADDRESS TO R1 FOR ERROR CALL ;DPM002
2317 021612 104013 ERROR +13 ;SR2 DID NOT LOCKUP VIRT. ADDR. OF ILL. MODE INST.
2318 ;FOR TIGHTER SCOPE LOOP, REPLACE ERROR CALL WITH 'BR 10$' = 000733
2319 021614 000403 BR 5$ ;BRANCH OVER 2ND ERROR CALL
2320 021616 012701 021502 45$: MOV #10$, R1 ;MOVE ADDRESS TO R1 FOR ERROR CALL ;DPM002
2321 021622 104054 ERROR +54 ;SR2 LOCKED UP AN 11/34 COMPATIBLE ;DPM002
2322 ;ADDRESS THAT DOES NOT MAKE IT COMPA- ;DPM002
2323 ;TIBLE WITH AN 11/70 SINCE THE OPTIONAL ;DPM002
2324 ;M7095 ECO #8 IS MISSING ;DPM002
2325 ;FOR TIGHTER SCOPE LOOP, REPLACE ERROR CALL WITH 'BR 10$' - 000727
2326 021624 042737 160000 177572 5$: BIC #160000, SRO ;CLEAR POSSIBLE ERROR BITS IN SRO

```

2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342

```
*****  
*  
* THE NEXT TWO (2) TESTS WILL BE CHECKING THE PAGE LENGTH  
* COMPARATORS AND SOME MORE OF THE KT ERROR DETECTION  
* AND STATUS LOGIC. THE PAGE LENGTH FIELD (PLF) IN KERNEL  
* PDR 4 IS VARIED AND FOR EVERY PLF, THREE (3) VIRTUAL  
* ADDRESSES ARE READ. WHILE USING BOTH UPWARD & DOWNWARD PAGE  
* EXPANSION, ONE OF THOSE THREE VIRTUAL ADDRESSES WILL CAUSE A  
* 'PAGE LENGTH ABORT' WHILE THE OTHER TWO WON'T.  
*  
* STATUS REGISTER 0 & 2 ARE CHECKED WHEN THE PAGE LENGTH  
* ABORT DOES OCCUR TO SEE THAT THE ABORT IS REPORTED AND THAT  
* THE VIRTUAL ADDRESS OF THE INSTRUCTION THAT CAUSED THE ABORT  
* IS LOCKED UP.  
*  
*****
```

2354

```
.SBTTL TEST # 4 - PAGE LENGTH FAULTS-UPWARD EXPANSION
*****
*TEST 4 PAGE LENGTH FAULTS-UPWARD EXPANSION
*
* THIS TEST VARIES THE PAGE LENGTH FIELD (PLF) IN KERNEL PDR 4
* FROM 1 TO 177 AND FOR EACH PLF, THREE VIRTUAL ADDRESSES (VBA'S)
* ARE ACCESSED. WHEN VBA <12:6> IS LESS THAN OR EQUAL TO PDR <14:8>
* NO ABORT SHOULD OCCUR. WHEN VBA <12:6> IS GREATER THAN PDR <14:8>,
* A PAGE LENGTH ABORT SHOULD OCCUR AND BE REPORTED BY SRO & SR2.
* THE PAGE EXPANSION DIRECTION IN THIS TEST IS UPWARD, (THE ED BIT
* (BIT 3) OF PDR 4 = 0).
*****
```

```
TST4: SCOPE
1$: MOV #77406,KIPDR3 ;MAKE SURE PDR3 IS DESCRIBED AS R/W
MOV #77406,KIPDR5 ;MAKE SURE PDR5 IS DESCRIBED AS R/W
MOV #100000,R0 ;LOAD VIRTUAL ADDR. TO SELECT PDR4 INTO R0
MOV #406,R4 ;LOAD FIRST PDR VALUE IN R4 (PLF=1, ACF=6)
2$: MOV #9$,MMVEC ;SETUP M.M. TRAP VECTOR FOR UNEXPECTED ABORTS
MOV R4,KIPDR4 ;LOAD KIPDR4 WITH PAGE LENGTH VALUE
MOV #3$,SLPERR ;SET LOOP ON ERROR POINTER TO 3$
3$: MOV #KERSTK,KSP ;MAKE SURE STACK POINTER IS ALL SET UP
MOV (R0),R1 ;ACCESS VIRTUAL ADDR. (VBA < PLF - NO ABORT)
ADD #100,R0 ;FORM NEXT VIRTUAL ADDRESS IN R0
MOV #4$,SLPERR ;SET LOOP ON ERROR POINTER TO 4$
4$: MOV #KERSTK,KSP ;MAKE SURE STACK POINTER IS ALL SET UP
MOV (R0),R1 ;ACCESS VIRTUAL ADDR. (VBA=PLF - NO ABORT)
ADD #100,R0 ;FORM NEXT VIRTUAL ADDR IN R0
CMP R0,#117700 ;HAVE ALL PLF'S BEEN TESTED YET?
BEQ 10$ ;BRANCH IF ALL VBA'S & PLF'S HAVE BEEN USED
MOV #5$,SLPERR ;SET LOOP ON ERROR POINTER TO 5$
MOV #6$,MMVEC ;SETUP M.M. TRAP VECTOR FOR EXPECTED ABORT
5$: MOV (R0),R1 ;ACCESS VIRTUAL ADDR. (VBA > PLF - ABORT TO 6$)
ERROR +10 ;EXPECTED PAGE LENGTH ABORT DID NOT OCCUR
;FOR TIGHTER SCOPE LOOP
;REPLACE ERROR CALL WITH
;'BR 5$' = 000776
BR 8$ ;BRANCH AROUND ABORT CHECKS
6$: MOV #KERSTK,KSP ;RESTORE STACK POINTER FOLLOWING ABORT
MOV SRO,WASSRO ;READ M.M. STATUS REG. 0
MOV SR2,WASSR2 ;READ M.M. STATUS REG. 2
MOV #40011,R2 ;PUT EXPECTED SRO CONTENTS IN R2
CMP R2,WASSRO ;DID SRO REPORT PG. LENGTH ABORT, PAGE 4, KERNEL?
BEQ 7$ ;BRANCH IF YES
ERROR +11 ;SRO DID NOT REPORT PG. LENGTH ABORT CORRECTLY
;FOR TIGHTER SCOPE LOOP
;REPLACE ERROR CALL WITH
;'BR 5$' = 000757
7$: MOV #5$,R3 ;PUT EXPECTED SR2 CONTENTS IN R3
CMP R3,WASSR2 ;DID SR2 LOCKUP VIRT. ADDR. OF ABORTED INSTRUCTION?
BEQ 8$ ;BRANCH IF YES
ERROR +12 ;SR2 DID NOT LOCKUP VIRT. ADDR. OF ABORT CORRECTLY
;FOR TIGHTER SCOPE LOOP
;REPLACE ERROR CALL WITH
;'BR 5$' = 000751
8$: BIC #160000,SRO ;CLEAR ERROR BITS IN SRO
ADD #400,R4 ;FORM NEXT PLF VALUE FOR KIPDR4
```


2427

.SBTTL TEST # 5 - PAGE LENGTH FAULTS-DOWNWARD EXPANSION

*TEST 5 PAGE LENGTH FAULTS-DOWNWARD EXPANSION

* THIS TEST VARIES THE PAGE LENGTH FIELD (PLF) IN KERNEL PDR4
 * FROM 176 TO 0 AND FOR EACH PLF, THREE VIRTUAL ADDRESSES (VBA'S)
 * ARE ACCESSED. WHEN VBA <12:6> IS GREATER THAN OR EQUAL TO PDR <14:8>
 * NO PAGE ABORT SHOULD OCCUR. WHEN VBA <12:6> IS LESS THAN PDR <14:8>
 * A PAGE LENGTH ABORT SHOULD OCCUR AND BE REPORTED BY SRO & SR2.
 * THE PAGE EXPANSION DIRECTION IN THIS TEST IS DOWNWARD, (THE ED BIT
 * (BIT 3) OF PDR4=1).

TST5:

SCOPE

2428	022126	000004			1S:	MOV	#117700,R0	:LOAD VIRTUAL ADDR. TO SELECT PDR4 INTO R0
2429	022130	012700	117700			MOV	#77016,R4	:LOAD FIRST PDR VALUE IN R4 (PLF=176,ACF=6)
2430	022134	012704	077016		2S:	MOV	#9\$,MMVEC	:SETUP M.M. TRAP VECTOR FOR UNEXPECTED ABORTS
2431	022140	012737	022332	000250		MOV	R4,KIPDR4	:LOAD KIPDR4 WITH PAGE LENGTH VALUE
2432	022146	010437	172310			MOV	#3\$,SLPERR	:SET LOOP ON ERROR POINTER TO 3\$
2433	022152	012737	022160	001110	3S:	MOV	#KERSTK,KSP	:MAKE SURE STACK POINTER IS ALL SET UP
2434	022160	012706	001100			MOV	(R0),R1	:ACCESS VIRTUAL ADDR. (VBA > PLF - NO ABORT)
2435	022164	011001				SUB	#100,R0	:FORM NEXT VIRTUAL ADDRESS IN R0
2436	022166	162700	000100			MOV	#4\$,SLPERR	:SET LOOP ON ERROR POINTER TO 4\$
2437	022172	012737	022200	001110	4S:	MOV	#KERSTK,KSP	:MAKE SURE STACK POINTER IS ALL SET UP
2438	022200	012706	001100			MOV	(R0),R1	:ACCESS VIRTUAL ADDR. (VBA=PLF - NO ABORT)
2439	022204	011001				SUB	#100,R0	:FORM NEXT VIRTUAL ADDR. IN R0
2440	022206	162700	000100			CMP	R0,#100000	:HAVE ALL PLF'S BEEN TESTED YET?
2441	022212	020027	100000			BEQ	10\$:BRANCH IF ALL VBA'S & PLF'S HAVE BEEN USED
2442	022216	001470				MOV	#5\$,SLPERR	:SET LOOP ON ERROR POINTER TO 5\$
2443	022220	012737	022234	001110		MOV	#6\$,MMVEC	:SETUP M.M. TRAP VECTOR FOR EXPECTED ABORT
2444	022226	012737	022242	000250	5S:	MOV	(R0),R1	:ACCESS VIRTUAL ADDR. (VBA < PLF - ABORT TO 6\$)
2445	022234	011001				ERROR	+10	:EXPECTED PAGE LENGTH ABORT DID NOT OCCUR
2446	022236	104010						:FOR TIGHTER SCOPE LOOP
2447								:REPLACE ERROR CALL WITH
2448								: 'BR 5\$' = 000776
2449	022240	000424				BR	8\$:BRANCH AROUND ABORT CHECKS
2450	022242	012706	001100		6S:	MOV	#KERSTK,KSP	:RESTORE STACK POINTER FOLLOWING ABORT
2451	022246	013737	177572	001264		MOV	SRO,WASSRO	:READ M.M. STATUS REG. 0
2452	022254	013737	177576	001270		MOV	SR2,WASSR2	:READ M.M. STATUS REG. 2
2453	022262	012702	040011			MOV	#40011,R2	:PUT EXPECTED SRO CONTENTS IN R2
2454	022266	020237	001264			CMP	R2,WASSRO	:DID SRO REPORT PG. LENGTH ABORT, PG. 4, KERNEL?
2455	022272	001401				BEQ	7\$:BRANCH IF YES
2456	022274	104011				ERROR	+11	:SRO DID NOT REPORT PG. LENGTH ABORT CORRECTLY
2457								:FOR TIGHTER SCOPE LOOP
2458								:REPLACE ERROR CALL WITH
2459								: 'BR 5\$' = 000757
2460	022276	012703	022234		7S:	MOV	#5\$,R3	:PUT EXPECTED SR2 CONTENTS IN R3
2461	022302	020337	001270			CMP	R3,WASSR2	:DID SR2 LOCKUP VIRT. ADDR. OF ABORTED INSTRUCTION?
2462	022306	001401				BEQ	8\$:BRANCH IF YES
2463	022310	104012				ERROR	+12	:SR2 DID NOT LOCKUP VIRT. ADDR. OF ABORT CORRECTLY
2464								:FOR TIGHTER SCOPE LOOP
2465								:REPLACE ERROR CALL WITH
2466								: 'BR 5\$' = 000751
2467	022312	042737	160000	177572	8S:	BIC	#160000,SRO	:CLEAR ERROR BITS IN SRO
2468	022320	162704	000400			SUB	#400,R4	:FORM NEXT PLF VALUE FOR KIPDR4
2469	022324	062700	000100			ADD	#100,R0	:FORM FIRST VIRT. ADDR. FOR THAT PLF VALUE
2470	022330	000703				BR	2\$:BRANCH BACK AND ACCESS 3 VBA'S FOR

```

2471
2472 022332 012637 001260          9$:  MOV    (KSP)+,TRAPPC  ;THE PLF VALUE JUST FORMED
2473 022336 012637 001262          MOV    (KSP)+,TRAPPS  ;SAVE PC & PS OF TRAP
2474 022342 013737 177572 001264  MOV    SRO,WASSRO    ;SAVE CONTENTS OF SRO FOR ERROR
2475 022350 013737 177576 001270  MOV    SR2,WASSR2    ;SAVE CONTENTS OF SR2 FOR ERROR
2476 022356 042737 160000 177572  BIC    #160000,SRO   ;CLEAR ERROR BITS IN SRO
2477 022364 104007          ERROR  +7           ;GOT PG. LENGTH ABORT BEFORE IT WAS EXPECTED
2478
2479
2480
2481 022366 013746 001262          MOV    TRAPPS,-(KSP)  ;FOR TIGHTER SCOPE LOOP
2482 022372 013746 001260          MOV    TRAPPC,-(KSP) ;REPLACE ERROR CALL WITH
2483 022376 000002          RTI                ;A 'NOP' = 000240
2484
2485 022400 012737 016142 000250 10$: MOV    #MGMERR,MMEVC  ;PUT PC & PS OF TRAP ON STACK
2486

```

```

;THE PLF VALUE JUST FORMED
;SAVE PC & PS OF TRAP
;SAVE CONTENTS OF SRO FOR ERROR
;SAVE CONTENTS OF SR2 FOR ERROR
;CLEAR ERROR BITS IN SRO
;GOT PG. LENGTH ABORT BEFORE IT WAS EXPECTED
;FOR TIGHTER SCOPE LOOP
;REPLACE ERROR CALL WITH
;A 'NOP' = 000240
;PUT PC & PS OF TRAP ON STACK
;RETURN FROM UNEXPECTED ABORT
;RESTORE NORMAL M.M. TRAP HANDLER
;ADDRESS TO M.M. TRAP VECTOR

```

2500

.SBTTL TEST # 6 - SR2 BIT TEST

*TEST 6 SR2 BIT TEST

THIS TEST CHECKS THE BITS IN MEMORY MANAGEMENT REGISTER 2 BY
CAUSING 'READ-ONLY ABORTS' AT VIRTUAL ADDRESSES BETWEEN 10000
TO 111000 (PHYSICAL ADDRESSES 060000-071000). KIPDR4 IS USED TO EXECUTE
THE FOLLOWING FOUR WORDS OF CODE WHICH ARE MOVED THRU MEMORY:
010727 MOV PC,(PC)+ ;THIS INSTRUCTION SHOULD CAUSE A R/O ABORT
000000 ;ITS VIRTUAL ADDR. SHOULD BE LOCKED UP IN SR2
000137 JMP @#3\$;THIS INSTRUCTION IS ALSO MOVED THRU MEMORY
(ADDR. OF 3\$) ;IN CASE A R/O ABORT DOES NOT OCCUR,
;IN WHICH CASE SR2 WILL NOT CONTAIN CORRECT ADDR.

```
TST6: SCOPE
1$: MOV #600,KIPAR3 ;BE SURE PAR3 IS MAPPED TO 12-16K
MOV #600,KIPAR4 ;BE SURE PAR4 IS MAPPED TO 12-16K
MOV #77406,KIPDR3 ;MAP PAGE 3 128 BLOCKS, R/W
MOV #77402,KIPDR4 ;MAP PAGE 4 128 BLOCKS, READ-ONLY
MOV #60000,R0 ;LOAD R0 WITH VIRTUAL ADDR. WHICH USES PDR3
MOV #100000,R1 ;LOAD R1 WITH VIRTUAL ADDR. WHICH USES PDR4
MOV #3$,MMVEC ;SET M.M. TRAP VECTOR TO 3$
MOV #2$,SLPERR ;SET LOOP ON ERROR POINTER TO 2$
2$: MOV #010727,(R0)+ ;LOAD 'MOV PC,(PC)+' INSTRUCTION AT ADDR.
CLR (R0)+ ; REACHED THRU PDR/PAR 4.
MOV #000137,(R0)+ ;LOAD 'JMP @#3$' INSTRUCTION AT VIRT. ADDR.
MOV #3$,(R0) ; IN CASE R/O VIOL. DOES NOT ABORT
MOV R1,PC ;TRANSFER PROGRAM EXECUTION TO 'PAGE 4 INSTRUCTIONS'
3$: MOV #KERSTK,KSP ;RESTORE STACK POINTER
MOV SR2,WASSR2 ;READ CONTENTS OF STATUS REG 2
CMP R1,WASSR2 ;WAS ADDR. OF 'RELOCATED - R/O ABORT'' LOCKED UP?
BEQ 4$ ;BRANCH IF YES
ERROR +13 ;SR2 DID NOT LOCK UP VIRTUAL ADDR. OF R/O VIOL.
2501 022406 000004 172346 ;FOR TIGHTER SCOPE LOOP
2502 022410 012737 000600 172350 ;REPLACE ERROR CALL WITH
2503 022424 012737 077406 172306 ;'BR 2$' = 000757
2504 022432 012737 077402 172310
2505 022440 012700 060000
2506 022444 012701 100000
2507 022450 012737 022504 000250
2508 022456 012737 022464 001110
2509 022464 012720 010727
2510 022470 005020
2511 022472 012720 000137
2512 022476 012710 022504
2513 022502 010107
2514 022504 012706 001100
2515 022510 013737 177576 001270
2516 022516 020137 001270
2517 022522 001401
2518 022524 104013
2519
2520
2521
2522 022526 042737 160000 177572 4$: BIC #160000,SRO ;CLEAR THE ERROR BITS IN SRO
2523 022534 162700 000004 SUB #4,R0 ;RESET R0 TO POINT TO NEXT VIRT. ADDR. TO LOAD
2524 022540 062701 000002 ADD #2,R1 ;FORM VIRTUAL ADDR. THAT SHOULD BE LOCKED UP NEXT
2525 022544 020127 111002 CMP R1,#111002 ;HAVE ALL VBA'S 100000-111000 BEEN TESTED?
2526 022550 103745 BLO 2$ ;BRANCH IF NO
2527
2528 022552 012737 077406 172310 5$: MOV #77406,KIPDR4 ;RESTORE PDR4 TO R/W ACCESS
2529 022560 012737 016147 000250 MOV #MGMERR,MMVEC ;RESTORE ADDRESS OF NORMAL M.M.
2530 ;TRAP HANDLER TO M.M. VECTOR
```


2544

.SBTTL TEST # 7 - MORE CHECKS OF SRO & SR2

TEST 7 MORE CHECKS OF SRO & SR2

THIS TEST PERFORMS SOME ADDITIONAL CHECKS OF THE SRO & SR2 LOGIC. FIRST IT CHECKS THAT SR2 "TRACKS" ALONG ACTING AS A VIRTUAL ADDRESS PROGRAM COUNTER. ALSO SRO & SR2 ARE LOCKED UP BY A PAGE LENGTH ABORT, THEN WITHOUT CLEARING SRO'S ERROR BITS, A R/O ABORT IS CAUSED. SRO & SR2 SHOULD NOT BE CHANGED BY THE SECOND ABORT AND THE INFORMATION ABOUT THE PAGE LENGTH ABORT SHOULD STILL BE LOCKED UP. IN ADDITION A "RESET" IS EXECUTED TO VERIFY THAT SRO IS CLEARED AND SR2 IS UNLOCKED BY A RESET. AFTER MEMORY MANAGEMENT IS TURNED BACK ON, SR2 IS CHECKED TO SEE THAT IT IS TRACKING AGAIN.

2545	022566	000004			TST7:	SCOPE	
2546	022570	012737	000600	172352	1\$:	MOV #600,KIPARS	:MAP KERNEL PAGE 5 TO 12-16\$
2547	022576	012737	000406	172310		MOV #406,KIPDR4	:SETUP PDR4 FOR PAGE LENGTH ABORT
2548	022604	012737	077402	172312		MOV #77402,KIPDR5	:SETUP PDR5 FOR R/O ABORT
2549	022612	012737	022620	001110		MOV #2\$,SLPERR	:SET LOOP ON ERROR POINTER TO 2\$
2550	022620	013737	177576	001270	2\$:	MOV SR2,WASSR2	:READ SR2 TO SEE IF ITS TRACKING
2551	022626	012701	022620			MOV #2\$,R1	:PUT EXPECTED VIRTUAL PC IN R1
2552	022632	020137	001270			CMP R1,WASSR2	:DID SR2 CONTAIN VIRTUAL PC AT 2\$?
2553	022636	001401				BEQ 3\$:BRANCH IF YES
2554	022640	104016				ERROR +16	:SR2 NOT TRACKING CORRECTLY
2555							:FOR TIGHTER SCOPE LOOP
2556							:REPLACE ERROR CALL WITH
2557	022642	012737	022650	001110	3\$:	MOV #4\$,SLPERR	:SET LOOP ON ERROR POINTER TO 4\$
2558	022650	013737	177576	001270	4\$:	MOV SR2,WASSR2	:READ SR2 TO SEE IF ITS TRACKING
2559	022656	012701	022650			MOV #4\$,R1	:PUT EXPECTED VIRTUAL PC IN R1
2560	022662	020137	001270			CMP R1,WASSR2	:DID SR2 CONTAIN VIRTUAL PC AT 4\$
2561	022666	001401				BEQ 5\$:BRANCH IF YES
2562	022670	104016				ERROR +16	:SR2 NOT TRACKING CORRECTLY
2563							:FOR TIGHTER SCOPE LOOP
2564							:REPLACE ERROR CALL WITH
2565							:BR 4\$ = 000767
2566	022672	012737	022700	001110	5\$:	MOV #6\$,SLPERR	:SET LOOP ON ERROR POINTER TO 6\$
2567	022700	012737	022716	000250	6\$:	MOV #7\$,MMVEC	:PUT ADDRESS OF 7\$ IN M.M. TRAP VECTOR
2568	022706	005037	001200			CLR \$TMP1	:CLEAR ERROR INDICATOR
2569	022712	005237	100500			INC @#100500	:CAUSE PAGE LENGTH ABORT - TRAP TO 7\$
2570	022716	012706	001100		7\$:	MOV #KERSTK,KSP	:RESTORE STACK POINTER AFTER ABORT
2571	022722	013737	177572	001176		MOV SRO,\$TMP0	:SAVE SRO'S INFORMATION ON PG. LGTH. ABORT
2572	022730	013737	177576	001202		MOV SR2,\$TMP2	:SAVE SR2'S INFORMATION ON PG. LGTH. ABORT
2573	022736	012737	022750	000250		MOV #8\$,MMVEC	:PUT ADDRESS OF 8\$ IN M.M. TRAP VECTOR
2574	022744	005237	120000			INC @#120000	:CAUSE R/O ABORT - TRAP TO 8\$
2575	022750	012706	001100		8\$:	MOV #KERSTK,KSP	:RESTORE STACK POINTER AFTER ABORT
2576	022754	013737	177572	001264		MOV SRO,WASSRO	:READ SRO FOLLOWING SECOND KT ABORT
2577	022762	013737	177576	001270		MOV SR2,WASSR2	:READ SR2 FOLLOWING SECOND KT ABORT
2578	022770	023737	001176	001264		CMP \$TMP0,WASSRO	:IS SRO STILL HOLDING INFO ON FIRST ABORT?
2579	022776	001402				BEQ 9\$:BRANCH IF YES
2580	023000	005237	001200			INC \$TMP1	:SET ERROR INDICATOR
2581	023004	023737	001202	001270	9\$:	CMP \$TMP2,WASSR2	:DOES SR2 STILL HOLD PC OF FIRST ABORT?
2582	023012	001402				BEQ 10\$:BRANCH IF YES
2583	023014	005237	001200			INC \$TMP1	:SET ERROR INDICATOR
2584	023020	005737	001200		10\$:	TST \$TMP1	:WERE SRO OR SR2 CHANGED BY A SECOND ABORT?
2585	023024	001401				BEQ 11\$:BRANCH IF NO

2586	023026	104014				ERROR	+14		:ONE OF STATUS REGS. CHANGED BY SECOND ABORT
2587									:FOR TIGHTER SCOPE LOOP
2588									:REPLACE ERROR CALL WITH
2589									: 'BR 6\$' = 000726
2590	023030	005037	001200		11\$:	CLR	\$TMP1		:CLEAR ERROR INDICATOR
2591	023034	000005				RESET			:EXECUTE A RESET, APPLYING AN "INIT"
2592	023036	013737	177572	001264		MOV	SRO,WASSRO		:READ SRO
2593	023044	005737	001264			TST	WASSRO		:WAS SRO CLEARED BY THE RESET?
2594	023050	001402				BEQ	12\$:BRANCH IF YES
2595	023052	005237	001200			INC	\$TMP1		:SRO NOT CLEARED BY A RESET
2596	023056	013737	177576	001270	12\$:	MOV	SR2,WASSR2		:READ SR2
2597	023064	022737	023056	001270		CMP	#12\$,WASSR2		:WAS SR2 UNLOCKED BY A RESET?
2598	023072	001402				BEQ	13\$:BRANCH IF YES
2599	023074	005237	001200			INC	\$TMP1		:SR2 NOT UNLOCKED BY A RESET
2600	023100	005737	001200		13\$:	TST	\$TMP1		:WERE SRO & SR2 BOTH "RESET" BY A RESET?
2601	023104	0C1401				BEQ	14\$:BRANCH IF YES
2602	023106	104015				ERROR	+15		:SRO OR SR2 NOT "RESET" BY A RESET
2603									:FOR TIGHTER SCOPE LOOP
2604									:REPLACE ERROR CALL WITH
2605									: 'BR 6\$' = 000676
2606	023110	005237	177572		14\$:	INC	SRO		:TURN MEMORY MANAGEMENT BACK ON
2607	023114	013737	177576	001270	15\$:	MOV	SR2,WASSR2		:READ SR2 TO SEE IF ITS TRACKING AGAIN
2608	023122	012701	023114			MOV	#15\$,R1		:PUT EXPECTED VIRTUAL PC IN R1
2609	023126	020137	001270			CMP	R1,WASSR2		:DID SR2 CONTAIN VIRTUAL PC AT 15\$
2610	023132	001401				BEQ	16\$:BRANCH IF YES
2611	023134	104016				ERROR	+16		:SR2 NOT TRACKING CORRECTLY
2612									:FOR TIGHTER SCOPE LOOP
2613									:REPLACE ERROR CALL WITH
2614									: 'BR 6\$' = 000663
2615	023136	012737	077406	172310	16\$:	MOV	#77406,KIPDR4		:RESET PDR4 TO 128 BLKS, R/W
2616	023144	012737	077406	172312		MOV	#77406,KIPDR5		:RESET PDR5 TO 128 BLKS, R/W
2617	023152	012737	016142	000250		MOV	#MGMERR,MMVEC		:RESTORE ADDRESS OF NORMAL MEMORY
2618									:MANAGEMENT TRAP ROUTINE TO M.M. VECTOR

2632

.SBTTL TEST # 10 - SUPER/USER ABORT PICKS UP KERNEL VECTOR

*TEST 10 SUPER/USER ABORT PICKS UP KERNEL VECTOR

* THIS TEST CHECKS TO BE SURE THAT WHEN AN ABORT OCCURS WHILE
 * IN SUPERVISOR OR USER MODE, THE TRAP VECTOR INFORMATION
 * FETCHED IS TAKEN FROM KERNEL SPACE. USER PAGE 0 IS MAPPED
 * TO 12K (60000-77776) SO THAT IF USER SPACE IS USED INSTEAD
 * OF KERNEL, THE NEW PC THAT WAS LOADED AT LOC. 060004 IS USED
 * INSTEAD OF THE NEW PC THAT SHOULD BE PICKED UP FROM LOC. 000004.
 * THE SUPERVISOR PAGE 0 IS THEN MAPPED TO 12K, AND THE TEST
 * IS REPEATED FOR SUPERVISOR MODE. AN ODD ADDRESS ERROR IS
 * USED TO CAUSE A TRAP TO '4'.
 * *****

TST10: SCOPE

2633	023160	000004			1\$: JSR	PC,TOFF	:TURN OFF T-BIT TRAPPING FOR THIS TEST
2634	023166	012737	023174	001110	MOV	#2\$, \$LPERR	:SET LOOP ON ERROR POINTER TO 2\$
2635	023174	005037	177776		2\$: CLR	PSW	:GO TO KERNEL MODE
2636	023200	012706	001100		MOV	#KERSTK, KSP	:SETUP KERNEL STACK PTR.
2637							
2638							
2639							
2640	023204	012737	000600	177640	MOV	#600, UIPARO	:MAP USER PAGE 0 TO 12K
2641	023212	012737	023274	000004	MOV	#4\$, @#4	:LOAD KERNEL VECTOR 4 (LOC.4) WITH 4\$
2642	023220	012737	000340	000006	MOV	#340, @#6	:LOAD VECTOR+2 WITH NEW PSW
2643	023226	012737	140000	177776	MOV	#140000, PSW	:GO TO USER MODE
2644	023234	012706	000600		MOV	#USESTK, USP	:SETUP USER STACK PTR.
2645	023240	012737	023260	000004	MOV	#3\$, @#4	:LOAD USER VECTOR 4 (LOC. 60004) WITH 3\$
2646	023246	012737	000340	000006	MOV	#340, @#6	:LOAD VECTOR+2 WITH NEW PSW
2647	023254	005737	023261		TST	3\$+1	:CAUSE ODD ADDR. ERROR TRAP TO '4'
2648							:SHOULD PICK UP NEW PC=4\$ FROM KERNEL
2649							:LOC. 4, NOT PC=3\$ FROM USER LOC. 4 (=60004)
2650	023260	013701	177776		3\$: MOV	PSW, R1	:SAVE PSW FOR ERROR
2651	023264	010602			MOV	SP, R2	:SAVE VALUE OF STACK POINTER FOR ERROR
2652	023266	005037	177776		CLR	PSW	:BE SURE BACK IN KERNEL MODE
2653	023272	104017			ERROR	+17	:DID NOT TRAP THRU KERNEL SPACE
2654							:FOR TIGHTER SCOPE LOOP
2655							:REPLACE ERROR CALL WITH
2656							: 'BR 2\$' = 000740
2657	023274	005037	177776		4\$: CLR	PSW	:BE SURE BACK IN KERNEL MODE
2658	023300	012706	001100		MOV	#KERSTK, KSP	:RESTORE KERNEL S.P. IN CASE IT CHANGED
2659	023304	005037	177640		CLR	UIPARO	:REMAP USER PAGE 0 TO 0-4K
2660	023310	012737	140000	177776	MOV	#140000, PSW	:GO TO USER MODE
2661	023316	012706	000600		MOV	#USESTK, USP	:RESTORE USER STACK POINTER
2662	023322	005037	177776		CLR	PSW	:GO BACK TO KERNEL MODE
2663							
2664							
2665							
2666	023326	012737	000600	172240	MOV	#600, SIPARO	:MAP SUPERVISOR PAGE 0 TO 12K
2667	023334	012737	023416	000004	MOV	#6\$, @#4	:LOAD KERNEL VECTOR 4 WITH 6\$
2668	023342	012737	000340	000006	MOV	#340, @#6	:LOAD VECTOR+2 WITH NEW PSW
2669	023350	012737	040000	177776	MOV	#40000, PSW	:GO TO SUPERVISOR MODE
2670	023356	012706	000700		MOV	#SUPSTK, SSP	:SETUP SUPERVISOR STACK PTR.
2671	023362	012737	023402	000004	MOV	#5\$, @#4	:LOAD SUPERVISOR VECTOR 4 (LOC. 60004) WITH 5\$
2672	023370	012737	000340	000006	MOV	#340, @#6	:LOAD VECTOR+2 WITH NEW PSW
2673	023376	005737	023403		TST	5\$+1	:CAUSE ODD ADDR. ERROR TRAP TO '4'

 * NOW TEST THE SUPERVISOR MODE ABORT
 * *****

2697

```
.SBTTL TEST # 11 - RTI IN SUPER/USER MODE DOES NOT CHANGE PSW
:*****
:*TEST 11 RTI IN SUPER/USER MODE DOES NOT CHANGE PSW
:*
:* THIS TEST CHECKS TO SEE THAT WHEN AN RTI IS EXECUTED IN SUPERVISOR
:* OR USER MODE, THE MODE OR PRIORITY BITS OF THE PSW ARE NOT CHANGED.
:*
:*****
```

023462 000004

TST11: SCOPE

2698									
2699	023464	012737	023476	001110	1\$:	MOV	#2\$, \$LPERR	:	SET LOOP ON ERROR POINTER TO 2\$
2700	023472	012702	170000			MOV	#170000, R2	:	LOAD 'PRESENT & EXPECTED' PSW VALUE INTO R2
2701	023476	010237	177776		2\$:	MOV	R2, PSW	:	GO TO PRESENT MODE-PRIORITY 0
2702	023502	012746	000340			MOV	#340, -(SP)	:	PUT A NEW PSW (PRIORITY=7) ON STACK
2703	023506	012746	023514			MOV	#3\$, -(SP)	:	PUT NEW PC ON THE STACK
2704	023512	000002				RTI		:	DO AN RTI FROM PRESENT MODE
2705	023514	013701	177776		3\$:	MOV	PSW, R1	:	READ NEW PSW INTO R1
2706	023520	042701	007437			BIC	#7437, R1	:	MASK OFF COND. CODE, T-BIT, AND UNUSED BITS
2707	023524	005037	177776			CLR	PSW	:	GO BACK TO KERNEL MODE
2708	023530	020201				CMP	R2, R1	:	DID PSW STAY IN PRESENT MODE, PRIORITY=0?
2709	023532	001401				BEQ	4\$:	BRANCH IF YES
2710	023534	104032				ERROR	+32	:	PSW CHANGED BY AN RTI FROM USER
2711								:	FOR A TIGHTER SCOPE LOOP
2712								:	REPLACE ERROR CALL WITH
2713								:	'BR=2\$' = 000760
2714	023536	022702	050000		4\$:	CMP	#50000, R2	:	IF SUPERVISOR MODE HAS BEEN CHECKED,
2715	023542	001403				BEQ	TST12	:	GO TO NEXT TEST
2716	023544	012702	050000			MOV	#50000, R2	:	ELSE, SET SUPERVISOR MODE,
2717	023550	000752				BR	2\$:	AND BRANCH BACK TO TEST IT.

2729

```
.SBTTL TEST # 12 - KT ERROR NOT SERVICED IF ODD ADDR. ERROR
:*****
:*TEST 12      KT ERROR NOT SERVICED IF ODD ADDR. ERROR
:*
:*      THIS TEST CHECKS TO SEE THAT IF A CERTAIN VIRTUAL ADDRESS THAT
:*      WOULD CAUSE A MEMORY MANAGEMENT ERROR CAUSES AN ODD ADDRESS
:*      ERROR FIRST, THE ODD ADDRESS ERROR IS SERVICED BUT THE MEMORY
:*      MANAGEMENT ERROR ISN'T. THIS MEANS THAT SRO AND SR2
:*      SHOULD NOT REPORT THE ERROR OR LOCK UP ITS VIRTUAL ADDRESS.
:*      A READ-ONLY VIOLATION IS USED AS THE POTENTIAL MEMORY MANAGEMENT
:*      ERROR
:*****
```

```
TST12: SCOPE
1$:  MOV      #600,KIPAR4      ;MAP KERNEL PAGE 4 TO 12-16K
    MOV      #77402,R5       ;LOAD PDR4 DATA INTO R5
    MOV      R5,KIPDR4       ;MAP PAGE 4 READ-ONLY
    MOV      #4$,@#4         ;SET CPU TRAP VECTOR TO ADDRESS OF 4$
    MOV      #3$,@#250       ;SET M.M. TRAP VECTOR TO ADDRESS OF 3$
    MOV      #2$, $LPERR     ;SET LOOP ON ERROR POINTER TO 2$
2$:  INC      60001           ;CAUSE ODD ADDR. ERROR & POTENTIAL R/O ABORT
3$:  ERROR   +20             ;TRAPPED THRU M.M. VECTOR BUT SHOULDN'T HAVE
    ;FOR TIGHTER SCOPE LOOP
    ;REPLACE ERROR CALL WITH
    ;'BR 2$' = 000776
4$:  MOV      #KERSTK,KSP    ;RESTORE STACK POINTER AFTER TRAPPING
    CLR      $TMP1           ;CLEAR ERROR INDICATOR
    MOV      SRO,WASSRO      ;READ STATUS REG. 0
5$:  MOV      SR2,WASSR2     ;READ STATUS REG. 2
    MOV      #17,R0          ;LOAD EXPECTED SRO CONTENTS INTO R0
    CMP      R0,WASSRO       ;SRO ERROR BITS LEFT CLEAR BY TRAPPING?
    BEQ      6$              ;BRANCH IF YES
    INC      $TMP1           ;SRO ERROR BITS SET WHEN ODD ADDR. SERVICED
6$:  MOV      #5$,R1         ;LOAD EXPECTED SR2 CONTENTS INTO R1
    CMP      R1,WASSR2       ;WAS SR2 LEFT UNLOCKED BY TRAPPING?
    BEQ      7$              ;BRANCH IF YES
    INC      $TMP1           ;SR2 LOCKED UP BY ODD ADDR. ERROR
7$:  TST      $TMP1          ;WHERE SRO OR SR2 EFFECTED?
    BEQ      8$              ;BRANCH IF NO
    ERROR   +21             ;SRO OR SR2 CHANGED BY ODD ADDR. ERROR
    ;FOR TIGHTER SCOPE LOOP
    ;REPLACE ERROR CALL WITH
    ;'BR 2$' = 000741
8$:  BIC      #160000,SRO     ;CLEAR ERROR BITS THAT MAY BE SET IN SRO
    MOV      #TIMERR,@#4     ;RESTORE ADDRESS OF NORMAL CPU TRAP HANDLER
    MOV      #MGERR,@#250    ;RESTORE ADDRESS OF NORMAL M.M. TRAP HANDLER
    MOV      #77406,KIPDR4   ;REMAP PAGE 4 TO READ/WRITE

2730 023552 000004
2731 023554 012737 000600 172350
2732 023562 012705 077402
2733 023566 010537 172310
2734 023572 012737 023622 000004
2735 023600 012737 023620 000250
2736 023606 012737 023614 001110
2737 023614 005237 060001
2738 023620 104020
2739
2740
2741 023622 012706 001100
2742 023626 005037 001200
2743 023632 013737 177572 001264
2744 023640 013737 177576 001270
2745 023646 012700 000017
2746 023652 020037 001264
2747 023656 001402
2748 023660 005237 001200
2749 023664 012701 023640
2750 023670 020137 001270
2751 023674 001402
2752 023676 005237 001200
2753 023702 005737 001200
2754 023706 001404
2755 023710 104021
2756
2757
2758
2759 023712 042737 160000 177572
2760 023720 012737 016070 000004
2761 023726 012737 016142 000250
2762 023734 012737 077406 172310
```

2777

.SBTTL TEST # 13 - PC & PSW SAVED FOR KT ERROR ON ODD ADDR.

 :TEST 13 PC & PSW SAVED FOR KT ERROR ON ODD ADDR.
 :*

:* THIS TEST CHECKS THE PC AND PROCESSOR STATUS WORD SAVED WHEN
 :* A KT ERROR OCCURS DURING THE SECOND PUSH ON THE STACK DURING
 :* SERVICING OF AN ODD ADDR. ERROR. DURING A 'DOUBLE ERROR'
 :* SEQUENCE SUCH AS THIS, THE PSW SAVED WILL BE THE ONE PICKED UP
 :* FROM VECTOR+2 (LOC. 6 IN THIS CASE) AFTER THE FIRST TRAP,
 :* NOT THE PSW PRESENT BEFORE THE FIRST TRAP. SRO AND SR2
 :* SHOULD RECORD THE KT ERROR (A R/O VIOLATION BY THE USER STACK PTR.)

:* NOTE THAT THE PREVIOUS MODE BITS <13:12> OF THE PSW
 :* WILL BE SET IN THE PSW THAT IS SAVED.
 :*

 TST13: SCOPE

2778	023742	000004		1\$: JSR	PC,TOFF	:TURN I-BIT TRAPPING OFF FOR THIS TEST
2779	023744	004737	002356	MOV	#600,UIPAR3	:MAP USER PAGE 3 TO 12-16K
2780	023750	012737	000600	MOV	#600,UIPAR4	:MAP USER PAGE 4 TO 12-16K
2781	023756	012737	000600	MOV	#77402,UIPDR3	:MAP USER PAGE 3 READ-ONLY
2782	023764	012737	077402	MOV	#77406,UIPDR4	:MAP USER PAGE 4 READ/WRITE
2783	023772	012737	077406	MOV	#4\$,a#4	:LOAD ADDRESS OF 4\$ IN CPU (ODD ADDR.) VECTOR
2784	024000	012737	024054	MOV	#140017,a#6	:LOAD PSW THAT SHOULD BE PUT ON STACK IN VECTOR+2
2785	024006	012737	140017	MOV	#4\$,a#250	:LOAD ADDRESS OF 4\$ IN M.M. TRAP VECTOR
2786	024014	012737	024054	MOV	#340,a#252	:LOAD A KERNEL PSW IN MMVEC+2
2787	024016	012737	000250	MOV	#2\$, \$LPERR	:SET LOOP ON ERROR POINTER TO 2\$
2788	024022	012737	000340	MOV	#140000,PSW	:GO TO USER MODE
2789	024030	012737	024036	MOV	#100002,USP	:SET USER STACK PTR. SO SECOND PUSH IS IN PG. 3
2790	024036	012706	100002	3\$: INC	100005	:CAUSE ODD ADDRESS ERROR THAT WILL CAUSE
2791	024050	005237	100005	4\$: MOV	2(KSP),R1	:R/O ERROR WHEN TRY TO SAVE OLD PC
2792	024054	016601	000002	MOV	(KSP),R3	:PUT PSW SAVED ON KERNEL STACK INTO R1
2793	024060	011603		MOV	SRO,WASSRO	:PUT PC SAVED ON KERNEL STACK INTO R3
2794	024062	013737	177572	MOV	SR2,WASSR2	:READ THE CONTENTS OF M.M. STATUS REG. 0
2795	024070	013737	177576	MOV	#160000,SRO	:READ THE CONTENTS OF M.M. STATUS REG. 2
2796	024076	042737	160000	BIC	PSW	:CLEAR THE ERROR BITS IN SRO
2797	024104	005037	177776	CLR	#KERSTK,KSP	:BE SURE IN KERNEL MODE
2798	024110	012706	001100	MOV	#140000,PSW	:RESTORE KERNEL STACK POINTER
2799	024114	012737	140000	MOV	#USESTK,USP	:GO TO USER MODE
2800	024122	012706	000600	MOV	PSW	:RESTORE USER STACK POINTER
2801	024126	005037	177776	CLR	\$TMP0	:GO BACK TO KERNEL MODE
2802	024132	005037	001176	CLR	R1,#170017	:CLEAR ERROR INDICATOR
2803	024136	020127	170017	CMP		:WAS THE PSW SAVED THE ONE PICKED UP BY THE
2804						:ODD ADDR. TRAP FROM ERRVEC+2?
2805						:VALUE 170017 = PSW FROM LOC. 6 WITH
2806						:PREVIOUS MODE BITS = USER
2807	024142	001402		BEQ	5\$:BRANCH IF YES
2808	024144	005237	001176	INC	\$TMP0	:WRONG PSW SAVED DURING 'DOUBLE ERROR' SEQUENCE
2809	024150	020327	024054	5\$: CMP	R3,#3\$+4	:WAS THE PC AT THE TIME OF THE ODD ADDR. ERROR
2810						:SAVED ON THE STACK?
2811	024154	001402		BEQ	6\$:BRANCH IF YES
2812	024156	005237	001176	INC	\$TMP0	:WRONG PC SAVED DURING TRAP SEQUENCE
2813	024162	023727	001264	6\$: CMP	WASSRO,#20147	:DID SRO REPORT - USER, PAGE 3, R/O ABORT?
2814	024170	001402		BEQ	7\$:BRANCH IF YES
2815	024172	005237	001176	INC	\$TMP0	:SRO DID NOT REPORT R/O ABORT
2816	024176	023727	001270	7\$: CMP	WASSR2,#3\$:DID SR2 LOCK UP VIRTUAL ADDR. OF LAST
2817						:INSTRUCTION SUCCESSFULLY FETCHED?

2818	024204	001402				BEQ	8\$:BRANCH IF YES
2819	024206	005237	001176			INC	\$TMP0		:SR2 DID NOT LOCK UP ADDR. OF ODD ADDR. INST.
2820	024212	005737	001176		8\$:	TST	\$TMP0		:ANY 'ERRORS' DURING TRAP SEQUENCE?
2821	024216	001401				BEQ	9\$:BRANCH IF NO
2822	024220	104022				ERROR	+22		:THE WRONG PC OR PSW WERE SAVED
2823									:OR SRO OR SR2 DID NOT REPORT R/O
2824									:ERROR DURING ODD ADDR. - KT TRAP
2825									:SEQUENCE
2826									:FOR TIGHTER SCOPE LOOP
2827									:REPLACE ERROR CALL WITH
2828									: 'BR 2\$' = 000710
2829	024222	012737	016070	000004	9\$:	MOV	#TIMERR,@#4		:RESTORE ADDRESS OF NORMAL CPU TRAP HANDLER
2830	024230	012737	000340	000006		MOV	#340,@#6		:RELOAD ERRVEC+2 WITH KERNEL PSW
2831	024236	012737	016142	000250		MOV	#MGMERR,@#250		:RESTORE ADDRESS OF NORMAL M.M. TRAP HANDLER
2832	024244	012737	077406	177606		MOV	#77406,UIPDR3		:REMAP USER PAGE 3 READ/WRITE
2833	024252	004737	002412			JSR	PC,TON		:TURN T-BIT TRAPPING BACK ON

2834
2835
2836

.SBTTL GROUP 2 D-SPACE TESTS
:/.
:/. \

2852

```
.SBTTL TEST # 14 - ENABLE D-SPACE AND SEE THAT I-SPACE IS FORCED
:*****
*TEST 14      ENABLE D-SPACE AND SEE THAT I-SPACE IS FORCED
:
*      THIS TEST SHOWS THAT I-SPACE IS FORCED DURING INSTRUCTION FETCHES,
*      AND ADDRESS, INDEX AND OPERAND FETCHES IF THE REGISTER FIELD IS 7.
:
*      ALL ERRORS FOUND IN THIS TEST ARE REPORTED WHEN THE CPU
*      ABORTS THRU 'MMVEC' TO SUBROUTINE 'MODSPAC'. THIS SUB-
*      ROUTINE WILL REPORT THAT D-SPACE WAS NOT ENABLED PROPERLY.
:
*      NOTE - WHENEVER A DSTM=3,6,7 IS SHOWN, AND THE OPERAND IS
*      '100000', I-SPACE IS FORCED IN THE OPERAND FETCH,
*      BUT D-SPACE WILL BE FORCED ON THE ACCESS OF THE
*      LOCATION; CORRECT OPERATION IS CHECKED.
:*****
```

```
024256 000004
2853
2854 024260 005037 177572
2855 024264 012700 077400
2856 024270 010037 172310
2857 024274 010037 172322
2858 024300 010037 172324
2859 024304 010037 172326
2860 024310 012737 000600 172370
2861 024316 012737 002232 000250
2862 024324 012737 024344 001110
2863 024332 005237 177572
2864 024336 012737 000024 172516
2865
2866
2867 024344 000400
2868 024346 000244
2869 024350 001776
2870 024352 000264
2871 024354 001376
2872 024356 000270
2873 024360 100376
2874
2875
2876
2877 024362 005700
2878 024364 005200
2879 024366 005300
2880 024370 006000
2881 024372 006100
2882 024374 005037 177572
2883
2884
2885 024400 012737 100002 060000
2886 024406 012737 024420 001110
2887 024414 005237 177572
2888 024420 005727 060000
2889 024424 005737 100000
2890 024430 005737 100000
2891 024434 005777 053340
```

```
TST14: SCOPE
:INITIALIZE KERNAL I/D SPACE PAR'S AND PDR'S
CLR      MMRO      :TURN OFF MEMORY MANAGEMENT
MOV      #77400,R0 :MAKE KERNAL D-SPACE PGS. 1,2&3 NON-RESIDENT
MOV      R0,KIPDR4 :AND KERNAL I-SPACE PDR4 NON-RESIDENT
MOV      R0,KDPDR1
MOV      R0,KDPDR2
MOV      R0,KDPDR3
MOV      #600,KDPAR4 :MAP KDPAR4 TO 12->16K
MOV      #NODSPAC,MMVEC :SET M.M. VECTOR TO D-SPACE SERVICE ROUTINE
MOV      #10$, $LPERR :SET LOOP ON ERROR POINTER TO 10$
INC      MMRO      :TURN ON MEMORY MANAGEMENT
MOV      #24,MMR3   :ENABLE 22-BIT,KERNAL D-SPACE MAPPING
:
*      TEST THAT INSTRUCTION FETCHES FORCE I-SPACE
:
:
10$: BR      4$      :BRANCH
4$:  CLZ      :CLEAR ZERO BIT IN PSW
BEQ      4$      :NO BRANCH
5$:  SEZ      :SET ZERO BIT IN PSW
BNE      5$      :NO BRANCH
6$:  SEN      :SET NEGATIVE BIT IN PSW
BPL      6$      :NO BRANCH
:
*      TRY SOME SOP INSTRUCTIONS WITH SRCM=DSTM=0
*      THESE SHOULD NEVER INVOKE D-SPACE
:
:
TST      R0
INC      R0
DEC      R0
ROR      R0
ROL      R0
CLR      MMRO      :TURN OFF MEMORY MANAGEMENT
:
*      TEST SOB NON-MOD WITH DSTM=2,3,6,7; DSTF=7
:
:
MOV      #100002,@#60000 :SET UP TEST LOCATION
MOV      #11$, $LPERR :SET LOOP ON ERROR POINTER TO 11$
INC      MMRO      :TURN ON MEMORY MANAGEMENT
11$: TST      #60000 :DSTM=2 SOP NON-MOD
TST      @#100000 :DSTM=3 SOP NON-MOD
TST      100000 :DSTM=6 SOP NON-MOD
TST      @100000 :DSTM=7 SOP NON-MOD
```

```

2892 024440 005037 177572          CLR      MMR0          ;TURN OFF MEMORY MANAGEMENT
2893          :*          TEST SOB MOD WITH DSTM=2,3,6,7; DSTF=7
2894          :*
2895 024444 012737 024464 001110    MOV      #12$, $LPERR  ;SET LOOP ON ERROR POINTER TO 12$
2896 024452 012737 100000 060002    MOV      #100000, @#60002 ;SET UP TEST VALUES
2897 024460 005237 177572          INC      MMR0          ;TURN ON MEMORY MANAGEMENT
2898 024464 005027 060000          12$:    CLR      #60000        ;DSTM=2 SOP MOD
2899 024470 005037 100000          CLR      @#100000     ;DSTM=3 SOP MOD
2900 024474 005037 100000          CLR      100000      ;DSTM=6 SOP MOD
2901 024500 005077 053276          CLR      @100002     ;DSTM=7 SOP MOD
2902 024504 005037 177572          CLR      MMR0        ;TURN OFF MEMORY MANAGEMENT
2903          :*
2904          :*          THE NEXT THREE TESTS ARE CONCERNED WITH TESTING
2905          :*          DOP AND NOT(SRCM=DSTM=0)
2906          :*
2907          :*          TEST DOP DEST NON-MOD SRCM=DSTM=2,3,6,7; SRCF=DSTF=7
2908          :*
2909 024510 012737 024530 001110    MOV      #13$, $LPERR  ;SET LOOP ON ERROR POINTER TO 13$
2910 024516 012737 100000 060002    MOV      #100000, @#60002 ;SET UP TEST VALUE
2911 024524 005237 177572          INC      MMR0          ;TURN ON MEMORY MANAGEMENT
2912 024530 022727 060000 060000    13$:    CMP      #60000, #60000  ;SRCM=2 DSTM=2 DOP NON-MOD
2913 024536 023737 100000 100000    CMP      @#100000, @#100000 ;SRCM=3 DSTM=3 DOP NON-MOD
2914 024544 023737 100000 100000    CMP      100000, 100000  ;SRCM=6 DSTM=6 DOP NON-MOD
2915 024552 027777 053224 053222    CMP      @100002, @100002 ;SRCM=7 DSTM=7 DOP NON-MOD
2916 024560 005037 177572          CLR      MMR0        ;TURN OFF MEMORY MANAGEMENT
2917          :*          TEST MOV DEST AND NOT(SRCM=DSTM=0)
2918          :*          SRCM=DSTM=2,3,6,7; SRCF=DSTF=7
2919          :*
2920 024564 012737 024604 001110    MOV      #14$, $LPERR  ;SET LOOP ON ERROR POINTER TO 14$
2921 024572 012737 100000 060002    MOV      #100000, @#60002 ;SET UP TEST VALUE
2922 024600 005237 177572          INC      MMR0          ;TURN ON MEMORY MANAGEMENT
2923 024604 012727 060002 060002    14$:    MOV      #60002, #60002  ;SRCM=2 DSTM=2 MOV
2924 024612 012737 060000 100000    MOV      #60000, @#100000 ;SRCM=2 DSTM=3 MOV
2925 024620 012737 060000 100000    MOV      #60000, 100000  ;SRCM=2 DSTM=6 MOV
2926 024626 012777 060000 053146    MOV      #60000, @100002 ;SRCM=2 DSTM=7 MOV
2927 024634 005037 177572          CLR      MMR0        ;TURN OFF MEMORY MANAGEMENT
2928          :*          TEST DOP DEST MOD AND NOT SUB
2929          :*          SRCM=DSTM=2,3,6,7; SRCF=DSTF=7
2930          :*
2931 024640 012737 024652 001110    MOV      #15$, $LPERR  ;SET LOOP ON ERROR POINTER TO 15$
2932 024646 005237 177572          INC      MMR0          ;TURN ON MEMORY MANAGEMENT
2933 024652 052727 060000 060000    15$:    BIS      #60000, #60000  ;SRCM=2 DSTM=2 DOP MOD
2934 024660 052737 000000 100000    BIS      #00000, @#100000 ;SRCM=2 DSTM=3 DOP MOD
2935 024666 052737 000000 100000    BIS      #00000, 100000  ;SRCM=2 DSTM=6 DOP MOD
2936 024674 052777 000000 053100    BIS      #00000, @100002 ;SRCM=2 DSTM=7 DOP MOD
2937 024702 005037 177572          CLR      MMR0        ;TURN OFF MEMORY MANAGEMENT
2938          :*          TEST SWAB WITH DSTM=2,3,6,7; DSTF=7
2939          :*
2940 024706 012737 024726 001110    MOV      #16$, $LPERR  ;SET LOOP ON ERROR POINTER TO 16$
2941 024714 012737 100002 060000    MOV      #100002, @#60000 ;SET UP TEST VALUES
2942 024722 005237 177572          INC      MMR0          ;TURN ON MEMORY MANAGEMENT
2943 024726 000327 060000          16$:    SWAB    #60000        ;DSTM=2 SWAB
2944 024732 000337 100002          SWAB    @#100002     ;DSTM=3 SWAB
2945 024736 000337 100002          SWAB    100002      ;DSTM=6 SWAB
2946 024742 000377 053032          SWAB    @100000     ;DSTM=7 SWAB
2947 024746 005037 177572          CLR      MMR0        ;TURN OFF MEMORY MANAGEMENT
2948          :*          TEST ROT/SHFT WITH DSTM=2,3,6,7; DSTF=7

```

```

2949
2950 024752 012737 024772 001110 ;*      MOV      #17$, $LPERR      ;SET LOOP ON ERROR POINTER TO 17$
2951 024760 012737 100000 060002      MOV      #100000, @#60002    ;SET UP TEST VALUES
2952 024766 005237 177572      INC      MMRO                ;TURN ON MEMORY MANAGEMENT
2953 024772 006127 060000      17$:    ROL      #60000              ;DSTM=2 ROT/SHFT
2954 024776 006137 100000      ROL      @#100000            ;DSTM=3 ROT/SHFT
2955 025002 006137 100000      ROL      100000              ;DSTM=6 ROT/SHFT
2956 025006 006177 052770      ROL      @100002            ;DSTM=7 ROT/SHFT
2957 025012 005037 177572      CLR      MMRO                ;TURN OFF MEMORY MANAGEMENT
2958 ;*      TEST   ASH/ASHC WITH DSTM=2,3,6,7; DSTF=7
2959 ;*
2960 025016 012737 025044 001110      MOV      #18$, $LPERR      ;SET LOOP ON ERROR POINTER TO 18$
2961 025024 012737 000001 060000      MOV      #1, @#60000        ;SET UP TEST VALUES
2962 025032 012737 100000 060002      MOV      #100000, @#60002   ;TURN ON MEMORY MANAGEMENT
2963 025040 005237 177572      INC      MMRO                ;TURN ON MEMORY MANAGEMENT
2964 025044 072027 000001      18$:    ASH      #1, R0          ;DSTM=2 ASH/ASHC
2965 025050 072037 100000      ASH      @#100000, R0       ;DSTM=3 ASH/ASHC
2966 025054 072037 100000      ASH      100000, R0        ;DSTM=6 ASH/ASHC
2967 025060 072077 052716      ASH      @100002, R0       ;DSTM=7 ASH/ASHC
2968 025064 005037 177572      CLR      MMRO                ;TURN OFF MEMORY MANAGEMENT
2969 ;*      TEST   MUL/DIV WITH DSTM=2,3,6,7; DSTF=7
2970 ;*
2971 025070 012737 025102 001110      MOV      #19$, $LPERR      ;SET LOOP ON ERROR POINTER TO 19$
2972 025076 005237 177572      INC      MMRO                ;TURN ON MEMORY MANAGEMENT
2973 025102 070027 000002      19$:    MUL      #2, R0           ;DSTM=2 MUL/DIV
2974 025106 070037 100000      MUL      @#100000, R0       ;DSTM=3 MUL/DIV
2975 025112 070037 100000      MUL      100000, R0        ;DSTM=6 MUL/DIV
2976 025116 070077 052660      MUL      @100002, R0       ;DSTM=7 MUL/DIV
2977 025122 005037 177572      CLR      MMRO                ;TURN OFF MEMORY MANAGEMENT
2978 ;*      TEST   JMP WITH DSTM=3,6,7; DSTF=7
2979 ;*
2980 025126 012737 025146 001110      MOV      #20$, $LPERR      ;SET LOOP ON ERROR POINTER TO 20$
2981 025134 012737 025162 060000      MOV      #23$, @#60000     ;SET UP TEST VALUES
2982 025142 005237 177572      INC      MMRO                ;TURN ON MEMORY MANAGEMENT
2983 025146 000137 025152      20$:    JMP      @#21$              ;DSTM=3 JMP
2984 025152 000137 025156      21$:    JMP      22$             ;DSTM=6 JMP
2985 025156 000177 052616      22$:    JMP      @100000        ;DSTM=7 JMP
2986 025162 005037 177572      23$:    CLR      MMRO                ;TURN OFF MEMORY MANAGEMENT
2987 ;*      TEST   SUB WITH DSTM=2,3,6,7; DSTF=7
2988 ;*
2989 025166 012737 025210 001110      MOV      #28$, $LPERR      ;SET LOOP ON ERROR POINTER TO 28$
2990 025174 005000      CLR      R0                  ;SET UP TEST VALUES
2991 025176 012737 100000 060002      MOV      #100000, @#60002   ;TURN ON MEMORY MANAGEMENT
2992 025204 005237 177572      INC      MMRO                ;TURN ON MEMORY MANAGEMENT
2993 025210 160027 060002      28$:    SUB      R0, #60002         ;DSTM=2 SUB
2994 025214 160037 100000      SUB      R0, @#100000       ;DSTM=3 SUB
2995 025220 160037 100000      SUB      R0, 100000         ;DSTM=6 SUB
2996 025224 160077 052552      SUB      R0, @100002       ;DSTM=7 SUB
2997 025230 005037 177572      CLR      MMRO                ;TURN OFF MEMORY MANAGEMENT

```

3008

```
.SBTTL TEST # 15 - ENABLE D-SPACE AND SEE I-SPACE IS NOT FORCED
*****
*TEST 15      ENABLE D-SPACE AND SEE I-SPACE IS NOT FORCED
*
*      THIS TEST SHOWS THAT I-SPACE IS NOT FORCED IF THE REGISTER FIELD
*      IS NOT 7, BUT THE OTHER CONDITIONS ARE MET.
*
*      ALL ERRORS FOUND IN THIS TEST ARE REPORTED WHEN THE CPU ABORTS
*      THROUGH 'MMVEC' TO SUBROUTINE 'NODSPAC'. THIS SUBROUTINE WILL
*      REPORT THAT D-SPACE WAS NOT ENABLED PROPERLY.
*****
```

```
025234 000004
3009 025236 012700 077406
3010 025242 010037 172310
3011 025246 010037 172322
3012 025252 010037 172324
3013 025256 010037 172326
3014 025262 105037 172306
3015
3016
3017 025266 012700 060000
3018 025272 010037 060000
3019 025276 012737 060002 C^0002
3020 025304 012737 060004 060004
3021 025312 012737 060006 060006
3022 025320 012737 025362 001110
3023 025326 012737 060000 060000
3024 025334 012737 060002 060002
3025 025342 012737 060004 060004
3026 025350 012737 060006 060006
3027 025356 005237 177572
3028 025362 005710
3029 025364 005720
3030 025366 005730
3031 025370 005750
3032 025372 005770 000000
3033 025376 005037 177572
3034
3035
3036 025402 012737 025414 001110
3037 025410 005237 177572
3038 025414 005010
3039 025416 005020
3040 025420 005030
3041 025422 005050
3042 025424 005070 000000
3043 025430 005037 177572
3044
3045
3046
3047 025434 012737 025476 001110
3048 025442 012702 000032
3049 025446 012700 060000
3050 025452 012701 060000
3051 025456 010021
3052 025460 062700 000002
```

```
TST15: SCOPE
MOV      #77406,R0
MOV      R0,KIPDR4      :MAKE KIPDR4 R/W,4K,200 BLOCKS
MOV      R0,KDPDR1      :MAKE KDPDR1 R/W,4K,200 BLOCKS
MOV      R0,KDPDR2      :MAKE KDPDR2 R/W,4K,200 BLOCKS
MOV      R0,KDPDR3      :MAKE KDPDR3 R/W,4K,200 BLOCKS
CLRB     KIPDR3         :MAKE KIPDR3 NON-RESIDENT
*
*      TEST SOP NON-MOD; DSTM=1,2,3,5,7
*
20$:    MOV      #60000,R0      :SET UP CONSTANTS FOR TEST
        MOV      R0,@#60000
        MOV      #60002,@#60002
        MOV      #60004,@#60004
        MOV      #60006,@#60006
        MOV      #1$, $LPERR    :SET LOOP ON ERROR POINTER TO 1$
        MOV      #60000,@#60000
        MOV      #60002,@#60002
        MOV      #60004,@#60004
        MOV      #60006,@#60006
        INC      MMRO           :TURN ON MEMORY MANAGEMENT
1$:     TST      (R0)           :DSTM=1 SOP NON-MOD
        TST      (R0)+         :DSTM=2 SOP NON-MOD
        TST      @(R0)+        :DSTM=3 SOP NON-MOD
        TST      @-(R0)        :DSTM=5 SOP NON-MOD
        TST      @0(R0)        :DSTM=7 SOP NON-MOD
        CLR      MMRO           :TURN OFF MEMORY MANAGEMENT
*
*      TEST SOP MOD; DSTM=1,2,3,5,7
*
2$:     MOV      #2$, $LPERR    :SET LOOP ON ERROR POINTER TO 2$
        INC      MMRO           :TURN ON MEMORY MANAGEMENT
        CLR      (R0)           :DSTM=1 SOP MOD
        CLR      (R0)+         :DSTM=2 SOP MOD
        CLR      @(R0)+        :DSTM=3 SOP MOD
        CLR      @-(R0)        :DSTM=5 SOP MOD
        CLR      @0(R0)        :DSTM=7 SOP MOD
        CLR      MMRO           :TURN OFF MEMORY MANAGEMENT
*
*      TEST SOP DEST NON-MOD WITH SRCM=1,2,3,5,7 AND DSTM=1,2,3,5,7
*      ALL SOURCE MODES TO BE TESTED ARE TESTED HERE
*
3$:     MOV      #3$, $LPERR    :SET LOOP ON ERROR POINTER TO 3$
        MOV      #32,R2         :SET UP ADDRESSES 60000-60064 FOR TEST
        MOV      #60000,R0
        MOV      #60000,R1
21$:    MOV      R0,(R1)+
        ADD      #2,R0
```

```

3053 025464 077204 SOB R2,21$
3054 025466 012700 060000 MOV #60000,R0
3055 025472 005237 177572 INC MMR0 ;TURN ON MEMORY MANAGEMENT
3056 025476 021010 3$: CMP (R0),(R0) ;SRCM=1 DSTM=1 DOP DEST NON-MOD
3057 025500 021020 CMP (R0),(R0)+ ;SRCM=1 DSTM=2 DOP DEST NON-MOD
3058 025502 021030 CMP (R0),a(R0)+ ;SRCM=1 DSTM=3 DOP DEST NON-MOD
3059 025504 021050 CMP (R0),a-(R0) ;SRCM=1 DSTM=5 DOP DEST NON-MOD
3060 025506 021070 000000 CMP (R0),a0(R0) ;SRCM=1 DSTM=7 DOP DEST NON-MOD
3061 025512 022010 CMP (R0)+,(R0) ;SRCM=2 DSTM=1 DOP DEST NON-MOD
3062 025514 022020 CMP (R0)+,(R0)+ ;SRCM=2 DSTM=2 DOP DEST NON-MOD
3063 025516 022030 CMP (R0)+,a(R0)+ ;SRCM=2 DSTM=3 DOP DEST NON-MOD
3064 025520 022050 CMP (R0)+,a-(R0) ;SRCM=2 DSTM=5 DOP DEST NON-MOD
3065 025522 022070 000000 CMP (R0)+,a0(R0) ;SRCM=2 DSTM=7 DOP DEST NON-MOD
3066 025526 023010 CMP a(R0)+,(R0) ;SRCM=3 DSTM=1 DOP DEST NON-MOD
3067 025530 023020 CMP a(R0)+,(R0)+ ;SRCM=3 DSTM=2 DOP DEST NON-MOD
3068 025532 023030 CMP a(R0)+,a(R0)+ ;SRCM=3 DSTM=3 DOP DEST NON-MOD
3069 025534 023050 CMP a(R0)+,a-(R0) ;SRCM=3 DSTM=5 DOP DEST NON-MOD
3070 025536 023070 000000 CMP a(R0)+,a0(R0) ;SRCM=3 DSTM=7 DOP DEST NON-MOD
3071 025542 025010 CMP a-(R0),(R0) ;SRCM=5 DSTM=1 DOP DEST NON-MOD
3072 025544 025020 CMP a-(R0),(R0)+ ;SRCM=5 DSTM=2 DOP DEST NON-MOD
3073 025546 025030 CMP a-(R0),a(R0)+ ;SRCM=5 DSTM=3 DOP DEST NON-MOD
3074 025550 025050 CMP a-(R0),a-(R0) ;SRCM=5 DSTM=5 DOP DEST NON-MOD
3075 025552 025070 000000 CMP a-(R0),a0(R0) ;SRCM=5 DSTM=7 DOP DEST NON-MOD
3076 025556 027010 000000 CMP a0(R0),(R0) ;SRCM=7 DSTM=1 DOP DEST NON-MOD
3077 025562 027020 000000 CMP a0(R0),(R0)+ ;SRCM=7 DSTM=2 DOP DEST NON-MOD
3078 025566 027030 000000 CMP a0(R0),a(R0)+ ;SRCM=7 DSTM=3 DOP DEST NON-MOD
3079 025572 027050 000000 CMP a0(R0),a-(R0) ;SRCM=7 DSTM=5 DOP DEST NON-MOD
3080 025576 027070 000000 000000 CMP a0(R0),a0(R0) ;SRCM=7 DSTM=7 DOP DEST NON-MOD
3081 025604 005037 177572 CLR MMR0 ;TURN OFF MEMORY MANAGEMENT
3082 ;* TEST DOP DEST MOD AND NOT SUB; DSTM=1,2,3,5,7
3083 ;*
3084 025610 005000 CLR R0 ;SET UP CONSTANTS FOR TEST
3085 025612 012701 060000 MOV #60000,R1
3086 025616 012737 025630 001110 MOV #4$,SLPERR ;SET LOOP ON ERROR POINTER TO 4$
3087 025624 005237 177572 INC MMR0 ;TURN ON MEMORY MANAGEMENT
3088 025630 050011 4$: BIS R0,(R1) ;DSTM=1 DOP DEST MOD
3089 025632 050021 BIS R0,(R1)+ ;DSTM=2 DOP DEST MOD
3090 025634 050031 BIS R0,a(R1)+ ;DSTM=3 DOP DEST MOD
3091 025636 050051 BIS R0,a-(R1) ;DSTM=5 DOP DEST MOD
3092 025640 050071 000000 BIS R0,a0(R1) ;DSTM=7 DOP DEST MOD
3093 025644 005037 177572 CLR MMR0 ;TURN OFF MEMORY MANAGEMENT
3094 ;* TEST MOV DEST AND NOT(SM0 AND DM0); DSTM=3,5,7
3095 ;*
3096 025650 012701 060000 MOV #60000,R1 ;SET UP CONSTANTS FOR TEST
3097 025654 012737 060002 060000 MOV #60002,a#60000
3098 025662 012737 025674 001110 MOV #5$,SLPERR ;SET LOOP ON ERROR POINTER TO 5$
3099 025670 005237 177572 INC MMR0 ;TURN ON MEMORY MANAGEMENT
3100 025674 010031 5$: MOV R0,a(R1)+ ;DSTM=3 MOV DEST
3101 025676 010051 MOV R0,a-(R1) ;DSTM=5 MOV DEST
3102 025700 010071 000000 MOV R0,a0(R1) ;DSTM=7 MOV DEST
3103 025704 005037 177572 CLR MMR0 ;TURN OFF MEMORY MANAGEMENT
3104 ;* TEST SWAB; DSTM=1,2,3,5,7
3105 ;*
3106 025710 012701 060000 MOV #60000,R1 ;SET UP CONSTANTS FOR TEST
3107 025714 012737 025726 001110 MOV #6$,SLPERR ;SET LOOP ON ERROR POINTER TO 6$
3108 025722 005237 177572 INC MMR0 ;TURN ON MEMORY MANAGEMENT
3109 025726 000311 6$: SWAB (R1) ;DSTM=1 SWAB
    
```

```
3110 025730 000321 SWAB (R1)+ ;DSTM=2 SWAB
3111 025732 000331 SWAB @ (R1)+ ;DSTM=3 SWAB
3112 025734 000351 SWAB @-(R1) ;DSTM=5 SWAB
3113 025736 000371 000000 SWAB @0(R1) ;DSTM=7 SWAB
3114 025742 005037 177572 CLR MMR0 ;TURN OFF MEMORY MANAGEMENT
3115 ;* TEST ROT/SHFT; DSTM=1,2,3,5,7
3116 ;*
3117 025746 012701 060000 MOV #60000,R1 ;SET UP CONSTANTS FOR TEST
3118 025752 012702 060006 MOV #60006,R2
3119 025756 010203 MOV R2,R3
3120 025760 012737 060000 060000 MOV #60000,@#60000
3121 025766 012737 060002 060002 MOV #60002,@#60002
3122 025774 012737 060004 060004 MOV #60004,@#60004
3123 026002 012737 060006 060006 MOV #60006,@#60006
3124 026010 012737 026022 001110 MOV #7$,SLPERR ;SET LOOP ON ERROR POINTER TO 7$
3125 026016 005237 177572 INC MMR0 ;TURN ON MEMORY MANAGEMENT
3126 026022 006111 7$: ROL (R1) ;DSTM=1 ROT/SHFT
3127 026024 006121 ROL (R1)+ ;DSTM=2 ROT/SHFT
3128 026026 006131 ROL @ (R1)+ ;DSTM=3 ROT/SHFT
3129 026030 006152 ROL @-(R2) ;DSTM=5 ROT/SHFT
3130 026032 006173 000000 ROL @0(R3) ;DSTM=7 ROT/SHFT
3131 026036 005037 177572 CLR MMR0 ;TURN OFF MEMORY MANAGEMENT
3132 ;* TEST MUL/DIV; DSTM=1,2,3,5,7
3133 ;*
3134 026042 012737 026056 001110 MOV #8$,SLPERR ;SET LOOP ON ERROR POINTER TO 8$
3135 026050 005003 CLR R3 ;SET UP CONSTANT FOR TEST
3136 026052 005237 177572 INC MMR0 ;TURN ON MEMORY MANAGEMENT
3137 026056 070310 8$: MUL (R0),R3 ;DSTM=1 MUL/DIV
3138 026060 070320 MUL (R0)+,R3 ;DSTM=2 MUL/DIV
3139 026062 070330 MUL @ (R0)+,R3 ;DSTM=3 MUL/DIV
3140 026064 070350 MUL @-(R0),R3 ;DSTM=5 MUL/DIV
3141 026066 070370 000000 MUL @0(R0),R3 ;DSTM=7 MUL/DIV
3142 026072 005037 177572 CLR MMR0 ;TURN OFF MEMORY MANAGEMENT
3143 ;* TEST ASH/ASHC; DSTM=1,2,3,5,7
3144 ;*
3145 026076 012737 000001 060000 MOV #1,@#60000 ;SET UP CONSTANTS FOR THE TEST
3146 026104 012737 060000 060002 MOV #60000,@#60002
3147 026112 012700 060000 MOV #60000,R0
3148 026116 012737 026130 001110 MOV #9$,SLPERR ;SET LOOP ON ERROR POINTER TO 9$
3149 026124 005237 177572 INC MMR0 ;TURN ON MEMORY MANAGEMENT
3150 026130 072310 9$: ASH (R0),R3 ;DSTM=1 ASH/ASHC
3151 026132 072320 ASH (R0)+,R3 ;DSTM=2 ASH/ASHC
3152 026134 072330 ASH @ (R0)+,R3 ;DSTM=3 ASH/ASHC
3153 026136 072350 ASH @-(R0),R3 ;DSTM=5 ASH/ASHC
3154 026140 072370 000000 ASH @0(R0),R3 ;DSTM=7 ASH/ASHC
3155 026144 005037 177572 CLR MMR0 ;TURN OFF MEMORY MANAGEMENT
3156 ;* TEST JMP; DSTM=3,7
3157 ;*
3158 026150 012737 026202 001110 MOV #10$,SLPERR ;SET LOOP ON ERROR POINTER TO 10$
3159 026156 012737 026204 060000 MOV #11$,@#60000 ;SET UP CONSTANTS FOR THE TEST
3160 026164 012737 026210 060002 MOV #12$,@#60002
3161 026172 012701 060000 MOV #60000,R1
3162 026176 005237 177572 INC MMR0 ;TURN ON MEMORY MANAGEMENT
3163 026202 000131 10$: JMP @ (R1)+ ;DSTM=3 JMP
3164 026204 000171 000000 11$: JMP @0(R1) ;DSTM=7 JMP
3165 026210 005037 177572 12$: CLR MMR0 ;TURN OFF MEMORY MANAGEMENT
3166 ;* TEST JSR; DSTM=3,7
```

```
3167
3168 026214 012737 026246 001110      :*      MOV      #13$, $LPERR      ;SET LOOP ON ERROR POINTER TO 13$
3169 026222 012737 026250 060000      MOV      #14$, @#60000    ;SET UP CONSTANTS FOR THE TEST
3170 026230 012737 026254 060002      MOV      #15$, @#60002
3171 026236 012701 060000      MOV      #60000, R1
3172 026242 005237 177572      INC      MMRO              ;TURN ON MEMCRY MANAGEMENT
3173 026246 004731              13$:   JSR      PC, @(R1)+     ;DSTM=3 JSR
3174 026250 004771 000000      14$:   JSR      PC, @0(R1)  ;DSTM=7 JSR
3175 026254 005037 177572      15$:   CLR      MMRO              ;TURN OFF MEMORY MANAGEMENT
3176 026260 112737 000006 172306  MOVB    #6, KIPDR3        ;MAKE KIPDR3 RESIDENT
3177 026266 012706 0011C0      MOV     #KERSTK, KSP     ;RESET STACK POINTER
```


3186

```
.SBTTL TEST # 16 - PROPER ENABLING OF SUPER. D-SPACE
*****
*TEST 16      PROPER ENABLING OF SUPER. D-SPACE
*
*      THIS TEST CHECKS FOR PROPER ENABLING OF THE SUPERVISOR D-SPACE.
*
*      ANY ERRORS ENCOUNTERED WILL BE REPORTED THROUGH 'MMVEC' TO
*      SUBROUTINE 'NODSPAC'.
*****
```

```
TST16: SCOPE
20$: CLR  SDPDR1      ;MAKE SDPDR1 NON-RESIDENT
      MOV  #1$, $LPERR ;SET LOOP ON ERROR POINTER TO 1$
      MOV  #22, MMR3   ;ENABLE 22-BIT SUPERVISOR D-SPACE
      BIS  #40000, PSW ;ENABLE SUPERVISOR MODE
      INC  MMR0        ;TURN ON MEMORY MANAGEMENT
      ;*      THE NEXT INSTRUCTIONS SHOULD NEVER INVOKE D-SPACE
      ;*
1$: BR   2$
2$: TST  R0
      INC R0
      CLR MMR0        ;TURN OFF MEMORY MANAGEMENT
      MOVB #6, SDPDR1 ;MAKE SDPDR1 RESIDENT
      CLRB SIPDR3    ;MAKE SIPDR3 NON-RESIDENT
      ;*      TEST SOP INSTRUCTIONS
      ;*
3$: MOV  #3$, $LPERR ;SET LOOP ON ERROR POINTER TO 3$
      INC  MMR0        ;TURN ON MEMORY MANAGEMENT
      TST  @#60000    ;DSTM=3 DSTF=7 SOP NON-MOD
      CLR  @#60000    ;DSTM=3 DSTF=7 SOP MOD
      CLR  MMR0        ;TURN OFF MEMORY MANAGEMENT
      ;*      TEST DOP INSTRUCTIONS
      ;*
4$: MOV  #4$, $LPERR ;SET LOOP ON ERROR POINTER TO 4$
      MOV  #60000, R0 ;SET UP CONSTANT FOR TEST
      INC  MMR0        ;TURN ON MEMORY MANAGEMENT
      CMP  @#60000, (R0) ;SRCM=3 DSTM=1 DOP DEST NON-MOD
      BIS  #0, @ (R0)+ ;SRCM=2 DSTM=3 DOP DEST MOD
      MOV  @#60002, @#60002 ;SRCM=3 DSTM=3 MOV DEST
      CLR  MMR0        ;TURN OFF MEMORY MANAGEMENT
      ;*      TEST ROT/SHFT AND ASH/ASHC INSTRUCTIONS
      ;*
5$: MOV  #5$, $LPERR ;SET LOOP ON ERROR POINTER TO 5$
      MOV  #1, @#60000 ;SET CONSTANT FOR TEST
      MOV  #1, R0     ;SET UP CONSTANT FOR TEST
      INC  MMR0        ;TURN ON MEMORY MANAGEMENT
      ROL  @#60000    ;DSTM=3 ROT/SHFT
      ASH  @#60000, R3 ;DSTM=3 ASH/ASHC
      CLR  MMR0        ;TURN OFF MEMORY MANAGEMENT
      ;*      TEST MUL/DIV AND SWAB INSTRUCTIONS
      ;*
6$: MOV  #6$, $LPERR ;SET LOOP ON ERROR POINTER TO 6$
      INC  MMR0        ;TURN ON MEMORY MANAGEMENT
      MUL  @#60000, R0 ;DSTM=3 MUL/DIV
      SWAB @#60004    ;DSTM=3 SWAB
      CLR  MMR0        ;TURN OFF MEMORY MANAGEMENT
      BIC  #2, MMR3   ;DISABLE SUPERVISOR D-SPACE
```

```
026272 000004
3187 026274 105037 172222
3188 026300 012737 026326 001110
3189 026306 012737 000022 172516
3190 026314 052737 040000 177776
3191 026322 005237 177572
3192
3193
3194 026326 000400
3195 026330 005700
3196 026332 005200
3197 026334 005037 177572
3198 026340 112737 000006 172222
3199 026346 105037 172206
3200
3201
3202 026352 012737 026364 001110
3203 026360 005237 177572
3204 026364 005737 060000
3205 026370 005037 060000
3206 026374 005037 177572
3207
3208
3209 026400 012737 026416 001110
3210 026406 012700 060000
3211 026412 005237 177572
3212 026416 023710 060000
3213 026422 052730 000000
3214 026426 013737 060002 060002
3215 026434 005037 177572
3216
3217
3218 026440 012737 026464 001110
3219 026446 012737 000001 060000
3220 026454 012700 000001
3221 026460 005237 177572
3222 026464 006137 060000
3223 026470 072337 060000
3224 026474 005037 177572
3225
3226
3227 026500 012737 026512 001110
3228 026506 005237 177572
3229 026512 070037 060000
3230 026516 000337 060004
3231 026522 005037 177572
3232 026526 042737 000002 172516
```

3233 026534 112737 000006 172206

MOVB #6,SIPDR3

;MAKE SIPDR3 RESIDENT

3242

```

.SBTTL TEST # 17 - PROPER ENABLING OF USER D-SPACE
*****
*TEST 17      PROPER ENABLING OF USER D-SPACE
*
*      THIS TEST CHECKS FOR PROPER ENABLING OF THE USER D-SPACE.
*
*      ANY ERRORS ENCOUNTERED WILL BE REPORTED THROUGH 'MMVEC' TO
*      SUBROUTINE 'NODSPAC'.
*****
    
```

```

3243 026542 000004
3243 026544 105037 177622
3244 026550 012737 026576 001110
3245 026556 012737 000021 172516
3246 026564 052737 140000 177776
3247 026572 005237 177572
3248
3249
3250 026576 000400
3251 026600 005700
3252 026602 005200
3253 026604 005037 177572
3254 026610 112737 000006 177622
3255 026616 105037 177606
3256
3257
3258 026622 012737 026634 001110
3259 026630 005237 177572
3260 026634 005737 060000
3261 026640 005037 060000
3262 026644 005037 177572
3263
3264
3265 026650 012737 026666 001110
3266 026656 012700 060000
3267 026662 005237 177572
3268 026666 023710 060000
3269 026672 052730 000000
3270 026676 013737 060002 060002
3271 026704 005037 177572
3272
3273
3274 026710 012737 026730 001110
3275 026716 012737 000001 060000
3276 026724 005237 177572
3277 026730 006137 060000
3278 026734 072337 060000
3279 026740 005037 177572
3280
3281
3282 026744 012737 026762 001110
3283 026752 012700 000001
3284 026756 005237 177572
3285 026762 070037 060000
3286 026766 000337 060004
3287 026772 005037 177572
3288 026776 042737 000001 172516
    
```

```

TST17: SCOPE
20$: CLR      UDPDR1      ;MAKE UDPDR1 NON-RESIDENT
      MOV      #1$, $LPERR ;SET LOOP ON ERROR POINTER TO 1$
      MOV      #21, MMR3   ;ENABLE 22-BIT USER D-SPACE
      BIS      #140000, PSW ;ENABLE USER MODE
      INC      MMR0        ;TURN ON MEMORY MANAGEMENT
      ;*      THE NEXT INSTRUCTIONS SHOULD NEVER INVOKE D-SPACE
      ;*
1$: BR      2$
2$: TST     RO
      INC     RO
      CLR     MMR0        ;TURN OFF MEMORY MANAGEMENT
      MOV     #6, UDPDR1  ;MAKE UDPDR1 RESIDENT
      CLR     UIPDR3     ;MAKE UIPDR3 NON-RESIDENT
      ;*      TEST SOP INSTRUCTIONS
      ;*
3$: MOV     #3$, $LPERR   ;SET LOOP ON ERROR POINTER TO 3$
      INC     MMR0        ;TURN ON MEMORY MANAGEMENT
      TST     @#60000     ;DSTM=3 DSTF=7 SOP NON-MOD
      CLR     @#60000     ;DSTM=3 DSTF=7 SOP MOD
      CLR     MMR0        ;TURN OFF MEMORY MANAGEMENT
      ;*      TEST DOP INSTRUCTIONS
      ;*
4$: MOV     #4$, $LPERR   ;SET LOOP ON ERROR POINTER TO 4$
      MOV     #60000, RO   ;SET UP CONSTANT FOR TEST
      INC     MMR0        ;TURN ON MEMORY MANAGEMENT
      CMP     @#60000, (RO) ;SRCM=3 DSTM=1 DOP DEST NON-MOD
      BIS     #0, @ (RO)+ ;SRCM=2 DSTM=3 DOP DEST MOD
      MOV     @#60002, @#60002 ;SRCM=3 DSTM=3 MOV DEST
      CLR     MMR0        ;TURN OFF MEMORY MANAGEMENT
      ;*      TEST ROT/SHFT AND ASH/ASHC INSTRUCTIONS
      ;*
5$: MOV     #5$, $LPERR   ;SET LOOP ON ERROR POINTER TO 5$
      MOV     #1, @#60000 ;SET CONSTANT FOR TEST
      INC     MMR0        ;TURN ON MEMORY MANAGEMENT
      ROL     @#60000     ;DSTM=3 ROT/SHFT
      ASH     @#60000, R3 ;DSTM=3 ASH/ASHC
      CLR     MMR0        ;TURN OFF MEMORY MANAGEMENT
      ;*      TEST MUL/DIV AND SWAB INSTRUCTIONS
      ;*
6$: MOV     #6$, $LPERR   ;SET LOOP ON ERROR POINTER TO 6$
      MOV     #1, RO      ;SET UP CONSTANT FOR TEST
      INC     MMR0        ;TURN ON MEMORY MANAGEMENT
      MUL     @#60000, RO  ;DSTM=3 MUL/DIV
      SWAB   @#60004     ;DSTM=3 SWAB
      CLR     MMR0        ;TURN OFF MEMORY MANAGEMENT
      BIC     #1, MMR3    ;DISABLE USER D-SPACE
    
```

3289 027004 112737 000006 177606
3290 027012 005037 177776

MOVB #6,UIPDR3
CLR PSW

:MAKE UIPDR3 RESIDENT
:RESET TO KERNAL SPACE

3299

```
.SSTTL TEST # 20 - TRAPPING IN D-SPACE KERNAL MODE
:*****
:*TEST 20 TRAPPING IN D-SPACE KERNAL MODE
:*
:* THIS TEST VERIFIES THAT THE ABORT VECTOR IS TAKEN FROM
:* D-SPACE AND NOT I-SPACE. THE I-SPACE VECTOR POINTS TO
:* 10$ AND THE D-SPACE VECTOR POINTS TO 15$. EACH PSW IN
:* VIRTUAL 252 IS DIFFERENT SO THE PROGRAM CAN TELL WHICH
:* AREA IT IS PICKED UP FROM.
:*****
```

```
TST20: SCOPE
3300 027016 000004 002356 JSR PC,TOFF ;TURN OF T-BIT FOR THIS TEST
3301 027020 004737 027060 001110 20$: MOV #1$,SLPERR ;SET LOOP ON ERROR POINTER TO 1$
3302 027032 012737 027126 000250 MOV #10$,@MMVEC ;SET M.M. VEC. TO HOLD BAD VECTOR
3303 027040 005037 000252 CLR @MMVEC+2 ;PSW IN 252 HAS PRIORITY OF ZERO
3304 027044 012737 027134 000350 MOV #15$,@#350 ;SET D-SPACE M.M VECTOR TO 350
3305 027052 012737 000340 000352 MOV #340,@#352 ;SET PSW PRIORITY TO 7
3306 027060 012706 001000 1$: MOV #1000,KSP ;SET UP KERNAL VECTOR
3307 027064 005237 177572 INC MMR0 ;TURN ON MEMORY MANAGEMENT
3308 ;NOW SET UP FOR AN ABORT IN KERNAL MODE WITH D-SPACE ENABLED
3309 ;
3310 027070 012737 077402 172330 MOV #77402,KDPDR4 ;KERNAL D-SPACE PAGE 4 IS READ ONLY
3311 027076 012737 000600 172370 MOV #600,KDPAR4 ;MAP D-SPACE PAGE 4 TO 12K
3312 027104 052737 000004 172516 BIS #BIT2,MMR3 ;ENABLE KERNAL D-SPACE MAPPING
3313 027112 012737 000001 172360 MOV #1,KDPAR0 ;MAP KERNAL D PAGE 0 TO 000100
3314 027120 012737 177777 100000 MOV #-1,@#100000 ;TRY TO WRITE TO PAGE 4
3315 027126 013700 177776 10$: MOV PSW,R0 ;SAVE PSW FOR COMPARE
3316 027132 000402 BR 16$ ;BRANCH TO D-SPACE READ CODE
3317 027134 013700 177776 15$: MOV PSW,R0 ;SAVE PSW FOR COMPARE
3318 027140 005037 172360 16$: CLR KDPAR0 ;REMAP KERNAL D PAGE 0 TO PHYSICAL 0
3319 027144 012706 001100 MOV #KERSTK,KSP ;RESET STACK POINTER AFTER D-SPACE ABORT
3320 027150 042737 000004 172516 BIC #BIT2,MMR3 ;TURN OFF KERNAL D-SPACE ENABLE
3321 027156 013701 177572 MOV MMR0,R1 ;SAVE MMR0 FOR COMPARE
3322 027162 013702 177574 MOV MMR1,R2 ;SAVE MMR1 FOR COMPARE
3323 027166 013703 177576 MOV MMR2,R3 ;SAVE MMR2 FOR COMPARE
3324 027172 122700 000340 CMPB #340,R0 ;DID YOU PICK CORRECT PSW
3325 027176 001401 BEQ 2$ ;BRANCH IF PSW IS 340
3326 027200 104033 ERROR +33 ;WRONG PSW PICKED IN ABORT SEQUENCE
3327 027202 022701 020031 2$: CMP #020031,R1 ;EXPECTING READ ONLY ABORT
3328 ;KERNAL MODE D-SPACE PAGE 4
3329 027206 001401 BEQ 3$ ;BRANCH IF CONDITION IS CORRECT
3330 027210 104027 ERROR +27 ;WRONG M.M. ABORT CONDITION
3331 027212 005037 177572 3$: CLR MMR0 ;CLEAR OFF MMR0 FOR EXIT OF TEST
3332 027216 012737 016142 000250 MOV #MGMERR,MMVEC ;RESTORE NORMAL M.M. TRAP VECTOR
3333 027224 012737 000340 000252 MOV #340,MMVEC+2 ;RESTORE TRAP PSW (PRIORITY=7)
3334
```


3359

```

:SBTTL TEST # 21 - MOVE FROM PREVIOUS (SUPERVISOR) I-SPACE
:*****
:*TEST 21 MOVE FROM PREVIOUS (SUPERVISOR) I-SPACE
:*
:* THIS TEST USES THE 'MFPI' INSTRUCTION TO ENSURE THAT THE PREVIOUS MODE
:* IS CLOKED CORRECTLY. THERE IS A DESCRIPTION BEFORE EACH DESTINATION
:* MODE TESTED. THE TEST ITSELF IS CARRIED OUT IN SUBROUTINE MFPITS,
:* WHICH USES THE MFPI INSTRUCTION CODE FOLLOWING THE JSR CALL TO EXECUTE
:* THE TEST. *IMPORTANT* - ALL 'NOP'S' FOLLOWING MFPI'S OF MODES 1,2,
:* 4 AND 5 ARE TO BE LEFT ALONE. THE SUBROUTINE LOADS THE TWO WORDS
:* AFTER THE JSR CALL, PREPARING FOR MODES 3, 6 AND 7.
:*
:* IF THE CORRECT MODE (SUPERVISOR) IS NOT ENABLED A NON-RESIDENT ABORT
:* WILL OCCUR AND TRAP TO MFPIV1, WHERE THE ERRORS ARE REPORTED.
:*
:*****
    
```

```

3360 027232 000004
3361 027234 004737 002060
3362 027240 012737 000001 177572
3363 027246 012737 000600 172350 1$.
3364 027254 012737 000600 172250
3365 027262 012700 036514
3366 027266 010037 100000
3367 027272 105037 172310
3368 027276 012737 027304 001110
3369 027304 012737 010340 177776 2$.
3370 027312 006506
3371 027314 022706 001100
3372 027320 001407
3373 027322 012600
3374 027324 012701 000700
3375 027330 020001
3376 027332 001403
3377 027334 104023
3378
3379 027336 000401
3380 027340 104025
3381
3382
3383
3384 027342 012737 002516 001110
3385 027350 012700 036514
3386 027354 012737 010340 002520
3387 027362 012702 100000
3388 027366 012737 027566 002622
3389 027374 004737 002464
3390 027400 006512
3391 027402 000240
3392 027404 104023
3393 027406 005726
3394
3395 027410 012702 100000
3396 027414 004737 002464
3397 027420 006522
3398 027422 000240
3399 027424 104023

TST21: SCOPE
JSR PC,APRINIT ;INIT ALL PAR/PDR'S
MOV #1,MMRO ;TURN ON MEMORY MANAGEMENT
MOV #600,KIPAR4 ;MAP KIPAR4 TO 12K
MOV #600,SIPAR4 ;MAP SIPAR4 TO 12K
MOV #36514,R0 ;LOAD DATA PATTERN INTO R0
MOV R0,#100000 ;LOAD DATA PATTERN INTO PHY 60000
CLRB KIPDR4 ;MAKE KERNEL I-SPACE PAGE 4 NON-RESIDENT
;THE FOLLOWING WILL TEST DSTM=0 MFPI
MOV #2$, $LPERR ;SET LOOP ON ERROR POINTER TO 2$
MOV #010340,PSW ;MAKE PREVIOUS MODE SUPERVISOR
MFPI SSP ;PUT SUPERVISOR STACK POINTER ON KERNEL STACK
CMP #KERSTK,KSP ;WAS SOMETHING PUSHED ON STACK AT 6$
BEQ 3$ ;BRANCH IF NOTHING WAS PUSHED
MOV (KSP)+,R0 ;POP KERNEL STACK INTO R0
MOV #SUPSTK,R1 ;EXPECTING TO GET 700 AS SSP
CMP R0,R1 ;DID YOU GET THE RIGHT POINTER?
BEQ 4$ ;BRANCH IF YOU DID
ERROR +23 ;WRONG THING WAS PUSHED ON STACK
;FOR TIGHTER SCOPE LOOP, REPLACE 'BEQ 4$' WITH 'BR 2$' = 000764
BR 4$ ;BRANCH TO NEXT TRY
3$: ERROR +25 ;NOTHING PUSHED ON STACK
;FOR TIGHTER SCOPE LOOP, REPLACE 'BEQ 3$' ABOVE WITH 'BR 2$' = 000771
;THE FOLLOWING WILL TEST DSTM=1 MFPI.
4$: MOV #MFPIILP,$LPERR ;SET LOOP ON ERROR POINTER TO MFPIILP IN SUBROUTINE
MOV #36514,R0 ;RELOAD DATA PATTERN IN R0
MOV #010340,MFPIPS ;MAKE PREVIOUS MODE SUPERVISOR IN SUBROUTINE
MOV #100000,R2 ;LOAD VIRTUAL ADDRESS INTO R2
MOV #MFPIV1,MFPIVC ;LOAD ADDRESS OF THIS TEST'S TRAP CATCHER TO MFPIVC
JSR PC,MFPITS ;GO DO TEST USING MFPI INSTRUCTION FOUND
MFPI (R2) ;<HERE - READ FROM PHYSICAL 60000
NOP ;MODE NOT 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
ERROR +23 ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
;THE FOLLOWING WILL TEST DSTM=2 MFPI.
MOV #100000,R2 ;LOAD VIRTUAL ADDRESS INTO R2
JSR PC,MFPITS ;GO DO TEST USING MFPI INSTRUCTION FOUND
MFPI (R2)+ ;<HERE - READ FROM PHYSICAL 60000
NOP ;MODE NOT 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
ERROR +23 ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
    
```

3400	027426	005726			TST (SP)+	;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3401					:THE FOLLOWING WILL TEST DSTM=3	MFPI.
3402	027430	004737	002464		JSR PC,MFPITS	;GO DO TEST USING MFPI INSTRUCTION FOUND
3403	027434	006537	100000		MFPI @#100000	;<HERE - READ FROM PHYSICAL 60000
3404	027440	104023			ERROR +23	;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3405	027442	005726			TST (SP)+	;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3406					:THE FOLLOWING WILL TEST DSTM=4	MFPI.
3407	027444	012702	100002		MOV #100002,R2	;LOAD VIRTUAL ADDRESS INTO R2
3408	027450	004737	002464		JSR PC,MFPITS	;GO DO TEST USING MFPI INSTRUCTION FOUND
3409	027454	006542			MFPI -(R2)	;<HERE - READ FROM PHYSICAL 60000
3410	027456	000240			NOP	;MODE NOT 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
3411	027460	104023			ERROR +23	;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3412	027462	005726			TST (SP)+	;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3413					:THE FOLLOWING WILL TEST DSTM=5	MFPI.
3414	027464	012737	100000	001202	MOV #100000,\$TMP2	;LOAD TEST LOC. VIRT. ADDR INTO LOC. \$TMP2
3415	027472	012702	001204		MOV #<\$TMP2+2>,R2	;LOAD ADDR. OF \$TMP2+2 INTO R2
3416	027476	004737	002464		JSR PC,MFPITS	;GO DO TEST USING MFPI INSTRUCTION FOUND
3417	027502	006552			MFPI @-(R2)	;<HERE - READ FROM PHYSICAL 60000
3418	027504	000240			NOP	;MODE NOT 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
3419	027506	104023			ERROR +23	;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3420	027510	005726			TST (SP)+	;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3421					:THE FOLLOWING WILL TEST DSTM=6	MFPI.
3422	027512	005002			CLR R2	;MAKE REGISTER 2 A ZERO
3423	027514	004737	002464		JSR PC,MFPITS	;GO DO TEST USING MFPI INSTRUCTION FOUND
3424	027520	006562	100000		MFPI 100000(R2)	;<HERE - READ FROM PHYSICAL 60000
3425	027524	104023			ERROR +23	;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3426	027526	005726			TST (SP)+	;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3427					:THE FOLLOWING WILL TEST DSTM=7	MFPI.
3428	027530	012737	100000	001202	MOV #100000,\$TMP2	;LOAD TEST LOC. V.A. INTO \$TMP2
3429	027536	012702	001202		MOV #\$TMP2,R2	;LOAD ADDRESS OF \$TMP2 INTO R2
3430	027542	004737	002464		JSR PC,MFPITS	;GO DO TEST USING MFPI INSTRUCTION FOUND
3431	027546	006572	000000		MFPI @0(R2)	;USE \$TMP2 TO FETCH VIRTUAL ADDRESS OF 60000
3432	027552	104023			ERROR +23	;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3433	027554	005726			TST (SP)+	;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3434	027556	112737	000006	172310	MOVB #6,KIPDR4	;MAKE KIPDR4 RESIDENT
3435	027564	000423			BR TST2	;:BRANCH TO NEXT TEST


```

3437
3438 027566 012637 001260
3439 027572 012637 001262
3440 027576 013737 177572 001264
3441 027604 013737 177576 001270
3442 027612 042737 160000 177572
3443 027620 104026
3444
3445 027622 013746 001262
3446 027626 013746 001260
3447 027632 000002

      .SBTTL MM TRAP CATCHER FOR ABOVE TEST
MFP1V1: MOV      (KSP)+,TRAPPC ;SAVE PC & PS OF TRAP
        MOV      (KSP)+,TRAPPS
        MOV      SRO,WASSRO   ;SAVE SRO FOR ERROR TYPEOUT
        MOV      SR2,WASSR2   ;SAVE SR2 FOR ERROR TYPEOUT
        BIC      #160000,SRO  ;CLEAR ERROR BITS IN SRO AND LEAVE
        ERROR    +26          ;TRIED TO READ NON-RESIDENT PAGE
;FOR TIGHTER SCOPE LOOP, REPLACE 1ST MOV INSTRUCTION WITH AN 'RTI' = 000002
        MOV      TRAPPS,-(KSP) ;PUT PC & PS OF TRAP ON STACK
        MOV      TRAPPC,-(KSP)
        RTI

```

3462

```
.SBTTL TEST # 22 - MOVE FROM PREVIOUS (USER) I-SPACE
:*****
:*TEST 22      MO' FROM PREVIOUS (USER) I-SPACE
:*
:*          THIS TEST USES THE 'MFPI' INSTRUCTION TO ENSURE THAT THE PREVIOUS MODE
:*          IS CLOCKED CORRECTLY. THERE IS A DESCRIPTION BEFORE EACH DESTINATION
:*          MODE TESTED. THE TEST ITSELF IS CARRIED OUT IN SUBROUTINE MFPIITS,
:*          WHICH USES THE MFPI INSTRUCTION CODE FOLLOWING THE JSR CALL TO EXECUTE
:*          THE TEST. *IMPORTANT* - ALL 'NOP'S' FOLLOWING MFPI'S OF MODES 1,2,
:*          4 AND 5 ARE TO BE LEFT ALONE. THE SUBROUTINE LOADS THE TWO WORDS
:*          AFTER THE JSR CALL, PREPARING FOR MODES 3, 6 AND 7.
:*
:*          IF THE CORRECT MODE (USER) IS NOT ENABLED A NON-RESIDENT ABORT WILL
:*          OCCUR AND TRAP TO MFPIV2, WHERE THE ERRORS ARE REPORTED.
:*
:*****
```

```
027634 000004
3463 027636 012700 036514
3464 027642 012737 000600 177650
3465 027650 010037 100000
3466 027654 105037 172310
3467
3468 027660 012737 027666 001110
3469 027666 012737 030340 177776
3470 027674 012737 030164 000250
3471 027702 006506
3472 027704 012737 016142 000250
3473 027712 022706 001076
3474 027716 001007
3475 027720 012600
3476 027722 012701 000600
3477 027726 020001
3478 027730 001403
3479 027732 104023
3480
3481 027734 000401
3482 027736 104025
3483
3484
3485 027740 012737 002516 001110
3486 027746 012737 030340 002520
3487 027754 012700 036514
3488 027760 012737 030164 002622
3489 027766 012702 100000
3490 027772 004737 002464
3491 027776 006512
3492 030000 000240
3493 030002 104023
3494 030004 005726
3495
3496 030006 012702 100000
3497 030012 004737 002464
3498 030016 006522
3499 030020 000240
3500 030022 104023
3501 030024 005726
3502
```

```
TST22: SCOPE
1$:  MOV      #36514,R0      ;LOAD DATA PATTERN INTO R0
     MOV      #600,UIPAR4   ;MAP UIPAR4 TO 12K
     MOV      R0,#100000    ;LOAD DATA PATTERN INTO PHY 60000
     CLRB     KIPDR4       ;MAKE KERNEL I-SPACE PAGE 4 NON-RESIDENT
;THE FOLLOWING WILL TEST DSTM=0 MFPI
     MOV      #2$, $LPERR   ;SET LOOP ON ERROR POINTER TO 2$
2$:  MOV      #030340,PSW   ;MAKE PREVIOUS MODE USER
     MOV      #MFPIV2,MMVEC ;LOAD ADDRESS OF THIS TEST'S TRAP CATCHER TO MMVEC
     MFPI     USP          ;PUT USER STACK POINTER ON KERNEL STACK
     MOV      #MGMERR,MMVEC ;SET M.M. VECTOR TO NORMAL ROUTINE
     CMP      #KERSTK-2,KSP ;WAS SOMETHING PUSHED ON STACK BY THE MFPI?
     BNE     3$           ;BRANCH TO ERROR IF POINTER IS WRONG
     MOV      (KSP)+,R0     ;POP KERNEL STACK INTO R0
     MOV      #USESTK,R1   ;EXPECTING TO GET 600 AS UC0
     CMP      R0,R1        ;DID YOU GET THE RIGHT POINTER?
     BEQ     4$           ;BRANCH IF YOU DID
     ERROR   +23          ;WRONG THING WAS PUSHED ON STACK
;FOR TIGHTER SCOPE LOOP, REPLACE 'BEQ 4$' WITH 'BR 2$' = 000764
     BR      4$           ;BRANCH TO NEXT TRY
3$:  ERROR   +25          ;NOTHING PUSHED ON STACK
;FOR TIGHTER SCOPE LOOP, REPLACE 'BNE 3$' ABOVE WITH 'BR 2$' = 000771
;THE FOLLOWING WILL TEST DSTM=1 MFPI.
4$:  MOV      #MFPIILP,$LPERR ;SET LOOP ON ERROR POINTER TO MFPIILP IN SUBROUTINE
     MOV      #030340,MFPIPS ;MAKE PREVIOUS MODE USER IN SUBROUTINE LOCATION
     MOV      #36514,R0     ;RELOAD DATA PATTERN IN R0
     MOV      #MFPIV2,MFPIVC ;LOAD ADDRESS OF THIS TEST'S TRAP CATCHER TO MFPIVC
     MOV      #100000,R2    ;LOAD VIRTUAL ADDRESS INTO R2
     JSR     PC,MFPIITS    ;GO DO TEST USING MFPI INSTRUCTION FOUND
     MFPI     (R2)         ;<HERE - READ FROM PHYSICAL 60000
     NOP     ;MODE NOT 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
     ERROR   +23          ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
     TST     (SP)+        ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
;THE FOLLOWING WILL TEST DSTM=2 MFPI.
     MOV      #100000,R2   ;LOAD VIRTUAL ADDRESS INTO R2
     JSR     PC,MFPIITS    ;GO DO TEST USING MFPI INSTRUCTION FOUND
     MFPI     (R2)+        ;<HERE - READ FROM PHYSICAL 60000
     NOP     ;MODE NOT 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
     ERROR   +23          ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
     TST     (SP)+        ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
;THE FOLLOWING WILL TEST DSTM=3 MFPI.
```

```

3503 030026 004737 002464      JSR    PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION FOUND
3504 030032 006537 100000      MFPI   @#100000      ;<HERE - READ FROM PHYSICAL 60000
3505 030036 104023              ERROR  +23           ;RETURN IS EHRE FOR ERROR - WRONG DATA WAS FETCHED
3506 030040 005726              TST    (SP)+         ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3507                                ;THE FOLLOWING WILL TEST DSTM=4 MFPI.
3508 030042 012702 100002      MOV    #100002,R2    ;LOAD VIRTUAL ADDRESS INTO R2
3509 030046 004737 002464      JSR    PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION FOUND
3510 030052 006542              MFPI   -(R2)         ;<HERE - READ FROM PHYSICAL 60000
3511 030054 000240              NOP                    ;MODE NOT 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
3512 030056 104023              ERROR  +23           ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3513 030060 005726              TST    (SP)+         ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3514                                ;THE FOLLOWING WILL TEST DSTM=5 MFPI.
3515 030062 012737 100000 001202  MOV    #100000,$TMP2 ;LOAD TEST LOC. VIRT. ADDR INTO LOC. $TMP2
3516 030070 012702 001204      MOV    #<$TMP2+2>,R2 ;LOAD ADDR. OF $TMP2+2 INTO R2
3517 030074 004737 002464      JSR    PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION FOUND
3518 030100 006552              MFPI   @-(R2)        ;<HERE - READ FROM PHYSICAL 60000
3519 030102 000240              NOP                    ;MODE NOT 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
3520 030104 104023              ERROR  +23           ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3521 030106 005726              TST    (SP)+         ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3522                                ;THE FOLLOWING WILL TEST DSTM=6 MFPI.
3523 030110 005002              CLR    R2             ;MAKE REGISTER 2 A ZERO
3524 030112 004737 002464      JSR    PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION FOUND
3525 030116 006562 100000      MFPI   100000(R2)    ;<HERE - READ FROM PHYSICAL 60000
3526 030122 104023              ERROR  +23           ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3527 030124 005726              TST    (SP)+         ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3528                                ;THE FOLLOWING WILL TEST DSTM=7 MFPI.
3529 030126 012737 100000 001202  MOV    #100000,$TMP2 ;LOAD TEST LOC. V.A. INTO $TMP2
3530 030134 012702 001202      MOV    #$TMP2,R2     ;LOAD ADDRESS OF $TMP2 INTO R2
3531 030140 004737 002464      JSR    PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION FOUND
3532 030144 006572 0000' )      MFPI   @0(R2)        ;USE $TMP2 TO FETCH VIRTUAL ADDRESS OF 60000
3533 030150 104023              ERROR  +23           ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3534 030152 005726              TST    (SP)+         ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3535 030154 112737 000006 172310  MOVB   #6,KIPDR4     ;MAKE KIPDR4 RESIDENT
3536 030162 000423              BR     TST23         ;:BRANCH TO NEXT TEST

```

```
3538 .SBTTL MM TRAP CATCHER FOR PREVIOUS TEST
3539 030164 012637 001260 MFPIV2: MOV (KSP)+,TRAPPC ;SAVE PC & PS OF TRAP
3540 030170 012637 001262 MOV (KSP)+,TRAPPS
3541 030174 013737 177572 001264 MOV SRO,WASSRO ;SAVE SRO FOR ERROR TYPEOUT
3542 030202 013737 177576 001270 MOV SR2,WASSR2 ;SAVE SR2 FOR ERROR TYPEOUT
3543 030210 042737 160000 177572 BIC #160000,SRO ;CLEAR ERROR BITS IN SRO AND LEAVE
3544 030216 104026 ERROR +26 ;TRIED TO READ NON-RESIDENT PAGE
3545 ;FOR TIGHTER SCOPE LOOP, REPLACE 1ST MOV INSTRUCTION WITH AN 'RTI' = 000002
3546 030220 013746 001262 MOV TRAPPS,-(KSP) ;PUT PC & PS OF TRAP ON STACK
3547 030224 013746 001260 MOV TRAPPC,-(KSP)
3548 030230 000002 RTI
```

3563

.SBTTL TEST # 23 - MOVE TO PREVIOUS (SUPERVISOR) I-SPACE

 *TEST 23 MOVE TO PREVIOUS (SUPERVISOR) I-SPACE

THIS TEST USES THE 'MTPI' INSTRUCTION TO ENSURE THAT THE PREVIOUS MODE IS CLOKED CORRECTLY. THERE IS A DESCRIPTION BEFORE EACH DESTINATION MODE TESTED. THE TEST ITSELF IS CARRIED OUT IN SUBROUTINE MFPITS, WHICH USES THE MTPI INSTRUCTION CODE FOLLOWING THE JSR CALL TO EXECUTE THE TEST. *IMPORTANT* - ALL 'NOP'S' FOLLOWING MTPI'S OF MODES 1,2, 4 AND 5 ARE TO BE LEFT ALONE. THE SUBROUTINE LOADS THE TWO WORDS AFTER THE JSR CALL, PREPARING FOR MODES 3, 6 AND 7.

IF THE CORRECT MODE IS NOT ENABLED A NON-RESIDENT ABORT WILL OCCUR AND TRAP TO MTPIV1, WHERE THE ERRORS ARE REPORTED.

```

3564 030232 000004
3565 030234 012737 077406 172210
3566 030242 012737 010340 177776
3567 030250 012746 007777
3568 030254 012737 030614 000250
3569 030262 006606
3570 030264 006506
3571 030266 012737 016142 000250
3572 030274 012601
3573 030276 022701 007777
3574 030302 001401
3575 030304 104025
3576
3577 030306 012737 010340 177776
3578 030314 012746 000700
3579 030320 012737 030614 000250
3580 030326 006606
3581 030330 012737 016142 000250
3582 030336
3583 030336 012737 002654 001110
3584 030344 012737 010340 002656
3585 030352 012702 100000
3586 030356 012700 125252
3587 030362 004737 002626
3588 030366 006612
3589 030370 000240
3590 030372 000000
3591 030374 104024
3592 030376 005726
3593
3594 030400 012700 125252
3595 030404 012702 100000
3596 030410 004737 002626
3597 030414 006622
3598 030416 000240
3599 030420 177776
3600 030422 104024
3601 030424 005726
3602
3603 030426 012700 052525
    
```

```

TST23: SCOPE
1$: MOV #77406,SIPDR4 ;SUPERVISOR I-SPACE PAGE 4 READ/WRITE
;THE FOLLOWING WILL TEST DSTM=0 MTPI
2$: MOV #010340,PSW ;MAKE PREVIOUS MODE SUPERVISOR
MOV #7777,-(KSP) ;PUSH DATA ON KERNEL STACK
MOV #MTPIV1,MMVEC ;LOAD ADDRESS OF THIS TEST'S TRAP CATCHER TO MMVEC
MTPI SSP ;LOAD SUPERVISOR STACK POINTER
MFPI SSP ;READ SUPERVISOR STACK POINTER
MOV #MGERR,MMVEC ;SET M.M. VECTOR TO NORMAL ROUTINE
MOV (KSP)+,R1 ;POP KERNEL STACK INTO R1
CMP #7777,R1 ;WAS SUPERVISOR STACK POINTER CHANGED
BEQ 3$ ;BRANCH IF IT WAS
ERROR +25 ;SUPERVISOR STACK POINTER NOT CHANGED
;FOR TIGHTER SCOPE LOOP, REPLACE 'BEQ 3$' WITH 'BR 2$' = 000765
3$: MOV #010340,PSW ;MAKE PREVIOUS MODE SUPERVISOR
MOV #SUPSTK,-(KSP) ;GET READY TO RESTORE SUPERVISOR S. POINT
MOV #MTPIV1,MMVEC ;LOAD ADDRESS OF THIS TEST'S TRAP CATCHER TO MMVEC
MTPI SSP ;RESTORE SUPERVISOR STACK POINTER
MOV #MGERR,MMVEC ;SET M.M. VECTOR TO NORMAL ROUTINE
4$: ;THIS WILL TEST DSTM = 1 MTPI.
MOV #MTPILP,$LPERR ;SET LOOP ON ERROR POINTER TO MTPILP IN SUBROUTINE
MOV #010340,MTPIPM ;MAKE PREVIOUS MODE SUPER IN LOCATION IN SUBROUTINE
MOV #100000,R2 ;LOAD VIRTUAL ADDRESS INTO R2
MOV #125252,R0 ;LOAD TEST DATA INTO R0
JSR PC,MTPITS ;GO DO THE TEST USING THE MTPI INSTRUCTION FOUND
MTPI (R2) ;<HERE - LOAD TEST DATA INTO PHYSICAL 60000
NOP ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
.WORD 0 ;ADD 0 TO R2 AFTER MTPI INSTRUCTION EXECUTE
ERROR +24 ;RETURN IS HERE FOR ERROR - INCORRECT STORE
TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
;THE FOLLOWING WILL TEST DSTM=2 MTPI.
MOV #125252,R0 ;LOAD TEST DATA INTO R0
MOV #100000,R2 ;LOAD VIRTUAL ADDRESS INTO R2
JSR PC,MTPITS ;GO DO THE TEST USING THE MTPI INSTRUCTION FOUND
MTPI (R2)+ ;<HERE - LOAD TEST DATA INTO PHYSICAL 60000
NOP ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
.WORD -2 ;ADD -2 TO R2 AFTER MTPI INSTRUCTION EXECUTE
ERROR +24 ;RETURN IS HERE FOR ERROR - INCORRECT STORE
TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
;THIS WILL TEST DSTM = 3 MTPI.
MOV #52525,R0 ;LOAD TEST DATA INTO R0
    
```

```

3604 030432 004737 002626 JSR PC,MTPITS ;GO DO THE TEST USING THE MTP1 INSTRUCTION FOUND
3605 030436 006637 100000 MTP1 @#100000 ;<HERE - LOAD TEST DATA INTO PHYSICAL 60000
3606 030442 000000 .WORD 0 ;ADD 0 TO R2 AFTER MTP1 INSTRUCTION EXECUTE
3607 030444 104024 ERROR +24 ;RETURN IS HERE FOR ERROR - INCORRECT STORE
3608 030446 005726 TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3609 ;THIS WILL TEST DSTM = 4 MTP1.
3610 030450 012700 125252 MOV #125252,R0 ;LOAD TEST DATA INTO R0
3611 030454 012702 100002 MOV #100002,R2 ;LOAD VIRTUAL ADDRESS INTO R2
3612 030460 004737 002626 JSR PC,MTPITS ;GO DO THE TEST USING THE MTP1 INSTRUCTION FOUND
3613 030464 005642 MTP1 -(R2) ;<HERE - LOAD TEST DATA INTO PHYSICAL 60000
3614 030466 000240 NOP ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
3615 030470 000000 .WORD 0 ;ADD 0 TO R2 AFTER MTP1 INSTRUCTION EXECUTE
3616 030472 104024 ERROR +24 ;RETURN IS HERE FOR ERROR - INCORRECT STORE
3617 030474 005726 TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3618 ;THE FOLLOWING WILL TEST DSTM=5 MTP1.
3619 030476 012700 052525 MOV #52525,R0 ;LOAD TEST DATA INTO R0
3620 030502 012702 001204 MOV #<$TMP2+2>,R2 ;LOAD ADDR. OF LOC. $TMP2+2 INTO R2
3621 030506 012737 100000 001202 MOV #100000,$TMP2 ;LOAD VIRT. ADDR. OF TEST LOC. INTO $TMP2
3622 030514 004737 002626 JSR PC,MTPITS ;GO DO THE TEST USING THE MTP1 INSTRUCTION FOUND
3623 030520 006652 MTP1 @-(R2) ;<HERE - LOAD TEST DATA INTO PHYSICAL 60000
3624 030522 000240 NOP ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
3625 030524 076576 .WORD 100000-$TMP2 ;ADD 100000-$TMP2 TO R2 AFTER MTP1 INSTRUCTION EXECUTE
3626 030526 104024 ERROR +24 ;RETURN IS HERE FOR ERROR - INCORRECT STORE
3627 030530 005726 TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3628 ;THIS WILL TEST DSTM = 6 MTP1.
3629 030532 012700 052525 MOV #52525,R0 ;LOAD TEST DATA INTO R0
3630 030536 005002 CLR R2 ;MAKE REGISTER 2 ZERO
3631 030540 004737 002626 JSR PC,MTPITS ;GO DO THE TEST USING THE MTP1 INSTRUCTION FOUND
3632 030544 006662 MTP1 100000(R2) ;<HERE - LOAD TEST DATA INTO PHYSICAL 60000
3633 030550 100000 .WORD 100000 ;ADD 100000 TO R2 AFTER MTP1 INSTRUCTION EXECUTE
3634 030552 104024 ERROR +24 ;RETURN IS HERE FOR ERROR - INCORRECT STORE
3635 030554 005726 TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3636 ;THE FOLLOWING WILL TEST DSTM=7 MTP1.
3637 030556 012700 125252 MOV #125252,R0 ;LOAD TEST DATA INTO R0
3638 030562 012737 100000 001202 MOV #100000,$TMP2 ;LOAD VIRT. ADDR. OF TEST LOCATION INTO LOCATION $TMP2
3639 030570 012702 001202 MOV #$TMP2,R2 ;LOAD ADDRESS OF $TMP2 INTO R2
3640 030574 004737 002626 JSR PC,MTPITS ;GO DO THE TEST USING THE MTP1 INSTRUCTION FOUND
3641 030600 006672 000000 MTP1 @0(R2) ;<HERE - LOAD TEST DATA INTO PHYSICAL 60000
3642 030604 076576 .WORD 100000-$TMP2 ;ADD 100000-$TMP2 TO R2 AFTER MTP1 INSTRUCTION EXECUTE
3643 030606 104024 ERROR +24 ;RETURN IS HERE FOR ERROR - INCORRECT STORE
3644 030610 005726 TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3645 030612 000423 BR TST24 ;;BRANCH TO NEXT TEST
3646
3647 030614 012637 001260 MTP1V1: MOV (KSP)+,TRAPPC ;SAVE PC & PS OF TRAP
3648 030620 012637 001262 MOV (KSP)+,TRAPPS
3649 030624 013737 177572 001264 MOV SRO,WASSRO ;SAVE SRO FOR ERROR TYPEOUT
3650 030632 013737 177576 001270 MOV SR2,WASSR2 ;SAVE SR2 FOR ERROR TYPEOUT
3651 030640 042737 160000 177572 BIC #160000,SRO ;CLEAR ERROR BITS IN SRO
3652 030646 104024 ERROR +24 ;TRIED TO LOAD A N.R. PAGE 4
3653 ;FOR TIGHTER SCOPE LOOP, REPLACE 1ST MOV INSTRUCTION WITH AN 'RTI' = 000002
3654 030650 013746 001262 MOV TRAPPS,-(KSP) ;PUT PC & PS OF TRAP ON STACK
3655 030654 013746 001260 MOV TRAPPC,-(KSP)
3656 030660 000002 RTI ;RETURN TO TEST

```

3657

.SBTTL TEST # 24 - MOVE TO PREVIOUS (USER) I-SPACE

*TEST 24 MOVE TO PREVIOUS (USER) I-SPACE

THIS TEST USES THE 'MTPI' INSTRUCTION TO ENSURE THAT THE PREVIOUS MODE IS CLOKED CORRECTLY. THERE IS A DESCRIPTION BEFORE EACH DESTINATION MODE TESTED. THE TEST ITSELF IS CARRIED OUT IN SUBROUTINE MFPITS, WHICH USES THE MTPI INSTRUCTION CODE FOLLOWING THE JSR CALL TO EXECUTE THE TEST. *IMPORTANT* - ALL 'NOP'S' FOLLOWING MTPI'S OF MODES 1,2, 4 AND 5 ARE TO BE LEFT ALONE. THE SUBROUTINE LOADS THE TWO WORDS AFTER THE JSR CALL, PREPARING FOR MODES 3, 6 AND 7.

IF THE CORRECT MODE IS NOT ENABLED A NON-RESIDENT ABORT WILL OCCUR AND TRAP TO MTPIV1, WHERE THE ERRORS ARE REPORTED.

3658	030662	000004		
3659	030664	012737	077406	177610
3660	030672	012737	000600	177650
3661	030700	012737	030340	177776
3662	030706	012746	007777	
3663	030712	012737	031260	000250
3664	030720	006606		
3665	030722	006506		
3666	030724	012737	016142	000250
3667	030732	012601		
3668	030734	022701	007777	
3669	030740	001401		
3670	030742	104025		
3671				
3672	030744	012737	030340	177776
3673	030752	012746	000600	
3674	030756	012737	031260	000250
3675	030764	006606		
3676	030766	012737	016142	000250
3677				
3678	030774	012737	002654	001110
3679	031002	012737	030340	002656
3680	031010	012737	031260	002744
3681	031016	012702	100000	
3682	031022	012700	125252	
3683	031026	004737	002626	
3684	031032	006612		
3685	031034	000240		
3686	031036	000000		
3687	031040	104024		
3688	031042	005726		
3689				
3690	031044	012700	125252	
3691	031050	012702	100000	
3692	031054	004737	002626	
3693	031060	006622		
3694	031062	000240		
3695	031064	177776		
3696	031066	104024		
3697	031070	005726		

TST24: SCOPE

1\$: MOV #77406,UIPDR4 :USER I-SPACE PAGE 4 READ/WRITE
 MOV #600,UIPAR4 :MAP USER I PAGE 4 TO 12K

:THE FOLLOWING WILL TEST DSTM=0 MTPI

2\$: MOV #030340,PSW :MAKE PREVIOUS MODE USER
 MOV #7777,-(KSP) :PUSH DATA ON KERNEL STACK
 MOV #MTPIV2,MMVEC :SET M.M. VECTOR TO 20\$
 MTPI USP :LOAD USER STACK POINTER
 MFPI USP :READ USER STACK POINTER
 MOV #MGMERR,MMVEC :RESTORE MM VECTOR TO NORMAL ROUTINE
 MOV (KSP)+,R1 :POP KERNEL STACK INTO R1
 CMP #7777,R1 :WAS USER STACK POINTER CHANGED
 BEQ 3\$:BRANCH IF IT WAS
 ERROR +25 :USER STACK POINTER NOT CHANGED

:FOR TIGHTER SCOPE LOOP, REPLACE 'BEQ 3\$' WITH 'BR 2\$' = 000765

3\$: MOV #030340,PSW :MAKE PREVIOUS MODE USER
 MOV #USESTK,-(KSP) :GET READY TO RESTORE USER S. POINT
 MOV #MTPIV2,MMVEC :SET M.M. VECTOR TO 20\$
 MTPI USP :RESTORE USER STACK POINTER
 MOV #MGMERR,MMVEC :RESTORE MM VECTOR TO NORMAL ROUTINE

:THIS WILL TEST DSTM = 1 MTPI.

MOV #MTPILP,\$LPERR :SET LOOP ON ERROR POINTER TO MTPILP IN SUBROUTINE
 MOV #030340,MTPIPM :SET PREVIOUS MODE = USER IN SUBROUTINE LOCATION
 MOV #MTPIV2,MTPIVC :SET THIS TEST'S MM TRAP HANDLER IN MTPIVC
 MOV #100000,R2 :LOAD VIRTUAL ADDRESS INTO R2
 MOV #125252,R0 :LOAD TEST DATA INTO R0
 JSR PC,MTPITS :GO DO TEST USING MTPI INSTRUCTION LOCATED
 MTPI (R2) :<HERE - LOAD TEST DATA INTO PHYSICAL 60000
 NOP :NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
 .WORD 0 :ADD 0 TO R2 AFTER MTPI INSTRUCTION EXECUTE
 ERROR +24 :RETURN IS HERE FOR ERROR - INCORRECT STORE
 TST (SP)+ :POP EXCESS RETURN OFF STACK - LOOPING NOT DONE

:THE FOLLOWING WILL TEST DSTM=2 MTPI.

MOV #125252,R0 :LOAD TEST DATA INTO R0
 MOV #100000,R2 :LOAD VIRTUAL ADDRESS INTO R2
 JSR PC,MTPITS :GO DO TEST USING MTPI INSTRUCTION LOCATED
 MTPI (R2)+ :<HERE - LOAD TEST DATA INTO PHYSICAL 60000
 NOP :NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
 .WORD -2 :ADD -2 TO R2 AFTER MTPI INSTRUCTION EXECUTE
 ERROR +24 :RETURN IS HERE FOR ERROR - INCORRECT STORE
 TST (SP)+ :POP EXCESS RETURN OFF STACK - LOOPING NOT DONE

```

3698 ;THIS WILL TEST DSTM = 3 MTPI.
3699 031072 012700 052525 MOV #52525,R0 ;LOAD TEST DATA INTO R0
3700 031076 004737 002626 JSR PC,MTPITS ;GO DO TEST USING MTPI INSTRUCTION LOCATED
3701 031102 006637 100000 MTPI @#100000 ;<HERE - LOAD TEST DATA INTO PHYSICAL 60000
3702 031106 000000 .WORD 0 ;ADD 0 TO R2 AFTER MTPI INSTRUCTION EXECUTE
3703 031110 104024 ERROR +24 ;RETURN IS HERE FOR ERROR - INCORRECT STORE
3704 03 12 005726 TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3705 ;THIS WILL TEST DSTM = 4 MTPI.
3706 031114 012700 125252 MOV #125252,R0 ;LOAD TEST DATA INTO R0
3707 031120 012702 100002 MOV #100002,R2 ;LOAD VIRTUAL ADDRESS INTO R2
3708 031124 004737 002626 JSR PC,MTPITS ;GO DO TEST USING MTPI INSTRUCTION LOCATED
3709 031130 006642 MTPI -(R2) ;<HERE - LOAD TEST DATA INTO PHYSICAL 60000
3710 031132 000240 NOP ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
3711 031134 000000 .WORD 0 ;ADD 0 TO R2 AFTER MTPI INSTRUCTION EXECUTE
3712 031136 104024 ERROR +24 ;RETURN IS HERE FOR ERROR - INCORRECT STORE
3713 031140 005726 TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3714 ;THE FOLLOWING WILL TEST DSTM=5 MTPI.
3715 031142 012700 052525 MOV #52525,R0 ;LOAD TEST DATA INTO R0
3716 031146 012702 001204 MOV #<$TMP2+2>,R2 ;LOAD ADDR. OF LOC. $TMP2+2 INTO R2
3717 031152 012737 100000 001202 MOV #100000,$TMP2 ;LOAD VIRT. ADDR. OF TEST LOC. INTO $TMP2
3718 031160 004737 002626 JSR PC,MTPITS ;GO DO TEST USING MTPI INSTRUCTION LOCATED
3719 031164 006652 MTPI @-(R2) ;<HERE - LOAD TEST DATA INTO PHYSICAL 60000
3720 031166 000240 NOP ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
3721 031170 076576 .WORD 100000-$TMP2 ;ADD 100000-$TMP2 TO R2 AFTER MTPI INSTRUCTION EXECUTE
3722 031172 104024 ERROR +24 ;RETURN IS HERE FOR ERROR - INCORRECT STORE
3723 031174 005726 TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3724 ;THIS WILL TEST DSTM = 6 MTPI.
3725 031176 012700 052525 MOV #52525,R0 ;LOAD TEST DATA INTO R0
3726 031202 005002 CLR R2 ;MAKE REGISTER 2 ZERO
3727 031204 004737 002626 JSR PC,MTPITS ;GO DO TEST USING MTPI INSTRUCTION LOCATED
3728 031210 006662 100000 MTPI 100000(R2) ;<HERE - LOAD TEST DATA INTO PHYSICAL 60000
3729 031214 100000 .WORD 100000 ;ADD 100000 TO R2 AFTER MTPI INSTRUCTION EXECUTE
3730 031216 104024 ERROR +24 ;RETURN IS HERE FOR ERROR - INCORRECT STORE
3731 031220 005726 TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3732 ;THE FOLLOWING WILL TEST DSTM=7 MTPI.
3733 031222 012700 125252 MOV #125252,R0 ;LOAD TEST DATA INTO R0
3734 031226 012737 100000 001202 MOV #100000,$TMP2 ;LOAD VIRT. ADDR. OF TEST LOCATION
3735 ;INTO LOCATION $TMP2
3736 031234 012702 001202 MOV # $TMP2,R2 ;LOAD ADDRESS OF $TMP2 INTO R2
3737 031240 004737 002626 JSR PC,MTPITS ;GO DO TEST USING MTPI INSTRUCTION LOCATED
3738 031244 006672 000000 MTPI @0(R2) ;<HERE LOAD TEST DATA INTO PHYSICAL 60000
3739 031250 076576 .WORD 100000-$TMP2 ;ADD 100000-$TMP2 TO R2 AFTER MTPI INSTRUCTION EXECUTE
3740 031252 104024 ERROR +24 ;RETURN IS HERE FOR ERROR - INCORRECT STORE
3741 031254 005726 TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3742 031256 000423 BR TST25 ;BRANCH TO NEXT TEST
3743
3744 031260 012637 001260 MTPIV2: MOV (KSP)+,TRAPPC ;SAVE PC & PS OF TRAP
3745 031264 012637 001262 MOV (KSP)+,TRAPPS
3746 031270 013737 177572 001264 MOV SRO,WASSRO ;SAVE SRO FOR ERROR TYPEOUT
3747 031276 013737 177576 001270 MOV SR2,WASSR2 ;SAVE SR2 FOR ERROR TYPEOUT
3748 031304 042737 160000 177572 BIC #160000,SRO ;CLEAR ERROR BITS IN SRO
3749 031312 104024 ERROR +24 ;TRIED TO LOAD A N.R. PAGE 4
3750 ;FOR TIGHTER SCOPE LOOP, REPLACE 1ST MOV INSTRUCTION WITH AN 'RTI' = 000002
3751 031314 013746 001262 MOV TRAPPS,-(KSP) ;PUT PC & PS OF TRAP ON STACK
3752 031320 013746 001260 MOV TRAPPC,-(KSP)
3753 031324 000002 RTI ;RETURN TO TEST
    
```


3768

.SBTTL TEST # 25 - MFPI (KERNEL) TO SUPERVISOR MODE

 *TEST 25 MFPI (KERNEL) TO SUPERVISOR MODE

* THIS TEST CHECKS THAT IF THE PREVIOUS MODE IS KERNEL THE FETCH IS FROM
 * KERNEL SPACE. THERE IS A DESCRIPTION BEFORE EACH DESTINATION MODE
 * TESTED. THE TEST ITSELF IS CARRIED OUT IN SUBROUTINE MFPIITS,
 * WHICH USES THE MFPI INSTRUCTION CODE FOLLOWING THE JSR CALL TO EXECUTE
 * THE TEST. *IMPORTANT* - ALL 'NOP'S' FOLLOWING MFPI'S OF MODES 1,2,
 * 4 AND 5 ARE TO BE LEFT ALONE. THE SUBROUTINE LOADS THE TWO WORDS
 * AFTER THE JSR CALL, PREPARING FOR MODES 3, 6 AND 7.

* IF THE CORRECT MODE IS NOT ENABLED A NON-RESIDENT ABORT WILL OCCUR AND
 * TRAP TO MFPIV3, WHERE THE ERRORS ARE REPORTED.

3769 031326 000004
 3770 031330 012737 031364 001110
 3771 031336 012737 040340 177776
 3772 031344 012700 036514
 3773 031350 010037 100000
 3774 031354 012702 100000
 3775 031360 105037 172210
 3776 031364 012737 040340 177776
 3777 031372 012737 031674 000250
 3778 031400 006506
 3779 031402 012737 016142 000250
 3780 031410 022706 000700
 3781 031414 001407
 3782 031416 012600
 3783 031420 012701 001100
 3784 031424 020001
 3785 031426 001403
 3786 031430 104023
 3787
 3788 031432 000401
 3789 031434 104025
 3790
 3791
 3792 031436 012737 002516 001110
 3793 031444 012737 040340 002520
 3794 031452 012737 031674 002622
 3795 031460 012700 036514
 3796 031464 012702 100000
 3797 031470 004737 002464
 3798 031474 006512
 3799 031476 000240
 3800 031500 104023
 3801 031502 005726
 3802
 3803 031504 012702 100000
 3804 031510 004737 002464
 3805 031514 006522
 3806 031516 000240
 3807 031520 104023
 3808 031522 005726

TST25: SCOPE
 MOV #1\$, \$LPERR ;SET LOOP ON ERROR TO 1\$
 MOV #040340, PSW ;GO TO SUPERVISOR MODE FOR THIS TEST
 MOV #36514, R0 ;LOAD DATA PATTERN INTO R0
 MOV R0, #100000 ;LOAD DATA PATTERN INTO PHY 60000
 MOV #100000, R2 ;LOAD VIRTUAL ADDRESS INTO R2
 :THE FOLLOWING WILL TEST DSTM=0 MFPI
 CLRB SIPDR4 ;MAKE SUPERVISOR I-SPACE PAGE 4 NON-RESIDENT
 1\$: MOV #040340, PSW ;MAKE PREVIOUS MODE KERNEL PRESENT SUPERVISOR
 MOV #MFPIV3, MMVEC ;SET M.M. VECTOR TO MFPIV3
 MFPI KSP ;PUT KERNEL STACK POINTER ON SUPERVISOR STACK
 MOV #MMGMERR, MMVEC ;RESTORE MM VECTOR TO NORMAL ROUTINE
 CMP #SUPSTK, SSP ;WAS SOMETHING PUSHED ON STACK AT THE MFPI
 BEQ 2\$;BRANCH TO ERROR IF NOTHING WAS PUSHED
 MOV (SSP)+, R0 ;POP SUPERVISOR STACK INTO R0
 MOV #KERSTK, R1 ;EXPECTING 1100 AS KSP
 CMP R0, R1 ;DID YOU GET THE RIGHT POINTER?
 BEQ 3\$;BRANCH IF YOU DID
 ERROR +23 ;WRONG THING WAS PUSHED ON STACK
 :FOR TIGHTER SCOPE LOOP, REPLACE 'BEQ 3\$' WITH 'BR 1\$' = 000756
 BR 3\$;BRANCH TO NEXT TRY
 2\$: ERROR +25 ;NOTHING PUSHED ON STACK
 :FOR TIGHTER SCOPE LOOP, REPLACE 'BEQ 2\$' ABOVE WITH 'BR 1\$' = 000762
 :THE FOLLOWING WILL TEST DSTM=1 MFPI.
 3\$: MOV #MFPIILP, \$LPERR ;SET LOOP ON ERROR POINTER TO MFPIILP IN SUBROUTINE
 MOV #040340, MFPIPS ;MAKE PREVIOUS MODE KERNEL PRESENT SUPERVISOR
 MOV #MFPIV3, MFPIVC ;MOVE THIS TEST'S MM TRAP VECTOR TO MFPIVC
 MOV #36514, R0 ;LOAD DATA EXPECTED INTO R0
 MOV #100000, R2 ;LOAD VIRTUAL ADDRESS INTO R2
 JSR PC, MFPIITS ;GO DO TEST USING MFPI INSTRUCTION LOCATED
 MFPI (R2) ;<HERE - READ FROM PHYSICAL 60000
 NOP ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
 ERROR +23 ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
 TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
 :THE FOLLOWING WILL TEST DSM=2 MFPI.
 MOV #100000, R2 ;LOAD VIRTUAL ADDRESS INTO R2
 JSR PC, MFPIITS ;GO DO TEST USING MFPI INSTRUCTION LOCATED
 MFPI (R2)+ ;<HERE - READ FROM PHYSICAL 60000
 NOP ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
 ERROR +23 ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
 TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE

```

3809          :THE FOLLOWING WILL TEST DSTM=3 MFPI.
3810 031524 004737 002464      JSR      PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION LOCATED
3811 031530 006537 100000      MFPI     @#100000      ;<HERE - READ FROM PHYSICAL 60000
3812 031534 104023              ERROR    +23           ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3813 031536 005726              TST      (SP)+          ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3814          :THE FOLLOWING WILL TEST DSTM=4 MFPI.
3815 031540 012702 100002      MOV      #100002,R2     ;LOAD VIRTUAL ADDRESS INTO R2
3816 031544 004737 002464      JSR      PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION LOCATED
3817 031550 006542              MFPI     -(R2)          ;<HERE - READ FROM PHYSICAL 60000
3818 031552 000240              NOP                       ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
3819 031554 104023              ERROR    +23           ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3820 031556 005726              TST      (SP)+          ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3821          :THE FOLLOWING WILL TEST DSTM=5 MFPI.
3822 031560 012737 100000 001202 MOV      #100000,$TMP2  ;LOAD TEST LOC. VIRT. ADDR INTO LOC. $TMP2
3823 031566 012702 001204      MOV      #<$TMP2+2>,R2 ;LOAD ADDRESS OF $TMP2+2 INTO R2
3824 031572 004737 002464      JSR      PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION LOCATED
3825 031576 006552              MFPI     @-(R2)        ;<HERE - READ FROM PHYSICAL 60000
3826 031600 000240              NOP                       ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
3827 031602 104023              ERROR    +23           ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3828 031604 005726              TST      (SP)+          ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3829          :THE FOLLOWING WILL TEST DSTM=6 MFPI.
3830 031606 005002              CLR      R2            ;MAKE REGISTER 2 A ZERO
3831 031610 004737 002464      JSR      PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION LOCATED
3832 031614 006562 100000      MFPI     100000(R2)    ;<HERE - READ FROM PHYSICAL 60000
3833 031620 104023              ERROR    +23           ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3834 031622 005726              TST      (SP)+          ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3835          :THE FOLLOWING WILL TEST DSTM=7 MFPI.
3836 031624 012737 100000 001202 MOV      #100000,$TMP2  ;LOAD TEST LOC. VIRT. ADDR. INTO $TMP2
3837 031632 012702 001202      MOV      #$TMP2,R2     ;LOAD ADDRESS OF $TMP2 INTO R2
3838 031636 004737 002464      JSR      PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION LOCATED
3839 031642 006572 000000      MFPI     @0(R2)        ;<HERE - READ FROM PHYSICAL 60000
3840 031646 104023              ERROR    +23           ;WRONG DATA WAS FETCHED
3841 031650 005726              TST      (SP)+          ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3842 031652 012737 000340 177776 MOV      #00340,PSW     ;GO BACK TO KERNEL MODE, PREVIOUS KERNEL
3843 031660 112737 000006 172210 MOVB     #6,SIPDR4      ;MAKE SIPDR4 RESIDENT
3844 031666 012706 001100      MOV      #KERSTK,KSP   ;RESET KERNEL STACK POINTER
3845 031672 000423              BR       TS:26         ;;BRANCH TO NEXT TEXT
  
```

```
3847  
3848 031674 012637 001260  
3849 031700 012637 001262  
3850 031704 013737 177572 001264  
3851 031712 013737 177576 001270  
3852 031720 042737 160000 177572  
3853 031726 104026  
3854  
3855 031730 013746 001262  
3856 031734 013746 001260  
3857 031740 000002
```

```
.SBTTL MM TRAP ROUTINE FOR ABOVE TEST  
MFPIV3: MOV (KSP)+,TRAPPC ;SAVE PC & PS OF TRAP  
MOV (KSP)+,TRAPPS  
MOV SRO,WASSRO ;SAVE SRO FOR ERROR TYPEOUT  
MOV SR2,WASSR2 ;SAVE SR2 FOR ERROR TYPEOUT  
BIC #160000,SRO ;CLEAR ERROR BITS IN SRO  
ERROR +26 ;TRIED TO READ NON-RESIDENT PAGE  
;FOR TIGHTER SCOPE LOOP, REPLACE 1ST MOV INSTRUCTION WITH AN 'RTI' = 000002  
MOV TRAPPS,-(KSP) ;PUT PC & PS OF TRAP ON STACK  
MOV TRAPPC,-(KSP)  
RTI ;RETURN TO TEST
```

3858

```
.SBTTL TEST # 26 - MFPI (KERNEL) TO USER MODE
:*****
:*TEST 26 MFPI (KERNEL) TO USER MODE
:*
:* THIS TEST CHECKS THAT IF THE PREVIOUS MODE IS KERNEL THE FETCH IS FROM
:* KERNEL SPACE. THERE IS A DESCRIPTION BEFORE EACH DESTINATION MODE
:* TESTED. THE TEST ITSELF IS CARRIED OUT IN SUBROUTINE MFPIITS,
:* WHICH USES THE MFPI INSTRUCTION CODE FOLLOWING THE JSR CALL TO EXECUTE
:* THE TEST. *IMPORTANT* - ALL 'NOP'S' FOLLOWING MFPI'S OF MODES 1,2,
:* 4 AND 5 ARE TO BE LEFT ALONE. THE SUBROUTINE LOADS THE TWO WORDS
:* AFTER THE JSR CALL, PREPARING FOR MODES 3, 6 AND 7.
:*
:* IF THE CORRECT MODE IS NOT ENABLED A NON-RESIDENT ABORT WILL OCCUR AND
:* TRAP TO MFPIV4, WHERE THE ERRORS ARE REPORTED.
:*****
```

```
031742 000004
3859 031744 012737 031752 001110
3860 031752 012737 140340 177776
3861 031760 012700 036514
3862 031764 010037 100000
3863 031770 012702 100000
3864
3865 031774 012737 032304 000250
3866 032002 105037 177610
3867 032006 012737 140340 177776
3868 032014 006506
3869 032016 012737 016142 000250
3870 032024 022706 000600
3871 032030 001407
3872 032032 012600
3873 032034 012701 001100
3874 032040 020001
3875 032042 001403
3876 032044 104023
3877
3878 032046 000401
3879 032050 104025
3880
3881
3882
3883 032052 012737 002516 001110
3884 032060 012737 140340 002520
3885 032066 012737 032304 002622
3886 032074 012700 036514
3887 032100 012702 100000
3888 032104 004737 002464
3889 032110 006512
3890 032112 000240
3891 032114 104023
3892 032116 005726
3893
3894 032120 012702 100000
3895 032124 004737 002464
3896 032130 006522
3897 032132 000240
3898 032134 104023
```

```
TST26: SCOPE
MOV #1$, $LPERR ;SET LOOP ON ERROR TO 1$
MOV #140340, PSW ;GO TO USER MODE FOR THIS TEST
MOV #36514, R0 ;LOAD DATA PATTERN INTO R0
MOV R0, #100000 ;LOAD DATA PATTERN INTO PHY 60000
MOV #100000, R2 ;LOAD VIRTUAL ADDRESS INTO R2
;THE FOLLOWING WILL TEST DSTM=0 MFPI
MOV #MFPIV4, MMVEC ;SET M.M. VECTOR TO MFPIV4
CLRB UIPDR4 ;MAKE USER I-SPACE PAGE 4 NON-RESIDENT
MOV #140340, PSW ;MAKE PREVIOUS MODE KERNEL PRESENT USER
MFPI KSP ;PUT KERNEL STACK POINTER ON USER STACK
MOV #MGMERR, MMVEC ;RESTORE MM VECTOR TO NORMAL ROUTINE
CMP #USESTK, USP ;WAS SOMETHING PUSHED ON STACK AT THE MFPI
BEQ 2$ ;BRANCH IF NOTHING WAS PUSHED
MOV (USP)+, R0 ;POP USER STACK INTO R0
MOV #KERSTK, R1 ;EXPECTING 1100 AS KSP
CMP R0, R1 ;DID YOU GET THE RIGHT POINTER?
BEQ 3$ ;BRANCH IF YOU DID
ERROR +23 ;WRONG THING WAS PUSHED ON STACK
;FOR TIGHTER SCOPE LOOP, REPLACE 'BEQ 3$' WITH 'BR 1$' = 000763
BR 3$ ;BRANCH TO NEXT TRY
2$: ERROR +25 ;NOTHING PUSHED ON STACK
;FOR TIGHTER SCOPE LOOP, REPLACE 'BEQ 2$' WITH 'BR 1$' = 000763
;THE FOLLOWING WILL TEST DSTM=1 MFPI.
3$: MOV #MFPIILP, $LPERR ;SET LOOP ON ERROR POINTER TO MFPIILP IN SUBROUTINE
MOV #140340, MFPIPS ;MAKE PREVIOUS MODE KERNEL PRESENT USER
MOV #MFPIV4, MFPIVC ;MOVE THIS TEST'S MM TRAP HANDLER TO MFPIVC
MOV #36514, R0 ;LOAD DATA EXPECTED INTO R0
MOV #100000, R2 ;LOAD VIRTUAL ADDRESS INTO R2
JSR PC, MFPIITS ;GO DO TEST USING MFPI INSTRUCTION LOCATED
MFPI (R2) ;<HERE - READ FROM PHYSICAL 60000
NOP ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
ERROR +23 ;WRONG DATA WAS FETCHED
TST (SP)+ ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
;THE FOLLOWING WILL TEST DSM=2 MFPI.
MOV #100000, R2 ;LOAD VIRTUAL ADDRESS INTO R2
JSR PC, MFPIITS ;GO DO TEST USING MFPI INSTRUCTION LOCATED
MFPI (R2)+ ;<HERE - READ FROM PHYSICAL 60000
NOP ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
ERROR +23 ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
```

```

3899 032136 005726          TST      (SP)+          ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3900          ;THE FOLLOWING WILL TEST DSTM=3 MFPI.
3901 032140 004737 002464   JSR      PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION LOCATED
3902 032144 006537 100000   MFPI     @#100000       ;<HERE - READ FROM PHYSICAL 60000
3903 032150 104023          ERROR    +23           ;WRONG DATA WAS FETCHED
3904 032152 005726          TST      (SP)+          ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3905          ;THE FOLLOWING WILL TEST DSTM=4 MFPI.
3906 032154 012702 100002   MOV      #100002,R2     ;LOAD VIRTUAL ADDRESS INTO R2
3907 032160 004737 002464   JSR      PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION LOCATED
3908 032164 006542          MFPI     -(R2)          ;<HERE - READ FROM PHYSICAL 60000
3909 032166 000240          NOP                        ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
3910 032170 104023          ERROR    +23           ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3911 032172 005726          TST      (SP)+          ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3912          ;THE FOLLOWING WILL TEST DSTM=5 MFPI.
3913 032174 012737 100000 001202  MOV      #100000,$TMP2   ;LOAD TEST LOC. VIRT. ADDR INTO LOC. $TMP2
3914 032202 012702 001204          MOV      #<$TMP2+2>,R2  ;LOAD ADDRESS OF $TMP2+2 INTO R2
3915 032206 004737 002464   JSR      PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION LOCATED
3916 032212 006552          MFPI     @-(R2)         ;<HERE - READ FROM PHYSICAL 60000
3917 032214 000240          NOP                        ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
3918 032216 104023          ERROR    +23           ;RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED
3919 032220 005726          TST      (SP)+          ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3920          ;THE FOLLOWING WILL TEST DSTM=6 MFPI.
3921 032222 005002          CLR      R2             ;MAKE REGISTER 2 A ZERO
3922 032224 004737 002464   JSR      PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION LOCATED
3923 032230 006562 100000   MFPI     100000(R2)     ;<HERE - READ FROM PHYSICAL 60000
3924 032234 104023          ERROR    +23           ;WRONG DATA WAS FETCHED
3925 032236 005726          TST      (SP)+          ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3926          ;THE FOLLOWING WILL TEST DSTM=7 MFPI.
3927 032240 012737 100000 001202  MOV      #100000,$TMP2   ;LOAD TEST LOC. VIRT. ADDR. INTO $TMP2
3928 032246 012702 001202          MOV      #$TMP2,R2     ;LOAD ADDRESS OF $TMP2 INTO R2
3929 032252 004737 002464   JSR      PC,MFPITS      ;GO DO TEST USING MFPI INSTRUCTION LOCATED
3930 032256 006572 000000   MFPI     @0(R2)         ;<HERE - READ FROM PHYSICAL 60000
3931 032262 104023          ERROR    +23           ;WRONG DATA WAS FETCHED
3932 032264 005726          TST      (SP)+          ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
3933 032266 012737 000340 177776   MOV      #00340,PSW     ;GO BACK TO KERNEL MODE, PREVIOUS KERNEL
3934 032274 112737 000006 177610   MOV      #6,UIPDR4      ;MAKE UIPDR4 RESIDENT
3935 032302 000423          BR       TST27          ;:BRANCH TO NEXT TEXT
    
```

```
3937  
3938 032304 012637 001260  
3939 032310 012637 001262  
3940 032314 013737 177572 001264  
3941 032322 013737 177576 001270  
3942 032330 042737 160000 177572  
3943 032336 104026  
3944  
3945 032340 013746 001262  
3946 032344 013746 001260  
3947 032350 000002  
  
      .SBTTL MM TRAP HANDLER FOR ABOVE TEST  
MFP1V4: MOV      (KSP)+,TRAPPC ;SAVE PC & PS OF TRAP  
        MOV      (KSP)+,TRAPPS  
        MOV      SRO,WASSRO    ;SAVE SRO FOR ERROR TYPEOUT  
        MOV      SR2,WASSR2    ;SAVE SR2 FOR ERROR TYPEOUT  
        BIC      #160000,SRO   ;CLEAR ERROR BITS IN SRO  
        ERROR    +26          ;TRIED TO READ NON-RESIDENT PAGE  
;FOR TIGHTER SCOPE LOOP, REPLACE 1ST MOV INSTRUCTION WITH AN 'RTI' = 000002  
        MOV      TRAPPS,-(KSP) ;PUT PC & PS OF TRAP ON STACK  
        MOV      TRAPPC,-(KSP)  
        RTI  
;RETURN TO TEST
```

3962

SBTTL TEST # 27 - MFPI (SUPERVISOR) WITH SUPER D-SPACE ENABLED

 *TEST 27 MFPI (SUPERVISOR) WITH SUPER D-SPACE ENABLED
 *

THIS TEST USES THE 'MFPI' INSTRUCTION TO ENSURE THAT PREVIOUS MODE IS
 CLOCKED CORRECTLY, AND THAT D-SPACE IS NOT ENABLED. THE TEST ITSELF
 IS CARRIED OUT IN SUBROUTINE MFPIITS, WHICH USES THE MFPI INSTRUCTION
 CODE FOLLOWING THE JSR CALL TO EXECUTE THE TEST. *IMPORTANT* - ALL
 'NOP'S' FOLLOWING MFPI'S OF MODES 1,2, 4 AND 5 ARE TO BE LEFT ALONE.
 THE SUBROUTINE LOADS THE TWO WORDS AFTER THE JSR CALL, PREPARING FOR
 MODES 3, 6 AND 7.

IF THE CORRECT MODE IS NOT ENABLED, A NON-RESIDENT ABORT WILL OCCUR AND
 TRAP TO MFPIV5, WHERE THE ERRORS ARE REPORTED.

3963	032352	000004	
3964	032354	012700	077400
3965	032360	010037	172330
3966	032364	010037	172230
3967	032370	010037	177630
3968	032374	010037	177610
3969	032400	012700	036514
3970	032404	010037	060000
3971	032410	052737	000002
3972	032416	105037	172310
3973			
3974	032422	012737	002516
3975	032430	012737	010340
3976	032436	012737	032562
3977	032444	012702	100000
3978	032450	004737	002464
3979	032454	006512	
3980	032456	000240	
3981	032460	104037	
3982	032462	005726	
3983			
3984	032464	012702	100000
3985	032470	004737	002464
3986	032474	006522	
3987	032476	000240	
3988	032500	104037	
3989	032502	005726	
3990			
3991	032504	012702	100000
3992	032510	004737	002464
3993	032514	006537	100000
3994	032520	104037	
3995	032522	005726	
3996			
3997	032524	012702	100002
3998	032530	004737	002464
3999	032534	006542	
4000	032536	000240	
4001	032540	104037	
4002	032542	005726	

172516

```

TST27: SCOPE
        MOV      #77400,R0          ;MAKE PAGE 4 IN ALL BUT SUPERVISOR I
                                           ;AND KERNAL I NON-RESIDENT
        MOV      R0,KDPDR4        ;KERNAL D-SPACE PAGE 4
        MOV      R0,SDPDR4        ;SUPERVISOR D-SPACE PAGE 4
        MOV      R0,UDPDR4        ;USER D-SPACE PAGE 4
        MOV      R0,UIPDR4        ;USER I-SPACE PAGE 4
        MOV      #36514,R0        ;LOAD DATA PATTERN INTO R0
        MOV      R0,#60000        ;LOAD DATA PATTERN INTO PHYS. 60000
        BIS      #BIT1,MMR3       ;ENABLE SUPERVISOR D-SPACE
        CLRB     KIPDR4           ;MAKE KERNAL I-SPACE PAGE 4 NON-RESIDENT
;THE FOLLOWING WILL TEST DSTM=1 MFPI.
        MOV      #MFPIILP,$LPERR  ;SET LOOP ON ERROR POINTER TO MFPIILP IN SUBROUTINE
        MOV      #010340,MFPIPS   ;MAKE PREVIOUS MODE SUPERVISOR IN SUBRTN LOCATION
        MOV      #MFPIV5,MFPIVC   ;MOVE THIS TEST'S MM TRAP HANDLER TO MFPIVC
        MOV      #100000,R2       ;LOAD VIRTUAL ADDRESS INTO R2
        JSR      PC,MFPIITS       ;GO DO TEST USING THE MFPI INSTRUCTION FOUND
        MFPI     (R2)             ;<HERE - READ FROM PHYSICAL 60000
        NOP      +37              ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
        ERROR    +37              ;RETURN IS HERE FOR ERROR - WRONG DATA FETCHED
        TST      (SP)+            ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
;THE FOLLOWING WILL TEST DSTM=2 MFPI.
        MOV      #100000,R2       ;LOAD VIRTUAL ADDRESS INTO R2
        JSR      PC,MFPIITS       ;GO DO TEST USING THE MFPI INSTRUCTION FOUND
        MFPI     (R2)+            ;<HERE - READ FROM PHYSICAL 100000
        NOP      +37              ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
        ERROR    +37              ;RETURN IS HERE FOR ERROR - WRONG DATA FETCHED
        TST      (SP)+            ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
;THE FOLLOWING WILL TEST DSTM=3 MFPI.
        MOV      #100000,R2       ;LOAD VIRTUAL ADDRESS INTO R2
        JSR      PC,MFPIITS       ;GO DO TEST USING THE MFPI INSTRUCTION FOUND
        MFPI     @#100000         ;<HERE - READ FROM PHYSICAL 100000
        ERROR    +37              ;RETURN IS HERE FOR ERROR - WRONG DATA FETCHED
        TST      (SP)+            ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
;THE FOLLOWING WILL TEST DSTM=4 MFPI.
        MOV      #100002,R2       ;LOAD VIRTUAL ADDRESS INTO R2
        JSR      PC,MFPIITS       ;GO DO TEST USING THE MFPI INSTRUCTION FOUND
        MFPI     -(R2)            ;<HERE - READ FROM PHYSICAL 100000
        NOP      +37              ;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
        ERROR    +37              ;RETURN IS HERE FOR ERROR - WRONG DATA FETCHED
        TST      (SP)+            ;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
    
```

4003	032544	112737	000006	172310	MOVB	#6,KIPDR4	:MAKE KIPDR4 RESIDENT
4004	032552	042737	000002	172516	BIC	#BIT1,MMR3	:DISABLE SUPERVISOR D-SPACE
4005	032560	000426			BR	TST30	::BRANCH TO NEXT TEST


```
4007 .SBTTL MM TRAP HANDLER FOR ABOVE TEST
4008 032562 013737 177572 001264 MFPIV5: MOV MMR0,WASSR0 ;SAVE MMR0 FOR ERROR TYPEOUT
4009 032570 013737 177574 001266 MOV MMR1,WASSR1 ;SAVE MMR1 FOR ERROR TYPEOUT
4010 032576 013737 177576 001270 MOV MMR2,WASSR2 ;SAVE MMR2 FOR ERROR TYPEOUT
4011 032604 013737 172516 001272 MOV MMR3,WASSR3 ;SAVE MMR3 FOR ERROR TYPEOUT
4012 032612 012637 001260 MOV (KSP)+,TRAPPC ;SAVE PC & PS OF TRAP
4013 032616 012637 001262 MOV (KSP)+,TRAPPS
4014 032622 104040 ERROR +40 ;TRIED TO READ NON-RESIDENT PAGE
4015 :FOR TIGHTER SCOPE LOOP, REPLACE 1ST MOV INSTRUCTION WITH AN 'RTI' = 000002
4016 032624 013746 001262 MOV TRAPPS,-(KSP) ;PUT PC & PS OF TRAP ON STACK
4017 032630 013746 001260 MOV TRAPPC,-(KSP)
4018 032634 000002 RTI
```

4033

.SBTTL TEST # 30 - MTPI (SUPERVISOR) WITH SUPER. D-SPACE ENABLED

*TEST 30 MTPI (SUPERVISOR) WITH SUPER. D-SPACE ENABLED

* *

THIS TEST USES THE 'MTPI' INSTRUCTION TO ENSURE THAT THE PREVIOUS MODE IS CLOKED CORRECTLY, AND THAT D-SPACE IS NOT ENABLED. THE TEST ITSELF IS CARRIED OUT IN SUBROUTINE MTPITS, WHICH USES THE MTPI INSTRUCTION CODE FOLLOWING THE JSR CALL TO EXECUTE THE TEST. *IMPORTANT* - ALL 'NOP'S' FOLLOWING MTPI'S OF MODES 1,2, 4 AND 5 ARE TO BE LEFT ALONE. THE SUBROUTINE LOADS THE TWO WORDS AFTER THE JSR CALL, PREPARING FOR MODES 3, 6 AND 7.

IF THE CORRECT MODE IS NOT ENABLED, A NON-RESIDENT ABORT WILL OCCUR AND AND TRAP TO MTPIV3, WHERE THE ERRORS ARE REPORTED.

* *

4034	032636	000004			TST30: SCOPE		
4035	032640	052737	000002	172516	BIS	#BIT1,MMR3	;ENABLE SUPERVISOR D-SPACE
4036	032646	012737	002654	001110	:THIS WILL TEST	DSTM = 1 MTPI	
4037	032654	012737	010340	002656	MOV	#MTPILP,\$LPERR	;SET LOOP ON ERROR POINTER TO MTPILP IN SUBROUTINE
4038	032662	012737	033022	002744	MOV	#010340,MTPIPM	;MAKE PREVIOUS MODE SUPERVISOR IN LOCAT'ON IN SUBR'M
4039	032670	012702	100000		MOV	#MTPIV3,MTPIVC	;LOAD THIS TEST'S MM TRAP HANDLER TO MTPIVC
4040	032674	012700	125252		MOV	#100000,R2	;LOAD VIRTUAL ADDRESS INTO R2
4041	032700	004737	002626		MOV	#125252,R0	;LOAD TEST DATA INTO R0
4042	032704	006612			JSR	PC,MTPITS	;GO DO THE TEST USING MTPI INSTRUCTION FOUND
4043	032706	000240			MTP	(R2)	;LOAD TEST DATA INTO PHYSICAL 100000
4044	032710	000000			NOP		;<HERE - NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
4045	032712	104035			.WORD	0	;ADD 0 TO R2 AFTER MTPI INSTRUCTION EXECUTE
4046	032714	005726			ERROR	+35	;RETURN IS HERE FOR ERROR - INCORRECT STORE
4047					TST	(SP)+	;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
4048	032716	012700	052525		:THIS WILL TEST	DSTM = 3 MTPI	
4049	032722	004737	002626		MOV	#52525,R0	;LOAD TEST DATA INTO R0
4050	032726	006637	100000		JSR	PC,MTPITS	;GO DO THE TEST USING MTPI INSTRUCTION FOUND
4051	032732	000000			MTP	@#100000	;<HERE - LOAD TEST DATA INTO PHYSICAL 100000
4052	032734	104035			.WORD	0	;ADD 0 TO R2 AFTER MTPI INSTRUCTION EXECUTE
4053	032736	005726			ERROR	+35	;RETURN IS HERE FOR ERROR - INCORRECT STORE
4054					TST	(SP)+	;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
4055	032740	012700	125252		:THIS WILL TEST	DSTM = 4 MTPI	
4056	032744	012702	100002		MOV	#125252,R0	;LOAD TEST DATA INTO R0
4057	032750	004737	002626		MOV	#100002,R2	;LOAD VIRTUAL ADDRESS INTO R2
4058	032754	006642			JSR	PC,MTPITS	;GO DO THE TEST USING MTPI INSTRUCTION FOUND
4059	032756	000240			MTP	-(R2)	;<HERE - LOAD TEST DATA INTO PHYSICAL 100000
4060	032760	000000			NOP		;NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD
4061	032762	104035			.WORD	0	;ADD 0 TO R2 AFTER MTPI INSTRUCTION EXECUTE
4062	032764	005726			ERROR	+35	;RETURN IS HERE FOR ERROR - INCORRECT STORE
4063					TST	(SP)+	;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
4064	032766	012700	052525		:THIS WILL TEST	DSTM = 6 MTPI	
4065	032772	005002			MOV	#52525,R0	;LOAD TEST DATA INTO R0
4066	032774	004737	002626		CLR	R2	;MAKE R2 ZERO
4067	033000	006662	100000		JSR	PC,MTPITS	;GO DO THE TEST USING MTPI INSTRUCTION FOUND
4068	033004	100000			MTP	100000(R2)	;<HERE - LOAD TEST DATA INTO PHYSICAL 100000
4069	033006	104035			.WORD	100000	;ADD 100000 TO R2 AFTER MTPI INSTRUCTION EXECUTE
4070	033010	005726			ERROR	+35	;RETURN IS HERE FOR ERROR - INCORRECT STORE
4071	033012	042737	000002	172516	TST	(SP)+	;POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
4072	033020	000410			BIC	#BIT1,MMR3	;DISABLE SUPERVISOR D-SPACE
					BR	TST31	;BRANCH TO NEXT TEST

4074
4075 033022 013700 177572
4076 033026 013701 177574
4077 033032 013702 177576
4078 033036 104036
4079
4080 033040 000002

```
.SBTTL MM TRAP HANDLER FOR ABOVE TEST
MTPIV3: MOV    MMR0,R0      ;SAVE MMR0 FOR ERROR TYPEOUT
        MOV    MMR1,R1      ;SAVE MMR1 FOR ERROR TYPEOUT
        MOV    MMR2,R2      ;SAVE MMR2 FOR ERROR TYPEOUT
        ERROR  +36          ;TRIED TO LOAD A NON-RESIDENT PAGE. 4
;FOR TIGHTER SCOPE LOOP, REPLACE 1ST MOV INSTRUCTION WITH AN 'RTI' = 000002
        RTI                    ;RETURN TO TEST
```

4081

```
.SBTTL TEST # 31 - MTP1 (USER) WITH USER D-SPACE ENABLED
:*****
:TEST 31 MTP1 (USER) WITH USER D-SPACE ENABLED
:
: THIS TEST USES THE 'MTP1' INSTRUCTION TO ENSURE THAT THE PREVIOUS MODE
: IS CLOCKED CORRECTLY, AND THAT D-SPACE IS NOT ENABLED. THE TEST ITSELF
: IS CARRIED OUT IN SUBROUTINE MTP1TS, WHICH USES THE MTP1 INSTRUCTION
: CODE FOLLOWING THE JSR CALL TO EXECUTE THE TEST. *IMPORTANT* - ALL
: 'NOP'S' FOLLOWING MTP1'S OF MODES 1,2, 4 AND 5 ARE TO BE LEFT ALONE.
: THE SUBROUTINE LOADS THE TWO WORDS AFTER THE JSR CALL, PREPARING FOR
: MODES 3, 6 AND 7.
:
: IF THE CORRECT MODE IS NOT ENABLED, A NON-RESIDENT ABORT WILL OCCUR AND
: AND TRAP TO MTP1V4, WHERE THE ERRORS ARE REPORTED.
:
:*****
```

4082	033042	000004				TST31: SCOPE		
4083	033044	012737	077400	172210		MOV #77400,SIPDR4	:MAKE SIPDR4 NON-RESIDENT	
4084	033052	012737	077406	177610		MOV #77406,UIPDR4	:MAKE UIPDR4 RESIDENT	
4085	033060	052737	000001	172516		BIS #BIT0,MMR3	:ENABLE USER D-SPACE	
4086	033066	012737	002654	001110		:THIS WILL TEST DSTM = 1 MTP1		
4087	033074	012737	030340	002656		MOV #MTP1LP,\$LPERR	:SET LOOP ON ERROR POINTER TO MTP1LP IN SUBROUTINE	
4088	033102	012737	033242	002744		MOV #030340,MTP1PM	:MAKE LOCATION IN SUBROUTINE PREVIOUS MODE USER	
4089	033110	012702	100000			MOV #MTP1V4,MTP1VC	:PUT THIS TEST'S MM TRAP HANDLER ADDRESS IN LOC MTP1VC	
4090	033114	012700	125252			MOV #100000,R2	:LOAD VIRTUAL ADDRESS INTO R2	
4091	033120	004737	002626			MOV #125252,R0	:LOAD TEST DATA INTO R0	
4092	033124	006612				JSR PC,MTP1TS	:GO DO TEST USING MTP1 INSTRUCTION FOUND	
4093	033126	000240				MTP1 (R2)	:<HERE - LOAD TEST DATA INTO PHYSICAL 100000	
4094	033130	000000				.WORD 0	:MODE NOT 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD	
4095	033132	104035				ERROR +35	:ADD 0 TO R2 AFTER MTP1 INSTRUCTION EXECUTE	
4096	033134	005726				TST (SP)+	:RETURN IS HERE FOR ERROR - INCORRECT STORE	
4097						:THIS WILL TEST DSTM = 3 MTP1	:POP EXCESS RETURN OFF STACK - LOOPING NOT DONE	
4098	033136	012700	052525			MOV #52525,R0	:LOAD TEST DATA INTO R0	
4099	033142	004737	002626			JSR PC,MTP1TS	:GO DO TEST USING MTP1 INSTRUCTION FOUND	
4100	033146	006637	100000			MTP1 @#100000	:<HERE - LOAD TEST DATA INTO PHYSICAL 100000	
4101	033152	000000				.WORD 0	:ADD 0 TO R2 AFTER MTP1 INSTRUCTION EXECUTE	
4102	033154	104035				ERROR +35	:RETURN IS HERE FOR ERROR - INCORRECT STORE	
4103	033156	005726				TST (SP)+	:POP EXCESS RETURN OFF STACK - LOOPING NOT DONE	
4104						:THIS WILL TEST DSTM = 4 MTP1		
4105	033160	012700	125252			MOV #125252,R0	:LOAD TEST DATA INTO R0	
4106	033164	012702	100002			MOV #100002,R2	:LOAD VIRTUAL ADDRESS INTO R2	
4107	033170	004737	002626			JSR PC,MTP1TS	:GO DO TEST USING MTP1 INSTRUCTION FOUND	
4108	033174	006642				MTP1 -(R2)	:LOAD TEST DATA INTO PHYSICAL 100000	
4109	033176	000240				NOP	:<HERE - MODE NOT 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD	
4110	033200	000000				.WORD 0	:ADD 0 TO R2 AFTER MTP1 INSTRUCTION EXECUTE	
4111	033202	104035				ERROR +35	:RETURN IS HERE FOR ERROR - INCORRECT STORE	
4112	033204	005726				TST (SP)+	:POP EXCESS RETURN OFF STACK - LOOPING NOT DONE	
4113						:THIS WILL TEST DSTM = 6 MTP1		
4114	033206	012700	052525			MOV #52525,R0	:LOAD TEST DATA INTO R0	
4115	033212	005002				CLR R2	:MAKE R2 ZERO	
4116	033214	004737	002626			JSR PC,MTP1TS	:GO DO TEST USING MTP1 INSTRUCTION FOUND	
4117	033220	006662	100000			MTP1 100000(R2)	:<HERE - LOAD TEST DATA INTO PHYSICAL 100000	
4118	033224	100000				.WORD 100000	:ADD 100000 TO R2 AFTER MTP1 INSTRUCTION EXECUTE	
4119	033226	104035				ERROR +35	:RETURN IS HERE FOR ERROR - INCORRECT STORE	
4120	033230	005726				TST (SP)+	:POP EXCESS RETURN OFF STACK - LOOPING NOT DONE	
4121	033232	042737	000001	172516		BIC #BIT0,MMR3	:DISABLE USER D-SPACE	

4122 033240 000410

BR TST32

::BRANCH TO NEXT TEST

```
MM TRAP CATCHER FOR THE ABOVE TEST  
4124 .SBTTL MM TRAP CATCHER FOR THE ABOVE TEST  
4125 033242 013700 177572 MTPIV4: MOV MMR0,R0 ;SAVE MMR0 FOR ERROR TYPEOUT  
4126 033246 013701 177574 MOV MMR1,R1 ;SAVE MMR1 FOR ERROR TYPEOUT  
4127 033252 013702 177576 MOV MMR2,R2 ;SAVE MMR2 FOR ERROR TYPEOUT  
4128 033256 104036 ERROR +36 ;TRIED TO LOAD A NON-RESIDENT PAGE 4  
4129 ;FOR TIGHTER SCOPE LOOP, REPLACE 1ST MOV INSTRUCTION WITH AN 'RTI' = 000002  
4130 033260 000002 RTI ;RETURN TO TEST
```

4139

```
.SBTTL TEST # 32 - MFPI (PREVIOUS=CURRENT=KERNEL)
:*****
:*TEST 32 MFPI (PREVIOUS=CURRENT=KERNEL)
:*
:* THIS TEST CHECKS THAT IF BOTH PREVIOUS AND CURRENT MODES ARE KERNEL,
:* AND THE SOURCE MODE IS 0, THE DESTINATION STACK IS NOT DECREMENTED
:* BEFORE ACCESS. 'MFPI KSP,' SHOULD PUSH THE NON-DECREMENTED VALUE OF KSP
:* (1100) ONTO THE STACK (AT LOC. 1076).
:*
:*****
```

```
TST32: SCOPE
1$:   MOVB #6,KDPDR4 ;MAKE KDPDR4 RESIDENT
      CLR @#PSW ;SET PREVIOUS = CURRENT = KERNEL
      MOV #STACK,R0 ;SETUP VALUE FOR STACK POINTER
      MOV R0,KSP ;LOAD STACK POINTER
      MFPI KSP ;THE VALUE 'STACK' SHOULD BE PUSHED BEFORE BEING DEC'D
      MOV (KSP),R1 ;READ DATA WHICH WAS PUSHED
      CMP R0,R1 ;WAS THE ORIGINAL VALUE OF THE STACK POINTER PUSHED?
      BEQ 2$ ;BRANCH IF YES
      ERROR +37 ;MFPI FETCHED WRONG DATA
;FOR TIGHTER SCOPE LOOP, REPLACE 'BEQ 2$' WITH 'BR 1$' = 000767
2$:   TST -(R0) ;SETUP EXPECTED STACK POINTER VALUE
      CMP KSP,R0 ;WAS THE STACK POINTER DECREMENTED?
      BEQ 3$ ;BRANCH IF YES
      ERROR +25 ;STACK NOT PUSHED BY THE MFPI
;FOR TIGHTER SCOPE LOOP, REPLACE 'BEQ 3$' WITH 'BR 1$' = 000760
3$:   MOV #STACK,KSP ;RESTORE STACK POINTER
```

```
033262 000004
4140 033264 112737 000006 172330
4141 033272 005037 177776
4142 033276 012700 001100
4143 033302 010006
4144 033304 006506
4145 033306 01 01
4146 033310 0200 1
4147 033312 0014 1
4148 033314 104037
4149
4150 033316 005740
4151 033320 020600
4152 033322 001401
4153 033324 104025
4154
4155 033326 012706 001100
```

4169

.SBTTL TEST # 33 - MFPD (SUPERVISOR) WITH SUPER D-SPACE ENABLED
 :*****
 :*TEST 33 MFPD (SUPERVISOR) WITH SUPER D-SPACE ENABLED
 :*

:* THIS TEST CHECKS TO SEE THAT THE REFERENCE IS TO D-SPACE IF THE INSTRU-
 :* TION IS AN MFPD. THE TEST ITSELF IS CARRIED OUT IN SUBROUTINE MFPDTS,
 :* WHICH USES THE MFPD INSTRUCTION CODE FOLLOWING THE JSR CALL TO EXECUTE
 :* THE TEST. *IMPORTANT* - ALL 'NOP'S' FOLLOWING MFPD'S OF MODES 1,2,
 :* 4 AND 5 ARE TO BE LEFT ALONE. THE SUBROUTINE LOADS THE TWO WORDS
 :* AFTER THE JSR CALL, PREPARING FOR MODES 3, 6 AND 7.
 :*
 :* IF THE CORRECT MODE IS NOT ENABLED, A NON-RESIDENT ABORT WILL OCCUR
 :* AND TRAP TO MFPDV1, WHERE THE ERRORS ARE REPORTED.
 :*

:*****

033332	000004								
4170	033334	012737	000600	172270		TST33: SCOPE			
4171	033342	012700	077400			MOV #600,SDPAR4	:MAP SDPAR4 TO 12K		
4172						20\$: MOV #77400,R0	:MAKE PAGE 4 IN ALL BUT SUPERVISOR D		
4173	033346	010037	172330			MOV R0,KDPDR4	:AND KERNAL I NON-RESIDENT		
4174	033352	010037	172210			MOV R0,SIPDR4	:KERNAL D-SPACE PAGE 4		
4175	033356	010037	177630			MOV R0,UDPDR4	:SUPERVISOR I-SPACE PAGE 4		
4176	033362	010037	177610			MOV R0,UIPDR4	:USER D-SPACE PAGE 4		
4177	033366	012737	077406	172230		MOV #77406,SDPDR4	:USER I-SPACE PAGE 4		
4178	033374	012700	036514			MOV #36514,R0	:MAKE SDPDR4 RESIDENT		
4179	033400	010037	100000			MOV R0,#100000	:LOAD DATA PATTERN INTO R0		
4180	033404	052737	000002	172516		BIS #BIT1,MMR3	:LOAD DATA PATTERN INTO PHYS. 100000		
4181	033412	105037	172310			CLR B KIPDR4	:ENABLE SUPERVISOR D-SPACE		
4182							:MAKE KERNAL I-SPACE PAGE 4 NON-RESIDENT		
4183	033416	012737	002770	001110		:THE FOLLOWING WILL TEST DSTM=1	MFPD		
4184	033424	012737	010340	002772		MOV #MFPDLP,\$LPERR	:SET LOOP ON ERROR POINTER TO MFPDLP IN SUBROUTINE		
4185	033432	012737	033564	003040		MOV #010340,MFPDPS	:MOVE PREVIOUS MODE=SUPERVISOR TO LOCATION IN SUBRTN		
4186	033440	012702	100000			MOV #MFPDV1,MFPDVC	:PUT ADDRESS OF THIS TEST'S MM TRAP CATCHER IN MFPDVC		
4187	033444	004737	002746			MOV #100000,R2	:LOAD VIRTUAL ADDRESS INTO R2		
4188	033450	106512				JSR PC,MFPDTS	:GO DO TEST USING THE MFPD INSTRUCTION LOCATED		
4189	033452	000240				MFPD (R2)	:<HERE - READ FROM PHYSICAL 100000		
4190	033454	104037				NOP	:NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD		
4191	033456	005726				ERROR +37	:RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED		
4192						TST (SP)+	:POP EXCESS RETURN OFF STACK - LOOPING NOT DONE		
4193	033460	012702	100000			:THE FOLLOWING WILL TEST DSTM=2	MFPD		
4194	033464	004737	002746			MOV #100000,R2	:LOAD VIRTUAL ADDRESS INTO R2		
4195	033470	106522				JSR PC,MFPDTS	:GO DO TEST USING THE MFPD INSTRUCTION LOCATED		
4196	033472	000240				MFPD (R2)+	:<HERE - READ FROM PHYSICAL 100000		
4197	033474	104037				NOP	:NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD		
4198	033476	005726				ERROR +37	:RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED		
4199						TST (SP)+	:POP EXCESS RETURN OFF STACK - LOOPING NOT DONE		
4200	033500	012702	100000			:THE FOLLOWING WILL TEST DSTM=3	MFPD		
4201	033504	004737	002746			MOV #100000,R2	:LOAD VIRTUAL ADDRESS INTO R2		
4202	033510	106537	100000			JSR PC,MFPDTS	:GO DO TEST USING THE MFPD INSTRUCTION LOCATED		
4203	033514	104037				MFPD @#100000	:<HERE - READ FROM PHYSICAL 100000		
4204	033516	005726				ERROR +37	:WRONG DATA WAS FETCHED		
4205						TST (SP)+	:POP EXCESS RETURN OFF STACK - LOOPING NOT DONE		
4206	033520	012702	100002			:THE FOLLOWING WILL TEST DSTM=4	MFPD		
4207	033524	004737	002746			MOV #100002,R2	:LOAD VIRTUAL ADDRESS INTO R2		
4208	033530	106542				JSR PC,MFPDTS	:GO DO TEST USING THE MFPD INSTRUCTION LOCATED		
4209	033532	000240				MFPD -(R2)	:<HERE - READ FROM PHYSICAL 100000		
4210	033534	104037				NOP	:NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD		
						ERROR +37	:RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED		

4211	033536	005726		TST	(SP)+	:POP EXCESS RETURN OFF STACK - LOOPING NOT DONE
4212	033540	042737	000002	BIC	#BIT1,MMR3	:DISABLE SUPERVISOR D-SPACE
4213	033546	012700	077406	MOV	#77406,R0	:SET UP R0 FOR 4K RESIDENT R/W
4214	033552	010037	172310	MOV	R0,KIPDR4	:MAKE KIPAR4 RESIDENT
4215	033556	010037	177630	MOV	R0,UDPDR4	:MAKE UDPDR4 RESIDENT
4216	033562	000423		BR	TST34	:BRANCH TO NEXT TEST

```

4218 .SBTTL MM TRAP HANDLER FOR THE ABOVE TEST
4219 033564 013737 177572 001264 MFPDV1: MOV MMR0,WASSR0 ;SAVE MMR0 FOR ERROR TYPEOUT
4220 033572 013737 177574 001266 MOV MMR1,WASSR1 ;SAVE MMR1 FOR ERROR TYPEOUT
4221 033600 013737 177576 001270 MOV MMR2,WASSR2 ;SAVE MMR2 FOR ERROR TYPEOUT
4222 033606 012637 001260 MOV (KSP)+,TRAPPC ;SAVE PC & PS OF TRAP
4223 033612 012637 001262 MOV (KSP)+,TRAPPS
4224 033616 104040 ERROR +40 ;TRIED TO READ NON-RESIDNT PAGE
4225 ;FOR TIGHTER SCOPE LOOP, REPLACE 1ST MOV INSTRUCTION WITH AN 'RTI' = 000002
4226 033620 013746 001262 MOV TRAPPS,-(KSP) ;PUT PC & PS OF TRAP ON STACK
4227 033624 013746 001260 MOV TRAPPC,-(KSP)
4228 033630 000002 RTI ;RETURN TO TEST

```

4240

SBTTL TEST # 34 - MFPI (USER/PREV USER) WITH USER D-SPACE ENABLED

 *TEST 34 MFPI (USER/PREV USER) WITH USER D-SPACE ENABLED

THIS TEST CHECKS THAT IF THE INSTRUCTION IS AN MFPI AND BOTH THE
 PRESENT AND PREVIOUS MODES ARE USER, THEN D-SPACE IS USED IF IT IS
 ENABLED. IN THIS WAY AN OPERATING SYSTEM CAN MAKE PROPRIETARY CODE
 "EXECUTE ONLY" FOR THE USER.

IF THE CORRECT MODE IS NOT ENABLED, A NON-RESIDENT ABORT WILL OCCUR AND
 TRAP TO MFPIV6, WHERE THE ERRORS ARE REPORTED.

 TST34: SCOPE

4241	033632	000004							
4241	033634	012737	000600	177670		MOV	#600,UDPAR4	:MAP UDPAR4 TO 12K	
4242	033642	012700	036514			MOV	#36514,R0	:LOAD DATA PATTERN INTO R0	
4243	033646	010037	100000			MOV	R0,@#100000	:LOAD DATA PATTERN INTO PHYS. 100000	
4244	033652	052737	000001	172516		BIS	#BIT0,MMR3	:ENABLE USER D-SPACE	
4245	033660	105037	172230			CLRB	SDPDR4	:MAKE SDPDR4 NON-RESIDENT	
4246	033664	105037	172310			CLRB	KIPDR4	:MAKE KERNAL I-SPACE PAGE 4 NON-RESIDENT	
4247									
4248	033670	012737	002516	001110		:THE FOLLOWING WILL TEST DSTM=1	MFPI		
4249	033676	012737	170340	002520		MOV	#MFPIIP,\$LPERR	:SET LOOP ON ERROR POINTER TO MFPIIP IN SUBROUTINE	
4250	033704	012737	034036	002622		MOV	#170340,MFPIPS	:SET PREVIOUS AND CURRENT MODE TO LOCATION IN SUBRTN	
4251	033712	012702	100000			MOV	#MFPIV6,MFPIVC	:PUT ADDRESS OF THIS TEST'S TRAP CATCHER IN MFPIVC	
4252	033716	004737	002464			MOV	#100000,R2	:LOAD VIRTUAL ADDRESS INTO R2	
4253	033722	006512				JSR	PC,MFPITS	:GO DO TEST USING THE MFPI INSTRUCTION LOCATED	
4254	033724	000240				MFPI	(R2)	:<HERE - READ FROM PHYSICAL 100000	
4255	033726	104037				NOP		:NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD	
4256	033730	005726				ERROR	+37	:RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED	
4257						TST	(SP)+	:POP EXCESS RETURN OFF STACK - LOOPING NOT DONE	
4258	033732	012702	100000			:THE FOLLOWING WILL TEST DSTM=2	MFPI		
4259	033736	004737	002464			MOV	#100000,R2	:LOAD VIRTUAL ADDRESS INTO R2	
4260	033742	006522				JSR	PC,MFPITS	:GO DO TEST USING THE MFPI INSTRUCTION LOCATED	
4261	033744	000240				MFPI	(R2)+	:<HERE - READ FROM PHYSICAL 100000	
4262	033746	104037				NOP		:NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD	
4263	033750	005726				ERROR	+37	:RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED	
4264						TST	(SP)+	:POP EXCESS RETURN OFF STACK - LOOPING NOT DONE	
4265	033752	012702	100000			:THE FOLLOWING WILL TEST DSTM=3	MFPI		
4266	033756	004737	002464			MOV	#100000,R2	:LOAD VIRTUAL ADDRESS INTO R2	
4267	033762	006537	100000			JSR	PC,MFPITS	:GO DO TEST USING THE MFPI INSTRUCTION LOCATED	
4268	033766	104037				MFPI	@#100000	:<HERE - READ FROM PHYSICAL 100000	
4269	033770	005726				ERROR	+37	:RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED	
4270						TST	(SP)+	:POP EXCESS RETURN OFF STACK - LOOPING NOT DONE	
4271	033772	012702	100002			:THE FOLLOWING WILL TEST DSTM=4	MFPI		
4272	033776	004737	002464			MOV	#100002,R2	:LOAD VIRTUAL ADDRESS INTO R2	
4273	034002	006542				JSR	PC,MFPITS	:GO DO TEST USING THE MFPI INSTRUCTION LOCATED	
4274	034004	000240				MFPI	-(R2)	:<HERE - READ FROM PHYSICAL 100000	
4275	034006	104037				NOP		:NOT MODE 3, 6 OR 7 - NEEDED FOR SUBROUTINE LOAD	
4276	034010	005726				ERROR	+37	:RETURN IS HERE FOR ERROR - WRONG DATA WAS FETCHED	
4277	034012	042737	000001	172516		TST	(SP)+	:POP EXCESS RETURN OFF STACK - LOOPING NOT DONE	
4278	034020	012737	000340	177776		BIC	#BIT0,MMR3	:DISABLE USER D-SPACE	
4279	034026	112737	000006	172310		MOV	#340,PSW	:MAKE PRESENT MODE KERNAL	
4280	034034	000423				MOVB	#6,KIPDR4	:MAKE KIPDR4 RESIDENT	
						BR	TST35	:BRANCH TO NEXT TEST	

```
4282 .SBTTL MM TRAP CATCHER FOR ABOVE TEST
4283 034036 013737 177572 001264 MFPIV6: MOV MMR0,WASSRO ;SAVE MMR0 FOR ERROR TYPEOUT
4284 034044 013737 177574 001266 MOV MMR1,WASSR1 ;SAVE MMR1 FOR ERROR TYPEOUT
4285 034052 013737 177576 001270 MOV MMR2,WASSR2 ;SAVE MMR2 FOR ERROR TYPEOUT
4286 034060 012637 001260 MOV (KSP)+,TRAPC ;SAVE PC & PS OF TRAP
4287 034064 012637 001262 MOV (KSP)+,TRAPPS
4288 034070 104040 ERROR +40 ;TRIED TO READ NON-RESIDENT PAGE
4289 ;FOR TIGHTER SCOPE LOOP, REPLACE 1ST MOV INSTRUCTION WITH AN 'RTI' = 003002
4290 034072 013746 001262 MOV TRAPPS,-(KSP) ;PUT PC & PS OF TRAP ON STACK
4291 034076 013746 001260 MOV TRAPPC,-(KSP)
4292 034102 000002 RTI ;RETURN TO TEST
```

4300

```
.SBTTL TEST # 35 - TEST CSM INSTRUCTION - ILLEGAL KERNEL MODE
*****
*TEST 35 TEST CSM INSTRUCTION - ILLEGAL KERNEL MODE
*****
* THIS TEST CHECKS OUT THE CSM (CALL SUPERVISOR MODE)
* INSTRUCTION TO MAKE SURE CSM IS ILLEGAL WHEN DISABLED
* IN KERNEL MODE.
*****
```

4301	034104	000004					TST35:	SCOPE		
4302	034106	005037	172516					CLR	MMR3	:MAKE SURE MMR3 IS CLEARED, DISABLING CSM
4303	034112	005037	177776					CLR	PSW	:MAKE SURE PSW PREVIOUS=CURRENT=KERNEL
4304	034116	013737	000010	001204				MOV	RESVEC,\$TMP3	:SAVE TRAPS TO 10 VECTOR
4305	034124	012737	034140	000010				MOV	#1\$,RESVEC	:TRAPS TO 10 GO TO 1\$
4306	034132	005237	177572					INC	MMR0	:TURN ON MEMORY MANAGEMENT
4307	034136	007000						CSMO		:CSM RO
4308	034140	013737	001204	000010	1\$:			MOV	\$TMP3,RESVEC	:RESTORE TRAPS TO 10 VECTOR
4309	034146	005037	177572					CLR	MMR0	:TURN OFF MEMORY MANAGEMENT
4310	034152	005037	177776					CLR	PSW	:RETURN TO KERNEL MODE
4311	034156	022726	034140					CMP	#1\$,(SP)+	:SEE IF IT WAS AN EXPECTED TRAP
4312	034162	001403						BEQ	2\$:BRANCH TO RESTORE STACK IF IT WAS
4313	034164	022626						CMP	(SP)+,(SP)+	:CORRECT STACK
4314	034166	104041						ERROR	+41	:ILLEGAL CSM DID NOT TRAP TO 10
4315	034170	000401						BR	TST36	:BRANCH AROUND STACK CORRECTION
	034172	005726			2\$:			TST	(SP)+	:CORRECT STACK

4323

```
.SBTTL TEST # 36 - TEST CSM INSTRUCTION - ILLEGAL SUPERVISOR MODE
:*****
:*TEST 36 TEST CSM INSTRUCTION - ILLEGAL SUPERVISOR MODE
:*****
:* THIS TEST CHECKS OUT THE CSM (CALL SUPERVISOR MODE)
:* INSTRUCTION TO MAKE SURE CSM IS ILLEGAL WHEN DISABLED
:* IN SUPERVISOR MODE.
:*****
:*****
```

```
TST36: SCOPE
4324 034174 000004 172516 CLR MMR3 :MAKE SURE MMR3 IS CLEARED, DISABLING CSM
4325 034202 052737 040000 177776 BIS #40000,PSW :GO TO SUPERVISOR MODE
4326 034210 013737 000010 001204 MOV RESVEC,$TMP3 :SAVE TRAPS TO 10 VECTOR
4327 034216 012737 034232 000010 MOV #1$,RESVEC :TRAPS TO 10 GO TO 1$
4328 034224 005237 177572 INC MMR0 :TURN ON MEMORY MANAGEMENT
4329 034230 007000 CSMO :CSM RO
4330 034232 013737 001204 000010 1$: MOV $TMP3,RESVEC :RESTORE TRAPS TO 10 VECTOR
4331 034240 005037 177572 CLR MMR0 :TURN OFF MEMORY MANAGEMENT
4332 034244 005037 177776 CLR PSW :GO BACK TO KERNEL MODE
4333 034250 022726 034232 CMP #1$, (SP)+ :SEE IF IT WAS AN EXPECTED TRAP
4334 034254 001400 BEQ 2$ :BRANCH AROUND ERROR CALL IF IT WAS
4335 034256 022626 CMP (SP)+, (SP)+ :CORRECT STACK
4336 034260 104041 ERROR +41 :ILLEGAL CSM DID NOT TRAP TO 10
4337 034262 000401 BR TST37 :BRANCH AROUND STACK CORRECTION
4338 034264 005726 2$: TST (SP)+ :CORRECT STACK
```

4346

```
.SBTTL TEST # 37 - TEST CSM INSTRUCTION - ILLEGAL USER MODE
*****
*TEST 37 TEST CSM INSTRUCTION - ILLEGAL USER MODE
*****
* THIS TEST CHECKS OUT THE CSM (CALL SUPERVISOR MODE)
* INSTRUCTION TO MAKE SURE CSM IS ILLEGAL WHEN DISABLED
* IN USER MODE.
*****
*****
```

```
TST37: SCOPE
4347 034266 000004          CLR      MMR3          :MAKE SURE MMR3 IS CLEARED, DISABLING CSM
4348 034270 005037 172516   CLR      #140000,PSW  :GO TO USER MODE
4349 034302 013737 140000 177776   MOV      RESVEC,$TMP3 :SAVE TRAPS TO 10 VECTOR
4350 034310 012737 000010 001204   MOV      #1$,RESVEC   :TRAPS TO 10 GO TO 1$
4351 034316 005237 177572          INC      MMRO         :TURN ON MEMORY MANAGEMENT
4352 034322 007000          CSMO          :CSM RO
4353 034324 013737 001204 000010 1$:   MOV      $TMP3,RESVEC :RESTORE TRAPS TO 10 VECTOR
4354 034332 005037 177572          CLR      MMRO         :TURN OFF MEMORY MANAGEMENT
4355 034336 005037 177776          CLR      PSW          :RETURN TO KERNEL MODE
4356 034342 022726 034324          CMP      #1$,(SP)+    :SEE IF IT WAS AN EXPECTED TRAP
4357 034346 001403          BEQ      2$          :BRANCH AROUND ERROR CALL IF IT WAS
4358 034350 022626          CMP      (SP)+,(SP)+ :CORRECT STACK
4359 034352 104041          ERROR     +41        :ILLEGAL CSM DID NOT TRAP TO 10
4360 034354 000401          BR       TST40       :BRANCH AROUND STACK CORRECTION
4361 034356 005726          2$:   TST      (SP)+      :CORRECT STACK
```



```

4404          .SBTTL  SUBROUTINE TO CHECK OPERATION OF AN EXECUTABLE CSM INST'N
4405 034530 012605          CSMSUB: MOV      (SP)+,R5      ;PUT RETURN ADDRESS INTO R5
4406 034532 012737 000340 177776 MOV      #340,PSW      ;KERNEL MODE
4407 034540 010037 035324          MOV      R0,PCSMRO     ;STORE PRECSM R0
4408 034544 012504          MOV      (R5)+,R4      ;MOVE OFFSET TO R4
4409 034546 010537 035342          MOV      R5,RETURN     ;SET RETURN LOCATION ADDRESS TO LOCATION 'RETURN'
4410 034552 012737 034704 035316 MOV      #5$,DOWELP    ;MOVE ADDRESS FOR INITIAL TESTING TO DOWELP
4411 034560 012764 034622 000010 MOV      #2$,RESVEC(R4) ;SETUP TRAPS TO 10 VECTOR TO 2$
4412 034566 012737 034614 001110 MOV      #1$,SLPERR    ;SETUP LOOP ON ERROR TO 1$
4413 034574 053737 035320 177776 BIS      PCSMPS,PSW     ;PUT USER/SUPERVISOR IN THE PSW
4414 034602 010637 035322          MOV      SP,PCSMSP     ;MOVE STACK POINTER VALUE TO PCSMSP
4415 034606 162737 000006 035322 SUB      #6,PCSMSP     ;SUBTRACT 6 FROM PCSMSP - EXPECT 3 PUSHES ON STACK
4416 034614 005237 177572          1$: INC      MMR0      ;TURN ON MEMORY MANAGEMENT
4417 034620 007000          CSMO
4418 034622 012737 000012 000010 2$: MOV      #RESVEC+2,RESVEC;RESTORE TRAPS TO 10 VECTOR
4419 034630 022716 034622          CMP      #2$, (SP)    ;SEE IF CSM ABORTED
4420 034634 001011          BNE      4$          ;BRANCH IF IT DIDN'T TO EXECUTE TEST
4421 034636 012737 000340 177776 3$: MOV      #340,PSW     ;GO BACK TO KERNEL PRIORITY 7
4422 034644 005037 177572          CLR      MMR0      ;TURN OFF MEMORY MANAGEMENT
4423 034650 022626          CMP      (SP)+, (SP)+ ;CORRECT STACK
4424 034652 104051          ERROR   +51        ;CSM ABORTED WHEN IT SHOULD NOT HAVE
4425 034654 000177 000462          JMP      @RETURN     ;JUMP TO ADDRESS PRESTORED IN LOCATION RETURN
4426 034660 010637 035336          4$: MOV      SSP,ACSMSP ;SAVE AFTER CSM STACK POINTER
4427 034664 012637 035326          MOV      (SP)+,CSM1ST ;POP 1ST WORD OFF STACK
4428 034670 012637 035330          MOV      (SP)+,CSM2ND ;POP 2ND WORD OFF STACK
4429 034674 012637 035332          MOV      (SP)+,CSM3RD ;POP 3RD WORD OFF STACK
4430 034700 000177 000412          JMP      @DOWELP    ;JUMP TO LOCATION IN DOWELP
4431 034704 013703 035320          5$: MOV      PCSMPS,R3   ;PUT PRE-CSM PSW IN R3
4432 034710 042703 037777          BIC      #37777,R3   ;WIPE OUT ALL BITS EXCEPT <15:14>,
4433 034714 000241          CLC          ;CLEAR THE CARRY BIT
4434 034716 006003          ROR      R3        ;MOVE <15:14> OVER TO
4435 034720 006003          ROR      R3        ;THE RIGHT TO <13:12>,
4436 034722 052703 040000          BIS      #BIT14,R3  ;AND SET <14>, PUTTING CURRENT=SUPERVISOR IN EXPECTED LOC
4437 034726 013737 177776 035334 MOV      PSW,ACSMPS  ;MOVE CURRENT PSW TO ACSMPS
4438 034734 042737 007777 035334 BIC      #7777,ACSMPS ;WIPE OUT ALL BITS BUT <15:12>
4439 034742 020337 035334          CMP      R3,ACSMPS  ;SEE IF PSW STATUS BITS MATCHES CALCULATED VALUE
4440 034746 001403          BEQ      6$        ;BRANCH AROUND ERROR CALL IF OK
4441 034750 005037 177572          CLR      MMR0      ;TURN OFF MEMORY MANAGEMENT
4442 034754 104042          ERROR   +42        ;NOT SUPERVISOR MODE
4443 034756 052737 000001 177572 6$: BIS      #BIT00,MMRO ;MAKE SURE MEMORY MANAGEMENT IS ON
4444 034764 013737 177776 035334 MOV      PSW,ACSMPS  ;MOVE CURRENT PSW TO ACSMPS
4445 034772 042737 037777 035334 BIC      #37777,ACSMPS ;CLEAR ALL BITS EXCEPT <15:14>
4446 035000 023737 035340 035334 CMP      SUPERM,ACSMPS ;SEE IF SUPERVISOR MODE
4447 035006 001414          BEQ      8$        ;BRANCH AROUND ERROR CALL IF OK
4448 035010 012737 034756 035316 MOV      #6$,DOWELP  ;SET ADDRESS FOR THIS CHECK TO DOWELP
4449 035016 005037 177572          CLR      MMR0      ;TURN OFF MEMORY MANAGEMENT
4450 035022 013703 035334          MOV      ACSMPS,R3  ;MOVE RECEIVED CONTENTS TO R3
4451 035026 052703 040000          BIS      #BIT14,R3  ;SET BIT 14 AND
4452 035032 042703 100000          BIC      #BIT15,R3  ;CLEAR BIT 15
4453 035036 104042          ERROR   +42        ;NOT SUPERVISOR MODE
4454 035040 052737 000001 177572 8$: BIS      #BIT00,MMRO ;MAKE SURE MEMORY MANAGEMENT IS ON
4455 035046 013704 177776          MOV      PSW,R4     ;MOVE CURRENT PSW TO R4
4456 035052 042704 147777          BIC      #147777,R4 ;CLEAR ALL BITS EXCEPT <13:12>
4457 035056 006304          ASL      R4        ;MOVE <13:12> BITS IN R4
4458 035060 006304          ASL      R4        ;TO THE <15:14> POSITION
4459 035062 013702 035320          MOV      PCSMPS,R2  ;MOVE PRECSM PSW TO R2
4460 035066 042702 037777          BIC      #37777,R2  ;CLEAR BITS 13 TO 0

```

```
4461 035072 020204          CMP      R2,R4          ;SEE IF PREVIOUS MODE IS OK
4462 035074 001406          BEQ      10$           ;BRANCH AROUND ERROR CALL IF OK
4463 035076 012737 035040 035316    MOV      #8$,DOWELP    ;SET ADDRESS FOR THIS CHECK TO DOWELP
4464 035104 005037 177572          CLR      MMRO         ;TURN OFF MEMORY MANAGEMENT
4465 035110 104043          ERROR   +43          ;WRONG PREVIOUS MODE
4466 035112 052737 000001 177572 10$:  BIS      #BIT00,MMRO   ;MAKE SURE MEMORY MANAGEMENT IS ON
4467 035120 023737 035336 035322    CMP      ACSMSP,PCSMSP ;SEE IF STACK POINTER VALUE WAS TRANSFERED
4468 035126 001406          BEQ      12$           ;BRANCH AROUND ERROR CALL IF SO
4469 035130 012737 035112 035316    MOV      #10$,DOWELP   ;SET ADDRESS FOR THIS CHECK TO DOWELP
4470 035136 005037 177572          CLR      MMRO         ;TURN OFF MEMORY MANAGEMENT
4471 035142 104044          ERROR   +44          ;INCORRECT STACK
4472 035144 052737 000001 177572 12$:  BIS      #BIT00,MMRO   ;MAKE SURE MEMORY MANAGEMENT IS ON
4473 035152 020037 035326    CMP      RO,CSM1ST    ;COMPARE RO WITH THE ARGUMENT THAT WAS ON STACK
4474 035156 001406          BEQ      14$           ;IF EQUAL, BRANCH AROUND ERROR
4475 035160 012737 035144 035316    MOV      #12$,DOWELP   ;SET ADDRESS FOR THIS CHECK TO DOWELP
4476 035166 005037 177572          CLR      MMRO         ;TURN OFF MEMORY MANAGEMENT
4477 035172 104045          ERROR   +45          ;INCORRECT ARGUMENT
4478 035174 052737 000001 177572 14$:  BIS      #BIT00,MMRO   ;MAKE SURE MEMORY MANAGEMENT IS ON
4479 035202 022737 034622 035330    CMP      #2$,CSM2ND   ;SEE IF UPDATED PC WAS CORRECT
4480 035210 001411          BEQ      16$           ;BRANCH AROUND ERROR IF OK
4481 035212 012737 035174 035316    MOV      #14$,DOWELP   ;SET ADDRESS FOR THIS CHECK TO DOWELP
4482 035220 005037 177572          CLR      MMRO         ;TURN OFF MEMORY MANAGEMENT
4483 035224 012737 034622 001176    MOV      #2$,STMPO    ;MOVE EXPECTED UPDATED PC TO STMPO
4484 035232 104046          ERROR   +46          ;WRONG PC
4485 035234 052737 000001 177572 16$:  BIS      #BIT00,MMRO   ;MAKE SURE MEMORY MANAGEMENT IS ON
4486 035242 032737 000017 035332    BIT      #17,CSM3RD   ;SEE IF PSW <3:0> WERE CLEARED
4487 035250 001406          BEQ      18$           ;BRANCH AROUND ERROR CALL IF OK
4488 035252 012737 035234 035316    MOV      #16$,DOWELP   ;SET ADDRESS FOR THIS CHECK TO DOWELP
4489 035260 005037 177572          CLR      MMRO         ;TURN OFF MEMORY MANAGEMENT
4490 035264 104047          ERROR   +47          ;BITS <3:0> SET IN PSW
4491 035266 022737 034704 035316 18$:  CMP      #5$,DOWELP   ;SEE IF ANY ERRORS THIS TIME AROUND
4492 035274 001406          BEQ      19$           ;BRANCH TO NORMAL RETURN JUMP IF NOT
4493 035276 032777 001000 143634    BIT      #BIT09,@SWR  ;SEE IF LOOP ON ERROR IS SET
4494 035304 001402          BEQ      19$           ;BRANCH IF SO
4495 035306 000137 034614          JMP      1$            ;JUMP BACK FOR LOOP ON ERROR
4496 035312 000177 000024 19$:  JMP      @RETURN      ;JUMP BACK TO RETURN ADDRESS IN LOCATION RETURN
4497
4498 035316 000000          DOWELP: .WORD 0      ;LOCATION HOLDING ADDRESS TO SHORTEN POSSIBLE ERROR LOOP
4499 035320 000000          PCSMPS: .WORD 0     ;LOCATION TO STORE PRE-CSM PSW
4500 035322 000000          PCSMSP: .WORD 0     ;LOCATION TO STORE PRE-CSM STACK POINTER
4501 035324 000000          PCSMRO: .WORD 0     ;LOCATION TO STORE PRE-CSM RO VALUE
4502 035326 000000          CSM1ST: .WORD 0    ;LOCATION TO STORE 1ST WORD POPPED AFTER CSM EXECUTION
4503 035330 000000          CSM2ND: .WORD 0    ;LOCATION TO STORE 2ND WORD POPPED AFTER CSM EXECUTION
4504 035332 000000          CSM3RD: .WORD 0    ;LOCATION TO STORE 3RD WORD POPPED AFTER CSM EXECUTION
4505 035334 000000          ACSMPS: .WORD 0    ;LOCATION TO STORE POST-CSM PSW
4506 035336 000000          ACSMSP: .WORD 0    ;LOCATION TO STORE POST-CSM STACK POINTER
4507 035340 040000          SUPERM: .WORD 40000 ;LOCATION TO STORE VALUE OF PRESENT MODE=SUPERVISOR
4508 035342 000000          RETURN: .WORD 0    ;LOCATION TO STORE RETURN ADDRESS OF THE CSMSUB
```


4567

```
.SBTTL TEST # 45 - TEST CSM INSTRUCTION - MODE TESTS
*****
*TEST 45 TEST CSM INSTRUCTION - MODE TESTS
* THIS TEST EXECUTES THE CSM INSTRUCTION LEGALLY IN MODES 1 THROUGH 7.
* CHECKING FOR PROPER REGISTER INCREMENT/DECREMENT AND THAT ARGUMENT
* CONTENTS IS PROPERLY ON THE STACK
*****
TST45: SCOPE
MOV #40000,PSW ;GO TO SUPERVISOR MODE
MOV #32,MMR3 ;ENABLE 22-BIT, CSM, SUPERVISOR
MOV #7,R1 ;DO 7 MODES
MOV #CSMINS,R2 ;LOAD CSM INSTRUCTION POINTER INTO R2
MOV #REGCHG,R3 ;LOAD REGISTER CHANGE TABLE POINTER TO R3
MOV #REGDAT,R4 ;LOAD ARGUMENT EXPECTED STACK POINTER TO R4
MOV #3$,RESVEC ;SET RETURNS TO 3$
1$: MOV (R2),2$ ;MOVE CSM INSTRUCTION TO TEST LOCATION
MOV #REGLAB,RO ;RESET RO
2$: .WORD 0,0 ;1ST WORD FOR CSM INSTRUCTION, 2ND FOR MODES 6 & 7
3$: MOV (SP),$TMP1 ;MOVE ARGUMENT WORD TO $TMP1
CMP (R3),RO ;SEE IF REGISTER CHANGED PROPERLY
BEQ 4$ ;BRANCH IF OK
ADD #6,SP ;POP STACK FOR POSSIBLE ERROR LOOPING
MOV (R3),$TMP0 ;MOVE EXPECTED DATA TO $TMP0
ERROR +52 ;CSM FAILED TO INCREMENT/DECREMENT REGISTER PROPERLY
4$: SUB #6,SP ;RESTORE STACK POINTER TO PRE-ERROR STATE
CMP (R4),$TMP1 ;SEE IF CORRECT ARGUMENT WAS LOADED
BEQ 5$ ;BRANCH IF OK
MOV (SP)+,$TMP3 ;POP STACK FOR POSSIBLE ERROR LOOPING
MOV (SP)+,$TMP4
MOV (SP)+,$TMP5
MOV (R4),$TMP2 ;MOVE EXPECTED DATA TO $TMP2
ERROR +53 ;CSM FAILED TO PUT PROPER ARGUMENT ON STACK
MOV $TMP5,-(SP) ;RESTORE STACK - NO ERROR LOOPING
MOV $TMP4,-(SP)
MOV $TMP3,-(SP)
5$: CMP (R2)+,(R3)+ ;INCREMENT R2 AND R3 TO NEXT LOCATIONS
TST (R4)+ ;INCREMENT R4 TO NEXT LOCATION
ADD #6,SP ;POP STACK OF CSM PUSHES
SOB R1,1$ ;SUBTRACT 1 AND BRANCH IF NOT ALL MODES CHECKED
CLR MMR0 ;TURN OFF MEMORY MANAGEMENT
CLR MMR3 ;CLEAR MMR3
CLR PSW ;RETURN MODE BACK TO KERNEL
BR $EOP ;SKIP OVER TABLES AND LOCATIONS
CSMINS: .WORD CSM1,CSM2,CSM3,CSM4,CSM5,CSM6,CSM7
. WORD REGLAB+2
REGLAB: .WORD REGLAB-2
. WORD 52525
REGCHG: .WORD REGLAB,REGLAB+2,REGLAB+2,REGLAB-2,REGLAB-2,REGLAB,REGLAB
REGDAT: .WORD REGLAB-2,REGLAB-2,REGLAB+2,REGLAB+2,52525,REGLAB-2,REGLAB+2
```

035542 000004
4568 035544 012737 040000 177776
4569 035552 012737 000032 172516
4570 035560 012701 000007
4571 035564 012702 035744
4572 035570 012703 035770
4573 035574 012704 036006
4574 035600 012737 035622 000010
4575 035606 011237 035616
4576 035612 012700 035764
4577 035616 000000 000000
4578 035622 011637 001200
4579 035626 021300
4580 035630 001407
4581 035632 062706 000006
4582 035636 011337 001176
4583 035642 104052
4584 035644 162706 000006
4585 035650 021437 001200
4586 035654 001417
4587 035656 012637 001204
4588 035662 012637 001206
4589 035666 012637 001210
4590 035672 011437 001202
4591 035676 104053
4592 035700 013746 001210
4593 035704 013746 001206
4594 035710 013746 001204
4595 035714 022223
4596 035716 005724
4597 035720 062706 000006
4598 035724 077150
4599 035726 005037 177572
4600 035732 005037 172516
4601 035736 005037 177776
4602 035742 000430
4603 035744 007010 007020 007030
4604 035762 035766
4605 035764 035762
4606 035766 052525
4607 035770 035764 035766 035766
4608 036006 035762 035762 035766

CK
CV
SY
MT
MT
ND
NO
PA
PB
PB
PC
PC
PC
PF
PF
PF
PF
PI
PI
PR
PR
PR
PR
PR
PR
PS
PS

PW
PW
RD
RD
RE
RE
RE
RE

RE
RE

RE
R6
R7
SA
SC


```
036260 000240          NOP          ;;ACT11
036262          $DOAGN: TRAP          ;;PUSH OLD PSW AND PC ON STACK
036262 104400          BIC          #20,(SP) ;;CLEAR THE 'T' BIT
036264 042716 000020          BIT          #BIT12,@SWR ;;RUN WITH TRACE TRAP?
036270 032777 010000 142642          BNE          1$          ;;BR IF NO
036276 001005          COM          $TBIT      ;;IS IT TIME FOR TRACE TRAP
036300 005137 001310          BMI          1$          ;;BR IF NO
036306 052716 000020          BIS          #20,(SP) ;;SET TRACE TRAP
036312 012746 036320 1$: MOV          #$LOOP,-(SP) ;;JUMP TO START OF TEST
036316 000002          $RTRN: RTI          ;;RETURN--THIS IS CHANGED TO
                                ;;AN 'RTI' IF 'RTI' IS A LEGAL
                                ;;INSTRUCTION

036320          $LOOP:          JMP          @(PC)+      ;;RETURN
036320 000137          $RTNAD: .WORD      LOOP
036322 020560          $ENULL: .BYTE      -1,-1,0
036324      377      000          .EVEN
                                .END

4610      000001
```


MTPILD	002676	SDPDR0=	172220	SW5	=	000040	TYPDS	=	104405	SCKSWR	004306	
MTPILP	002654	SDFDR1=	172222	SW6	=	000100	TYPE	=	104401	SCLR.T	036242	
MTPIPM	002656	SDPDR2=	172224	SW7	=	000200	TYPOC	=	104402	SCMTAG	001100	
MTPITA	002720	SDPDR3=	172226	SW8	=	000400	TYPON	=	104404	SCM1	=	000006
MTPITS	002626	SDPDR4=	172230	SW9	=	001000	TYPOS	=	104403	SCM2	=	000014
MTPIVC	002744	SDPDR5=	172232	TBIT	=	000020	UDPAR0=	177660	SCM3	=	000006	
MTPIV1	030614	SDPDR6=	172234	TBITPS	=	001274	UDPAR1=	177662	SCM4	=	000C06	
MTPIV2	031260	SDPDR7=	172236	TBITVE=	000014	UDPAR2=	177664	SCNTLC	001312			
MTPIV3	033022	SIPAR0=	172240	TESTNO	001254	UDPAR3=	177666	SCNTLG	005253			
MTPIV4	033242	SIPAR1=	172242	TIMERR	016070	UDPAR4=	177670	SCNTLU	005246			
NDFLAG	002242	SIPAR2=	172244	TIMFLG	016072	UDPAR5=	177672	SCPUOP	001252			
NODSPA	002232	SIPAR3=	172246	TKVEC	=	000060	UDPAR6=	177674	SCRFL	001221		
PATCH	016232	SIPAR4=	172250	TOFF	002356	UDPAR7=	177676	SDBLK	006762			
PBAHI	001302	SIPAR5=	172252	TON	002412	UDPDR0=	177620	SDB20	007066			
PBALO	001300	SIPAR6=	172254	TPVEC	=	000064	UDPDR1=	177622	SDEVCT	001234		
PCSMPS	035320	SIPAR7=	172256	TRAPP	001260	UDPDR2=	177624	SDOAGN	036262			
PCSMRO	035324	SIPDR0=	172200	TRAPPS	001262	UDPDR3=	177626	SDTBL	006752			
PCSMSP	035322	SIPDR1=	172202	TRAPVE=	000034	UDPDR4=	177630	SENDAD	036252			
PFECDF	004302	SIPDR2=	172204	TRTVEC=	000014	UDPDR5=	177632	SENDCT	036054			
PFECDH	004242	SIPDR3=	172206	TST1	020704	UDPDR6=	177634	SENULL	036324			
PFECDT	004272	SIPDR4=	172210	TST10	023160	UDPDR7=	177636	SENV	001244			
PFECFM	004202	SIPDR5=	172212	TST11	023462	UIPAR0=	177640	SENVN	001245			
PFECWS	004172	SIPDR6=	172214	TST12	023552	UIPAR1=	177642	SEOP	036024			
PIRQ	=	SIPDR7=	172216	TST13	023742	UIPAR2=	177644	SEOPCT	036046			
PIRQVE=	000240	SRO	=	TST14	024256	UIPAR3=	177646	SERFLG	001103			
PRO	=	SR1	=	TST15	025234	UIPAR4=	177650	SERMAX	001115			
PR1	=	SR2	=	TST16	026272	UIPAR5=	177652	SERROR	003270			
PR2	=	SR3	=	TST17	026542	UIPAR6=	177654	SERRPC	001116			
PR3	=	SSP	=	TST2	021222	UIPAR7=	177656	SERRTB	001320			
PR4	=	STACK	=	TST20	027016	UIPDR0=	177600	SERTTL	001112			
PR5	=	START	020000	TST21	027232	UIPDR1=	177602	SESCAP	001212			
PR6	=	STKLMT=	177774	TST22	027634	UIPDR2=	177604	SETABL	001244			
PR7	=	SUPERM	035340	TST23	030232	UIPDR3=	177606	SETEND	001254			
PS	=	SUPSTK=	000700	TST24	030662	UIPDR4=	177610	SFATAL	001226			
PSW	=	SWR	001140	TST25	031326	UIPDR5=	177612	SFFLG	006242			
PWRMSG	007460	SWREG	000176	TST26	031742	UIPDR6=	177614	SFILLC	001156			
PWRVEC-	000024	SW0	=	TST27	032352	UIPDR7=	177616	SFILLS	001155			
RDCHR	=	SW00	=	TST3	021456	USESTK=	000600	SGADR	001120			
RDLIN	=	SW01	=	TST30	032636	USP	=	0000006	SGDDAT	001124		
REGCHG	035770	SW02	=	TST31	033042	VIRT1	001276	SGET42	036224			
REGDAT	036006	SW03	=	TST32	033262	WASR6	001256	SGTSWR	004356			
REGLAB	035764	SW04	=	TST33	033332	WASSR0	001264	SHD	=	000000		
RESREG=	104414	SW05	=	TST34	033632	WASSR1	001266	SHIBTS	000204			
RESVEC-	000010	SW06	=	TST35	034104	WASSR2	001270	SICNT	001104			
RETURN	035342	SW07	=	TST36	034174	WASSR3	001272	SILLUP	007452			
R6	=	SW08	=	TST37	034266	WBIT	=	000100	SINTAG	001135		
R7	=	SW09	=	TST4	021632	WAPTHD	000204	SITEMB	001114			
SAVREG=	104413	SW1	=	TST40	034360	SATYC	006022	SLF	001222			
SCOPE	=	SW10	=	TST41	034446	SATY1	005776	SLFLG	006241			
SDPAR0=	172260	SW11	=	TST42	035344	SATY3	006004	SLOOP	036320			
SDPAR1=	172262	SW12	=	TST43	035420	SATY4	006014	SLPADR	001106			
SDPAR2=	172264	SW13	=	TST44	035474	SAUTOB	001134	SLPERR	001110			
SDPAR3=	172266	SW14	=	TST45	035542	SBADR	001122	SMAIL	001224			
SDPAR4=	172270	SW15	=	TST5	022126	SBDDAT	001126	SMBADR	000206			
SDPAR5=	172272	SW2	=	TST6	022406	SBELL	001214	SMFLG	006240			
SDPAR6=	172274	SW3	=	TST7	022566	SBIN	006316	SMNEW	005271			
SDPAR7=	172276	SW4	=	TYPBN	-	SCHARC	005772	SMGAD	001240			

\$MSGLG	001242	\$QUES	001220	\$SCOPE	003042	\$TMP4	001206	\$TYPE	005432
\$MSGTY	001224	\$RDCHR	004630	\$SETUP=	000137	\$TMP5	001210	\$TYPEC	005644
\$MSWR	005260	\$RDLIN	004760	\$STUP =	177777	\$TN =	000046	\$TYPEX	005774
\$MXCNT	001306	\$RDSZ =	000010	\$SVLAD	003216	\$TPB	001152	\$TYPOC	006344
\$NULL	001154	\$REGAD	001160	\$SVPC =	000204	\$TPFLG	001157	\$TYPON	006360
\$NWTST=	000001	\$REGO	001162	\$SWR =	173400	\$TPS	001150	\$TYPOS	006320
\$OCNT	006542	\$REG1	001164	\$SWREG	001246	\$TRAP	007206	\$UNIT	001236
\$OCTVL	007170	\$REG2	001166	\$SWRMK=	000000	\$TRAP2	007230	\$UNITM	000214
\$CMODE	006544	\$REG3	001170	\$TBIT	001310	\$TRP =	000015	\$USWR	001250
\$OVER	003252	\$REG4	001172	\$TESTN	001230	\$TRPAD	007242	\$XOFF =	000023
\$PASS	001232	\$REG5	001174	\$TKB	001146	\$TSTM	000210	\$XON =	000021
\$PASTM	000212	\$RESRE	007030	\$TKS	001144	\$TSTNM	001102	\$XTSTR	003054
\$PWRAD	007434	\$RTNAD	036322	\$TMP0	001176	\$TTYIN	005236	\$GET4=	000001
\$PWRDN	007274	\$RTRN	036316	\$TMP1	001200	\$TYPBN	006244	\$OFILL	006543
\$PWRMG	007430	\$SAVRE	006772	\$TMP2	001202	\$TYPDS	006546	.\$X -	000204
\$PWRUP	007346	\$SAVR6	007456	\$TMP3	001204				

. ABS. 036330 000
000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 55080 WORDS (216 PAGES)

DYNAMIC MEMORY: 20034 WORDS (77 PAGES)

ELAPSED TIME: 00:10:18

CKKTBD.BIN,CKKTBD/CR/-SP/NL:TOC=CKKTBD.MLB/ML,CKKTBD.P11

SYMBOL CROSS REFERENCE

SYMBOL	CROSS REFERENCE VALUE	REFERENCES
LSM7	= 007070	#15-1192 109-4603
DDISP	= 177570	#15-1197 20-1249 58-2106
DF1	016034	23-1392 24-1422 24-1434 24-1447 25-1458 25-1464 25-1471 25-1478 25-1485
DF12	016057	#55-2035 21-1254 21-1278 21-1284 21-1290 22-1301 22-1307 22-1320 23-1350 23-1360
DF2	016041	#55-2039 21-1260 24-1453 #55-2036
DF3	016050	21-1266 21-1272 22-1295 22-1313 22-1326 22-1332 22-1338 23-1367 23-1374
		23-1386 24-1403 24-1409 24-1428 24-1441 25-1491 25-1509 26-1514 26-1522
DF32	016065	#55-2037 23-1380 23-1398 #55-2040
DF5	016054	23-1343 24-1415 25-1497 25-1503 #55-2038
DH1	012672	21-1252 #53-1963
DH10	013042	21-1264 21-1270 #53-1965
DH12	013102	21-1276 #53-1966
DH13	013162	21-1282 #53-1967
DH14	013242	21-1288 #53-1968
DH15	013322	22-1293 #53-1969
DH16	013362	22-1299 #53-1970
DH17	013442	22-1305 #53-1971
DH2	012752	21-1258 #53-1964
DH20	013522	22-1311 22-1330 23-1341 26-1520 #53-1972
DH21	013562	22-1317 #53-1973
DH22	013677	22-1324 #53-1975
DH24	013737	22-1336 #53-1976
DH26	013777	23-1347 #53-1977
DH27	014111	23-1354 #53-1979
DH30	014306	23-1364 23-1371 24-1438 25-1468 25-1475 25-1482 #53-1984
DH32	014362	23-1378 23-1396 24-1451 25-1495 25-1501 #53-1986
DH33	014401	23-1384 #53-1987
DH34	014441	23-1390 #53-1988
DH36	014532	24-1401 #53-1989
DH37	014572	24-1407 #53-1990
DH40	014632	24-1413 #53-1991
DH41	014703	24-1419 #53-1992
DH42	015007	24-1426 #53-1994
DH43	015047	24-1432 24-1445 #53-1995
DH44	015117	25-1456 25-1462 25-1489 #53-1996
DH45	015157	#53-1997
DH55	015207	25-1507 #53-1998
DH57	015246	26-1512 #53-1999
DISPLA	001142	#20-1249 36-1785 37-1787 *58-2106 *58-2106
DISPRE	000174	#17-1246 58-2106
DOWELP	035316	*105-4410 105-4430 *105-4448 *105-4463 *105-4469 *105-4475 *105-4481 *105-4488 105-4491
		#105-4498
DSWR	= 177570	#15-1197 20-1249 58-2106
DT1	015306	21-1253 #54-2003
DT10	015344	21-1265 21-1271 #54-2005
DT12	015356	21-1277 #54-2006
DT13	015374	21-1283 #54-2007
DT14	015412	21-1289 #54-2008
DT15	015430	22-1294 #54-2009

SSI
SSISTI
ST
STI

STI

STI

STI

STI

STI

STI

STI

STI

STI

STI

STI

STI

STI

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
KDPDR0	=	172320	#15-1198
KDPDR1	=	172322	#15-1198 *73-2857 *74-3011
KDPDR2	=	172324	#15-1198 *73-2858 *74-3012
KDPDR3	=	172326	#15-1198 *73-2859 *74-3013
KDPDR4	=	172330	#15-1198 *77-3310 *89-3965 *95-4140 *96-4173
KDPDR5	=	172332	#15-1198
KDPDR6	=	172334	#15-1198
KDPDR7	=	172336	#15-1198
KERSTK	=	001100	#15-1211 27-1539 62-2305 64-2362 64-2366 64-2379 65-2433 65-2437 65-2450 66-2514 67-2570 67-2575 68-2636 68-2658 68-2684 70-2741 71-2798 74-3177 77-3319 79-3371 81-3473 85-3783 85-3844 87-3873
KIPAR0	=	172340	#15-1198 27-1547
KIPAR1	=	172342	#15-1198
KIPAR2	=	172344	#15-1198
KIPAR3	=	172346	#15-1198 *60-2152 *66-2501
KIPAR4	=	172350	#15-1198 *60-2153 *66-2502 *70-2730 *79-3362
KIPAR5	=	172352	#15-1198 *67-2545
KIPAR6	=	172354	#15-1198
KIPAR7	=	172356	#15-1198 27-1557
KIPDR0	=	172300	#15-1198 27-1535
KIPDR1	=	172302	#15-1198
KIPDR2	=	172304	#15-1198
KIPDR3	=	172306	#15-1198 *64-2355 *66-2503 *74-3014 *74-3176
KIPDR4	=	172310	#15-1198 *33-1732 *33-1736 *60-2163 *61-2234 *64-2360 *65-2431 *66-2504 *66-2528 *67-2546 *67-2615 *70-2732 *70-2762 *73-2856 *74-3010 *79-3366 *79-3434 *81-3466 *81-3535 *89-3972 *89-4003 *96-4181 *96-4214 *98-4246 *98-4279
KIPDR5	=	172312	#15-1198 *64-2356 *67-2547 *67-2616
KIPDR6	=	172314	#15-1198
KIPDR7	=	172316	#15-1198
KSP	=	%000006	#15-1205 28-1591 *28-1592 *28-1593 *28-1604 *28-1605 *33-1731 *39-1790 *39-1818 *39-1843 39-1845 *39-1846 *39-1850 *39-1851 *39-1857 39-1859 *39-1860 *39-1863 *39-1864 *39-1870 *39-1871 *56-2061 *56-2062 *56-2063 *56-2067 *56-2068 *57-2087 *57-2088 57-2089 *57-2095 *57-2096 *58-2110 *64-2362 *64-2366 *64-2379 *64-2401 *64-2402 *64-2410 *64-2411 *65-2433 *65-2437 *65-2450 *65-2472 *65-2473 *65-2481 *65-2482 *66-2514 *67-2570 *67-2575 *68-2636 *68-2658 *68-2684 *70-2741 71-2792 71-2793 *71-2798 *74-3177 *77-3306 *77-3319 79-3371 *79-3373 *80-3438 *80-3439 *80-3445 *80-3446 81-3473 *81-3475 *82-3539 *82-3540 *82-3546 *82-3547 *83-3567 *83-3572 *83-3578 *83-3647 *83-3648 *83-3654 *83-3655 *84-3662 *84-3667 *84-3673 *84-3744 *84-3745 *84-3751 *84-3752 85-3778 *85-3844 *86-3848 *86-3849 *86-3855 *86-3856 87-3868 *88-3938 *88-3939 *88-3945 *88-3946 *90-4012 *90-4013 *90-4016 *90-4017 *95-4143 95-4144 95-4145 95-4151 *95-4155 *97-4222 *97-4223 *97-4226 *97-4227 *99-4286 *99-4287 *99-4290 *99-4291
LF	=	000012	#15-1197 43-1903 43-1903
LOOP	=	020560	#58-2109 110-4609
MFPDLD	=	003004	*34-1767 *34-1768 #34-1774
MFPDLP	=	002770	#34-1770 34-1781 96-4183
MFPDPS	=	002772	#34-1771 *96-4184
MFPDTS	=	002746	#34-1765 96-4187 96-4194 96-4201 96-4207
MFPDVC	=	003040	34-1773 #34-1783 *96-4185
MFPDV1	=	033564	96-4185 #97-4219
MFPILD	=	002532	*32-1678 *32-1679 #32-1687
MFPILP	=	002516	#32-1683 32-1698 79-3384 81-3485 85-3792 87-3883 89-3974 98-4248

SP
ST

SW
TR
TY
TY
TY
TY
TY
TY
US
SS
SS
SS

SS
SS
SS
SS
E
E

.H
.K
.S
.S
.S
.S

SYMBOL	CROSS REFERENCE	REFERENCES
SYMBOL	VALUE	
MFPIPS	002520	#32-1684 *79-3386 *81-3486 *85-3793 *87-3884 *89-3975 *98-4249
MFPIPS	002464	#32-1676 79-3389 79-3396 79-3402 79-3408 79-3416 79-3423 79-3430 81-3490
		81-3497 81-3503 81-3509 81-3517 81-3524 81-3531 85-3797 85-3804 85-3810
		85-3816 85-3824 85-3831 85-3838 87-3888 87-3895 87-3901 87-3907 87-3915
		87-3922 87-3929 89-3978 89-3985 89-3992 89-3998 98-4252 98-4259 98-4266
		98-4272
MFPIVC	002622	32-1686 #32-1703 *79-3388 *81-3488 *85-3794 *87-3885 *89-3976 *98-4250
MFPIV1	027566	79-3388 #80-3438
MFPIV2	030164	81-3470 81-3488 #82-3539
MFPIV3	031674	85-3777 85-3794 #86-3848
MFPIV4	032304	87-3865 87-3885 #88-3938
MFPIV5	032562	89-3976 #90-4008
MFPIV6	034036	98-4250 #99-4283
MGMERR	016142	32-1688 33-1735 34-1775 #57-2079 58-2118 60-2216 61-2281 62-2301 62-2304
		64-2414 65-2485 66-2529 67-2617 70-2761 71-2831 77-3332 81-3472 83-3571
		83-3581 84-3666 84-3676 85-3779 87-3869
MGMFLG	016144	#57-2080 *57-2094 *58-2122
MMRO	= 177572	#15-1201 28-1594 *28-1602 *58-2124 *60-2167 *60-2198 *61-2238 *61-2269 *62-2297
		*73-2854 *73-2863 *73-2882 *73-2887 *73-2892 *73-2897 *73-2902 *73-2911 *73-2916
		*73-2922 *73-2927 *73-2932 *73-2937 *73-2942 *73-2947 *73-2952 *73-2957 *73-2963
		*73-2968 *73-2972 *73-2977 *73-2982 *73-2986 *73-2992 *73-2997 *74-3027 *74-3033
		*74-3037 *74-3043 *74-3055 *74-3081 *74-3087 *74-3093 *74-3099 *74-3103 *74-3108
		*74-3114 *74-3125 *74-3131 *74-3136 *74-3142 *74-3149 *74-3155 *74-3162 *74-3165
		*74-3172 *74-3175 *75-3191 *75-3197 *75-3203 *75-3206 *75-3211 *75-3215 *75-3221
		*75-3224 *75-3228 *75-3231 *76-3247 *76-3253 *76-3259 *76-3262 *76-3267 *76-3271
		*76-3276 *76-3279 *76-3284 *76-3287 *77-3307 *77-3321 *77-3331 *79-3361 *90-4008
		92-4075 94-4125 97-4219 99-4283 *100-4305 *100-4308 *101-4328 *101-4331 *102-4351
		*102-4354 *103-4374 *103-4377 *105-4416 *105-4422 *105-4441 *105-4443 *105-4449 *105-4454
		*105-4464 *105-4466 *105-4470 *105-4472 *105-4476 *105-4478 *105-4482 *105-4485 *105-4489
		*109-4599
MMR1	= 177574	#15-1202 28-1595 77-3322 90-4009 92-4076 94-4126 97-4220 99-4284
MMR2	= 177576	#15-1203 28-1596 77-3323 90-4010 92-4077 94-4127 97-4221 99-4285
MMR3	= 172516	#15-1204 *28-1582 *28-1606 *58-2125 *73-2864 *75-3189 *75-3232 *76-3245 *76-3288
		*77-3312 *77-3320 *89-3971 *89-4004 90-4011 *91-4034 *91-4071 *93-4084 *93-4121
		*96-4180 *96-4212 *98-4244 *98-4277 *100-4301 *101-4324 *102-4347 *103-4370 *104-4396
		*106-4518 *107-4536 *108-4554 *109-4569 *109-4600
MMVEC	= 000250	#15-1198 *32-1686 *32-1688 *33-1733 *33-1735 *34-1773 *34-1775 *58-2118 *58-2119
		*60-2162 *60-2216 *61-2233 *61-2281 *62-2296 *62-2301 *62-2304 *64-2359 *64-2372
		*64-2414 *65-2430 *65-2443 *65-2485 *66-2507 *66-2529 *67-2567 *67-2573 *67-2617
		*73-2861 *77-3302 *77-3303 *77-3332 *77-3333 *81-3470 *81-3472 *83-3568 *83-3571
		*83-3579 *83-3581 *84-3663 *84-3666 *84-3674 *84-3676 *85-3777 *85-3779 *87-3865
		*87-3869
MTPILD	002676	*33-1724 *33-1725 #33-1734
MTPILP	002654	#33-1728 33-1745 83-3583 84-3678 91-4036 93-4086
MTPIPM	002656	#33-1729 *83-3584 *84-3679 *91-4037 *93-4087
MTPITA	002720	*33-1726 #33-1738
MTPITS	002626	#33-1722 83-3587 83-3596 83-3604 83-3612 83-3622 83-3631 83-3640 84-3683
		84-3692 84-3700 84-3708 84-3718 84-3727 84-3737 91-4041 91-4049 91-4057
		91-4066 93-4091 93-4099 93-4107 93-4116
MTPIVC	002744	33-1733 #33-1747 *84-3680 *91-4038 *93-4088
MTPIV1	030614	83-3568 83-3579 #83-3647
MTPIV2	031260	84-3663 84-3674 84-3680 #84-3744

SYMBOL CROSS REFERENCE

SYMBOL	VALUE	REFERENCES								
MTPIV3	033022	91-4038	#92-4075							
MTPIV4	033242	93-4088	#94-4125							
NDFLAG	002242	#28-1584	*28-1603							
NODSPA	002232	#28-1581	73-2861							
PATCH	016232	#57-2100								
PBAHI	001302	#20-1249								
PBALO	001300	#20-1249								
PCSMPS	035320	*104-4397	105-4413	105-4431	105-4459	#105-4499	*106-4519	*107-4537	*108-4555	
PCSMRO	035324	*105-4407	#105-4501							
PCSMSP	035322	*105-4414	*105-4415	105-4467	#105-4500					
PFECDF	004302	39-1876	#39-1881							
PFECDH	004242	39-1876	#39-1878							
PFECDT	004272	39-1876	#39-1880							
PFECEM	004202	39-1876	#39-1877							
PFECWS	004172	39-1801	#39-1876							
PIRQ	= 177772	#15-1197								
PIRQVE	= 000240	#15-1197								
PRO	= 000000	#15-1197								
PR1	= 000040	#15-1197								
PR2	= 000100	#15-1197								
PR3	= 000140	#15-1197								
PR4	= 000200	#15-1197								
PR5	= 000240	#15-1197								
PR6	= 000300	#15-1197								
PR7	= 000340	#15-1197								
PS	= 177776	#15-1197	15-1197							
PSW	= 177776	#15-1197	29-1617	29-1619	32-1685	*32-1692	*32-1699	33-1730	34-1772	*58-2111
		*58-2113	*58-2115	60-2169	*60-2202	*60-2207	*60-2213	*60-2215	61-2240	*61-2273
		*61-2278	*61-2280	*62-2298	*68-2635	*68-2643	68-2650	*68-2652	*68-2657	*68-2660
		*68-2662	*68-2669	68-2676	*68-2678	*68-2683	*68-2686	*68-2688	*69-2701	69-2705
		*69-2707	*71-2788	*71-2797	*71-2799	*71-2801	*75-3190	*76-3246	*76-3290	77-3315
		77-3317	*79-3369	*81-3469	*83-3566	*83-3577	*84-3661	*84-3672	*85-3770	*85-3776
		*85-3842	*87-3860	*87-3867	*87-3933	*95-4141	*98-4278	*100-4302	*100-4309	*101-4325
		*101-4332	*102-4348	*102-4355	*103-4371	*104-4401	*105-4406	*105-4413	*105-4421	105-4437
		105-4444	105-4455	*106-4520	*106-4525	*107-4538	*107-4543	*108-4560	*109-4568	*109-4601
		51-1911	#51-1912							
PWRMSG	= 007460	#15-1197	*51-1911	*51-1911	*51-1911	*51-1911	*51-1911	*51-1911	*51-1911	*58-2106
PWRVEC	= 000024	40-1882	#50-1910							
RDCHR	= 104411	#50-1910								
RDLIN	= 104412	109-4572	#109-4607							
REGCHG	035770	109-4573	#109-4608							
REGDAT	036006	109-4576	109-4604	#109-4605	109-4605	109-4607	109-4607	109-4607	109-4607	109-4607
REGLAB	035764	109-4607	109-4607	109-4608	109-4608	109-4608	109-4608	109-4608	109-4608	
RESREG	= 104414	49-1909	#50-1910							
RESVEC	= 000010	#15-1197	*58-2106	58-2106	*58-2106	100-4303	*100-4304	*100-4307	101-4326	*101-4327
		*101-4330	102-4349	*102-4350	*102-4353	103-4372	*103-4373	*103-4376	*105-4411	105-4418
		*105-4418	*109-4574							
		*105-4409	105-4425	105-4496	#105-4508					
RETURN	035342	#15-1197	*58-2106	*58-2106	58-2106					
R6	=%000006	#15-1197								
R7	=%000007	#15-1197								
SAVREG	= 104413	49-1909	#50-1910							
SCOPE	= 000004	#15-1197	60-2150	61-2226	62-2294	64-2354	65-2427	66-2500	67-2544	68-2632

SYMBOL	CROSS REFERENCE VALUE	REFERENCES	70-2729	71-2777	73-2852	74-3008	75-3186	76-3242	77-3299	79-3359
		69-2697	70-2729	71-2777	73-2852	74-3008	75-3186	76-3242	77-3299	79-3359
		81-3462	83-3563	84-3657	85-3768	87-3858	89-3962	91-4033	93-4081	95-4139
		96-4169	98-4240	100-4300	101-4323	102-4346	103-4369	104-4392	106-4517	107-4535
		108-4553	109-4567	110-4609						
SDPAR0	= 172260	#15-1198	27-1560	*104-4395	*104-4402					
SDPAR1	= 172262	#15-1198								
SDPAR2	= 172264	#15-1198								
SDPAR3	= 172266	#15-1198								
SDPAR4	= 172270	#15-1198	*96-4170							
SDPAR5	= 172272	#15-1198								
SDPAR6	= 172274	#15-1198								
SDPAR7	= 172276	#15-1198								
SDPDR0	= 172220	#15-1198								
SDPDR1	= 172222	#15-1198	*75-3187	*75-3198						
SDPDR2	= 172224	#15-1198								
SDPDR3	= 172226	#15-1198								
SDPDR4	= 172230	#15-1198	*89-3966	*96-4177	*98-4245					
SDPDR5	= 172232	#15-1198								
SDPDR6	= 172234	#15-1198								
SDPDR7	= 172236	#15-1198	27-1543							
SIPAR0	= 172240	#15-1198	27-1559	*68-2666	*68-2685	*106-4521	*106-4526			
SIPAR1	= 172242	#15-1198								
SIPAR2	= 172244	#15-1198								
SIPAR3	= 172246	#15-1198	*60-2154							
SIPAR4	= 172250	#15-1198	*60-2155	*79-3363						
SIPAR5	= 172252	#15-1198								
SIPAR6	= 172254	#15-1198								
SIPAR7	= 172256	#15-1198	27-1562							
SIPDR0	= 172200	#15-1198	27-1541							
SIPDR1	= 172202	#15-1198								
SIPDR2	= 172204	#15-1198								
SIPDR3	= 172206	#15-1198	*75-3199	*75-3233						
SIPDR4	= 172210	#15-1198	*60-2164	*61-2235	*83-3564	*85-3775	*85-3843	*93-4082	*96-4174	
SIPDR5	= 172212	#15-1198								
SIPDR6	= 172214	#15-1198								
SIPDR7	= 172216	#15-1198								
SRO	= 177572	#15-1198	15-1201	57-2090	*57-2092	60-2183	61-2254	62-2306	62-2309	*62-2326
			64-2380	*64-2396	64-2403	*64-2405	65-2451	*65-2467	65-2474	*65-2476
			67-2571	67-2576	67-2592	*67-2606	70-2743	*70-2759	71-2794	*71-2796
			*80-3442	82-3541	*82-3543	83-3649	*83-3651	84-3746	*84-3748	86-3850
			88-3940	*88-3942						*86-3852
SR1	= 177574	#15-1198	15-1202							
SR2	= 177576	#15-1198	15-1203	57-2091	60-2184	61-2255	62-2303	64-2381	64-2404	65-2452
			65-2475	66-2515	67-2549	67-2558	67-2572	67-2596	67-2607	70-2744
			71-2795	80-3441	82-3542	83-3650	84-3747	86-3851	88-3941	
SR3	= 172516	#15-1198	15-1204							
SSP	X000006	#15-1206	*58-2112	*68-2670	*68-2687	79-3370	*83-3569	83-3570	*83-3580	85-3780
			*85-3782	*104-4398	105-4426	*106-4522	*107-4540	*108-4557		
STACK	= 001100	#15-1197	15-1211	15-1212	15-1213	58-2106	58-2110	95-4142	95-4155	
START	= 020000		17-1246	51-1911	*58-2106					
STKLMT	= 177774	#15-1197								
SUPERM	= 035340	105-4446	#105-4507							

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES								
SUPSTK	=	000700	#15-1212	58-2112	68-2670	68-2687	79-3374	83-3578	85-3780	104-4398	106-4522
SWR	=	001140	#20-1249	36-1785	36-1785	36-1785	36-1785	37-1787	37-1787	37-1787	37-1787
			40-1882	40-1882	51-1911	51-1911	58-2106	*58-2106	58-2106	*58-2106	*58-2106
			58-2107	105-4493	110-4609						
SWREG		000176	#17-1246	40-1882	40-1882	58-2106	58-2107				
SW0	=	000001	#15-1197								
SW00	=	000001	#15-1197	15-1197							
SW01	=	000002	#15-1197	15-1197							
SW02	=	000004	#15-1197	15-1197							
SW03	=	000010	#15-1197	15-1197							
SW04	=	000020	#15-1197	15-1197							
SW05	=	000040	#15-1197	15-1197							
SW06	=	000100	#15-1197	15-1197							
SW07	=	000200	#15-1197	15-1197							
SW08	=	000400	#15-1197	15-1197							
SW09	=	001000	#15-1197	15-1197							
SW1	=	000002	#15-1197								
SW10	=	002000	#15-1197								
SW11	=	004000	#15-1197								
SW12	=	010000	#15-1197								
SW13	=	020000	#15-1197								
SW14	=	040000	#15-1197								
SW15	=	100000	#15-1197								
SW2	=	000004	#15-1197								
SW3	=	000010	#15-1197								
SW4	=	000020	#15-1197								
SW5	=	000040	#15-1197								
SW6	=	000100	#15-1197								
SW7	=	000200	#15-1197								
SW8	=	000400	#15-1197								
SW9	=	001000	#15-1197								
TBIT	=	000020	#15-1208	29-1617	29-1622	30-1634					
TBITPS	=	001274	#20-1249	*29-1620	30-1634	30-1636	*30-1637	*58-2123			
TBITVE	=	000014	#15-1197	*58-2106	*58-2106						
TESTNO	=	001254	#20-1249	*37-1787	54-2003	54-2004	54-2005	54-2006	54-2007	54-2008	54-2009
			54-2010	54-2011	54-2012	54-2013	54-2014	54-2015	54-2016	54-2017	54-2018
			54-2019	54-2020	54-2021	54-2022	54-2023	54-2024	54-2025	54-2026	54-2027
			54-2028	54-2029	54-2030	54-2031	54-2032				
			56-2053	58-2116	68-2689	70-2760	71-2829				
TIMERR	=	016070	#56-2054	*56-2065	*58-2121						
TIMFLG	=	016072	#15-1197								
TKVEC	=	000060	#29-1617	68-2633	71-2778	77-3300					
TOFF	=	002356	#30-1634	68-2690	71-2833						
TON	=	002412	#15-1197								
TPVEC	=	000064	#20-1249	*28-1592	28-1605	54-2003	54-2004	*56-2061	56-2068	*57-2087	57-2096
TRAPPC	=	001260	*64-2401	64-2411	*65-2472	65-2482	*80-3438	80-3446	*82-3539	82-3547	*83-3647
			83-3655	*84-3744	84-3752	*86-3848	86-3856	*88-3938	88-3946	*90-4012	90-4017
			*97-4222	97-4227	*99-4286	99-4291					
			#20-1249	*28-1593	28-1604	54-2003	54-2004	*56-2062	56-2067	*57-2088	57-2095
			*64-2402	64-2410	*65-2473	65-2481	*80-3439	80-3445	*82-3540	82-3546	*83-3648
			83-3654	*84-3745	84-3751	*86-3849	86-3855	*88-3939	88-3945	*90-4013	90-4016
			*97-4223	97-4226	*99-4287	99-4290					

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
TRAPVE	=	000034	#15-1197 *58-2106 *58-2106
TRTVEC	=	000014	#15-1197
TST1		020704	#60-2150
TST10		023160	#68-2632
TST11		023462	#69-2697
TST12		023552	69-2715 #70-2729
TST13		023742	#71-2777
TST14		024256	#73-2852
TST15		025234	#74-3008
TST16		026272	#75-3186
TST17		026542	#76-3242
TST2		021222	#61-2226
TST20		027016	#77-3299
TST21		027232	#79-3359
TST22		027634	79-3435 #81-3462
TST23		030232	81-3536 #83-3563
TST24		030662	83-3645 #84-3657
TST25		031326	84-3742 #85-3768
TST26		031742	85-3845 #87-3858
TST27		032352	87-3935 #89-3962
TST3		021456	#62-2294
TST30		032636	89-4005 #91-4033
TST31		033042	91-4072 #93-4081
TST32		033262	93-4122 #95-4139
TST33		033332	#96-4169
TST34		033632	96-4216 #98-4240
TST35		034104	98-4280 #100-4300
TST36		034174	100-4314 #101-4323
TST37		034266	101-4337 #102-4346
TST4		021632	#64-2354
TST40		034360	102-4360 #103-4369
TST41		034446	103-4382 #104-4392
TST42		035344	104-4403 #106-4517
TST43		035420	#107-4535
TST44		035474	#108-4553
TST45		035542	#109-4567
TST5		022126	#65-2427
TST6		022406	#66-2500
TST7		022566	#67-2544
TYPBN	=	104406	39-1838 #50-1910
TYPDS	=	104405	39-1832 41-1894 #50-1910 110-4609 110-4609
TYPE	=	104401	37-1787 37-1787 39-1789 39-1810 39-1812 39-1815 39-1817 39-1847 39-1861
			39-1867 39-1872 40-1882 40-1882 40-1882 40-1882 40-1882 40-1882
			40-1882 40-1882 40-1882 40-1882 40-1882 40-1882 40-1882 40-1882
			40-1882 41-1888 41-1892 43-1903 45-1905 46-1906 47-1907 #50-1910 51-1911
			58-2107 58-2108 110-4609 110-4609 110-4609
			39-1797 39-1826 40-1882 41-1891 #50-1910
TYPQC	=	104402	39-1797 39-1826 40-1882 41-1891 #50-1910
TYPON	=	104404	#50-1910
TYPOS	=	104403	#50-1910
UDPAR0	=	177660	#15-1198 27-1566 *107-4539 *107-4544
UDPAR1	=	177662	#15-1198
UDPAR2	=	177664	#15-1198

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
UDPAR3	=	177666	#15-1198
UDPAR4	=	177670	#15-1198 *98-4241
UDPAR5	=	177672	#15-1198
UDPAR6	=	177674	#15-1198
UDPAR7	=	177676	#15-1198
UDPDR0	=	177620	#15-1198
UDPDR1	=	177622	#15-1198 *76-3243 *76-3254
UDPDR2	=	177624	#15-1198
UDPDR3	=	177626	#15-1198
UDPDR4	=	177630	#15-1198 *89-3967 *96-4175 *96-4215
UDPDR5	=	177632	#15-1198
UDPDR6	=	177634	#15-1198
UDPDR7	=	177636	#15-1198
UIPAR0	=	177640	#15-1198 27-1565 *68-2640 *68-2659 *108-4556 *108-4561
UIPAR1	=	177642	#15-1198
UIPAR2	=	177644	#15-1198
UIPAR3	=	177646	#15-1198 *60-2156 *71-2779
UIPAR4	=	177650	#15-1198 *60-2157 *71-2780 *81-3464 *84-3659
UIPAR5	=	177652	#15-1198
UIPAR6	=	177654	#15-1198
UIPAR7	=	177656	#15-1198
UIPDR0	=	177600	#15-1198 27-1545
UIPDR1	=	177602	#15-1198
UIPDR2	=	177604	#15-1198
UIPDR3	=	177606	#15-1198 *71-2781 *71-2832 *76-3255 *76-3289
UIPDR4	=	177610	#15-1198 *60-2165 *61-2236 *71-2782 *84-3658 *87-3866 *87-3934 *89-3968 *93-4083
			*96-4176
UIPDR5	=	177612	#15-1198
UIPDR6	=	177614	#15-1198
UIPDR7	=	177616	#15-1198
USESTK	=	000600	#15-1213 58-2114 68-2644 68-2661 71-2800 81-3476 84-3673 87-3870 107-4540
			108-4557
USP	=	X000006	#15-1207 *58-2114 *68-2644 *68-2661 *71-2789 *71-2800 81-3471 *84-3664 84-3665
			*84-3675 87-3870 *87-3872
VIRT1		001276	#20-1249
WASR6		001256	#20-1249 54-2003 54-2004 *56-2063 *57-2089
WASSRO		001264	#20-1249 *28-1594 28-1597 54-2004 54-2006 54-2008 54-2010 54-2013 54-2014
			54-2016 54-2017 54-2021 54-2023 54-2026 *57-2090 *60-2183 60-2185 *61-2254
			61-2256 *62-2309 *64-2380 64-2383 *64-2403 *65-2451 65-2454 *65-2474 *67-2576
			67-2578 *67-2592 67-2593 *70-2743 70-2746 *71-2794 71-2813 *80-3440 *82-3541
			*83-3649 *84-3746 *86-3850 *88-3940 *90-4008 *97-4219 *99-4283
WASSR1		001266	#20-1249 *28-1595 54-2023 54-2026 *90-4009 *97-4220 *99-4284
WASSR2		001270	#20-1249 *28-1596 54-2004 54-2007 54-2008 54-2011 54-2012 54-2013 54-2014
			54-2016 54-2017 54-2023 54-2026 *57-2091 *60-2184 60-2192 *61-2255 61-2263
			*62-2303 62-2312 62-2314 *64-2381 64-2390 *64-2404 *65-2452 65-2461 *65-2475
			*66-2515 66-2516 *67-2549 67-2551 *67-2558 67-2560 *67-2577 67-2581 *67-2596
			67-2597 *67-2607 67-2609 *70-2744 70-2750 *71-2795 71-2816 *80-3441 *82-3542
			*83-3650 *84-3747 *86-3851 *88-3941 *90-4010 *97-4221 *99-4285
WASSR3		001272	#20-1249 *90-4011
WBIT	=	000100	#15-1209
\$APTHD		000204	19-1248 #19-1248
\$ASTAT	=	*****	44-1904 44-1904

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES	CREF	V01						
SESCAP		001212	#20-1249	*36-1785	37-1787	37-1787	38-1787	38-1787	*58-2106		
SETABL		001244	#20-1249								
SETEND		001254	19-1248	#20-1249							
SFATAL		001226	#20-1249	*44-1904							
SFFLG		006242	*44-1904	*44-1904	44-1904	*44-1904	#44-1904				
SFILLC		001156	#20-1249	43-1903	43-1903	43-1903					
SFILLS		001155	#20-1249	43-1903	43-1903						
SGADR		001120	#20-1249								
SGDAT		001124	#20-1249								
SGET42		036224	110-4609	110-4609	#110-4609						
SGTSWR		004356	#40-1882	50-1910	50-1910						
SHD	=	000000	15-1195	15-1195	15-1195						
SHIBTS		000204	#19-1248								
SICNT		001104	#20-1249								
SILLUP		007452	51-1911	51-1911	#51-1911						
SINTAG		001135	#20-1249	40-1882	40-1882	40-1882	40-1882				
SITEMB		001114	#20-1249	*37-1787	37-1787	37-1787	*37-1787	37-1787	38-1787	38-1787	39-1792
SLF		001222	#20-1249	38-1787	38-1787	40-1882	40-1882	40-1882	43-1903	43-1903	
SLFLG		006241	*44-1904	#44-1904							
SLOOP		036320	110-4609	#110-4609							
SLPADR		001106	#20-1249	*36-1785	*36-1785	36-1785	36-1785	36-1785	*58-2106		
SLPERR		001110	#20-1249	36-1785	*36-1785	36-1785	36-1785	36-1785	37-1787	*58-2106	*60-2166
			*62-2295	*64-2361	*64-2365	*64-2371	*65-2432	*65-2436	*65-2442	*66-2508	*67-2548
			*67-2557	*67-2566	*68-2634	*69-2699	*70-2735	*71-2787	*73-2862	*73-2886	*73-2895
			*73-2909	*73-2920	*73-2931	*73-2940	*73-2950	*73-2960	*73-2971	*73-2980	*73-2989
			*74-3022	*74-3036	*74-3047	*74-3086	*74-3098	*74-3107	*74-3124	*74-3134	*74-3148
			*74-3158	*74-3168	*75-3188	*75-3202	*75-3209	*75-3218	*75-3227	*76-3244	*76-3258
			*76-3265	*76-3274	*76-3282	*77-3301	*79-3368	*79-3384	*81-3468	*81-3485	*83-3583
			*84-3678	*85-3769	*85-3792	*87-3859	*87-3883	*89-3974	*91-4036	*93-4086	*96-4183
			*98-4248	*105-4412							
SMAIL		001224	19-1248	19-1248	#20-1249	36-1785	37-1787	43-1903	58-2106	58-2107	
SMBADR		000206	#19-1248								
SMFLG		006240	*44-1904	44-1904	*44-1904	#44-1904					
SMNEW		005271	40-1882	#40-1882							
SMSGAD		001240	#20-1249	*44-1904	44-1904						
SMSGLG		001242	#20-1249	*44-1904							
SMSGTY		001224	#20-1249	44-1904	*44-1904	44-1904	*44-1904				
SMSWR		005260	40-1882	#40-1882							
SMXCNT		001306	#20-1249								
SNULL		001154	#20-1249	43-1903	43-1903	43-1903					
SNWTST	=	000001	#59-2150	59-2150	#60-2150	60-2150	#60-2226	60-2226	#61-2226	61-2226	#61-2294
			61-2294	#62-2294	62-2294	#63-2354	63-2354	#64-2354	64-2354	#64-2427	64-2427
			#65-2427	65-2427	#65-2500	65-2500	#66-2500	66-2500	#66-2544	66-2544	#67-2544
			67-2544	#67-2632	67-2632	#68-2632	68-2632	#68-2697	68-2697	#69-2697	69-2697
			#69-2729	69-2729	#70-2729	70-2729	#70-2777	70-2777	#71-2777	71-2777	#72-2852
			72-2852	#73-2852	73-2852	#73-3008	73-3008	#74-3008	74-3008	#74-3186	74-3186
			#75-3186	75-3186	#75-3242	75-3242	#76-3242	76-3242	#76-3299	76-3299	#77-3299
			77-3299	#78-3359	78-3359	#79-3359	79-3359	#80-3462	80-3462	#81-3462	81-3462
			#82-3563	82-3563	#83-3563	83-3563	#83-3657	83-3657	#84-3657	84-3657	#84-3768
			84-3768	#85-3768	85-3768	#86-3858	86-3858	#87-3858	87-3858	#88-3962	88-3962
			#89-3962	89-3962	#90-4033	90-4033	#91-4033	91-4033	#92-4081	92-4081	#93-4081
			93-4081	#94-4139	94-4139	#95-4139	95-4139	#95-4169	95-4169	#96-4169	96-4169

SYMBOL	CROSS REFERENCE	SYMBOL	VALUE	REFERENCES
				65-2427 66-2500 67-2544 68-2632 69-2697 70-2729 71-2777 73-2852 74-3008
				75-3186 76-3242 77-3299 79-3359 81-3462 83-3563 84-3657 85-3768 87-3858
				89-3962 91-4033 93-4081 95-4139 96-4169 98-4240 100-4300 101-4323 102-4346
				103-4369 104-4392 106-4517 107-4535 108-4553 109-4567 110-4609 110-4609 110-4609
\$SWREG	001246			#20-1249 58-2106
\$SWRMK	= 000000			15-1196 15-1196 15-1196 15-1196 15-1196 15-1196 15-1196 15-1196 15-1196
				36-1785 36-1785 36-1785 36-1785 36-1785 36-1785 36-1785 36-1785 36-1785
\$TBIT	001310			#20-1249 *51-1911 *58-2106 *110-4609 110-4609 110-4609
\$TESTN	001230			#20-1249 *36-1785 39-1880
\$TKB	001146			#20-1249 40-1882 40-1882 40-1882 40-1882 40-1882 40-1882 43-1903 43-1903
				43-1903 43-1903
\$TKS	001144			#20-1249 40-1882 40-1882 40-1882 40-1882 40-1882 40-1882 40-1882 40-1882
				43-1903 43-1903 43-1903 43-1903
\$TMP0	001176			#20-1249 *32-1681 32-1693 32-1700 54-2005 54-2006 54-2007 54-2013 54-2018
				54-2029 54-2031 54-2032 *60-2169 60-2199 60-2204 *61-2240 61-2270 61-2275
				*67-2571 67-2578 *71-2802 *71-2808 *71-2812 *71-2815 *71-2819 71-2820 *105-4483
				*109-4582
\$TMP1	001200			#20-1249 *32-1682 32-1694 32-1701 54-2032 *67-2568 *67-2580 *67-2583 67-2584
				*67-2590 *67-2595 *67-2599 67-2600 *70-2742 *70-2748 *70-2752 70-2753 *109-4578
				109-4585
\$TMP2	001202			#20-1249 54-2013 *67-2572 67-2581 *79-3414 79-3415 *79-3428 79-3429 *81-3515
				81-3516 *81-3529 81-3530 83-3620 *83-3621 83-3625 *83-3638 83-3639 83-3642
				84-3716 *84-3717 84-3721 *84-3734 84-3736 84-3739 *85-3822 85-3823 *85-3836
				85-3837 *87-3913 87-3914 *87-3927 87-3928 *109-4590
\$TMP3	001204			#20-1249 *100-4303 100-4307 *101-4326 101-4330 *102-4349 102-4353 *103-4372 103-4376
				*109-4587 109-4594
\$TMP4	001206			#20-1249 *39-1855 39-1857 *109-4588 109-4593
\$TMP5	001210			#20-1249 *39-1856 *41-1886 *41-1887 41-1893 *109-4589 109-4592
\$TN	= 000046			#15-1184 15-1195 59-2150 60-2150 *60-2150 60-2226 61-2226 #61-2226 61-2294
				62-2294 #62-2294 63-2354 64-2354 *64-2354 64-2427 65-2427 #65-2427 65-2500
				66-2500 #66-2500 66-2544 67-2544 *67-2544 67-2632 68-2632 #68-2632 68-2697
				69-2697 #69-2697 69-2715 69-2729 70-2729 #70-2729 70-2777 71-2777 #71-2777
				72-2852 73-2852 #73-2852 73-3008 74-3008 #74-3008 74-3186 75-3186 #75-3186
				75-3242 76-3242 #76-3242 76-3299 77-3299 #77-3299 78-3359 79-3359 #79-3359
				79-3435 80-3462 81-3462 #81-3462 81-3536 82-3563 83-3563 #83-3563 83-3645
				83-3657 84-3657 #84-3657 84-3742 84-3768 85-3768 #85-3768 85-3845 86-3858
				87-3858 #87-3858 87-3935 88-3962 89-3962 #89-3962 89-4005 90-4033 91-4033
				#91-4033 91-4072 92-4081 93-4081 #93-4081 93-4122 94-4139 95-4139 #95-4139
				95-4169 96-4169 #96-4169 96-4216 97-4240 98-4240 #98-4240 98-4280 99-4300
				100-4300 #100-4300 100-4314 100-4323 101-4323 #101-4323 101-4337 101-4346 102-4346
				#102-4346 102-4360 102-4369 103-4369 #103-4369 103-4382 103-4392 104-4392 #104-4392
				105-4517 106-4517 #106-4517 106-4535 107-4535 #107-4535 107-4553 108-4553 #108-4553
				108-4567 109-4567 #109-4567
\$TPB	001152			#20-1249 43-1903 43-1903 43-1903
\$TPFLG	001157			#20-1249 43-1903 43-1903 43-1903
\$TPS	001150			#20-1249 43-1903 43-1903 43-1903
\$TRAP	007206			#50-1910 58-2106
\$TRAP2	007230			#50-1910 50-1910
\$TRP	= 000015			#50-1910 50-1910 50-1910 50-1910 50-1910 50-1910 #50-1910 50-1910 50-1910 50-1910

SYMBOL	CROSS REFERENCE VALUE	REFERENCES	50-1910	50-1910	50-1910	50-1910	50-1910	50-1910	50-1910	50-1910
		50-1910	50-1910	#50-1910	50-1910	50-1910	50-1910	50-1910	#50-1910	50-1910
		50-1910	50-1910	50-1910	#50-1910	50-1910	50-1910	50-1910	50-1910	#50-1910
		50-1910	50-1910	50-1910	50-1910	#50-1910	50-1910	50-1910	50-1910	50-1910
		#50-1910	50-1910	50-1910	50-1910	50-1910	#50-1910	50-1910	50-1910	50-1910
		50-1910	#50-1910	50-1910	50-1910	50-1910	50-1910	50-1910	#50-1910	50-1910
		50-1910	#50-1910	50-1910	50-1910	50-1910	50-1910	50-1910	#50-1910	50-1910
STRPAD	007242									
\$TSTM	000210	#19-1248								
\$TSTNM	001102	#20-1249	36-1785	36-1785	*36-1785	36-1785	36-1785	36-1785	36-1785	37-1787
		37-1787	38-1787	38-1787	41-1889	*110-4609				
		40-1882	40-1882	40-1882	40-1882	40-1882	#40-1882			
\$TTYIN	005236	#45-1905	50-1910	50-1910						
\$TYPBN	006244	#47-1907	50-1910	50-1910						
\$TYPDS	006546	#43-1903	44-1904	50-1910	50-1910					
\$TYPE	005432	40-1882	43-1903	43-1903	43-1903	43-1903	#43-1903			
\$TYPEC	005644	43-1903	43-1903	43-1903	#43-1903					
\$TYPEX	005774	#46-1906	50-1910	50-1910						
\$TYPOC	006344	46-1906	#46-1906	50-1910						
\$TYPON	006360	#46-1906	50-1910	50-1910						
\$TYPOS	006320	#46-1906	50-1910							
\$UNIT	001236	#20-1249								
\$UNITM	000214	#19-1248								
\$USWR	001250	#20-1249								
\$XOFF	= 000023	43-1903	43-1903							
\$XON	= 000021	40-1882	43-1903	43-1903	43-1903					
\$XTSTR	= 003054	#36-1785								
\$SGT4	= 000001	#110-4609	#110-4609	110-4609						
\$OFILL	006543	*46-1906	*46-1906	46-1906	#46-1906					
\$4OCAT	= *****	36-1785	37-1787							
.\$ASTA	= *****	44-1904	44-1904							
.\$X	= 000204	#19-1248	19-1248							

MACRO CROSS REFERENCE

MACRO NAME	REFERENCES									
COMMEN	#15-1197									
ENDCOM	#15-1197									
ESCAPE	#15-1197									
GETPRI	#15-1197	110-4609								
GETSWR	#15-1197	#58-2107	58-2107							
MES350	#99-4293	100-4300								
MES351	#100-4316	#101-4323								
MES352	#101-4339	102-4346								
MES353	#102-4362	#103-4369								
MES354	#103-4384	#104-4392								
MES355	#105-4509	106-4517								
MES356	#106-4527	#107-4535								
MES357	#107-4545	#108-4553	#108-4562	#109-4567						
MSG30	#59-2142	60-2150								
MSG31	#60-2218	#61-2226								
MSG31A	#61-2283	62-2294								
MSG32	#63-2343	#64-2354								
MSG33	#64-2416	65-2427								
MSG34	#65-2487	66-2500								
MSG35	#66-2531	#67-2544								
MSG36	#67-2619	68-2632								
MSG36A	#68-2691	69-2697								
MSG37	#69-2718	#70-2729								
MSG40	#70-2763	#71-2777								
MSG40A	#76-3291	#77-3299								
MSG40B	#72-2837	73-2852								
MSG40C	#73-2998	#74-3008								
MSG40D	#74-3178	#75-3186								
MSG40E	#75-3234	76-3242								
MSG41	#78-3345	#79-3359								
MSG41A	#80-3448	81-3462								
MSG42	#82-3549	#83-3563	#84-3657							
MSG43	#84-3754	#85-3768	#87-3858							
MSG43A	#88-3948	89-3962								
MSG44	#90-4019	#91-4033	#93-4081							
MSG45	#94-4131	95-4139								
MSG46	#95-4156	#96-4169								
MSG47	#97-4229	98-4240								
MULT	#15-1197									
NEWST	#15-1178	#15-1197	#59-2150	#60-2226	#61-2294	#63-2354	#64-2427	#65-2500	#66-2544	#67-2632
	#68-2697	#69-2729	#70-2777	#72-2852	#73-3008	#74-3186	#75-3242	#76-3299	#78-3359	#80-3462
	#82-3563	#83-3657	#84-3768	#86-3858	#88-3962	#90-4033	#92-4081	#94-4139	#95-4169	#97-4240
	#99-4300	#100-4323	#101-4346	#102-4369	#103-4392	#105-4517	#106-4535	#107-4553	#108-4567	
POP	#15-1197	#44-1904	#44-1904	#47-1907	#48-1908	#51-1911	#51-1911			
PUSH	#15-1197	44-1904	44-1904	44-1904	47-1907	48-1908	51-1911	51-1911		
REPORT	#15-1197									
SAVR	#15-1166	#37-1787								
SETPRI	#15-1197									
SETTRA	#50-1910	50-1910	50-1910	50-1910	50-1910	50-1910	50-1910	50-1910	50-1910	50-1910
	50-1910	50-1910	50-1910							
SETUP	#15-1197	58-2106								
SKIP	#15-1197	69-2715	79-3435	81-3536	83-3645	84-3742	85-3845	87-3935	89-4005	91-4072

MACRO CROSS REFERENCE

MACRO NAME	REFERENCES
.SAPT8	#20-1249 #20-1249
.SAPTH	#15-1181 #18-1248
.SAPTY	#15-1181 43-1904
.SCATC	#15-1179 16-1246
.SCMTA	#15-1179 19-1249
.SDB20	#15-1182 #48-1909
.SEOP	#15-584 110-4609
.SERRO	#15-771 37-1787
.SPOWE	#15-1180 50-1911
.SREAD	#15-1181 #40-1882
.SSAVE	#15-1182 #47-1908
.SSCOP	#15-950 #36-1785
.STRAP	#15-1180 49-1910
.STYPB	#15-1181 #44-1905
.STYPD	#15-1180 #46-1907
.STYPE	#15-1179 #42-1903
.STYPO	#15-1180 45-1906