

# Indigo™

## AV MIXER

Audio

by Rolf Grzibek

Software Version 1.2.18

Document Order Number:  
Printing: **May 2008**

## ***Published by***

### **Grass Valley Germany GmbH**

Brunnenweg 9  
D-64331 Weiterstadt, Germany  
P.O. Box 1165

Tel: +49 (0) 6150-104-0  
Fax: +49 (0) 6150-104-300

Web Site: [www.thomsongrassvalley.com](http://www.thomsongrassvalley.com)

## ***Trademarks***

All product names mentioned in this manual are the trademarks of their respective owners.

## ***Copyrights***

Information in this document is subject to change without notice. This document and any updates and/or supplemental information, including any copies thereof, cannot be reproduced, neither communicated to a third party, without written authorization from Grass Valley Germany GmbH.

Please notify Grass Valley Germany GmbH of any errors in this document. We also would appreciate any comments you have to improve this manual.

© Grass Valley Germany GmbH 2008. All rights reserved.

# ***Revision Report***

## **NOTE**

Before reading the entire manual, please check for any supplements at the end of the manual!

Item	Rev	Date	Serial No	Pages affected	Contents	Remarks

<b>1</b>	<b>AUDIO PROCESSING .....</b>	<b>5</b>
1.1	OVERVIEW .....	5
1.2	SETUP .....	7
1.2.1	Operation Mode .....	7
1.2.2	Input .....	9
1.2.3	Fader Assignment.....	11
1.2.4	Output.....	12
1.2.5	Audio Follow Video.....	13
1.2.6	Delay .....	14
1.2.7	Audio Dynamics .....	15
1.3	OPERATION.....	15
1.3.1	Mixing .....	15
1.3.2	Channel Adjust.....	19
1.3.3	Channel Dynamics .....	20
1.3.4	Output.....	23
1.3.5	Presets Clipboard.....	24
1.4	TIPS & TRICKS .....	25
1.4.1	Delay .....	25
1.4.2	Equalizer.....	25
1.4.3	Dynamics.....	28
1.5	TECHNICAL NOTES .....	37
1.5.1	Connections.....	37
1.5.2	Mixer .....	37
1.6	GLOSSARY .....	38

# 1 Audio Processing

Audio is an important part of any audio-visual presentation or TV production. The Indigo AV Mixer has powerful and unique tools included to meet the requirement of many productions.

As you read through each section, note that the Tips & Tricks information and Glossary provide additional definitions and use cases for each of these features.

## 1.1 Overview

Because of its number and type of inputs and outputs as well as its processing capabilities the audio mixer in the Indigo is ideally suited for the following types of production:

- live presentations like sales trainings, shareholder meetings, Houses of Worship, etc.




Figure 1

- arena / stadium image magnification

- Unilateral TV production at international events e.g. Olympic Games, world championships, etc.




Figure 2

- linear editing
- manual Master Control rooms

Motorized Faders with touch sense, Level indicators, and channel On and PFL buttons on the control panel as well as clear menus with touch screen interaction provide the necessary controls for easy and familiar operation.

Audio inputs and outputs include

- balanced analogue audio
- unbalanced analogue audio
- AES/EBU audio (110 ohm; 75 ohm with a balun)
- embedded audio

This allows connecting a variety of audio sources:

- consumer CD and DVD players
- professional CD and DVD players
- Video Servers/Tape recorders
- Audio Servers
- dynamic microphones
- condenser microphones

Indigo allows connecting up to eight line level or digital stereo sources and up to four microphones – see section 1.2.1 Operation Mode for details.

Indigo does not contain a power amplifier, because the power requirements differ too much from location to location and the power amplifier would add space, weight and heat. Use an external Public Address system, power amplifier or active speakers instead.

Audio processing capabilities include

- 48 kHz sample rate
- 24 bits resolution
- stereo and mono channels
- submix
- equalizer (4-band parametric)
- low-cut filter
- dynamics ( compressor, limiter, expander, gate with look-ahead and stereo processing)
- delay
- output limiter

Indigo generates three output signals:

- **Main**  
The Main out – as the name says – is the signal that goes to the Public Address system, the transmitter or the recording device.
- **Sub**  
The Sub out carries a selectable signal (either main mix or sub mix) which can be delayed.
- **Phones**  
The Phones out is used by the operator for pre-listening. The output has an amplifier for headphones.

The next sections guide through the setup and the operation of the audio mixer.

## **1.2 Setup**

The setup topics are explained below in a logical order – not necessarily in the order of the menus.

The Operation Mode determines the architecture of the mixer and defines how many and what type of mixer channels are available.

Next, Inputs are routed to mixer channels, and (physical) Faders are assigned to mixer channels and/or output faders.

Output levels and audio re-embedding is set in 1.2.4 Output.

Associated audio for audio-follow-video operation is set in 1.2.5 Audio Processing.

### **1.2.1 Operation Mode**

The Operation Mode determines the architecture of the mixer and defines how many and what type of mixer channels are available.




Figure 3

There are three choices available:

- **8 Stereo**  
The mixer operates with eight channels of stereo signals. The channels are named **Stereo1** through **Stereo8**.
- **7 Stereo 2 Mic**  
The mixer operates with seven channels of stereo signals and two channels of mono signals. The channels are named **Micro1** through **Micro2** and **Stereo1** through **Stereo7**.
- **6 Stereo 4 Mic**  
The mixer operates with six channels of stereo signals and four channels of mono signals. The channels are named **Micro1** through **Micro4** (mono) and **Stereo1** through **Stereo6**.

A stereo channel gets an input pair (L & R) or a digital stereo pair routed in the **Audio Input** tab. In the mixer menu a stereo channel has a fader and a **balance** control.

A mono channel pair – Micro1 & Micro2 is a pair and Micro3 & 4 is a pair - gets an input pair (L & R) or a digital stereo pair routed in the **Audio Input** tab. In the mixer menu a mono channel has a fader and a **panorama** control.



### 1.2.2 Input

In the Setup – Audio – Input tab the physical audio inputs are routed to the inputs of the available mixer channels.



Figure 4

In the left **Mixer Inputs** list box you see the available mixer channels depending on the selected Operation Mode.

The mono channels Micro1/2 and Micro3/4 are shown as a pair because the inputs are also routed as a pair – the L (left) part of the signal gets routed to the channel with the lower number. In the Figure 4 above Micro 3 & 4 have the input TRS 4 routed to them. That means: the signal from the TRS 4 L connector goes to channel Micro3 and the signal from the TRS 4 L connector goes to channel Micro4.

Stereo channels are routed as a pair always.

It is possible to route physical inputs to multiple mixer inputs.

The available physical audio inputs are:

- **SineGen**  
The internal sine generator. You can also select the frequency: 440 Hz (the note a'), 1 kHz or 10KHz. The frequency selection is for the sine generator: When the generator is routed to more than one mixer input it has the same frequency everywhere.
- **RCA1, RCA2**  
Two pairs of unbalanced analogue inputs suitable for consumer audio equipment.

- **TRS3 through TRS8**  
Six pairs of analogue audio inputs for line level.




Figure 5

- **TRS Source Level**  
For every input you can also define whether the source has a low, mid, or high voltage output. In other words you select the nominal sensitivity of the A/D conversion.  
**Low +4dBu:** a level of +4dBu is full range 0dbFS. in other words a peak voltage of 1.73V is the full range of the A/D conversion and higher levels are clipped.  
**Mid +16dBu:** a level of +16dBu is full range 0dbFS. in other words a peak voltage of 6.91V is the full range of the A/D conversion and higher levels are clipped.  
**High +28dBu:** a level of +28dBu is full range 0dbFS. in other words a peak voltage of 27.5V is the full range of the A/D conversion and higher levels are clipped.  
This selection is for the physical input: The same TRS input cannot be used with different Source Level settings. The **Channel Gain** adjustment in **Channel Adjust** is used to fine tune the sensitivity.
- **XLR7, XLR8**  
two pairs of XLR connectors (combo connector with TRS7 and TRS8). The XLR inputs have the microphone pre-amplifiers. The **Pre Gain** for them is adjusted in **Channel Adjust**. Do not use the XLR inputs for audio sources with high line level output power.
- **AES1 through AES6**  
six digital audio inputs (each one is stereo). The optional INDGO1-AUDIO-CABLE has the XLR connectors for inputs and outputs.  
The digital coding of the S/PDIF digital audio format is compatible with those inputs. Use of a proper balun or transformer is recommended in this case.
- **SDI 1 through SDI 12**  
the 12 digital video inputs of the Indigo base unit have de-embedders for the embedded audio.




Figure 6

- For every mixer input you can select any stereo pair in any of the four groups. This includes different pairs of the same video input.  
Note: The HD-SDI inputs on the HiRes card do not have de-embedders. Embedded audio in these signals must be de-embedded externally and then can be connected to the AES inputs of Indigo.

Indigo cannot use the audio of the IEEE 1394 (DV) inputs, so these can not be selected.

AES and embedded audio can carry proprietary encoded surround audio (e.g. Dolby® E). Indigo does not process such signals.

### 1.2.3 Fader Assignment




Figure 7

In Setup – Control Panel – Fader Assign you assign channel faders to the six physical Faders on the Indigo surface.

Select the physical Fader in the left box and select the channel fader or an output fader in the right box and press the **Assign** button. The selectable channel faders depend on the operation mode. In addition to those you can select the **Main Out**, **Sub Out** and **Add-Sub-to-Main** faders as well as **None**. None means the Fader on the surface is not active.

**Default All** assigns the first six channel faders to the six physical faders. **Default** assigns the default channel fader to the selected fader.

## 1.2.4 Output




Figure 8

In this menu you define the setup for the audio outputs.

### Main Out

Select the **VU Source**, i.e. if you want the PFL (“pre masterfader”) or the AFL (“after masterfader”) signal to be displayed by the main VU meter on the right side of the screen.

You can also set the **XLR Out Level** (i.e., the output gain after the D/A conversion). With digital full scale (0dBFS) you can have +4dBu, +12dBu, +16dBu or +24dBu analogue output level.

### Sub Out

Select the source of the Sub Out: it can be either the Main Mix or the Sub Mix.

Select the **VU Source** to be displayed by the Sub VU meter on the right side of the screen.

You can also set the **TRS Out Level**.

In addition, you can set a **Delay** in milliseconds (independently for left and right channel), for example, to compensate distances between the speakers. See more in Tips & Tricks.

### Embedded Audio

Here you set which SDI video output will have the audio re-embedded into the digital video signal. The Main Mix is in Pair 1 Group A and the Sub Mix is in Pair 2 Group A.

### 1.2.5 Audio Follow Video



Figure 9

In this section you enable Audio Follow Video and assign the related audio to the video. It is possible to assign the same audio to multiple video sources. And, of course some video sources may not have a related audio.

To enable Audio Follow Video:

1. Press **AVF Enable**. The **Video Sources** list is displayed.
2. Select the video signal from the **Video Sources** list. You can also select Stills from this list.
3. Press **Audio Sources**. The **Audio Sources** list with the available mixer channels is displayed.
4. Select the audio input from the **Audio Sources** list.
5. Press **Level-Set**. The volume output level faders for the volume output level are displayed.
6. If desired, you can change the volume level (in dB) for “on air” (right fader) and “off air” (left fader). Normally the “off air” level is  $-\infty$ , but if the source should stay audible then this value can be higher. If needed for some unusual reason the “off-air” level can be higher than the “on-air” level.

### 1.2.6 Delay



Figure 10

In this section, you can set the delay for the mixer channels

To change the delay settings for a channel:

1. Select the channel in the **Mixer Inputs** list.
2. Select the **Delay Units**.

For **Fields** and **msec**, a **Delay** parameter field is displayed which allows you to set the delay in fields or milliseconds.

**No Delay** sets the delay to zero.

**Auto Delay** sets the delay automatically in sync with the video signal. For example when the audio was de-embedded from the video.

3. Set the delay in the **Delay** parameter field.

### 1.2.7 Audio Dynamics



Figure 11

In this setup page, you can select a compressor sidechain input for each mixer channel input. Select a mixer input in the **Mixer Inputs** listbox and then select in the **Sidechain Input** listbox the required sidechain input, or switch sidechain off. By default every Channel uses its own input signal for the gain control. This is “Sidechain off”.

With the radiogroup **Pre/Post Fader** you can choose if you take the sidechain signal before the channel fader (Pre) or after the channel fader (Post). In any case the sidechain signal includes the EQ and Dynamics processing of that channel.

## 1.3 Operation

### 1.3.1 Mixing

The audio mixing is controlled using the audio subpanel and the Mixer menu.

#### 1.3.1.1 Audio Control Subpanel




Figure 12

The elements are:

### Master Volume

The Master Volume knob lets you adjust the Main Out level.

The six Fader strips control the assigned channel. (It is a good idea to label the strips with adhesive tape in the bottom area.)

### Fader

The fader adjusts the level of the assigned Mixer channel within the range of  $-\infty$  to +10 dB. (If an output level is assigned, the range is  $-\infty$  to 0 dB.)

The faders are motorized and will move (e.g. when an E-MEM register is recalled or by audio-follow-video). Because of touch sensing you can intervene manually by touching or moving the fader.

### LED Meters

The meters show the level of the assigned channel with three different colours:

- *Green*:  $-\infty$  to -6 dB
- *Yellow*: -6 dB to -2 dB
- *Red*: -2 dB to +10 dB

### Mute and PFL Buttons and LEDs

#### PFL (Pre-Fader-Listening)

Changes to PFL mode. This allows you to hear the audio signal on the headphones as it sounds before the fader.

#### On

Turns the assigned audio channel on or off. This is useful to turn off a microphone channel but leave the fader where it is.



**Headphones** (not pictured)

On the left hand side of the Indigo AV mixer you find a TRS connector for headphones and the headphones volume knob. (There is a second Phones output on the rear panel; it has a separate amplifier but the same signal and volume.)

The Headphone output is used for prelistening and monitoring.

When the PFL mode is active for one channel, you prelisten to that channel, when PFL mode is active for several channels you prelisten to (the sum of) those channels. When no channel is in PFL then you hear the signal selected in the **Audio Mixer – Output** menu for Phones Out. (You have the choice for Main Out or Sub Out and Pre- and After- Fade for both)


**1.3.1.2 Audio Mixer – Mixer menu**

Figure 13

This is the menu where you see and operate all channels at once.

Every channel is displayed like this:




Figure 14

The Settings indicator shows (from left top to right) bottom:

- EQ** Equalizer is active (see **Channel Adjust** menu)
- DN** Dynamics (Compressor / Limiter / Noise gate) are active (see **Channel Dynamics** menu)
- M** Channel is mixed into the Main-Mix (see **Channel Adjust** menu)
- S** Channel is mixed into the Sub-Mix (see **Channel Adjust** menu)

The meter on the right side (which is present in all menus) can be switched to display Main Out, or Sub Out, or both just by touching the area.




Figure 15

### 1.3.2 Channel Adjust

Use the **CHANNEL ADJUST** submenu to adjust the settings for the channel selected in the **MIXER** submenu, for example, the 4-band equalizer and the Channel gain.




Figure 16

#### Equalizer On

turns the Equalizer on/off for the selected channel – which you can see in the lower right box.

The **Low**, **Mid 1**, **Mid 2**, and **High** sections allow you to adjust the four filters of the parametric equalizer. A positive Gain amplifies the frequency band and a negative gain reduces it. The frequency of each of the four bands can be set individually. You may also set the Q factor (quality) – i.e., the width of the filter – for the Mid 1 and Mid 2 bands.

**Low** Freq. 20Hz - 400Hz

**Mid1** Freq. 150Hz - 4kHz, Quality 0.1 – 4.5

**Mid2** Freq. 1kHz - 8kHz, Quality 0.1 – 4.5

**High** Freq. 4kHz - 20kHz

#### Presets Clipboard

opens the Presets Clipboard for the EQ settings. See also **Presets Clipboard** in the User Manual.

For more information how the equalizer works please see **Tips & Tricks Equalizer**.

In the lower right box, you see a duplicate of the Channel fader and Balance from the Mixer menu.

Also you can select

### Main

Activate this button to make the channel part of the MAIN mix.

### Sub

Activate this button to make the channel part of the SUB mix.

### Phase Invert

This button is only available if this is a mono channel - which you typically use for Microphones. It shifts the phase of the monaural audio signal 180 degrees to match the phase of the other microphones – for example if the microphone cable accidentally has reversed polarity.

### Low Cut

Attenuates frequencies below 80 Hz, to reduce low-level noise (aka rumble). This is especially recommended if a Microphone signal is the source of the channel.

Left of this box is a slider that lets you adjust the input level to get a good level for mixing.  
For a LINE or DIGITAL input the slider is **Channel Gain**. **Pre Gain** is for the inputs with Microphone preamplifiers – the XLR Inputs.

## 1.3.3 Channel Dynamics

### 1.3.3.1 Standard Mode




Figure 17

Display of the  
Characteristic curve

Adjustment of the points  
of the Characteristic  
curve

With the **Channel Dynamics** menu you can change the dynamic behaviour of the channel.

The five points in the **In/Out Level** group construct the characteristic input-to-output-level curve displayed in the box on the left side. These five points also give you the possibility to combine Limiter, Compressor, Expander and Noise-gate in one stage. For simpler processing the points 2, 3, and 4 can be disabled individually with the numbered button.

The **VU Meter** in the middle shows the Input Level of the dynamics stage.

The **Chan Gain** group allows to adjust the **input** gain which identical to the **Channel Gain** in the **Channel Adjust** menu.

In the **Compressor** group you can adjust **attack-time**, **release-time** and **output level**.

With the **A<>B** button you can exchange your settings with the clip-board.

The **Sidechain** gives you the possibility to control the channel dynamics from a different channel. The **Sidechain** button enables/disables this feature and is only present when a sidechain input has been selected. The name of the sidechain input is shown inside the button in brackets. You can select the sidechain input in the **Setup- Audio - Dynamics** menu.

**Expert Mode** changes the menu to **Expert Mode**.

### 1.3.3.2 Expert Mode




Figure 18

In the **Expert Mode** you can manually adjust more settings of the dynamics processor.

In order to better understand the Expert Mode Settings here is a Block diagram:




Figure 19

- **Sidechain On/Off** selects whether the channel signal itself or the sidechain input is used. It is only present when a sidechain input has been selected in **Setup > Audio > Dynamics**.
- **Attack** adjusts how fast the **Peak** Level Detector follows a rising signal.  
**Release** adjusts how fast the **Peak** Level Detector follows a falling signal.  
The adjustment group is visible when **Method Peak** or **Both** is selected.
- **AvgT** adjusts how fast the **Average** Level Detector follows the signal (rising or falling).  
The adjustment is visible when **Method AVG** or **Both** is selected.
- **Characteristic Curve** defines the relation of input to output levels and determines the Gain of the Controlled Amplifier.
- **Look Ahead Delay** delays the audio signal to compensate for latency in the detector path. It is set automatically..
- **Rise** adjusts how fast the Controlled Amplifier follows **increasing** Gain.
- **Fall** adjusts how fast the Controlled Amplifier follows **decreasing** Gain.
- **Output Gain** adjusts the output level.
- **Method:**  
**Peak:** the Peak detector is used for the Dynamics.  
**AVG:** the average detector is used for the Dynamics.  
**Both:** both detectors are used and the higher level is used for the Dynamics.

### 1.3.4 Output




Figure 20

This menu has been changed from “Monitor” in earlier software versions to “Output”.

Use this submenu to adjust the volume of Main Out, Sub-Out and the headphones.

#### Mute

Mutes the corresponding output.

This applies to the **Main Out**, **Sub Out**, **Add Sub to Main**, and **Phones Out** sections.

#### Limiter (button)

Enables the Output Limiter (new since V 1.2.11). (**Main Out**, **Sub Out** and **Phones Out**)

#### Limiter (slider)

Adjusts the Output Limiter (new since V 1.2.11) (**Main Out** and **Sub Out**. For the **Phones Out** the Limiter is fixed to 0dB.)

#### Level (sliders)

Adjusts the Output Levels.

#### Link

Links/unlinks an output's left and right channel faders. If **Link** is on, moving one fader automatically moves the other one. **Unlink** the faders for balancing different left and right audio levels:

1. Deactivate **Link**.
2. Set left and right channel to the required levels.
3. Activate **Link**.

Now you can turn the volume of the output up and down without the need to compensate for the different levels. (i.e. the previously set level difference is kept.)

This applies to the **Main Out**, **Sub Out**, **Add Sub to Main**, and **Phones Out** sections.

### Add Sub to Main

Use these faders to mix the Sub-Mix to Main-Mix.

### Phones Out

The **Phones Out** section has some additional buttons:

- **Main**

Allows you to hear the signals of the Main output on the headphones. This button is only available if no channel PFL is active.

- **Sub**

Allows you to hear the signals of the Sub output on the headphones. This button is only available if no channel PFL is active.

- **PFL/AFL**

Choose if you want to hear the signals of the Main and Sub outputs in AFL or PFL mode on the headphones. These buttons are only available if no channel PFL is active.

- **Channel PFL**

This button is only available if at least one channel PFL is activated. Press it to deactivate all channel PFL.

- **100%/50%/25%**

Allows you to set the power of the phone amp to adjust it to your headphones.

The faders of the **Phones Out** section control the volume on the headphones and work in parallel with the knob on the Indigo panel.

### 1.3.5 Presets Clipboard

The Preset Clipboard is used in the Channel Adjust and Channel Dynamics menu to recall fixed and user preset settings and save the user presets.

#### Button Functions

The clipboard will only affect (a subset) of the parameters shown on the current dialog. It stores a copy of each parameter in volatile memory that is lost after power cycle. The initial state of the clipboard after power up equals the default settings.

- **Load**  
A dialog appears to load a specific preset file from the USB Flash Memory.
- **Save**  
A dialog appears to store the current settings as preset to the USB Flash Memory.
- **Copy**  
Copies the current parameter settings and the values stored to the clipboard.
- **A <math>\leftrightarrow</math> B**  
Toggles between the current parameter settings and the values stored on the clipboard. This is useful to compare two EQ or Dynamics settings.
- **Paste**  
Upgrade parameters with the current clipboard content.
- **Cancel**  
Closes the Preset/Clipboard dialog.
- **Built-in Presets**  
There are several fixed presets suitable for the current dialog.

User Presets saved from the Channel Adjust menu will contain the Equalizer settings, but not level, balance, Channel Gain and Low Cut. The saved file has the extension “**.eq**”.

User Presets saved from the Channel Dynamics menu will contain the Dynamics settings, but not the Input Gain. The saved file has the extension “**.dyn**”.



## 1.4 Tips & Tricks

### 1.4.1 Delay

#### 1.4.1.1 Why use Output Delay?

Sometimes the PA system used has support speakers that are positioned away from stage into the audience. If those speakers get the MAIN mix, the sound from the support speakers arrives before the sound of the main speakers in front of the auditorium. The brain of the listener has to do a lot of work to associate the early sound from a different direction with the person on stage.

If the PA system does not have a compensation for speaker distance, then Indigo has: You select the main mix for the SUB output and delay it. Sound speed is approximately 340 meters per second, or in other words it takes sound about 3 milliseconds to travel 1 meter. So, if the support speakers are 10 meters into the audience then a delay of 30 milliseconds just about compensates the distance.

The delay can be increased a bit more because of the Haas effect. The Haas effect (after Helmut Haas) or “Law of the wave front” describes that a 10 – 30msec delayed signal may be up to 10dB higher in level but is still not separated from the original and the first wave front gives the directional information to the listener and the support speakers give the appropriate level.

#### 1.4.1.2 Why use Input Delay?

This adjustment is used to correct lip-sync issues. The video may be delayed in the frame synchronizer, in the DVE, in the upscaler and in the downscaler.

If the audience hears the sound before seeing the action in the video, this is quite unnatural. In order to compensate: evaluate the path the video is going through. Frame synchronizer, DVE, upscaler and the downscaler: each one has one frame (or two fields) delay. Add together and adjust the delay to that number of fields. For finer resolution you can also adjust the delay in milliseconds. You will also want to check and maybe correct the delay setting by looking and listening.

Another thing that delay can be used for is double tracking. This is a technique used in recording studios to make voices sound “fuller.” To do this, you route the same audio source to multiple mixer channels and give every (but the first) channel a different delay. The value of the delay is strictly an artistic decision so there is no recommendation here.

Up to the “echo threshold,” the ear and brain do not separate the sound events but instead accumulate them. The echo threshold depends on the type of sound and the level. With pulses (drums) and/or high sound pressure levels the echo threshold is lower than with strings or vocals and at lower levels. Some sources give 30 – 50 msec as the lowest echo threshold. With a noticeable delay (echo), the illusion of a room can be created, the room appearing larger with longer delays.

Many creative things can be done here. Consider further reading on recording techniques.

### 1.4.2 Equalizer

An Equalizer is a tool that amplifies or suppresses certain frequency bands. For example, in an auditorium with heavy carpet, thick curtains and so on, you may need to amplify the presence and treble frequencies and in a room with bare floor and walls you may need to lower them.

There are two generic types of equalizer. First, the so-called graphic equalizer has a set of fixed bandwidth filters (typically an octave or 1/3 octave) each of which has a slider for its gain control. The position of the sliders gives a representation of the overall frequency response – thus the name graphic equalizer.

The second type is the parametric equalizer, which uses fewer but more freely adjustable filters.

Indigo has such a parametric equalizer with four bands for each channel that you enable and adjust in the **Channel Adjust** menu.

There is a LOW band and a HIGH band where you can adjust the gain and the cut-off frequency and two mid bands where you can adjust gain, centre frequency and quality.

Quality or Q-Factor is the relation of centre frequency to bandwidth. That means the higher the Quality is the smaller the bandwidth of the filter and the lower the quality is, the wider the filter.

For example: with centre frequency 1 kHz and a quality of 1, the bandwidth is 1 kHz as well, so very simplified speaking the filter influences frequencies from 500Hz to 1500Hz. In reality the bandwidth is not symmetric to the centre frequency: with  $Q = 1$  the bandwidth is 618 – 1618 Hz and with  $Q = 0.5$  it is 414 – 2414 Hz. The product of the lower and the upper frequency equates the squared centre frequency. Also the filter slope is not infinitely steep.

For the musicians: a quality of 1.4 results in a bandwidth of 1 octave and  $Q = 3.3$  is 1/3 octave bandwidth.

To start off with equalizing the Indigo has a couple built in presets you can recall from the preset clipboard.

Let's look at the DEFAULT:



Figure 21

The gain is flat in all bands but let's look at the frequencies:

- The cut-off for the LOW band is lower than the fundamental notes of most voices.
- The Mid1 band's centre frequency and Q-factor create a filter with which you can emphasize or lower the fundamental and lower harmonics of voices and instruments.
- The Mid2 band is set for the brilliance frequencies. With a bit emphasize here the voice or instrument sounds more "brilliant" and "Present".
- The High band is the higher harmonics of instruments and voices and also this where sibilance can occur. Lowering here can make that less noticeable.

Have also a look at the other built-in presets.

**Rock** gives you more bass and treble and lowers the mid frequencies.



Figure 22

**Pop** is similar but more flat.



Figure 23

**Classic** reduces bass and presence and adds in the lower mids and treble



Figure 24

Once you started working with the EQ you will find adjustments that you want to re-use. You can save those presets on your USB-flash-drive in the PRESET CLIPBOARD.

Every situation and auditorium is different so we cannot give general rules how to adjust the EQ. You can search the Internet and study literature on sound recording. Also by start working you will make your own experience.

Just one tip for presenter microphones: Depending on the microphone model and the distance it has to the speaker, the fundamental notes get amplified. As a consequence, the sound may get dull and cannot be understood very well.

You can lower the frequency band from about 180 – 300Hz. to avoid that. Use Mid1 and adjustment centre frequency to 240Hz and  $Q=2$ . Start with a level -3dB and adjust so the sound is not too thin. In order to improve understandability (at least acoustically) you can emphasize the range from 2 – 4 kHz. We use Mid2 band and set frequency to 2.8 kHz and  $Q = 1.4$ . Adjust the level so the sound becomes clear but not high-pitched. Also you may need to lower the LOW band to suppress humming and rumble and lower the HIGH band to reduce the 's'es.

### 1.4.3 Dynamics

#### 1.4.3.1 What is Dynamics? And why use it?

Dynamics is the generalized term for an audio processing stage with variable gain – which is controlled depending on the level of the signal. Typical examples are: Compressor, Limiter, Expander, and Noise-Gate.

A **Limiter** is used to protect electronic devices like power amplifiers, modulators, or A/D converters from being overloaded. A power amplifier may need to produce excessive current, a modulator for radio transmission may exceed allowed bandwidth, an A/D converter may clip when overloaded. Instead of just clipping at a specified level a Limiter reduces the gain so that a certain output level is not exceeded. A clipper would just clip and thus create harmonic distortion. (That is why clippers are used to create the distortion effect e.g. for guitars). A Limiter avoids the distortion.

A **Compressor** (see also Standard Compressor ) also reduces the gain when a certain input level is exceeded. It still allows higher output levels, but the output level is compressed by the compression ratio.

Some acoustical musical instruments have a different volume depending on the notes played. Also singers and speakers (especially untrained) have difficulties to keep an equal volume. A properly adjusted compressor evens volume differences out but still leaves 'life' in the sound. A speaker will be much better understandable – acoustically – when the volume is evened out by a compressor which makes the average volume louder. You can hear extreme cases in the sound of many commercial advertisements on radio and TV.

An **Expander** reduces gain when the level gets **below** a certain threshold. This is used to reduce unwanted sounds such as the noises a guitar player makes on the fingerboard or sound from other instruments.

A Noise-Gate is the extreme of an Expander. When the level gets **below** a certain threshold the gain is reduced to zero. Again this is used to eliminate unwanted sounds.

### 1.4.3.2 Standard Compressor

For those not familiar with this effect here is how a typical compressor works:




Figure 25

A compressor reduces the dynamic range of the voice or music in this way:

Above a certain level called THRESHOLD this stage has a lower gain which is reduced by the Compression RATIO. Effectively louder input levels are reduced on the output. For example with Threshold = -20dB and ratio 4:1 an input level of 0dB gets reduced to -15dB – Basically all levels between -20dB and 0dB get compressed into -20dB to -15dB.

With the GAIN adjustment the output level is raised to make it louder again. In this example we set the gain to 15dB and then an input level of 0dB has an output level of 0dB but an input level of -20dB now has an output level of -5dB – this is much louder. So the signal has a higher average level and that causes more “power” and better understandability. The further advantage versus just a gain of 15dB is: no higher risk of clipping distortion.

The compressor stage has two more adjustments:

ATTACK controls how fast the gain reduction above the threshold is invoked. A short ATTACK time eliminates even short peaks and a long ATTACK time will let short peaks pass through nearly uncompressed. Typically it is several milliseconds up to a couple hundred milliseconds.

RELEASE controls how fast the compressor returns to normal gain when the level gets below the threshold again. Typically the RELEASE time is longer than the ATTACK time. Short ATTACK and RELEASE makes the compressor react faster and longer times make it react slower.

### 1.4.3.3 Indigo’s Dynamics processor

The Indigo has an advanced dynamics processor that allows it to be an expander, compressor and limiter at the same time. The signal path has a look-ahead delay that compensates for latency in the level detection and gain control stages. Most commonly dynamics processors are used in Mono Channels. Indigo can do dynamics in

stereo channels, by using both channels in the detection, and control the gain in both channels equally so that stereo panorama does not move.

When turning Dynamics On you have already a 0dB Full Scale limiter which already greatly avoids clipping distortions.

The input-to-output characteristic is programmed with up to five points which are adjusted and enabled in the In/Out Level box.




Figure 26

To start with let us put them on a straight unity-gain line.

To adjust the compressor, select point 1 and reduce the output level. You are adjusting the compression ratio above the threshold that is defined by point 2. The next images show the setting for a 4:1 compressor (input levels between -20 dB and 0 dB – that is a 20 dB range - get compressed into -20dB to -15dB output level – that is a 5 dB range.  $20:5 = 4:1$




Figure 27

When further reducing the point 1 output level until it has reached point 2 output level you get a LIMITER with -20dB limit. Further reducing point 1 output level will reduce the point 2 output level automatically.

To build a Noise-Gate select point 4 and reduce its output level to -100. Input levels below -80dB will be gated to -100dB (in the Indigo that is the same as  $-\infty$ ). The segment between point 3 and 4 is an Expander (the input level range -80 to -40 dB gets expanded into output levels  $-\infty$  to -40dB).




Figure 28

Just to recap the Compression or Expansion ratio is calculated as the relation of the difference of the **Input Levels** to the difference of the **Output Levels** of the segment of the characteristic curve. Compression Ratios of 2:1 to 5:1 can be used without making the compression too obvious. Indigo has a fixed preset for a 4:1 compressor.

In this example the peak output level has been reduced to -15dB. With **Out Gain** the output level can now be brought up by 15dB and this increases the average volume!

Please take care: when you are in an auditorium this may increase the probability of getting feedbacks. A PA System with feedback destroyer will greatly help.

For the adjustment of ATTACK and RELEASE times there is no fail-safe recipe. It always depends on what is needed.

Attack and Release very short (1 – 10ms): about every syllable may cause the Compressor to react

Attack and Release long: whole groups of words cause the compressor to react.

Attack and Release too long: Listeners start to hear the Gain-Adjustment going on. That should be avoided.

Attack short and Release too long (> 0.5 sec) then short pulses of the speaker can reduce the gain for quite along time.

For a speaker an ATTACK of 1ms and a RELEASE of 200ms can be a start.

Use the A-B button a lot to compare two settings and decide which one works better.

An adjustment like the following could be used to counter a too high compression of the source.




Figure 29

Input levels of -5dB to 0dB (e.g. today's pop music) get expanded to -20 to 0 dB.

The Indigo comes with the following fixed presets.




Figure 30: "Default"






Figure 31 "Compr. 2:1 &gt; -50dB"




Figure 32: "Compressor 4:1 > -20dB"




Figure 33 "Expander 1:3 < -20dB"




Figure 34 “Expander 1:4 &gt; -5dB”




Figure 35: "Noise-Gate -60dB"

In addition to those fixed presets you can save your own on the USB flash drive.

#### 1.4.3.3.1 Sidechain

As explained above a Dynamics processing stage has a main signal path (where the gain varies) and a level detection and gain control path. The latter one is often called ‘**sidechain**’. Many specialized compressor devices have an input called **sidechain** where a different signal can be plugged in. When enabled, this signal then controls the gain of the main signal path.

This feature can be used as a creative effect or for special purposes.

- **“Ducking”**, automatic voice-over

For this function you use a microphone as the sidechain for the channel where the music is on. Make it a compressor that reduces the level – do not increase Output Level. Set Attack to a short time and Release to a medium to long time. Now when the Speaker starts talking the music is automatically reduced in level. When he pauses (for longer than the Release time) it comes up again.

- **De-esser**

Remember the sibilance in the higher frequencies? Just reducing the high frequencies in the equalizer may not be enough. This can be improved by using EQ and Dynamics: Take the same input into a 2<sup>nd</sup> channel, turn on the EQ and amplify above 6kHz or so and reduce Low and Mid, and then use this as the sidechain input. Now with short Attack and Release the dynamics processor working as a De-esser.

The Sidechain input is selected in **Setup Audio Dynamics**.

By default every Channel uses its own input signal for the gain control. This is “Sidechain off”.

You can also select whether you use the Pre Fader signal or the Post Fader signal. When selecting Pre-Fader the signal on the sidechain input - which controls the gain in the dynamics - is taken before the channel fader. In consequence the level is independent from your mix. When selecting Post-Fader, the signal is taken after the channel fader. Consequently, the dynamics gain is then dependent on your mix.

In any case the sidechain signal includes the EQ and Dynamics processing of the selected channel.

You enable the sidechain input in the Channel Dynamics menu.

## **1.5      Technical Notes**

### **1.5.1      Connections**

See Indigo User Manual section 3.6 Audio Connections

### **1.5.2      Mixer**

The mixer operates at 48 kHz sample rate with 24 bit resolution.

The AES/EBU inputs and the de-embedders from the SDI video inputs have built-in sample-rate converters. It is not necessary to synchronize the digital audio sources with a word clock or AES sync.

Due to the sample rate converters, Indigo also accepts digital audio signals with 32 kHz, 44.1 kHz (CD Audio), and 96 kHz sample rate.

The AES/EBU digital audio data format has provision for “Audio sample word used for purposes other than linear PCM samples”. This possibility is used by some manufacturers for proprietary audio formats. Indigo does not process such formats. An example of such a proprietary format is Dolby E – which can also be found in embedded audio – a format that encodes surround audio into one stereo pair.

The Phones Out outputs can drive headphones and speakers with impedance of 16 Ohm and higher. Output Power is about 1 Watt – which depends on the load resistance.

The XLR inputs have an analogue pre-amplifier which is controlled as **Pre-Gain** in the **Channel Adjust** menu of the channel that has an XLR input. The **Channel Gain** of the channels with TRS, RCA or digital input signal works in the digital domain.

The low-cut filter is a 24dB per octave filter with ~80 Hz corner frequency.

## 1.6 Glossary

### AES

Audio Engineering Society (<http://www.aes.org>) a professional society devoted exclusively to audio technology. Technical standards are continually being developed under the auspices of the society. Many of them have since been accepted by international standards organizations as the model for their standards on the same material.

### AES/EBU (digital) audio

Commonly used term for the broadcast & professional standard digital audio format.

The format is standardized by documents of the AES (standard AES3), the EBU and the IEC. The interface is designed to carry two channels of "periodically sampled and linearly represented" audio. Recommended sample rate is 48 kHz. Quantization is 16, 20 or 24 bits per sample, coding is PCM. This and other information is coded in the signal itself. The signal is transported using 110  $\Omega$  twisted pair cable or 75  $\Omega$  coaxial cable (informational document AES-3id). The interface allows for "Audio sample word used for purposes other than linear PCM samples" as well; for example proprietary encoded surround audio. Indigo processes AES/EBU audio but only the linear PCM coded audio.

### Audio follow Video

A technique used in TV and AV production. When a transition or cut from one (background) video to another is made the audio mixer fades the associated audio signals automatically. Of course, the audio source must be associated to the video source in the setup.

### balun

Pronounced /"bæl.ʊn/ ("bal-un"), is a passive electronic device that converts between balanced and unbalanced electrical signals. They often also change impedance. In many cases the balun is a transformer.

### dB (decibel)

A logarithmic unit of measurement that expresses the magnitude of a physical quantity (usually power or intensity) relative to a specified or implied *reference level*.

Taking voltage as an example, this leads to the equation:

$$G_{\text{dB}} = 20 \log_{10} \left( \frac{V_1}{V_0} \right)$$

where  $V_1$  is the voltage being measured,  $V_0$  is a specified reference voltage, and  $G_{\text{dB}}$  is the power gain expressed in decibels.

### dBFS or dBfs

dB(full scale) — the amplitude of a signal (usually audio) compared to the maximum which a device can handle before clipping occurs. In digital systems, 0 dBFS (peak) would equal the highest level (number) the processor is capable of representing. Measured values are usually negative, since they should be less than the maximum.

### dBu or dBv

dB(0.775  $V_{\text{RMS}}$ ) — voltage relative to 0.775 volts. Originally dBv, it was changed to dBu to avoid confusion with dBV. The "v" comes from "volt", while "u" comes from "unloaded". dBu can be used regardless of impedance, but is derived from a 600  $\Omega$  load dissipating 0 dBm (1 mW).

### Dynamics

The generalized term for an audio processing stage with variable gain – which is controlled depending on the level of the signal. Typical examples are: Compressor, Limiter, Expander, and Noise-Gate.

**EBU**

European Broadcasting Union (<http://www.ebu.ch/>) a.k.a. UER - Union Européenne de Radio-Télévision.

Association of national broadcasters in Europe. Most publicly known activity is the *Eurovision* TV program exchange. EBU works with other organizations e.g. AES and SMPTE on standardization of audio and video formats.

**Embedded audio**

Digital audio contained in the serial digital video data. The (broadcast) serial digital video format has bandwidth to carry so-called ancillary data (non-video) data along with the video data and reference codes. Embedded audio is a form of ancillary data (in the horizontal blanking aka HANC) that carries multiple AES streams.

Indigo can de-embed audio from the SDI video inputs on the base unit (not from the HiRes-card). The Main Mix can be re-embedded into the SDI video outputs.

**Equalizer**

An Equalizer is a tool that amplifies or suppresses certain frequency bands.

**Gain (audio)**

An amplification factor (output level : input level). Very often gain is expressed in dB with 0dB is gain = 1 and gain = 0 is -∞dB. Most audio mixers have a Gain adjustment on the input of the mixer channels to adapt to differing input source levels.

**PFL (Pre Fade Listen)**

Monitoring audio before level adjustments with the audio channel faders. Used to check the input audio.

**RCA connector**(a.k.a. “Cinch-Connector” or “phono connector”)

A coaxial connector unbalanced audio and video typically found in consumer electronics.

**S/PDIF**

Stands for **Sony/Philips Digital Interconnect Format** (more commonly known as **Sony Philips Digital Interface**) the format of digital audio for consumer devices.

**Main Differences between AES/EBU and S/PDIF**

	<b>AES/EBU</b>	<b>S/PDIF</b>
<b>cable</b>	110 ohm shielded twisted pair, 75 ohm coaxial	75 ohm coaxial, fibre
<b>connector</b>	3-Pin XLR, 25-pin D-sub, BNC	RCA, BNC, TOSLINK
<b>signal level</b>	3 – 10 V	0.5 – 1 V
<b>typ. resolution</b>	24 bits	16 bits
<b>max. resolution</b>	24 bits	20 bits (24 bits optional)

**SMPTE**

Society of Motion Picture and Television Engineers (<http://www.smpte.org>) is the leading technical society for the motion imaging industry. SMPTE publishes ANSI-approved Standards, Recommended Practices, and Engineering Guidelines.

**TRS**

**Tip-Ring-Sleeve** (aka ¼-inch, “phones jack”, “Stereo Jack”, “Klinkenstecker”). A connector used in professional and consumer audio. It has a triple contact: the Tip, the Ring and the Sleeve. The cable shield is connected to the Sleeve contact – which is connected to ground in the device. In professional audio Tip and Ring are used for the balanced signal with Tip = signal+ or ‘hot’ and Ring = signal- or ‘cold’.

In an unbalanced connection the Ring is not connected or connected to ground.

When used for stereo connections the Tip is the left and the Ring is the right channel.

Indigo uses the 'balanced' version on its TRS connectors with the exception of the headphones outputs which are stereo.

**XLR connector**

A connector used in professional audio and other applications. The connector is mechanically very robust. Versions with different number of pins are available. Professional audio uses the 3-pin version for balanced analogue audio and AES/EBU digital audio.

Some Indigo inputs have a combo socket for 3-pin XLR and 1/4-inch TRS.