



TABLE OF CONTENTS

Chapter 1: Getting Started

Introduction	1-2
The Purpose of this Manual.....	1-2
Supplemental Manuals.....	1-2
Technical Support.....	1-2
Conventions Used	1-3
Key Topics for Each Chapter.....	1-3
Product Overview	1-4
Quick Start Steps	1-5
Step 1 – Unpack and Inspect.....	1-5
Step 2 – Install Optional Hardware Accessories.....	1-6
Step 3 – Become Familiar with Available Communication Ports.....	1-7
Step 4 – Install the Programming Software and Develop a Project.....	1-8
Step 5 – Connect Touch Panel to Computer.....	1-9
Step 6 – Provide Power to the Touch Panel.....	1-10
Step 7 – Access the Touch Panel Setup Screens.....	1-12
Step 8 – Choose Touch Panel to Device Protocol & Cables.....	1-13
Step 9 – Connect Touch Panel to PLC.....	1-16

Chapter 2: Specifications

Available Models	2-4
Model Specifications	2-5
Specifications common to all models.....	2-6
6-inch Models.....	2-7
7-inch Models.....	2-8
8-inch and 10-inch Models.....	2-9
12-inch and 15-inch Models.....	2-10

Table of Contents

EA9-T6CL-R, EA9-T6CL	2-11
Dimensions, Inches [mm].....	2-11
Ports and Memory Expansion.....	2-12
EA9-T7CL-R, EA9-T7CL	2-13
Dimensions, Inches [mm].....	2-13
Ports and Memory Expansion.....	2-14
EA9-T8CL	2-15
Dimensions, Inches [mm].....	2-15
Ports and Memory Expansion.....	2-16
EA9-T10CL	2-17
Dimensions, Inches [mm].....	2-17
EA9-T10WCL	2-18
Dimensions, Inches [mm].....	2-18
Ports and Memory Expansion.....	2-19
EA9-T12CL	2-20
Dimensions, Inches [mm].....	2-20
Ports and Memory Expansion.....	2-21
EA9-T15CL-R, EA9-T15CL	2-22
Dimensions, Inches [mm].....	2-22
Ports and Memory Expansion.....	2-23
Mounting Clearances	2-25
EA9-T15CL-R, EA9-T15CL Derating	2-26
Communications Ports	2-27
Handling External Memory Devices	2-30
Writing to External Memory Devices	2-30
Memory Device Formatting.....	2-30
Minimizing Data Errors.....	2-31
Monitoring Available Memory	2-31
File Name Limitations.....	2-32
Power Loss Retention	2-32
Chemical Compatibility	2-32

Chapter 3: Accessories

Accessories Overview.....	3-2
AC/DC Power Adapter	3-3
AC/DC Power Adapter Dimensions	3-5
AC/DC Power Adapter Installation.....	3-6
D-SUB 15-pin to Terminal Block Adapters.....	3-7
Non-glare Screen Covers.....	3-8
Clear Screen Overlay Installation	3-9
SD Card	3-10
USB FLASH Drive	3-10

Chapter 4: Installation and Wiring

Safety Guidelines	4-2
Introduction.....	4-3
EA9-T6CL-R, EA9-T6CL, EA9-T7CL-R and EA9-T7CL Cutout Dimensions	4-4
EA9-T8CL and EA9-T10WCL Cutout Dimensions.....	4-5
EA9-T12CL Cutout Dimensions	4-7
EA9-T15CL-R and EA9-T15CL Cutout Dimensions	4-8
Mounting Clearances	4-9
EA9-T15CL-R, EA9-T15CL Derating	4-10
Wiring Guidelines	4-11
Agency Approvals.....	4-11
Providing Power to the Touch Panel	4-12
C-more LED Status Indicators	4-13

Chapter 5: System Setup Screens

Introduction.....	5-2
Accessing the System Setup Screens (no project loaded)	5-3
Accessing the System Setup Screens (with project loaded)	5-4
System Setup Screens – Enable Password in Software	5-6
System Setup Screens Flowchart	5-12
Main Menu.....	5-13

Information Menu	5-14
Setting Menu	5-18
Test Menu	5-25
Memory Menu	5-34

Chapter 6: PLC Communications

Introduction.....	6-2
Direct LOGIC PLCs Password Protection.....	6-2
PLC Protocol & Cables	6-3
PLC Communication Cables & Wiring Diagrams.....	6-5
AutomationDirect PLCs RS-232C Serial.....	6-7
AutomationDirect PLCs RS-422A/RS-485A.....	6-10
Direct LOGIC Universal Isolated Network Adapter, p/n FA-ISOCAN:	6-16
Direct LOGIC Universal Converter, p/n F2-UNICON:	6-17
RS-422A/RS-485A Multi-Drop Wiring Diagram Examples	6-18
Allen-Bradley	6-22
GE.....	6-27
GE VersaMax Micro.....	6-27
Mitsubishi.....	6-28
Omron	6-30
Modicon Modbus RS-232.....	6-31
Modicon Micro Series.....	6-31
Modicon Modbus with RJ45.....	6-31
Siemens.....	6-32

Chapter 7: Maintenance

Project Backup	7-2
Check Operating Environment	7-2
Check Operating Voltage	7-2
Check Status Indicators	7-2
Check Physical Conditions.....	7-3
Run Tests under System Setup Screens.....	7-3
Check Memory Usage	7-4
Check/Adjust Display Brightness.....	7-4

Check Error Log	7-4
Adjust Touch Panel.....	7-4
Cleaning the Display Screen.....	7-5
Check Project Functionality	7-6
Checks from C-more Programming Software	7-6
Notes:	7-7

Chapter 8: Troubleshooting

Common Problems	8-2
Troubleshooting Flow Chart.....	8-3
Touch Panel does not Power up.....	8-4
Display is Blank	8-5
Display is Dim	8-6
No User Program	8-7
Firmware Recovery Tool	8-8
No System Found.....	8-9
No Communications between Panel and PC (Personal Computer) via USB	8-10
USB Driver Troubleshooting	8-12
No Communications between Panel and PC (Personal Computer) via Ethernet	8-14
No Communications between Panel and PLC	8-18
IP Address in System Setup Screens displays 0.0.0.0	8-21
Difficulty Connecting to the Panel over the Internet (Web server and Remote Access features).....	8-22
PLC Protocol Error Codes	8-23
Touch Panel Runtime Errors	8-24
Panel Constantly Displays “Initializing” when Powering up	8-25
Data not Logging Problems	8-25
Electrical Noise Problems.....	8-26

Chapter 9: Replacement Parts

Replacement Parts Overview	9-2
Panel Mounting Clip Replacements – EA9-BRK.....	9-3
Logo Label Replacement Insert - EA9-LBL	9-4
3-wire Communications Terminal Block – EA9-3TB.....	9-5
DC Panel Power Connector Replacement – EA-DC-CON	9-5

AC Power Adapter Connector Replacement– EA-AC-CON.....	9-6
Panel Gasket Replacements – EA9-xx-GSK	9-7
Gasket Replacement Installation Instructions:	9-7

Appendix A: Panel and PLC Error Code Tables

Introduction.....	A-2
C-more Touch Panel Error Code Table	A-3
DirectLOGIC – Panel Error Code PLC-499 Explanation	A-5
DirectLOGIC K-Sequence Protocol – PLC Error Code Table.....	A-5
DirectLOGIC DirectNET Protocol – PLC Error Codes	A-5
Modbus Protocols Error Code P499 Explanation	A-6
AutomationDirect CLICK	A-6
AutomationDirect DirectLOGIC - Modbus (Koyo).....	A-6
Modicon Modbus RTU	A-6
Entivity Modbus RTU.....	A-6
DirectLOGIC ECOM Protocol – PLC Error Codes	A-6
Productivity Error Code P499.....	A-7
AutomationDirect Do-More Error Codes.....	A-8
Allen-Bradley – Panel Error Code PLC-499 Explanation	A-9
Allen-Bradley DF1 & DH485 Protocols – PLC Error Code Tables	A-10
Allen-Bradley EtherNet/IP Protocol – Panel Error Code PLC-496, 497 and 498 Explanation	A-12
Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables ControlLogix, CompactLogix, & FlexLogix.....	A-13
Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables.....	A-17
Generic EtherNet IP Protocol – PLC Error Codes	A-22
GE 90-30 – Panel Error Code PLC-499 Explanation	A-23
GE 90-30 SNPX Protocol – PLC Error Code Tables.....	A-24
Mitsubishi FX Protocol – PLC Error Codes.....	A-33
Omron – Panel Error Code PLC-499 Explanation	A-33
Omron Host Link Protocol – PLC Error Code Table	A-34

Omron FINS Protocol – PLC Error Code TableA-35
 Omron – Panel Error Code P495 ExplanationA-38
 Omron CS/CJ FINS Ethernet Protocol – PLC Error Code Table.....A-39
 Siemens – Panel Error Code P499 Explanation.....A-40
 Siemens PPI Protocol – PLC Error Code Table.....A-41
 Siemens ISO over TCP Protocol – PLC Error Code TableA-42

Appendix B: Touch Panel Runtime Errors

Introduction..... B-2
 Runtime Errors..... B-3
 Log File Naming..... B-4

Appendix C: Security Considerations for Control Systems Networks

Security Considerations for Control Systems Networks..... C-2

