

# Table of Contents

---

## Chapter 1: Introduction

<b>Manual Overview</b> .....	<b>1-2</b>
The Purpose of this Manual .....	1-2
Supplemental Manuals .....	1-2
Who Should Read this Manual .....	1-2
Technical Support .....	1-2
Manual Layout .....	1-3
Appendix .....	1-3
Symbols Used .....	1-3
<b>Introduction to MODBUS</b> .....	<b>1-4</b>
<b>Terminator I/O System</b> .....	<b>1-5</b>
<b>T1K-MODBUS Base Controller</b> .....	<b>1-6</b>
MODBUS Base Controller Features .....	1-6

## Chapter 2: T1K-MODBUS Base Controller Specifications

<b>T1K-MODBUS Base Controller Specifications</b> .....	<b>2-2</b>
Status Indicators .....	2-3
<b>Setting the DIP Switches</b> .....	<b>2-4</b>
DIP Switch Settings .....	2-4
<b>Setting the Rotary Address Switches</b> .....	<b>2-7</b>
Converting HEX Addresses to Decimal .....	2-7
<b>MODBUS Port Pin-out and Wiring</b> .....	<b>2-8</b>
<b>RJ12 Serial Port Pin-out and Wiring</b> .....	<b>2-9</b>
Using D2-DSCBL to Connect PC to RJ-12 Serial Port .....	2-9

## Chapter 3: MODBUS RTU Functions and Addressing Modes

<b>MODBUS RTU Function Codes</b> .....	<b>3-2</b>
MODBUS Function Codes Supported .....	3-2
<b>DirectLogic Addressing Mode</b> .....	<b>3-3</b>
Using the T1K-MODBUS with a <i>DirectLogic</i> PLC Modbus Master .....	3-3
<b>584/984 Addressing Mode</b> .....	<b>3-4</b>
Using the T1K-MODBUS with a 584 / 984 MODBUS Master .....	3-4

---

## **Chapter 4: Using the T1K–MODBUS Setup Tool**

<b>Configuring the T1K–MODBUS Port .....</b>	<b>4–2</b>
Installing the Setup Tool .....	4–2
Launching the Setup Tool .....	4–2
Select the PC Comm Port .....	4–3
Configure the MODBUS Port .....	4–3

## **Appendix A: I/O Module Hot Swap**

<b>T1K–MODBUS I/O Module Hot Swap Feature .....</b>	<b>A–2</b>
Check External 24VDC Wiring Before Hot Swapping! .....	A–2
Hot Swap: I/O Module Replacement .....	A–3
Outputs Enable / Disable Switch .....	A–3

## **Appendix B: Analog Output Module Configuration**

<b>Analog Output Module Control Byte .....</b>	<b>B–2</b>
--	------------

---