

# GeckoBot Code Manual

Lars Schiller

June 21, 2018

## Contents

<b>1</b>	<b>Setting Up the BBB</b>	<b>1</b>
1.1	Install OS on BBB	1
1.2	Log in BBB for the first time	2
1.3	Set LAN connection on BBB at AmP	2
1.4	Configure SSH Connection to BBB	3
1.5	Configure BBB Device Tree	4
1.6	Installing Software on BBB	4
1.7	Running the Code	5
<b>2</b>	<b>Pin Layout</b>	<b>5</b>
<b>3</b>	<b>Auxiliary</b>	<b>5</b>
3.1	Formatting SD Card with debian	5
3.2	Set WiFi connection	6
3.3	Setup for analog inputs	6

## 1 Setting Up the BBB

### 1.1 Install OS on BBB

The developers of BBB embedded linux systems decided to change the device tree structure from `kernel` overlay (till version 8.7), to `uboot` overlay (9.1+). (Don't ask me to explain). However, the PWM setup for all pins is only possible with `kernel` overlay (or at least I'm not able to configure it in version 9.1+). Therefore you have to use the following image:

`bone-debian-8.7-iot-armhf-2017-03-19-4gb.img` (Download: <http://beagleboard.org/latest-images>)

To install it on a 8GB Micro-SD Card follow the instructions:

- You can use Etcher (<https://etcher.io/>).

OR (on debian):

- Instructions from: <http://derekmolloy.ie/write-a-new-image-to-the-beaglebone-black/>  
and from: <https://learn.adafruit.com/beaglebone-black-installing-operating-systems?view=all#copying-the-image-to-a-microsd>
- Decompress and write on SD card (need to be `su` and make sure the security locker of SD Adapter is in writing mode):

```
1 $ xz -d bone-debian-*.img.xz
2 $ dd if=./bone-debian-*.img of=/dev/sdX
```

(Here, `sdX` is the mounted empty uSD Card. It can be found with multiple use of the command `mount` or `df`.)

- Obsolete:
  - In order to turn these images into eMMC flasher images, edit the `/boot/uEnv.txt` file on the BBB and remove the # on the line with  
`cmdline=init=/opt/scripts/tools/eMMC/init-eMMC-flasher-v3.sh.`  
 Enabling this will cause booting the microSD card to flash the eMMC. Images are no longer provided here to avoid people accidentally overwriting their eMMC flash.
  - Insert the SD Card in the unpowered BBB, and power it by plugging in the USB or the 5VDC supply. Wait until all 4 LED have solid lights. This can take up to 45 minutes.
  - Flash MicroSD 4 with: `Debian 8.7 2017-03-19 4GB SD IoT` from <http://beagleboard.org/latest-images> (MicroSD 3 is weird ...).
  - Insert MicroSD in (unpowered) BBB, press the USER Button, and apply power.
  - It will take 30-45 minutes to flash the image onto the on-board chip. Once it is done, the bank of 4 LEDs to the right of the Ethernet port will all turn off. You can then power down your BBB.

## 1.2 Log in BBB for the first time

Assuming you are called `bianca` and your PC is also called `bianca`, your BBB is called `beaglebone` and the default user on BBB is called `debian`, then the following syntax is correct.

- Connect your PC with a MicroUSB cable to the BBB.
- Open a terminal and ssh into BBB as `debian` and then get superuser to configure the Board.

```

1 bianca@bianca:~ ssh debian@192.168.7.2
2 tempwd
3 debian@beaglebone:~ su
4 root
5 root@beaglebone:~#

```

- Note that the default passwords are:
 

tempwd	for debian
root	for root

## 1.3 Set LAN connection on BBB at AmP

This is from:

<https://groups.google.com/forum/#!msg/beaglebone/AS2US9rtNd4/8y0mZ3LxAwAJ>

- You have to configure `eth0` like this:
 

address	134.28.136.51 (ask administrator for your personal IP)
netmask	255.255.255.0
dns-nameservers	134.28.205.14
gateway	134.28.136.1

- Plug in LAN cable.
- Get the name of the LAN connection:

```

1 su
2 root@beaglebone:/etc/network# connmanctl services
3 *Ac Wired ethernet_689e19b50543_cable

```

- Using the appropriate ethernet service, tell `connman` to setup a static IP address for this service.

Syntax:

```

1 connmanctl config <service> --ipv4 manual <ip_addr> <netmask> <gateway> --nameservers <
  dns_server>

```

In our case:

```

1 connmanctl config ethernet_689e19b50543_cable --ipv4 manual 134.28.136.51 255.255.255.0
  134.28.136.1 --nameservers 134.28.205.14

```

- Reboot and you are done.
- You can revert back to a DHCP configuration simply as follows:

```
1 $ sudo connmanctl config ethernet_689e19b50543_cable --ipv4 dhcp
```

## 1.4 Configure SSH Connection to BBB

- Source: <https://askubuntu.com/questions/115151/how-to-set-up-passwordless-ssh-access-for-root-user>
- If your Board crashed, and you were forced to reinstall the OS, there already exist a ssh-key. This you have to remove first (this is for USB cable):

```
1 bianca@bianca:~ ssh-keygen -f "/home/bianca/.ssh/known_hosts" -R 192.168.7.2
```

- Generate a new key:

```
1 bianca@bianca:~ ssh-keygen -f "/home/bianca/.ssh/key_bianca"
```

When you are prompted for a password, just hit the enter key and you will generate a key with no password.

- Allow to log in as root with a password on the server, in aim to transfer the created key to it:

```
1 root@beaglebone:# nano /etc/ssh/sshd_config
```

Make sure you allow root to log in with the following syntax

```
1 PermitRootLogin yes
2 PasswordAuthentication yes
```

Restart the ssh-server:

```
1 root@beaglebone:# service ssh restart
```

- Now you are able to transfer the key to the server:

```
1 bianca@bianca:~ ssh-copy-id -i /home/bianca/.ssh/key_bianca root@192.168.7.2
```

- Check if its work:

```
1 bianca@bianca:~ ssh root@192.168.7.2
```

- Now disable root login with password on server (for saftey):

```
1 root@beaglebone:# nano /etc/ssh/sshd_config
```

And modify the Line:

```
1 PermitRootLogin without-password
2 PasswordAuthentication yes
```

This will allow to login as root with valid key, but not with a password. All other users can further login with a password. Restart the ssh-server and you are done:

```
1 root@beaglebone:# service ssh restart
```

## 1.5 Configure BBB Device Tree

In order to enable P9.28 as pwm pin, you have to load `cape-universala`. This you gonna do in `/boot/uEnv.txt`:

- source: <https://groups.google.com/forum/#!topic/beagleboard/EYSwmyxYjDM>
- `/boot/uEnv.txt` should be looking something like this:

```
1 root@beaglebone:# cat /boot/uEnv.txt | grep -v "#"  
3 uname_r=4.4.54-ti-r93  
4 cmdline=coherent_pool=1M quiet cape_universal=enable
```

Edit it with:

```
1 root@beaglebone:# nano /boot/uEnv.txt
```

Add the following lines, such that `/boot/uEnv.txt` looks like:

```
1 root@beaglebone:# cat /boot/uEnv.txt | grep -v "#"  
3 uname_r=4.4.54-ti-r93  
4 dtb=am335x-boneblack-overlay.dtb  
5 cmdline=coherent_pool=1M quiet cape_universal=enable  
6 cape_enable=bone_capemgr.enable_partno=cape-universala
```

- Reboot and you should be able to configure with:

```
1 root@beaglebone:# config-pin P9_28 pwm
```

Note:

- In `debian-elix-9.1+` the `/boot/uEnv.txt` looks like:

```
1 root@beaglebone:# cat /boot/uEnv.txt | grep -v "#"  
3 uname_r=4.9.82-ti-r102  
4 enable_uboot_overlays=1  
5 enable_uboot_cape_universal=1  
6 cmdline=coherent_pool=1M net.ifnames=0 quiet
```

If you see this, you may want to find a way to enable all the pins. I failed.

Robert C Nelson seems to be the only one, who has an idea whats going on... [https://elinux.org/Beagleboard:BeagleBoneBlack\\_Debian#U-Boot\\_Overlays](https://elinux.org/Beagleboard:BeagleBoneBlack_Debian#U-Boot_Overlays)

## 1.6 Installing Software on BBB

In order to run the `GeckoBot` software on the BBB install following packages:

- on BBB as `su`

```
1 root@beaglebone:# apt-get update  
2 root@beaglebone:# apt-get install ntpdate  
3 root@beaglebone:# ntpdate pool.ntp.org  
4 root@beaglebone:# apt-get install build-essential python-dev python-pip -y  
5 root@beaglebone:# pip install --upgrade pip  
6 root@beaglebone:# pip install Adafruit_BBIO  
7 root@beaglebone:# pip install Adafruit_GPIO  
8 root@beaglebone:# pip install termcolor  
9 root@beaglebone:# pip install numpy  
  
11 root@beaglebone:~# mkdir Git  
12 root@beaglebone:~# cd Git  
13 root@beaglebone:~/Git/# git clone https://github.com/larslevity/GeckoBot.git
```


## 1.7 Running the Code

To run the geckobot code:

- on BBB as su

```
1 root@beaglebone:~# cd Git/GeckoBot/Code
2 root@beaglebone:~ Git/GeckoBot/Code/# python server_hardware_controlled.py
```

## 2 Pin Layout

P9					P8			
Function	Physical Pins	Function	Function		Physical Pins	Function		
DGND	1	2	DGND	DGND	1	2	DGND	
VDD 3.3 V	3	4	VDD 3.3 V	MMC1_DAT6	3	4	MMC1_DAT7	
VDD 5V	5	6	VDD 5V	MMC1_DAT2	5	6	MMC1_DAT3	
SYS 5V	7	8	SYS 5V	GPIO_66	7	8	GPIO_67	
PWR_BTN	9	10	SYS_RESET	GPIO_69	9	10	GPIO_68	
UART4_RXD	11	12	GPIO_60	GPIO_45	11	12	GPIO_44	
UART4_TXD	13	14	EHRPWM1A	EHRPWM2B	13	14	GPIO_26	
GPIO_48	15	16	EHRPWM1B	GPIO_47	15	16	GPIO_46	
SPIO_CSO	17	18	SPIO_D1	GPIO_27	17	18	GPIO_65	
I2C_SCL	19	20	I2C_SDA	EHRPWM2A	19	20	MMC1_CMD	
SPIO_DO	21	22	SPIO_SLCK	MMC1_CLK	21	22	MMC1_DAT5	
GPIO_49	23	24	UART1_TXD	MMC1_DAT4	23	24	MMC1_DAT1	
GPIO_117	25	26	UART1_RXD	MMC1_DAT0	25	26	GPIO_61	
GPIO_115	27	28	SP11_CSO	LCD_VSYNC	27	28	LCD_PCLK	
SP11_DO	29	30	GPIO_112	LCD_HSYNC	29	30	LCD_AC_BIAS	
SP11_SCLK	31	32	VDD_ADC	LCD_DATA14	31	32	LCD_DATA15	
AIN4	33	34	GND_ADC	LCD_DATA13	33	34	LCD_DATA11	
AIN6	35	36	AIN5	LCD_DATA12	35	36	LCD_DATA10	
AIN2	37	38	AIN3	LCD_DATA8	37	38	LCD_DATA9	
AIN0	39	40	AIN1	LCD_DATA6	39	40	LCD_DATA7	
GPIO_20	41	42	ECAPWMO	LCD_DATA4	41	42	LCD_DATA5	
DGND	43	44	DGND	LCD_DATA2	43	44	LCD_DATA3	
DGND	45	46	DGND	LCD_DATA0	45	46	LCD_DATA1	

LEGEND	
Power, Ground, Reset	
Digital Pins	
PWM Output	
1.8 Volt Analog Inputs	
Shared I2C Bus	
Reconfigurable Digital	

Figure 1: Pin layout of BBB

The following pins were used, where Fx means foot x and y means leg or belly y:

Table 1: Used pins (Outdated)

P8-7	P8-8	P8-9	P8-10	P8-13	P8-19		
F1	F2	F3	F4	2	1		
P9-1	P9-5	P9-14	P9-16	P9-19	P9-20	P9-21	P9-22
VDD	GND	6	5	I2C-SCL	I2C-SDA	4	3

## 3 Auxilary

### 3.1 Formatting SD Card with debian

- Source: <https://www.techwalla.com/articles/how-to-format-an-sd-card-in-debian-linux>

- Determine location of SDCard (in the following called: `/dev/mmcblk0p2`) and directory where it is mounted (in the following called: `/media/SDCard`):

```
1 su
2 df
```

- Unmount, format, and remount:

```
1 umount /dev/mmcblk0p2
2 mkdosfs /dev/mmcblk0p2 -F16
3 mount /dev/mmcblk0p2 /media/SDCard
```

- For formatting SD with more than one partition, use:

```
1 cfdisk /dev/mmcblk0
```

and follow the instructions.

## 3.2 Set WiFi connection

- Order WiFi Antenna TP-LINK WLAN LITEN HI.G USB ADA. WN722N from somewhere.
- Complete this tutorial ...

## 3.3 Setup for analog inputs

- <https://groups.google.com/forum/#!topic/beagleboard/Lk3vWNIExiQ>
- Insert in command line on BBB:

```
1 su apt-get install bb-cape-overlays
3 cd /opt/source/bb.org-overlays
5 ./dtc-overlay.sh
7 ./install.sh
9 sudo sh -c "echo 'BB-ADC' > /sys/devices/platform/bone_capemgr/slots"
```

- Reboot.
- For readout the ADC input Pins from python: <https://learn.adafruit.com/setting-up-io-python-library-on-beaglebone-black/adc>