

For manual SDI plasma panel see: 3122 785 14940

Service
Service
Service



E_14710_000.eps
240604

Service Manual

Contents	Page
1. Technical Specifications, Connections, and Chassis Overview	2
2. Safety Instructions, Warnings, and Notes	4
3. Directions for Use	5
4. Mechanical Instructions	6
5. Service Modes, Error Codes, and Faultfinding	9
6. <i>Block Diagrams, Testpoint Overviews, and Waveforms</i>	
Wiring Diagram	15
Block Diagram Audio and Video	16
Block Diagram Audio and Video	17
Testpoint Overview SSB (Top Side)	18
I2C IC Overview	19
Supply Voltage Overview	20
7. <i>Circuit Diagrams and PWB Layouts</i>	<i>Diagram PWB</i>
SSB: Tuner and VIF (Diagram A1)	21 38-47
SSB: Histogram and Hercules (Diagram A2)	22 38-47
SSB: Histogram and Hercules (Diagram A3)	23 38-47
SSB: Audio Delay line (Lip sync) (Diagram A4)	24 38-47
SSB: Audio Amplifier (Diagram A5)	25 38-47
SSB: TV-Supply (Diagram A6)	26 38-47
SSB: Scaler (Diagram A7)	27 38-47
SSB: Scaler Supply (Diagram A8)	28 38-47
SSB: Scaler Interface (Diagram A9)	29 38-47
SSB: SDRAM (Diagram A10)	30 38-47
SSB: Flash / Control (Diagram A11)	31 38-47
SSB: HDMI (Reserved) (Diagram A12)	32 38-47
SSB: PCHD-MUX (Diagram A13)	33 38-47
SSB: Supply (Diagram A14)	34 38-47
SSB: DC-DC Converter (Diagram A15)	35 38-47
SSB: PCHD IO (Diagram A16)	36 38-47
SSB: Rear IO Scart (Diagram A17)	37 38-47
PDP Audio Panel (Diagram C)	48 49
Side IO Panel (Diagram D)	50 51

Contents	Page
Top Control Panel (Diagram E)	52 53
EMC Filter Panel (Diagram EMC)	54 55
LED and Switch Panel (Diagram J)	56 57
8. Alignments	59
9. Circuit Descriptions	63
Abbreviation List	68
IC Data Sheets	70
10 Spare Parts List	73
11 Revision List	78

©Copyright 2004 Philips Consumer Electronics B.V. Eindhoven, The Netherlands.
All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise without the prior permission of Philips.



1. Technical Specifications, Connections, and Chassis Overview

Index of this chapter:

- 1.1 Technical Specifications
- 1.2 Connection Overview
- 1.3 Chassis Overview

Note: Figures below can deviate slightly from the actual situation, due to the different set executions.

1.1 Technical Specifications

1.1.1 Vision

Display type	: PDP (SDI)
Screen size	: 37" (94 cm), 16:9
	: 42" (106 cm), 16:9
Resolution (HxV pixels)	: 852x480
Contrast ratio	: 3000:1
Light output (cd/m ²)	: 1000
Viewing angle (HxV degrees)	: 160x160
Tuning system	: PLL
TV Colour systems	: PAL B/G, D/K, I
	: SECAM B/G, D/K, L/L'
Video playback	: NTSC M/N 4.43
	: PAL B/G
	: SECAM L/L'
Supported inputs	: VGA (640x350)
	: VGA (640x480)
	: VGA (720x400)
	: MAC (640x480)
	: MAC (832x624)
	: SVGA (800x600)
	: XVGA (1024x768)
	: WXGA (1280x768)
	: PAL 576i 1fH CVI
	: NTSC 480i 1fH CVI
	: PAL 576p 2fH HD
	: NTSC 480p 2fH HD
Channel selections	: 100 presets
	: UVSH
Aerial input	: 75 ohm, Coax
	: IEC-type

1.1.2 Sound

Sound systems	: FM-mono
	: AM-mono
	: FM-stereo B/G
	: NICAM B/G, D/K, I, L
Maximum power (W _{RMS})	: 2 x 15

1.1.3 Miscellaneous

Power supply:	
- Mains voltage (V _{AC})	: 90 - 264
- Mains frequency (Hz)	: 50
Ambient conditions:	
- Temperature range (deg. C)	: +5 to +40°C
- Maximum humidity	: 90% R.H.

1.2 Connection Overview

Note: The following connector colour abbreviations are used (acc. to DIN/IEC 757): Bk= Black, Bu= Blue, Gn= Green, Gy= Grey, Rd= Red, Wh= White, and Ye= Yellow.

1.2.1 Rear Connections




Figure 1-1 Rear I/O

Cinch: Video CVBS - In, Audio - In

Wh - Audio L	0.5 V _{RMS} / 10kohm	⊕
Rd - Audio R	0.5 V _{RMS} / 10kohm	⊕
Ye - Video CVBS	1 V _{PP} / 75 ohm	⊕

SVHS (Hosiden): Video Y/C - In

1 - Ground Y	Gnd	⊕
2 - Ground C	Gnd	⊕
3 - Video Y	1 V _{PP} / 75 ohm	⊕
4 - Video C	0.3 V _{PP} / 75 ohm	⊕

VGA: Video RGB - In




Figure 1-2 VGA Connector

1 - Video Red	0.7 V _{PP} / 75 ohm	⊕
2 - Video Green	0.7 V _{PP} / 75 ohm	⊕
3 - Video Blue	0.7 V _{PP} / 75 ohm	⊕
4 - n.c.		
5 - Ground	Gnd	⊕
6 - Ground Red	Gnd	⊕
7 - Ground Green	Gnd	⊕
8 - Ground Blue	Gnd	⊕
9 - +5V_DC	+5 VDC	⊕
10 - Ground Sync	Gnd	⊕
11 - n.c.		
12 - DDC_SDA	DDC data	⊕
13 - H-sync	0 - 5 V	⊕
14 - V-sync	0 - 5 V	⊕
15 - DDC_SCL	DDC clock	⊕

Cinch: VGA (PC) Audio - In

Rd - Audio - R	0.5 V _{RMS} / 10 kohm	⊕
Wh - Audio - L	0.5 V _{RMS} / 10 kohm	⊕

Cinch: Audio - Out

Rd - Audio - R	0.5 V _{RMS} / 10 kohm	⊕
Wh - Audio - L	0.5 V _{RMS} / 10 kohm	⊕

External 2: Video CVBS/YC - In/Out, Audio - In/Out




Figure 1-3 SCART connector

1	- Audio R	0.5 V _{RMS} / 1 kohm	⊕
2	- Audio R	0.5 V _{RMS} / 10 kohm	⊕
3	- Audio L	0.5 V _{RMS} / 1 kohm	⊕
4	- Ground Audio	Gnd	⊥
5	- Ground Blue	Gnd	⊥
6	- Audio L	0.5 V _{RMS} / 10 kohm	⊕
7	- Video C	0.7 V _{PP} / 75 ohm	⊕
8	- Function Select	0 - 2 V: INT 4.5 - 7 V: EXT 16:9 9.5 - 12 V: EXT 4:3	⊕
9	- Ground Green	Gnd	⊥
10	- Easylink P50	0 - 5 V / 4.7 kohm	⊕
11	- n.c.		
12	- n.c.		
13	- Ground Red	Gnd	⊥
14	- Ground FBL	Gnd	⊥
15	- Video C	0.7 V _{PP} / 75 ohm	⊕
16	- n.c.		
17	- Ground Video	Gnd	⊥
18	- n.c.		
19	- Video CVBS	1 V _{PP} / 75 ohm	⊕
20	- Video Y/CVBS	1 V _{PP} / 75 ohm	⊕
21	- Shield	Gnd	⊥

External 1: Video RGB/YUV-In, CVBS-In/Out, Audio-In/Out

1	- Audio R	0.5 V _{RMS} / 1 kohm	⊕
2	- Audio R	0.5 V _{RMS} / 10 kohm	⊕
3	- Audio L	0.5 V _{RMS} / 1 kohm	⊕
4	- Ground Audio	Gnd	⊥
5	- Ground Blue	Gnd	⊥
6	- Audio L	0.5 V _{RMS} / 10 kohm	⊕
7	- Video Blue/U	0.7 V _{PP} / 75 ohm	⊕
8	- Function Select	0 - 2 V: INT 4.5 - 7 V: EXT 16:9 9.5 - 12 V: EXT 4:3	⊕
9	- Ground Green	Gnd	⊥
10	- n.c.		
11	- Video Green/Y	0.7 or 1 V _{PP} / 75 ohm	⊕
12	- n.c.		
13	- Ground Red	Gnd	⊥
14	- n.c.		
15	- Video Red/V	0.7 V _{PP} / 75 ohm	⊕
16	- RGB Ctrl	0 - 0.4 V: INT 1 - 3 V: EXT / 75 ohm	⊕
17	- Ground Video	Gnd	⊥
18	- Ground RGB Ctrl	Gnd	⊥
19	- Video CVBS	1 V _{PP} / 75 ohm	⊕
20	- Video CVBS	1 V _{PP} / 75 ohm	⊕
21	- Shield	Gnd	⊥

Aerial - In

-	- IEC-type (EU)	Coax, 75 ohm	⊥
---	-----------------	--------------	---

Service connector 1 (UART)

1	- UART_TX	Transmit data	⊕
2	- Ground	Gnd	⊥
3	- UART_RX	Receive data	⊕

Service connector 2 (ComPair)

1	- SDA-S	I ² C Data (0 - 5 V)	⊕
2	- SCL-S	I ² C Clock (0 - 5 V)	⊕
3	- Ground	Gnd	⊥

1.3 Chassis Overview




Figure 1-4 PWB / CBA locations

2. Safety Instructions, Warnings, and Notes

2.1 Safety Instructions

Safety regulations require that **during** a repair:

- Connect the set to the AC Power via an isolation transformer (> 800 VA).
- Replace safety components, indicated by the symbol ▲, only by components identical to the original ones. Any other component substitution (other than original type) may increase risk of fire or electrical shock hazard.

Safety regulations require that **after** a repair, the set must be returned in its original condition. Pay in particular attention to the following points:

- Route the wire trees correctly and fix them with the mounted cable clamps.
- Check the insulation of the AC Power lead for external damage.
- Check the strain relief of the AC Power cord for proper function.
- Check the electrical DC resistance between the AC Power plug and the secondary side (only for sets which have a AC Power isolated power supply):
 1. Unplug the AC Power cord and connect a wire between the two pins of the AC Power plug.
 2. Set the AC Power switch to the "on" position (keep the AC Power cord unplugged!).
 3. Measure the resistance value between the pins of the AC Power plug and the metal shielding of the tuner or the aerial connection on the set. The reading should be between 4.5 Mohm and 12 Mohm.
 4. Switch "off" the set, and remove the wire between the two pins of the AC Power plug.
- Check the cabinet for defects, to avoid touching of any inner parts by the customer.

2.2 Warnings

- All ICs and many other semiconductors are susceptible to electrostatic discharges (ESD ▲). Careless handling during repair can reduce life drastically. Make sure that, during repair, you are connected with the same potential as the mass of the set by a wristband with resistance. Keep components and tools also at this same potential. Available ESD protection equipment:
 - Complete kit ESD3 (small tablemat, wristband, connection box, extension cable and earth cable) 4822 310 10671.
 - Wristband tester 4822 344 13999.
- Be careful during measurements in the high voltage section.
- Never replace modules or other components while the unit is switched "on".
- When you align the set, use plastic rather than metal tools. This will prevent any short circuits and the danger of a circuit becoming unstable.

2.3 Notes

2.3.1 General

- Measure the voltages and waveforms with regard to the chassis (= tuner) ground (⊕), or hot ground (⊖), depending on the tested area of circuitry. The voltages and waveforms shown in the diagrams are indicative. Measure them in the Service Default Mode (see chapter 5) with a colour bar signal and stereo sound (L: 3 kHz, R: 1 kHz unless stated otherwise) and picture carrier at 475.25 MHz for PAL, or 61.25 MHz for NTSC (channel 3).

- Where necessary, measure the waveforms and voltages with (⊖) and without (⊕) aerial signal. Measure the voltages in the power supply section both in normal operation (⊖) and in standby (⊕). These values are indicated by means of the appropriate symbols.
- The semiconductors indicated in the circuit diagram and in the parts lists, are interchangeable per position with the semiconductors in the unit, irrespective of the type indication on these semiconductors.
- Manufactured under license from Dolby Laboratories. "Dolby" and the "double-D symbol", are trademarks of Dolby Laboratories.

2.3.2 Schematic Notes

- All resistor values are in ohms and the value multiplier is often used to indicate the decimal point location (e.g. 2K2 indicates 2.2 kohm).
- Resistor values with no multiplier may be indicated with either an "E" or an "R" (e.g. 220E or 220R indicates 220 ohm).
- All capacitor values are given in micro-farads ($\mu = \times 10^{-6}$), nano-farads ($n = \times 10^{-9}$), or pico-farads ($p = \times 10^{-12}$).
- Capacitor values may also use the value multiplier as the decimal point indication (e.g. 2p2 indicates 2.2 pF).
- An "asterisk" (*) indicates component usage varies. Refer to the diversity tables for the correct values.
- The correct component values are listed in the Electrical Replacement Parts List. Therefore, always check this list when there is any doubt.

2.3.3 Rework on BGA (Ball Grid Array) ICs

General

Although (LF)BGA assembly yields are very high, there may still be a requirement for component rework. By rework, we mean the process of removing the component from the PWB and replacing it with a new component. If an (LF)BGA is removed from a PWB, the solder balls of the component are deformed drastically so the removed (LF)BGA has to be discarded.

Device Removal

As is the case with any component that, it is essential when removing an (LF)BGA, the board, tracks, solder lands, or surrounding components are not damaged. To remove an (LF)BGA, the board must be uniformly heated to a temperature close to the reflow soldering temperature. A uniform temperature reduces the chance of warping the PWB. To do this, we recommend that the board is heated until it is certain that all the joints are molten. Then carefully pull the component off the board with a vacuum nozzle. For the appropriate temperature profiles, see the IC data sheet.

Area Preparation

When the component has been removed, the vacant IC area must be cleaned before replacing the (LF)BGA. Removing an IC often leaves varying amounts of solder on the mounting lands. This excessive solder can be removed with either a solder sucker or solder wick. The remaining flux can be removed with a brush and cleaning agent. After the board is properly cleaned and inspected, apply flux on the solder lands and on the connection balls of the (LF)BGA. **Note:** Do not apply solder paste, as this has shown to result in problems during re-soldering.

Device Replacement

The last step in the repair process is to solder the new component on the board. Ideally, the (LF)BGA should be aligned under a microscope or magnifying glass. If this is not possible, try to align the (LF)BGA with any board markers. To reflow the solder, apply a temperature profile according to the *IC data sheet*. So as not to damage neighbouring components, it may be necessary to reduce some temperatures and times.

More Information

For more information on how to handle BGA devices, visit this URL: www.atyourservice.ce.philips.com (needs subscription, not available for all regions)). After login, select "Magazine", then go to "Workshop Information". Here you will find Information on how to deal with BGA-ICs.

2.3.4 Lead Free Solder

Philips CE is going to produce lead-free sets (PBF) from 1.1.2005 onwards.

Lead-free sets will be indicated by the PHILIPS-lead-free logo on the Printed Wiring Boards (PWB):




Figure 2-1 Lead-free logo

This sign normally has a diameter of 6 mm, but if there is less space on a board also 3 mm is possible.

In case of doubt whether the board is lead-free or not (or with mixed technologies), you can use the following method:

- Always use the highest temperature to solder, when using SAC305 (see also instructions below).
- De-solder thoroughly (clean solder joints to avoid mix of two alloys).

Caution: For BGA-ICs, you **must** use the correct temperature-profile, which is coupled to the 12NC. For an overview of these profiles, visit the website www.atyourservice.ce.philips.com (needs subscription, but is not available for all regions) You will find this and more technical information within the "Magazine", chapter "Workshop information". For additional questions please contact your local repair-helpdesk.

Due to lead-free technology some rules have to be respected by the workshop during a repair:

- Use only lead-free soldering tin Philips SAC305 with order code 0622 149 00106. If lead-free solder paste is required, please contact the manufacturer of your soldering equipment. In general, use of solder paste within workshops should be avoided because paste is not easy to store and to handle.
 - Use only adequate solder tools applicable for lead-free soldering tin. The solder tool must be able
 - To reach at least a solder-tip temperature of 400°C.
 - To stabilise the adjusted temperature at the solder-tip.
 - To exchange solder-tips for different applications.
 - Adjust your solder tool so that a temperature around 360°C - 380°C is reached and stabilised at the solder joint. Heating time of the solder-joint should not exceed ~ 4 sec. Avoid temperatures above 400°C, otherwise wear-out of tips will rise drastically and flux-fluid will be destroyed. To avoid wear-out of tips, switch "off" unused equipment or reduce heat.
 - Mix of lead-free soldering tin/parts with leaded soldering tin/parts is possible but PHILIPS recommends strongly to avoid mixed regimes. If not to avoid, clean carefully the solder-joint from old tin and re-solder with new tin.
 - Use only original spare-parts listed in the Service-Manuals. Not listed standard material (commodities) has to be purchased at external companies.
 - Special information for lead-free BGA ICs: these ICs will be delivered in so-called "dry-packaging" to protect the IC against moisture. This packaging may only be opened short before it is used (soldered). Otherwise the body of the IC gets "wet" inside and during the heating time the structure of the IC will be destroyed due to high (steam-)pressure inside the body. If the packaging was opened before usage, the IC has to be heated up for some hours (around 90°C) for drying (think of ESD-protection !).
- Do not re-use BGAs at all!**
- For sets produced before 1.1.2005, containing leaded soldering tin and components, all needed spare parts will be available till the end of the service period. For the repair of such sets nothing changes.

2.3.5 Practical Service Precautions

- **It makes sense to avoid exposure to electrical shock.** While some sources are expected to have a possible dangerous impact, others of quite high potential are of limited current and are sometimes held in less regard.
- **Always respect voltages.** While some may not be dangerous in themselves, they can cause unexpected reactions - reactions that are best avoided. Before reaching into a powered TV set, it is best to test the high voltage insulation. It is easy to do, and is a good service precaution.

3. Directions for Use

You can download this information from the following websites:

<http://www.philips.com/support>
<http://www.p4c.philips.com>

4. Mechanical Instructions


Index of this chapter:

- 4.1 Cable Dressing
- 4.2 Service Positions
- 4.3 Assy/Panel Removal
- 4.4 Set Re-assembly

Notes:

- Figures below can deviate slightly from the actual situation, due to the different set executions.
- Follow the disassemble instructions in described order.

4.1 Cable Dressing



E_14720_012.eps
130804


Figure 4-1 Cable dressing

4.2 Service Positions

For easy servicing of this set, there are a few possibilities created:

- The buffers from the packaging (see figure "Rear cover").
- Foam bars (created for service).
- Aluminium service stands (created for Service).

4.2.1 Foam Bars




E_06532_018.eps
170504

Figure 4-2 Foam bars

The foam bars (order code 3122 785 90580 for two pieces) can be used for all types and sizes of Flat TVs. By laying the TV face down on the (ESD protective) foam bars, a stable situation is created to perform measurements and alignments. By placing a mirror under the TV, you can monitor the screen.

4.2.2 Aluminium Stands



E_06532_019.eps
170504

Figure 4-3 Aluminium stands (drawing of MkI)

The aluminium stands (order code 3122 785 90480) can be mounted with the back cover removed or still left on. So, the stand can be used to store products or to do measurements. It is also very suitable to perform duration tests without taking much space, without having the risk of overheating, or the risk of products falling. The stands can be mounted and removed quick and easy with use of the delivered screws that can be tightened and loosened manually without the use of tools. See figure above.

Note: Only use the delivered screws to mount the monitor to the stands.

4.3 Assy/Panel Removal

4.3.1 Metal Back Plate

Warning: Disconnect the mains power cord before you open the set.

1. Place the TV set upside down on a table top, using the foam bars (see part "Foam Bars").
Caution: do **not** put pressure on the display, but let the monitor lean on the speakers or the Front cover.
2. Remove all T10 screws from the metal back plate.
3. Then, remove the four "mushrooms" from the back plate.
4. Lift the back plate from the set. Make sure that wires and flat foils are not damaged during the back plate removal.

4.3.2 Rear Cover

1. Remove the screws that secure the rear cover. The screws are located at the top, bottom, left and right sides.
2. Lift the rear cover from the cabinet. Make sure that wires and flat foils are not damaged during cover removal.

4.3.3 EMC Interface Panel

1. Disconnect the cables from the panel.
2. Remove the fixation screws.
3. Take out the panel.

4.3.4 LED/Switch Panel

1. Remove the fixation screws.
2. Take out the panel.
3. Disconnect the cable from the rear of the panel.

4.3.5 Top Control Panel

1. Remove the fixation screws.
2. Release the two fixation clamps and lift the panel out of the bracket.
3. Take out the panel.
4. Disconnect the cable from the panel.

4.3.6 Small Signal Panel (SSB) and Side I/O Panel




Figure 4-4 SSB Connector plate




Figure 4-5 Shielding of the SSB

1. Remove the middle fixation screw (1) from the bottom side of the connector plate (as this holds the SSB bracket).
Note: Sometimes it is easier to loosen the complete connector plate and remove it together with the SSB.
2. Remove all connector fixation screws (2) from the front side of the connector plate.
3. Remove the two female screw locks (3) of the VGA connector.
4. Release the plastic cable clips (4) on the shielding and disconnect all cables from the SSB.
Note: Be careful with the fragile LVDS connector on the SSB.
5. Now, completely remove the SSB (together with all the shieldings) from the set.
6. Once the SSB is out, remove the fixation screws (5) from the shielding.
7. Remove the shielding, it hinges at the left side (acc. photo).
8. Remove the fixation screws that hold the panel(s), and take out the panel(s).

Notes:

- Pay special attention to the EMC foam on the SSB shielding. These must be replaced in their initial positions during set re-assembly.
- Insulate the tuner pins, so they cannot touch the shielding (see also figure "SDM Service jumper" in Chapter 5).

4.3.7 Audio Panel

1. Disconnect all cables from the panel.
2. Remove the fixation screws and take out the panel.

4.3.8 Plasma Panel

Important: Be sure to work in a dust free environment during the following activities. In addition, the use of (fabric) hand gloves is advised.




Figure 4-6 Plasma panel disassembly

Disassembly

1. Place the TV set face down on the foam bars. Place the bars at the edges of the set, so they will support the front frame and not only the glass plate!
2. Remove the LED/Switch and Top Control panels (1).
3. Next step is to unplug the following cables (see also "Wiring Diagram" in Chapter 6):
 - AC Power (Mains) plug between Mains Filter and PSU (loosen cable from clamps).
 - All cables on the Audio panel.
 - LVDS plug on SSB. **Caution:** Be careful, because this connection is very fragile!
 - SSB supply plugs on PSU.
 - Audio Panel supply plug on PSU.

- Loudspeaker connections on speakers.
- 4. Remove all T10 parker screws around the frame (2).
- 5. Remove the two T10 tapping screws that hold the SSB (3).
- 6. Remove the four T25 screws (4) that hold the plasma panel.
- 7. Lift the (gold coloured) plastic frame together with its PWBs (except the Audio Panel) from the PDP panel.
- 8. Now the PDP (incl. the PSU and driving panels) can be removed.
- 9. Before sending the plasma panel to the NSO for repair or exchange, remove all its panels.

Assembly

In order to centre the (new) plasma panel correctly w.r.t. the glass plate, do the following:

1. Place the (new) plasma panel face down on foam bars.
2. Also, place the front assy (front panel with glass plate) on two other foam bars.
3. Mount the plastic frame on the plasma panel.
4. Lift the assy (frame and PDP), and place it into the front assy.
5. Now follow the above described disassembly process in reverse order.

4.4 Set Re-assembly

To re-assemble the whole set, execute all processes in reverse order.

Notes:

- While re-assembling, make sure that all cables are placed and connected in their original position. See figure "Cable dressing".
- Pay special attention not to damage the EMC foams at the SSB shields. Control that EMC foams are put correctly on their places.

5. Service Modes, Error Codes, and Fault Finding

Index of this chapter:

- 5.1 Test Points
- 5.2 Service Modes
- 5.3 Problems and Solving Tips Related to CSM
- 5.4 ComPair
- 5.5 Error Codes
- 5.6 The Blinking LED Procedure
- 5.7 Fault Finding and Repair Tips

5.1 Test Points

This chassis is equipped with test points in the service printing. In the schematics test points are identified with a rectangle box around Fxxx or lxxx. These test points are specifically mentioned in the service manual as "half moons" with a dot in the centre.

Perform measurements under the following conditions:

- Television set in Service Default Alignment Mode.
- Video input: Colour bar signal.
- Audio input: 3 kHz left channel, 1 kHz right channel.

5.2 Service Modes

Service Default mode (SDM) and Service Alignment Mode (SAM) offers several features for the service technician, while the Customer Service Mode (CSM) is used for communication between the call centre and the customer.

This chassis also offers the option of using ComPair, a hardware interface between a computer and the TV chassis. It offers the abilities of structured troubleshooting, error code reading, and software version read-out for all chassis.

Minimum requirements for ComPair: a Pentium processor, a Windows OS, and a CD-ROM drive (see also paragraph "ComPair").

5.2.1 Service Default Mode (SDM)

Purpose

- To create a predefined setting for measurements to be made.
- To override software protections.
- To start the blinking LED procedure.
- To inspect the error buffer.
- To check the life timer.

Specifications

- Tuning frequency: 475.25 MHz.
- Colour system: PAL B/G.
- All picture settings at 50% (brightness, colour contrast, hue).
- Bass, treble and balance at 50%; volume at 25%.
- All service-unfriendly modes (if present) are disabled. The service unfriendly modes are:
 - Timer / Sleep timer.
 - Child / parental lock.
 - Blue mute.
 - Hotel / hospital mode.
 - Auto shut off (when no "IDENT" video signal is received for 15 minutes).
 - Skipping of non-favourite presets / channels.
 - Auto-storage of personal presets.
 - Auto user menu time-out.
 - Auto Volume Levelling (AVL).

How to enter


To enter SDM, use one of the following methods:

- Press the following key sequence on the remote control transmitter: "062596" directly followed by the MENU

button (do not allow the OSD display to time out between entries while keying the sequence).

- Short SDM jumper (item 4022, see Figure "Service jumper") on the TV board and apply AC Power. Remove the short after start-up.


Caution: Entering SDM by shorting "Service" jumpers will override the software protections. Do this only for a short period. **When doing this, the service-technician must know exactly what he is doing, as it could damage the television set.**



E_14710_062.eps
260804

Figure 5-1 SDM Service jumper

After entering SDM, the following screen is visible, with SDM in the upper right corner of the screen to indicate that the television is in Service Default Alignment Mode.



E_14710_006.eps
240604

Figure 5-2 SDM menu (example from LC4.2E)

How to navigate

When you press the MENU button on the remote control, the set will switch on the normal user menu in the SDM mode.

How to exit

Switch the set to STANDBY by pressing the POWER button on the remote control transmitter.

If you turn the television set off by removing the mains (i.e., unplugging the television) or by using the POWER button on the TV set, the television set will remain in SDM when mains is re-applied, and the error buffer is not cleared.

5.2.2 Service Alignment Mode (SAM)

Purpose

- To change option settings.
- To display / clear the error code buffer.
- To perform alignments.


Specifications

- Operation hours counter (maximum five digits displayed).
- Software version, Error codes, and Option settings display.
- Error buffer clearing.
- Option settings.
- Software alignments (Tuner, White Tone, Geometry, and Audio).
- NVM Editor.
- ComPair Mode switching.

How to enter

Press the following key sequence on the remote control transmitter: "062596" directly followed by the OSD/STATUS/INFO button (do not allow the OSD display to time out between entries while keying the sequence).

After entering SAM, the following screen is visible, with SAM in the upper right corner of the screen to indicate that the television is in Service Alignment Mode.



E_14710_007.eps
240604

Figure 5-3 SAM menu (example from LC4.2E)

Menu explanation

1. **LLLLL**. This represents the run timer. The run timer counts normal operation hours (including "on/off" switching), but does not count stand-by hours.
2. **AAAABCD-X.YY/EEEEEE_F.GG**. This is the software identification of the Main/Scaler microprocessor:
 - **A**= the chassis name.
 - **B**= the region: E= Europe, A= Asia Pacific, U= NAFTA, L= LATAM.
 - **C**= the software diversity:
 - **Europe**: T= 1 pg TXT, F= Full TXT, V= Voice ctrl.
 - **LATAM and NAFTA**: N= Stereo non-dBx, S= Stereo dBx.
 - **Asian Pacific**: T= TXT, N= non-TXT, C= NTSC.
 - **ALL regions**: M= mono, D= DVD, Q= Mk2.
 - **D**= the language cluster number.
 - **X**= the Main software version number (updated with a major change that is incompatible with previous versions).
 - **YY**= the sub software version number (updated with a minor change that is compatible with previous versions).
 - **EEEEEE**= the Scaler SW cluster
 - **F**= the Scaler SW version no.
 - **GG**= the sub-version no.
3. **SAM**. Indication of the Service Alignment Mode.

4. **ERROR BUFFER (ERR)**. Shows all errors detected since the last time the buffer was erased. Five errors possible.
5. **OPTION BYTES (OP)**. Shows all option settings. See "Options" in the Alignments section for a detailed description. Seven codes are available.
6. **CLEAR**. Erases the contents of the error buffer. Select the CLEAR menu item and press the CURSOR RIGHT key. The content of the error buffer is cleared.
7. **OPTIONS**. Used to set the option bits. See "Options" in the Alignments section for a detailed description.
8. **TUNER**. Used to align the tuner. See "Tuner" in the Alignments section for a detailed description.
9. **WHITE TONE**. Used to align the white tone. See "White Tone" in the Alignments section for a detailed description.
10. **AUDIO**. No audio alignment is necessary for this television set.
11. **NVM EDITOR**. Can be used to change the NVM data in the television set.
12. **SC NVM EDITOR**. Can be used to edit Scaler NVM.
13. **TEST PATTERN**. For future use.
14. **COMPAIR**. Can be used to switch the television to "In System Programming" (ISP) mode, for software uploading via ComPair.

Caution: When this mode is selected without ComPair connected, the TV will be blocked. Remove the AC power to reset the TV.

How to navigate

- In SAM, select menu items with the CURSOR UP/DOWN keys on the remote control transmitter. The selected item will be highlighted. When not all menu items fit on the screen, use the CURSOR UP/DOWN keys to display the next / previous menu items.
- With the CURSOR LEFT/RIGHT keys, it is possible to:
 - Activate the selected menu item.
 - Change the value of the selected menu item.
 - Activate the selected submenu.
- In SAM, when you press the MENU button twice, the set will switch to the normal user menus (with the SAM mode still active in the background). To return to the SAM menu press the MENU button again.
- When you press the MENU key in while in a submenu, you will return to the previous menu.

How to store SAM settings

To store the settings changed in SAM mode, leave the top level SAM menu by using the POWER button on the remote control transmitter or the television set.

How to exit

Switch the set to STANDBY by pressing the POWER button on the remote control transmitter or on the television set.

5.2.3 Customer Service Mode (CSM)

Purpose

The Customer Service Mode shows error codes and information on the TV's operation settings. The call centre can instruct the customer (by telephone) to enter CSM in order to identify the status of the set. This helps the call centre to diagnose problems and failures in the TV set before making a service call.

The CSM is a read-only mode; therefore, modifications are not possible in this mode.

How to enter

To enter CSM, press the following key sequence on the remote control transmitter: "123654" (do not allow the OSD display to time out between entries while keying the sequence).

Upon entering the Customer Service Mode, the following screen will appear:


```

1 00022 LC42EP1 2.03/S42GV1 2.02 CSM
2 CODES 0 0 0 0 0
3 OP 000 057 140 032 120 128 000
4
5
6 NOT TUNED
7 PAL
8 STEREO
9 CO 50 CL 50 BR 50
0 AVL Off

```

E_14710_008.eps
240604

Figure 5-4 CSM menu (example from LC4.2E)

Menu explanation

1. Indication of the decimal value of the operation hours counter, Main/Scaler software version (see "Service Alignment Mode" for an explanation), and service mode (CSM= Customer Service Mode).
2. Displays the last five errors detected in the error code buffer.
3. Displays the option bytes.
4. Displays the type number version of the set (option).
5. Reserved.
6. Indicates the television is receiving an "IDENT" signal on the selected source. If no "IDENT" signal is detected, the display will read "NOT TUNED"
7. Displays the detected Colour system (e.g. PAL/NTSC).
8. Displays the detected Audio (e.g. stereo/mono).
9. Displays the picture setting information.
10. Displays the sound setting information.

How to exit

To exit CSM, use one of the following methods:

- Press the MENU, STATUS (or EXIT/INFO/[i+]), or POWER button on the remote control transmitter.
- Press the POWER button on the television set.

5.3 Problems and Solving Tips Related to CSM

5.3.1 Picture Problems

Note: The problems described below are all related to the TV settings. The procedures used to change the value (or status) of the different settings are described.

Picture too dark or too bright

If:

- The picture improves when you press the AUTO PICTURE button on the remote control transmitter, or
- The picture improves when you enter the Customer Service Mode,

Then:

1. Press the AUTO PICTURE button on the remote control transmitter repeatedly (if necessary) to choose PERSONAL picture mode.
2. Press the MENU button on the remote control transmitter. This brings up the normal user menu.
3. In the normal user menu, use the CURSOR UP/DOWN keys to highlight the PICTURE sub menu.
4. Press the CURSOR LEFT/RIGHT keys to enter the PICTURE sub menu.
5. Use the CURSOR UP/DOWN keys (if necessary) to select BRIGHTNESS.

6. Press the CURSOR LEFT/RIGHT keys to increase or decrease the BRIGHTNESS value.
7. Use the CURSOR UP/DOWN keys to select PICTURE.
8. Press the CURSOR LEFT/RIGHT keys to increase or decrease the PICTURE value.
9. Press the MENU button on the remote control transmitter twice to exit the user menu.
10. The new PERSONAL preference values are automatically stored.

White line(s) around picture elements and text

If:

The picture improves after you have pressed the AUTO PICTURE button on the remote control transmitter,

Then:

1. Press the AUTO PICTURE button on the remote control transmitter repeatedly (if necessary) to choose PERSONAL picture mode.
2. Press the MENU button on the remote control transmitter. This brings up the normal user menu.
3. In the normal user menu, use the CURSOR UP/DOWN keys to highlight the PICTURE sub menu.
4. Press the CURSOR LEFT/RIGHT keys to enter the PICTURE sub menu.
5. Use the CURSOR UP/DOWN keys to select SHARPNESS.
6. Press the CURSOR LEFT key to decrease the SHARPNESS value.
7. Press the MENU button on the remote control transmitter twice to exit the user menu.
8. The new PERSONAL preference value is automatically stored.

Snowy picture

Check CSM line 6. If this line reads "Not Tuned", check the following:

- Antenna not connected. Connect the antenna.
- No antenna signal or bad antenna signal. Connect a proper antenna signal.
- The tuner is faulty (in this case line 2, the Error Buffer line, will contain error number 10). Check the tuner and replace/repair the tuner if necessary.

Black and white picture

If:

- The picture improves after you have pressed the AUTO PICTURE button on the remote control transmitter,

Then:

1. Press the AUTO PICTURE button on the remote control transmitter repeatedly (if necessary) to choose PERSONAL picture mode.
2. Press the MENU button on the remote control transmitter. This brings up the normal user menu.
3. In the normal user menu, use the CURSOR UP/DOWN keys to highlight the PICTURE sub menu.
4. Press the CURSOR LEFT/RIGHT keys to enter the PICTURE sub menu.
5. Use the CURSOR UP/DOWN keys to select COLOUR.
6. Press the CURSOR RIGHT key to increase the COLOUR value.
7. Press the MENU button on the remote control transmitter twice to exit the user menu.
8. The new PERSONAL preference value is automatically stored.

Menu text not sharp enough

If:

- The picture improves after you have pressed the AUTO PICTURE button on the remote control transmitter,

Then:

1. Press the AUTO PICTURE button on the remote control transmitter repeatedly (if necessary) to choose PERSONAL picture mode.
2. Press the MENU button on the remote control transmitter. This brings up the normal user menu.
3. In the normal user menu, use the CURSOR UP/DOWN keys to highlight the PICTURE sub menu.
4. Press the CURSOR LEFT/RIGHT keys to enter the PICTURE sub menu.
5. Use the CURSOR UP/DOWN keys to select PICTURE.
6. Press the CURSOR LEFT key to decrease the PICTURE value.
7. Press the MENU button on the remote control transmitter twice to exit the user menu.
8. The new PERSONAL preference value is automatically stored.

5.4 ComPair

5.4.1 Introduction

ComPair (Computer Aided Repair) is a service tool for Philips Consumer Electronics products. ComPair is a further development on the European DST (service remote control), which allows faster and more accurate diagnostics. ComPair has three big advantages:

- ComPair helps you to quickly get an understanding on how to repair the chassis in a short time by guiding you systematically through the repair procedures.
- ComPair allows very detailed diagnostics (on I²C level) and is therefore capable of accurately indicating problem areas. You do not have to know anything about I²C commands yourself because ComPair takes care of this.
- ComPair speeds up the repair time since it can automatically communicate with the chassis (when the microprocessor is working) and all repair information is directly available. When ComPair is installed together with the Force/SearchMan electronic manual of the defective chassis, schematics and PWBs are only a mouse click away.

5.4.2 Specifications

ComPair consists of a Windows based fault finding program and an interface box between PC and the (defective) product. The ComPair interface box is connected to the PC via a serial (or RS232) cable.

For this chassis, the ComPair interface box and the TV communicate via a bi-directional service cable via the service connector(s).

The ComPair fault finding program is able to determine the problem of the defective television. ComPair can gather diagnostic information in two ways:

- Automatic (by communication with the television): ComPair can automatically read out the contents of the entire error buffer. Diagnosis is done on I²C/UART level. ComPair can access the I²C/UART bus of the television. ComPair can send and receive I²C/UART commands to the micro controller of the television. In this way, it is possible for ComPair to communicate (read and write) to devices on the I²C/UART buses of the TV-set.
- Manually (by asking questions to you): Automatic diagnosis is only possible if the micro controller of the television is working correctly and only to a certain extend. When this is not the case, ComPair will guide you through

the fault finding tree by asking you questions (e.g. *Does the screen give a picture? Click on the correct answer: YES / NO*) and showing you examples (e.g. *Measure test-point I7 and click on the correct oscilloscope you see on the oscilloscope*). You can answer by clicking on a link (e.g. text or a waveform picture) that will bring you to the next step in the fault finding process.

By a combination of automatic diagnostics and an interactive question / answer procedure, ComPair will enable you to find most problems in a fast and effective way.

Beside fault finding, ComPair provides some **additional features** like:

- Up- or downloading of pre-sets.
- Managing of pre-set lists.
- Emulation of the (European) Dealer Service Tool (DST).
- If both ComPair and Force/SearchMan (Electronic Service Manual) are installed, all the schematics and the PWBs of the set are available by clicking on the appropriate hyperlink.

Example: *Measure the DC-voltage on capacitor C2568 (Schematic/Panel) at the Mono-carrier.*

- Click on the “Panel” hyperlink to automatically show the PWB with a highlighted capacitor C2568.
- Click on the “Schematic” hyperlink to automatically show the position of the highlighted capacitor.

5.4.3 How To Connect

1. First, install the ComPair Browser software (see the Quick Reference Card for installation instructions).
2. Connect the RS232 interface cable between a free serial (COM) port of your PC and the PC connector (marked with “PC”) of the ComPair interface.
3. Connect the mains adapter to the supply connector (marked with “POWER 9V DC”) of the ComPair interface.
4. Switch the ComPair interface “OFF”.
5. Switch the television set “OFF” with the POWER switch.
6. Connect the ComPair I²C/UART interface cable between the connector on the rear side of the ComPair interface (marked with “I²C” or for UART on the connector marked “VCR”) and the appropriate ComPair connector at the rear side of the TV (I²C or UART).

Note: Some chassis need an additional I²C extension cable due to a different connector pitch!

7. Plug the mains adapter in a mains outlet, and switch the interface “ON”. The green and red LEDs light up together. The red LED extinguishes after approx. 1 second while the green LED remains lit.
8. Start the ComPair program and read the “Introduction” chapter.




Figure 5-5 ComPair Interface connection

5.4.4 How To Order

ComPair order codes (EU/AP/LATAM):

- Starter kit ComPair32/SearchMan32 software and ComPair interface (excl. transformer): 3122 785 90450.
- ComPair interface (excluding transformer): 4822 727 21631.
- Starter kit ComPair32 software (registration version): 3122 785 60040.

- Starter kit SearchMan32 software: 3122 785 60050.
- ComPair32 CD (update): 3122 785 60070 (year 2002, 3122 785 60110 (year 2003).
- SearchMan32 CD (update): 3122 785 60080 (year 2002), 3122 785 60120 (year 2003), 3122 785 60130 (year 2004).
- ComPair I²C interface cable: 3122 785 90004.
- ComPair firmware upgrade IC: 3122 785 90510.
- Transformer (non-UK): 4822 727 21632.
- Transformer (UK): 4822 727 21633.
- ComPair I²C extension cable: 3139 131 03791.
- ComPair UART interface cable: 3122 785 90630.

Note: If you encounter any problems, contact your local support desk.

5.5 Error Codes

The error code buffer contains all errors detected since the last time the buffer was erased. The buffer is written from left to right. When an error occurs that is not yet in the error code buffer, it is displayed at the left side and all other errors shift one position to the right.

5.5.1 How To Read The Error Buffer

You can read the error buffer in 3 ways:

- On screen via the SAM (if you have a picture).
 - Examples:**
 - ERROR: 0 0 0 0 0: No errors detected
 - ERROR: 6 0 0 0 0: Error code 6 is the last and only detected error
 - ERROR: 9 6 0 0 0: Error code 6 was detected first and error code 9 is the last detected (newest) error
- Via the blinking LED procedure (when you have no picture). See “The Blinking LED Procedure”.
- Via ComPair.

5.5.2 How To Clear The Error Buffer

The error code buffer is cleared in the following cases:

- By using the CLEAR command in the SAM menu:
 - To enter SAM, press the following key sequence on the remote control transmitter: “062596” directly followed by the OSD/STATUS button (do not allow the OSD display to time out between entries while keying the sequence).
 - Make sure the menu item CLEAR is highlighted. Use the CURSOR UP/DOWN buttons, if necessary.
 - Press the CURSOR RIGHT button to clear the error buffer. The text on the right side of the “CLEAR” line will change from “CLEAR?” to “CLEARED”
- If an error does not reoccur within 50 hours it is deleted from the error buffer.

5.5.3 Error Codes

In case of non-intermittent faults, write down the errors present in the error buffer and clear the error buffer before you begin the repair. This ensures that old error codes are no longer present.

If possible, check the entire contents of the error buffer. In some situations, an error code is only the result of another error and not the actual cause of the problem (for example, a fault in the protection detection circuitry can also lead to a protection).

Table 5-1 Error code overview

Error	Device	Error description	Check item	Diagram
0	Not applicable	-	-	-
1	Not applicable	-	-	-
2	Not applicable	-	-	-
3	Not applicable	-	-	-
4	GM1501 Scaler Flash-ROM	I ² C error while communicating with the Genesis Scaler and/or Flash-ROM is faulty/empty	7401 7530	A7 A11
5	Not applicable	+5V protection	7930	A6
6	I ² C bus	General I ² C error	7011, 3088, 3096	A2
7	Not applicable	-	-	-
8	M24C32	I ² C error while communicating with the Scaler EEPROM	7531	A11
9	M24C16	I ² C error while communicating with the EEPROM	7099	A2
10	Tuner	I ² C error while communicating with the PLL tuner	1302, 3302, 3303, 3327	A1
11	Not applicable	-	-	-
12	Not applicable	-	-	-
13	Not applicable	-	-	-
14	K4D263238M	Read-write error with the Scaler SDRAM	7501	A10
15	TDA9178T/N1	I ² C error while communicating with Histogram	7560	A3
16	TDA9178T/N1	I ² C error while communicating with EPLD on Pixel Plus panel	7560	A3

5.6 The Blinking LED Procedure

Using this procedure, you can make the contents of the error buffer visible via the front LED. This is especially useful when there is no picture.

When the SDM is entered, the front LED will blink the contents of the error-buffer:

- The LED blinks with as many pulses as the error code number, followed by a time period of 1.5 seconds, in which the LED is “off”.
- Then this sequence is repeated.

Any RC5 command terminates this sequence.

Example of error buffer: **12 9 6 0 0**

After entering SDM, the following occurs:

- 1 long blink of 5 seconds to start the sequence,
- 12 short blinks followed by a pause of 1.5 seconds,
- 9 short blinks followed by a pause of 1.5 seconds,
- 6 short blinks followed by a pause of 1.5 seconds,
- 1 long blink of 1.5 seconds to finish the sequence,
- The sequence starts again at 12 short blinks.

5.7 Fault Finding and Repair Tips

Notes:

- It is assumed that the components are mounted correctly with correct values and no bad solder joints.
- Before any fault finding actions, check if the correct options are set.

5.7.1 NVM Editor

In some cases, it can be handy if one directly can change the NVM contents. This can be done with the "NVM Editor" in SAM mode. With this option, single bytes can be changed.

	Hex	Dec	Description
.ADR	0x000A	10	Existing value
.VAL	0x0000	0	New value
.Store	Store ?		

5.7.2 Load default NVM values

In case a blank NVM is placed or when the NVM content is corrupted, default values can be downloaded into the NVM. After the default values are downloaded it will be possible to start up and to start aligning the TV set. This is no longer initiated automatically; to initiate the download the following action has to be performed:

1. Switch the TV set "off" via the AC Power switch.
2. Short circuit the SDM jumpers (keep short-circuited).
3. Press P+ or Ch+ on the local keyboard (and keep it pressed).
4. Switch the TV set "on" via the AC Power switch.
5. When the set has started, the P+/Ch+ button can be released and the short circuit of the SDM jumpers can be removed.
6. The red LED will be on continuously to indicate that the download is initiated (normally when SDM is activated the red LED will start with the Blinking LED sequence).
7. Wait +/- 30 s (time needed to download default values to the NVM).

5.7.3 Tuner and IF

No Picture in RF mode

1. Check whether picture is present in EXT. If not, go to Video processing troubleshooting section.
2. If present, check that the Option settings are correct.
3. Check that all supply voltages are present.
4. Check if I²C lines are working correctly (3.3V).
5. Manually store a known channel and check if there is IF output at Tuner pin 11.
6. Feed in 105 dBuV at Tuner pin 11 and check whether there is RGB output from Video Processing IC. If yes, Tuner may be defect. Replace Tuner.

Required system is not selected correctly

1. Check whether a Service jumper (#4022, 0805 size) is present. If yes, remove it.

5.7.4 Video Processing

No power

1. Check +12 V and 3V3 at position 1910.
2. If no supply, check the connector 1910.
3. If it is correct, check the power supply board.

Power supply is correct but no green LED

1. Check if connectors 1005 and 1601 are properly inserted.
2. If yes, check if the 3V3 is present.

No picture display

1. Check the RGB signal.
2. If it is present, check 3-IC7016 (NE555).
3. If it has output, the problem is in SCALER part.
4. Otherwise, check H-out on pin 2 of NE555. If the input signal of pin2 is present, but no output, the IC is defect.

Note:

- If the H-out (pin 67) doesn't have signal or the level is low, check the output of NE555 (pin 3) during start up.

- If the H-out (pin 67) has a signal (or has a signal for a very short time), change IC7016 (NE555).

No TV but PC is present

1. Check if HSYNC and VSYNC are present at pin 3 of 7017 and 7015.
2. If they are present, check RGB output.
3. If there is no RGB output, the IC TDA120xx can be defect.

Comb Filter not working

Check Option Byte 5 in SAM (see also chapter 8 "Alignments").

5.7.5 Power Supply


In this service manual the power supply of the PDP panel is described as "black box". Defects in this panel, can be traced by error-codes in the error buffer, or by incorrect behaviour of the panel.

For some basic voltage-measurements, you can use the block diagram(s) in Chapter 6.


Note: For a complete description of the Plasma panel, see the SDI plasma panel Service Manual (12nc is listed on the frontpage).

6. Block Diagrams, Testpoint Overviews, and Waveforms


Wiring Diagram



Block Diagram Audio and Video




Block Diagram Audio and Video




Testpoint Overview SSB (Top Side)

F002 B2	F014 C3	F029 C3	F041 B3	F053 C3	F075 B3	F090 C3	F104 D5	F110 D5	F120 D4	F134 D5	F148 D6	F159 D5	F255 A7	F307 C2	F401 C5	F413 B7	F434 A5	F486 B5	F540 A5	F605 C5	F626 C4	F685 D7	F702 A2	F718 B2	F801 C6	F821 C7	I112 D3	I456 B5	I827 C6
F003 D2	F018 C3	F030 C3	F042 C4	F058 C4	F076 B3	F093 C2	F104 D5	F110 D5	F120 D4	F134 D5	F148 D6	F159 D5	F257 A7	F308 D1	F402 A5	F414 B7	F436 A5	F501 B7	F541 A5	F606 C5	F680 D7	F686 D7	F705 A1	F719 B2	F802 C7	F822 C6	I114 D3	I457 A5	I828 C6
F004 B4	F019 B4	F031 C3	F043 C3	F060 B4	F077 B1	F094 C3	F105 D3	F111 D3	F121 D4	F135 D5	F153 D6	F160 D5	F258 A6	F309 B3	F403 A5	F415 B7	F437 A5	F530 A4	F580 A3	F607 C5	F680 D7	F686 D7	F706 A1	F720 B2	F803 C6	F823 C6	I114 D3	I458 A5	I834 C6
F005 C4	F020 C3	F032 C3	F044 B4	F061 C4	F078 B1	F095 C4	F105 D3	F111 D3	F121 D4	F135 D5	F153 D6	F160 D5	F259 A4	F310 C3	F404 A5	F416 B7	F447 B5	F531 B5	F584 B3	F608 C5	F681 D7	F687 D7	F707 A1	F721 A1	F804 C7	F824 C7	I116 D4	I459 B5	I836 C6
F006 C4	F021 B4	F033 C3	F045 C4	F062 C4	F079 B1	F096 C4	F106 D3	F113 D3	F127 D4	F137 D5	F154 D5	F161 D3	F260 B7	F311 C2	F405 A5	F417 B5	F451 B5	F532 B5	F585 A3	F612 C5	F681 D7	F687 D7	F708 A1	F722 A2	F805 C6	F826 B6	I116 D4	I460 A5	I838 C6
F007 B3	F022 B3	F034 C3	F046 C3	F063 C4	F080 B1	F099 A3	F106 D3	F113 D3	F127 D4	F137 D5	F154 D5	F161 D3	F300 B2	F313 D2	F406 A5	F418 B7	F461 B6	F533 B5	F586 A3	F613 C5	F682 D7	F688 D7	F710 C3	F723 A2	F806 B5	F827 C6	I118 D4	I502 A7	I840 C6
F008 B3	F023 B3	F035 C3	F047 C3	F067 C4	F081 B1	F101 D3	F107 D2	F115 D3	F128 D4	F141 D5	F156 D6	F191 D5	F301 C3	F314 D2	F407 A5	F419 A6	F463 B5	F534 B4	F587 B3	F614 C5	F682 D7	F688 D7	F711 A1	F724 A2	F807 B5	F870 A5	I118 D4	I503 B7	I841 C6
F009 B3	F024 B1	F036 C3	F048 B1	F068 C4	F082 C1	F101 D3	F107 D2	F115 D3	F128 D4	F141 D5	F156 D6	F191 D5	F302 D2	F315 D2	F408 A5	F420 C1	F465 C5	F535 B5	F588 B3	F615 C5	F683 D7	F689 D7	F712 A1	F725 A2	F808 C6	F871 A5	I119 D4	I607 C5	I842 C6
F010 B2	F025 B1	F037 A2	F049 C3	F069 C4	F083 B1	F102 D4	F108 D5	F117 D4	F129 D5	F143 D6	F157 D5	F251 A7	F303 D2	F316 C2	F409 A5	F421 C1	F466 C5	F536 A5	F590 A2	F616 C5	F683 D7	F689 D7	F713 A1	F726 A3	F809 C7	F872 A6	I119 D4	I608 C5	I844 B6
F011 B2	F026 C1	F038 C3	F050 C4	F071 B4	F087 B3	F102 D4	F108 D5	F117 D4	F129 D5	F143 D6	F157 D5	F252 A7	F305 C2	F316 C2	F409 A5	F422 B4	F470 B5	F537 A5	F602 C5	F620 C5	F684 D7	F690 D7	F714 A1	F727 A3	F810 C6	F873 A5	I120 D4	I618 C5	I847 C6
F012 B3	F027 B1	F039 B2	F051 C3	F072 B1	F088 B3	F103 D3	F109 D3	F119 D4	F133 D4	F147 D6	F158 D5	F253 A7	F306 C2	F318 C3	F411 B7	F423 B4	F478 B6	F538 A5	F603 C5	F624 B4	F684 D7	F690 D7	F716 B2	F728 A3	F811 B6	F874 A5	I120 D4	I619 C5	I848 C6
F013 C3	F028 C3	F040 C3	F052 C3	F073 A4	F089 B2	F103 D3	F109 D3	F119 D4	F133 D4	F147 D6	F158 D5	F254 A7	F306 C2	F319 B2	F412 B7	F424 B4	F482 A5	F539 A5	F604 C5	F625 C4	F685 D7	F701 B2	F717 B3	F729 A2	F820 C7	F912 A3	I126 D5	I620 C5	I860 A3




3139 123 5837.1




I2C IC Overview

I2C BUS INTERCONNECTION DIAGRAM




Supply Voltage Overview




7. Circuit Diagrams and PWB Layouts

Small Signal Board: Tuner and VIF



Small Signal Board: Histogram and Hercules

A2 HISTOGRAM & HERCULES



Item	No	3D	3D
4004	Yes	Yes	
4005	Yes	Yes	
4007	Yes	-	
4002	Yes	-	
2083	-	Yes	

*	HETV (15W)	MTV (5W)
3380	5K6	10K
3381	5K6	10K
3382	5K6	10K
3383	5K6	10K


- 1001 D4
- 1004 I12
- 1009 H4
- 1036 H1
- 1336 H1
- 1402 B1
- 2000 E2
- 2001 E3
- 2002 F10
- 2004 C6
- 2005 D5
- 2006 D4
- 2007 D4
- 2008 E4
- 2009 E4
- 2010 E4
- 2012 F3
- 2013 H7
- 2014 H8
- 2015 H8
- 2016 H8
- 2017 H8
- 2018 H8
- 2023 F10
- 2024 F2
- 2025 E10
- 2026 E10
- 2027 E10
- 2029 E10
- 2030 E10
- 2031 E10
- 2032 E10
- 2033 E11
- 2035 D11
- 2036 H3
- 2037 I3
- 2040 C14
- 2041 D10
- 2043 E4
- 2044 D10
- 2052 D10
- 2053 J11
- 2056 F12
- 2059 G2
- 2060 E4
- 2061 E4
- 2062 E4
- 2065 G4
- 2066 H5
- 2068 D5
- 2069 G2
- 2070 B3
- 2071 D5
- 2072 B5
- 2073 B6
- 2074 C6
- 2076 C9
- 2077 C10
- 2078 B11
- 2079 H2
- 2080 H2
- 2081 H2
- 2082 F9
- 2083 G7
- 2084 D9
- 2087 H2
- 2088 I2
- 2090 I2
- 2091 I2
- 2092 I2
- 2093 J2
- 2094 J2
- 2095 K2
- 2096 K2
- 2097 J2
- 2098 J2
- 2099 A11
- 2355 G7
- 4085 I3
- 2357 G6
- 2358 G6
- 2359 F5
- 2360 I14
- 2361 J16
- 2362 J16
- 2363 J16
- 2364 J16
- 2365 J16
- 2366 J16
- 2367 I14
- 2368 K14
- 2370 G5
- 2371 G5
- 2372 G5
- 2373 G6
- 2374 G6
- 2375 G6
- 2376 G12
- 2377 H12
- 2378 D9
- 2380 D10
- 2381 D10
- 2382 D5
- 2386 H11
- 2387 G5
- 2388 G5
- 2392 G11
- 2394 C10
- 2395 H6
- 2396 H6
- 2397 G9
- 2398 G9
- 2399 D2
- 3001 E3
- 3002 E2
- 3003 E2
- 3004 E1
- 3005 D2
- 3006 D5
- 3007 E4
- 3008 F4
- 3009 G8
- 3010 F5
- 3011 E11
- 3012 H16
- 3013 H8
- 3014 D14
- 3015 C15
- 3016 D15
- 3017 C15
- 3018 D15
- 3019 B14
- 3023 I2
- 3024 J2
- 3025 J2
- 3027 J2
- 3028 F9
- 3031 H16
- 3033 H16
- 3034 I16
- 3035 E10
- 3036 I16
- 3037 I2
- 3038 H2
- 3040 F12
- 3048 D11
- 3049 C11
- F022 A12
- F023 B6
- F024 J2
- F025 K2
- F026 J2
- F027 I2
- F028 J4
- F029 J4
- F030 I4
- F031 I4
- F032 I4
- F033 B6
- F034 I4
- F035 I4
- F036 F5
- F037 G2
- F038 I4
- F039 I4
- F040 K4
- F041 B6
- F042 K4
- F043 I4
- F044 K4
- F045 K4
- F046 G4
- F047 G4
- F048 J2
- F049 H4
- F051 G4
- F052 B1
- F053 E4
- F054 G4
- F055 G4
- F056 E6
- F057 H2
- F058 E6
- F059 J2
- F060 J2
- F061 J2
- F062 B1
- F063 B1
- F064 B1
- F065 F9
- F066 B5
- F067 B5
- F068 C5
- F069 C3
- F070 E5
- F071 F3
- F072 F3
- F073 H6
- F074 H7
- F075 D9
- F076 D10
- F077 C10

3139 123 5837.1

E_14710_016.eps
020904

Small Signal Board: Histogram and Hercules

A3 HISTOGRAM & HERCULES




- 1008 B1
- 1320 F1
- 2003 F4
- 2019 A8
- 2020 B7
- 2021 D9
- 2022 D10
- 2028 B9
- 2034 C9
- 2042 D8
- 2045 F4
- 2046 F4
- 2047 B11
- 2048 F4
- 2049 G4
- 2050 G4
- 2051 C8
- 2057 F4
- 2058 F4
- 2062 G4
- 2067 G4
- 2085 D1
- 2086 D1
- 2089 D1
- 2560 C6
- 2561 C5
- 2562 C6
- 2563 E4
- 2564 B4
- 2565 F2
- 2566 F3
- 3020 A7
- 3021 A8
- 3022 A7
- 3023 F3
- 3029 C11
- 3030 C10
- 3032 C10
- 3039 B7
- 3058 D9
- 3063 G3
- 3066 F3
- 3340 A6
- 3342 C9
- 3343 C9
- 3344 D9
- 3345 C11
- 3346 A10
- 3348 D9
- 3349 D10
- 3560 C6
- 3561 C6
- 3562 C5
- 3563 D5
- 3564 D4
- 3565 D4
- 3566 E4
- 3567 E4
- 3568 E4
- 3579 F5
- 4009 B2
- 4010 B2
- 4011 C2
- 4012 C2
- 4015 E7
- 4016 D11
- 4017 F2
- 4018 F2
- 4019 F2
- 4020 F2
- 5066 F3
- 5067 G3
- 5560 B4
- 6020 B7
- 6021 C10
- 6563 D5
- 6564 D5
- 6565 F5
- 7015 C8
- 7016 B8
- 7017 B10
- 7018 B7
- 7019 D10
- 7560 B5
- 7561 E5
- 7562 A5
- 7563 D3
- 7579 F5
- F018 B6
- F058 B2
- F060 B2
- F061 B2
- F062 C2
- F063 C2
- F067 C1
- F068 C1
- F069 C2
- F071 C2
- F073 D2
- F075 D2
- F076 B2
- F077 B2
- F078 B2
- F079 B2
- F080 B2
- F081 B2
- F082 C5
- F083 F1
- F087 F1
- F088 F1
- F089 F1
- F090 F1
- F091 F1
- F092 F1
- F093 F1
- F094 F1
- F095 B7
- F130 F5
- F131 E4

3139 123 5837.1

E_14710_017.eps
020904

Small Signal Board: Audio Delay line (Lip sync)


A4 AUDIO DELAY LINE (LIP SYNC)



- 2580 B1
- 2581 D1
- 2582 B2
- 2583 B7
- 2584 B8
- 2585 F6
- 2586 F6
- 2587 D9
- 2588 D9
- 3580 F5
- 3581 F6
- 4580 F2
- 4581 F2
- 4582 F2
- 4583 F2
- 4584 F2
- 4585 F2
- 4586 C9
- 4587 C9
- 4588 C9
- 4589 C9
- 4590 C9
- 4591 C9
- 4592 C9
- 4593 D9
- 5580 A1
- 7580 B1
- 7581 F1
- 7582 B2
- 7583 C6
- 7584 C8
- 7585 F6
- F580 A1
- F584 F9
- F585 F5
- F586 F6
- F587 D9
- F588 D9
- F590 B2

Small Signal Board: Audio Amplifier

A5 AUDIO AMPLIFIER




- 1701 D8
- 1702 A1
- 1735 E11
- 1752 C1
- 2701 B8
- 2702 A5
- 2703 F6
- 2704 A3
- 2705 B5
- 2706 B3
- 2707 A10
- 2708 B5
- 2709 C8
- 2710 B11
- 2711 C11
- 2712 C6
- 2713 D9
- 2714 D9
- 2715 B10
- 2716 D7
- 2718 E7
- 2719 D9
- 2720 B1
- 2725 F10
- 2736 F10
- 2737 F10
- 2738 F10
- 2739 C7
- 2740 C7
- 2741 C7
- 2742 E7
- 2743 A5
- 2744 B5
- 2746 E7
- 2747 C2
- 2748 C2
- 2749 C2
- 2750 C2
- 3701 F1
- 3702 G2
- 3703 A4
- 3704 G2
- 3705 A5
- 3706 F6
- 3707 G8
- 3708 A4
- 3709 B4
- 3710 B4
- 3711 A11
- 3712 B4
- 3713 B4
- 3714 C6
- 3715 C6
- 3716 B8
- 3717 C6
- 3718 B11
- 3719 D5
- 3720 C7
- 3721 G8
- 3722 D6
- 3723 F2
- 3724 F2
- 3725 D6
- 3726 E7
- 3727 E7
- 3728 G3
- 3729 G4
- 3735 E10
- 3736 E10
- 3737 E10
- 3738 E10
- 3739 A5
- 3740 A6
- 3741 A6
- 3742 B6
- 3743 B5
- 3744 E7
- 3745 B5
- 3746 F6
- 3747 D6
- 3748 F6
- 3749 D6
- 3750 F6
- 3751 F7
- 3752 B3
- 3753 C3
- 4701 A5
- 4702 B5
- 4703 D5
- 4704 B7
- 4705 B7
- 4706 A10
- 4707 B10
- 4708 E3
- 4709 E3
- 4710 F8
- 4711 G8
- 4714 G3
- 4715 F3
- 4716 G3
- 4720 B1
- 5720 B1
- 5721 B2
- 5722 C2
- 5735 E9
- 5736 D9
- 6701 G7
- 7702-1 D6
- 7702-2 C5
- 7703-1 F6
- 7703-2 E6
- 7706-1 E4
- 7706-2 E4
- 7706-3 F4
- 7706-4 G4
- 7707 B8
- 7708-1 F9
- 7708-2 G8

#	HETV	MTV	** ITV	ITV	MTV	* 2 X 3W	2 X 5W
3702	2K2	6K8	10K	YES	NO	12K	8K2
3704	470R	1K	-	NO	YES	-	-
3728	2K2	5K6	-	NO	YES	-	-
3729	3K9	3K3	-	YES	NO	-	-
4714	Yes	Yes	No	-	-	-	-
4715	-	-	Yes	-	-	-	-
4716	-	-	Yes	-	-	-	-

7708	
HETV	MTV
BC847BS	PUMH7
3716	4710
3721	4711


Small Signal Board: TV Supply

A6 TV-SUPPLY



- 2910 D8
- 2911 D9
- 2920 E4
- 2921 E5
- 2930 C3
- 2931 B6
- 2932 C4
- 2933 C7
- 2934 C4
- 2935 C8
- 3910 B7
- 3911 D7
- 3930 B3
- 3931 B4
- 3932 C4
- 3933 C4
- 5910 D8
- 5920 E3
- 5930 C3
- 5931 B7
- 5932 C8
- 6910 D8
- 6911 D9
- 6930 C7
- 7910 D7
- 7920 E4
- 7930 A5
- F912 D9
- F913 E9
- F915 C9
- I901 B4
- I902 C3
- I903 C4
- I904 B7
- I905 B6
- I906 C7
- I907 D8
- I908 D7


Small Signal Board: Scaler



- 1401 D2
1408 J15
2487 D2
2488 D2
2490 G2
2491 G2
2492 G2
3401-1 B12
3401-2 B12
3401-3 B12
3401-4 B12
3402-1 B12
3402-2 B12
3402-3 B12
3402-4 B12
3403-1 C12
3403-2 C12
3403-3 C12
3403-4 C12
3404-1 C12
3404-2 C12
3404-3 C12
3404-4 C12
3405-1 C12
3405-2 C12
3405-3 C12
3405-4 C12
3406-1 C12
3406-2 C12
3406-3 D12
3406-4 D12
3407-1 D12
3407-2 D12
3407-3 D12
3407-4 D12
3408-1 D12
3408-2 D12
3408-3 D12
3408-4 D12
3409-1 D14
3409-2 D14
3409-3 D14
3409-4 D14
3410-1 D14
3410-2 D14
3410-3 D14
3410-4 D14
3411-1 D14
3411-2 D14
3411-3 D14
3411-4 D14
3412-1 E12
3412-2 E12
3412-3 E12
3412-4 E12
3413-1 E12
3413-2 E12
3413-3 E12
3413-4 E12
3414-1 F12
3414-2 F12
3414-3 F12
3414-4 F12
3415-1 F12
3415-2 F12
3415-3 F12
3415-4 F12
3416-1 G11
3416-2 G11
3416-3 G11
3416-4 G11
3417-1 G11
3417-2 G11
3417-3 G11
3417-4 G11
3418-1 H11
3418-2 H11
3418-3 H11
3418-4 H11
3419-1 H11
3419-2 H11
3419-3 H11
3419-4 H11
3420-1 I11
3420-2 I11
3420-3 I11
3420-4 I11
3421-1 I11
3421-2 I11
3421-3 I11
3421-4 I11
3422-1 J11
3422-2 J11
3422-3 J11
3422-4 J11
3423-1 J11
3423-2 J11
3423-3 J11
3423-4 J11
3424-1 J11
3424-2 J11
3424-3 J11
3424-4 J11
3425-1 K11
3425-2 K11
3425-3 K11
3425-4 K11
3426-1 K11
3426-2 K11
3426-3 K11
3426-4 K11
3427-1 K11
3427-2 K11
3427-3 K11
3427-4 K11
3428-1 L11
3428-2 L11
3428-3 L11
3428-4 L11
3429-1 L11
3429-2 L11
3429-3 L11
3429-4 L11
3430-1 L11
3430-2 L11
3430-3 L11
3430-4 L11
3431-1 L11
3431-2 L11
3431-3 L11
3431-4 L11
3432-1 L11
3432-2 L11
3432-3 L11
3432-4 L11
3433-1 L11
3433-2 L11
3433-3 L11
3433-4 L11
3434-1 L11
3434-2 L11
3434-3 L11
3434-4 L11
3435-1 L11
3435-2 L11
3435-3 L11
3435-4 L11
3436-1 L11
3436-2 L11
3436-3 L11
3436-4 L11
3437-1 L11
3437-2 L11
3437-3 L11
3437-4 L11
3438-1 L11
3438-2 L11
3438-3 L11
3438-4 L11
3439-1 L11
3439-2 L11
3439-3 L11
3439-4 L11
3440-1 L11
3440-2 L11
3440-3 L11
3440-4 L11
3441-1 L11
3441-2 L11
3441-3 L11
3441-4 L11
3442-1 L11
3442-2 L11
3442-3 L11
3442-4 L11
3443-1 L11
3443-2 L11
3443-3 L11
3443-4 L11
3444-1 L11
3444-2 L11
3444-3 L11
3444-4 L11
3445-1 L11
3445-2 L11
3445-3 L11
3445-4 L11
3446-1 L11
3446-2 L11
3446-3 L11
3446-4 L11
3447-1 L11
3447-2 L11
3447-3 L11
3447-4 L11
3448-1 L11
3448-2 L11
3448-3 L11
3448-4 L11
3449-1 L11
3449-2 L11
3449-3 L11
3449-4 L11
3450-1 L11
3450-2 L11
3450-3 L11
3450-4 L11
3451-1 L11
3451-2 L11
3451-3 L11
3451-4 L11
3452-1 L11
3452-2 L11
3452-3 L11
3452-4 L11
3453-1 L11
3453-2 L11
3453-3 L11
3453-4 L11
3454-1 L11
3454-2 L11
3454-3 L11
3454-4 L11
3455-1 L11
3455-2 L11
3455-3 L11
3455-4 L11
3456-1 L11
3456-2 L11
3456-3 L11
3456-4 L11
3457-1 L11
3457-2 L11
3457-3 L11
3457-4 L11
3458-1 L11
3458-2 L11
3458-3 L11
3458-4 L11
3459-1 L11
3459-2 L11
3459-3 L11
3459-4 L11
3460-1 L11
3460-2 L11
3460-3 L11
3460-4 L11

Small Signal Board: Scaler Supply

2401 C1	2405 C2	2409 C3	2413 C4	2417 B1	2421 B2	2425 B3	2429 B4	2433 B5	2437 B4	2441 B5	2445 B6	2449 C6	2453 B3	2461 C6	2465 B1	2469 B2	2473 B6	2477 B7	2481 B8	2485 A9	F401 C1	F451 A2	F466 B1	F486 A7
2402 C1	2406 C2	2410 C3	2414 C4	2418 B1	2422 B2	2426 B3	2430 B4	2434 B4	2438 B5	2442 B6	2446 A6	2450 C6	2454 B3	2462 C7	2466 B1	2470 B5	2474 B6	2478 A7	2482 B8	2486 A7	F419 B1	F461 C6	F470 B5	
2403 C1	2407 C2	2411 C3	2415 C4	2419 B2	2423 B3	2427 B3	2431 B4	2435 B4	2439 B5	2443 B6	2447 C5	2451 B2	2455 B3	2463 C5	2467 B1	2471 B6	2475 B6	2479 B8	2483 B9	2495 B7	F434 A4	F463 C5	F478 A7	
2404 C2	2408 C3	2412 C3	2416 C4	2420 B2	2424 B3	2428 B4	2432 B4	2436 B4	2440 B5	2444 B6	2448 C5	2452 B3	2456 A3	2464 C5	2468 B2	2472 B6	2476 B7	2480 B8	2484 B9	2496 B8	F447 C5	F465 A1	F482 A9	




3139 123 5837.1

E_14710_022.eps
130504


Small Signal Board: Scaler Interface

A9 SCALER INTERFACE




- 1403 D11
- 1409 A6
- 1450 D4
- 1860 D2
- 1861 D2
- 1862 E2
- 1863 F2
- 1864 F2
- 2493 D8
- 2494 C6
- 2860 D3
- 2861 D3
- 2862 D3
- 2863 D3
- 2864 E3
- 2865 E3
- 2866 F3
- 2867 F3
- 2868 F3
- 2869 F3
- 2870 C3
- 2871 C4
- 2872 B2
- 2874 G4
- 2875 G4
- 2876 C9
- 2877 E8
- 2878 D9
- 2879 C10
- 2880 E9
- 2881 D10
- 2882 F8
- 2883 E9
- 2884 E7
- 2885 F9
- 2886 F9
- 2887 E9
- 2889 F9
- 3416 C6
- 3417 D7
- 3418 C6
- 3427 C6
- 3444 C7
- 3460 C7
- 3870 C3
- 3871 C3
- 3876 C9
- 3877 E9
- 3879 D9
- 3883 E9
- 3885 F9
- 3886 E7
- 3887 E7
- 4427 C7
- 4428 C8
- 4444 C8
- 4445 C7
- 4871 B2
- 4872 B2
- 4887 E7
- 4888 F6
- 5872 B2
- 5874 G4
- 5882 F9
- 7416 C6
- 7872 B2
- 7887 E7
- F411 B6
- F412 B6
- F413 B6
- F414 B6
- F415 B6
- F416 B6
- F418 B6
- F870 C4
- F871 C4
- F872 G3
- F873 F4
- F874 E4
- I428 C6
- I436 C7
- I437 C8
- I444 C7
- I445 C7
- I445 C8
- I445 C9
- I445 C10
- I445 C11
- I445 C12
- I445 C13
- I445 C14
- I445 C15
- I445 C16
- I445 C17
- I445 C18
- I445 C19
- I445 C20
- I445 C21
- I445 C22
- I445 C23
- I445 C24
- I445 C25
- I445 C26
- I445 C27
- I445 C28
- I445 C29
- I445 C30
- I445 C31
- I445 C32
- I445 C33
- I445 C34
- I445 C35
- I445 C36
- I445 C37
- I445 C38
- I445 C39
- I445 C40
- I445 C41
- I445 C42
- I445 C43
- I445 C44
- I445 C45
- I445 C46
- I445 C47
- I445 C48
- I445 C49
- I445 C50
- I445 C51
- I445 C52
- I445 C53
- I445 C54
- I445 C55
- I445 C56
- I445 C57
- I445 C58
- I445 C59
- I445 C60
- I445 C61
- I445 C62
- I445 C63
- I445 C64
- I445 C65
- I445 C66
- I445 C67
- I445 C68
- I445 C69
- I445 C70
- I445 C71
- I445 C72
- I445 C73
- I445 C74
- I445 C75
- I445 C76
- I445 C77
- I445 C78
- I445 C79
- I445 C80
- I445 C81
- I445 C82
- I445 C83
- I445 C84
- I445 C85
- I445 C86
- I445 C87
- I445 C88
- I445 C89
- I445 C90
- I445 C91
- I445 C92
- I445 C93
- I445 C94
- I445 C95
- I445 C96
- I445 C97
- I445 C98
- I445 C99
- I445 C100

Small Signal Board: SDRAM



- 2501 B1
- 2502 B1
- 2503 B1
- 2504 B1
- 2505 B2
- 2506 B2
- 2507 B2
- 2508 B3
- 2509 B3
- 2510 B3
- 2511 B3
- 2512 B4
- 2513 B4
- 2514 B4
- 2515 B5
- 2516 B5
- 2517 B4
- 2526 B4
- 3501 B3
- 3502 C3
- 3503 C2
- 7501 C3
- F501 C3
- I502 C2
- I503 B2


Small Signal Board: Flash / Control



- 1530 C7
- 1532 E4
- 2530 A3
- 2531 E2
- 2532 E4
- 2533 A3
- 3531 E2
- 3532 E4
- 3533 E6
- 3534 E6
- 3536 B7
- 3538-1 C5
- 3538-2 C5
- 3538-3 C5
- 3538-4 C5
- 3539-1 C5
- 3539-2 C5
- 3539-3 C5
- 3539-4 C5
- 3540-1 B6
- 3540-2 B6
- 3540-3 B6
- 3540-4 B6
- 3541 D6
- 3542 D6
- 3543 D7
- 3544-1 B5
- 3544-2 B5
- 3544-3 C5
- 3544-4 C5
- 3545-1 B5
- 3545-2 B5
- 3545-3 B5
- 3545-4 B5
- 3546-1 B5
- 3546-2 B5
- 3546-3 B5
- 3546-4 B5
- 3547-1 A5
- 3547-2 A5
- 3547-3 A6
- 3547-4 A6
- 3548 A6
- 3549 B6
- 3550 A6
- 3551 B6
- 3552 A6
- 3553 A6
- 5530 A2
- 7530 A2
- 7531 E3
- 7532 E5
- F530 A2
- F531 E2
- F532 E2
- F533 E2
- F534 E4
- F535 E5
- F536 C7
- F537 C6
- F538 C6
- F539 C6
- F540 C7
- F541 C7


Small Signal Board: HDMI

2803 B6	2810 B5	2815 B8	2820 B7	2825 B7	2830 B6	2836 F12	2841 G11	2846 H13	2851 G14	3802-1 B11	3803-2 C11	3804-3 D11	3805-4 D11	3807 H9	3813-2 G9	3817 H12	3824 D4	3829 G14	3834 F4	3839 H15	5803 B7	7807 E3	F802 B5	F807 G2	F820 D2	F826 E12	I816 H11	I825 G5	I836 F13	I844 H12
2806 B8	2811 B6	2816 B5	2821 C8	2826 B7	2832 D3	2837 G4	2842 G13	2847 F13	3801-1 B11	3802-2 B11	3803-3 C11	3804-4 D11	3806-1 E11	3808 B2	3813-3 G9	3819 H13	3825 D4	3830 H9	3835 C5	4836 G14	5804 B6	7808 D5	F803 B7	F808 I7	F821 D2	F827 F12	I819 H13	I826 G5	I838 F13	I847 F13
2807 B6	2812 B3	2817 B6	2822 B5	2827 C8	2833 E11	2838 G4	2843 H12	2848 F13	3801-2 B11	3802-3 C11	3803-4 C11	3804-1 C11	3805-2 D11	3809 B3	3813-4 G9	3821 D5	3826 E12	3831 G4	3836 F14	4838 G14	5805 B7	7809 F11	F804 B6	F809 B3	F822 D2	F828 D2	I822 E4	I827 H14	I840 G4	I848 F13
2808 B8	2813 B7	2818 B6	2823 C5	2828 B5	2834 E12	2839 G4	2844 H12	2849 D2	3801-3 B11	3802-4 C11	3803-1 C11	3805-3 D11	3806-3 E11	3810 B3	3815 H11	3822 D4	3827 E12	3832 D2	3837 H14	5801 B6	7801 B2	7810 G13	F805 B7	F810 G10	F823 I2	I803 D3	I823 E4	I828 I14	I841 G11	I849 H12
2809 B7	2814 B7	2819 B7	2824 B6	2829 C6	2835 F11	2840 G4	2845 H11	2850 G14	3801-4 B11	3803-1 C11	3804-2 D11	3805-4 D11	3806-4 E11	3813-1 G9	3816 H11	3823 D4	3828 D2	3833 G15	3838 F14	5802 B5	7806 E4	F801 B6	F806 G2	F811 F13	F824 D2	I815 H11	I834 F5	I842 H12		



Small Signal Board: PCHD MUX

A13 PCHD-MUX





3139 123 5837.1

E_14710_027.eps 020904

- 2601 A6
- 2605 E6
- 2606 E4
- 2607 D9
- 2608 D9
- 2609 D9
- 2610 D9
- 2611 D9
- 2612 E10
- 2613 E10
- 2614 E10
- 2615 F10
- 2616 F10
- 2617 F10
- 2618 F10
- 2619 F7
- 2620 G10
- 2621 B2
- 2622 B2
- 2623 C2
- 2624 D4
- 2625 D4
- 2626 D4
- 2627 B4
- 2628 B4
- 2629 B4
- 2630 D7
- 2631 D7
- 2632 D7
- 2633 B9
- 2634 B9
- 2635 B9
- 2636 A9
- 2637 A9
- 2638 A9
- 2639 E4
- 2640 F5
- 2641 E10
- 2642 E10
- 2643 F10
- 2644 F10
- 2645 F10
- 2646 F10
- 2647 F10
- 2648 F10
- 2649 F10
- 2650 F10
- 2651 F10
- 2652 F10
- 2653 F10
- 2654 F10
- 2655 F10
- 2656 F10
- 2657 F10
- 2658 F10
- 2659 F10
- 2660 F10
- 2661 F10
- 2662 F10
- 2663 F10
- 2664 F10
- 2665 F10
- 2666 F10
- 2667 F10
- 2668 F10
- 2669 F10
- 2670 F10
- 2671 F10
- 2672 F10
- 2673 F10
- 2674 F10
- 2675 F10
- 2676 F10
- 2677 F10
- 2678 F10
- 2679 F10
- 2680 F10
- 2681 F10
- 2682 F10
- 2683 F10
- 2684 F10
- 2685 F10
- 2686 F10
- 2687 F10
- 2688 F10
- 2689 F10
- 2690 F10
- 2691 F10
- 2692 F10
- 2693 F10
- 2694 F10
- 2695 F10
- 2696 F10
- 2697 F10
- 2698 F10
- 2699 F10
- 2700 F10

Small Signal Board: Supply

A 14 SUPPLY




ITEM	13"	≥15"
2959	---	100N
3958	1K	15K
5954	---	YES
5955	YES	---
5956	---	YES
5957	YES	---
7953	---	L4940D2T12

- 1951 B2
- 2953 F2
- 2954 F2
- 2955 G3
- 2956 F5
- 2957 G5
- 2958 G5
- 2959 B4
- 2960 B5
- 2961 C3
- 2992 D7
- 2993 D8
- 2994 D8
- 2995 E7
- 2996 E8
- 3951 F2
- 3952 F2
- 3953 F2
- 3954 F3
- 3955 C3
- 3958 C3
- 5952 F1
- 5953 F5
- 5954 F5
- 5955 B3
- 5956 B3
- 5957 C4
- 5959 B4
- 5960 B2
- 5984 A9
- 5985 B9
- 5986 B9
- 5987 B9
- 5988 B9
- 5989 C9
- 5990 C9
- 5991 C9
- 5994 C9
- 5996 E9
- 5997 E9
- 5998 E9
- 6951 F5
- 7952 E3
- 7953 B5
- 7954 C4
- 7955 D3
- 7992 C8
- 7995 E8
- F954 F5
- F955 D2
- F988 B9
- I951 E2
- I952 F2
- I953 F3
- I954 F3
- I955 F5
- I956 C3
- I957 C4
- I959 B4
- I960 F5
- I961 C3
- I962 B2
- I963 B2
- I964 B2
- I992 C8
- I995 E7
- I996 E8


Small Signal Board: DC-DC Converter

A15 DC-DC CONVERTER




- 1251 A1
- 2251 B2
- 2252 B2
- 2253 B3
- 2254 B3
- 2255 B2
- 2261 D4
- 2262 D4
- 2263 D3
- 2264 D4
- 2265 E5
- 2266 E5
- 2268 E7
- 2269 E7
- 2271 B6
- 3251 A2
- 3259 D2
- 3260 D3
- 3266 E5
- 3267 E6
- 3268 E6
- 3270 B6
- 3271 B6
- 3273 A7
- 3274 A7
- 4251 A2
- 4255 B2
- 5251 A3
- 5252 A3
- 5257 B3
- 5258 B3
- 5259 C3
- 5262 D3
- 5267 D6
- 5268 D7
- 6259 D3
- 6262 D3
- 6267 E6
- 6270 A6
- 7260 C4
- 7262 D4
- 7271 B7
- 7272 B7
- F251 A1
- F252 A1
- F253 A1
- F254 A1
- F255 A1
- F257 B1
- F258 A4
- F259 B7
- F260 C7
- I251 C3
- I252 C4
- I253 C4
- I254 D3
- I255 D4
- I256 D5
- I257 E5
- I258 E5
- I259 E5
- I260 D7
- I261 A6
- I262 B6
- I263 B6
- I264 A2

Small Signal Board: PCHD IO



- 1687 A1
- 2681 D7
- 2686 D7
- 2688 C2
- 2693 D2
- 2698 F3
- 2699 F4
- 2784 C1
- 2785 C2
- 3680 D6
- 3681 D6
- 3683 B6
- 3684 B6
- 3685 D6
- 3686 D6
- 3687 C6
- 3689 C5
- 3693 E3
- 3696 D4
- 3697 D4
- 3698 F3
- 3699 F3
- 3700 F4
- 3781 F4
- 3782 B2
- 3783 B3
- 3784 B2
- 3786 E5
- 3787 E5
- 3788 C6
- 5680 D6
- 5683 A6
- 5684 B6
- 5685 D6
- 5686 B3
- 5687 B6
- 6693 B3
- 7693 E2
- F680 B2
- F681 B2
- F682 B2
- F683 B2
- F684 B2
- F685 B2
- F686 B2
- F687 C2
- F688 B2
- F689 B2
- F690 E3
- I680 D8
- I681 D8
- I682 B2
- I683 B3
- I684 B2
- I685 D2
- I690 C8
- I699 F8
- I700 F8
- I722 F2
- I723 F2
- S698 F2
- S699 F2


Small Signal Board: Rear IO Scart




1101-1 A1	6121 F2
1102-1 A10	6143 E9
1105 G1	7119 F3
2101 A3	7138 D8
2103 B3	F101 A2
2104 B4	F102 B10
2105 B3	F103 B2
2107 C3	F104 B10
2108 C4	F105 B2
2109 A1	F106 B1
2110 B1	F107 C2
2111 B1	F108 C1
2112 B1	F109 C2
2127 A8	F110 B10
2128 B8	F111 D2
2129 B8	F112 D2
2131 B8	F115 E2
2132 C8	F117 E2
2133 C8	F119 F2
2134 B10	F120 F3
2135 A10	F121 F2
2136 B10	F127 A9
2137 B10	F128 B9
2138 D8	F129 B9
2139 F3	F133 C9
2140 F3	F134 C8
2152 G3	F135 C9
2153 G2	F137 D9
2155 G3	F141 D9
2157 G2	F143 E9
2169 E1	F147 G3
3101 A3	F148 G3
3102 A3	F153 G2
3103 B3	F154 G1
3104 B3	F156 G2
3105 B3	F157 C10
3106 B3	F158 C10
3107 C3	F159 C10
3108 C3	F160 D1
3109 C3	F161 E1
3110 C3	F191 D6
3111 D3	I102 A3
3112 D3	I104 B3
3113 D3	I106 B3
3114 D3	I110 C3
3115 E3	I112 D3
3116 E3	I114 D3
3117 E3	I116 E3
3118 E3	I118 E3
3119 F2	I119 F2
3120 F4	I120 F3
3121 F2	I126 A8
3122 F2	I128 B8
3123 F2	I132 C8
3124 A3	I136 D8
3125 B3	I139 D8
3126 A8	I140 D9
3127 A9	I142 E8
3128 B8	I50 C3
3129 B9	S101 A2
3130 B8	S103 B2
3131 B9	S104 C1
3132 C8	S105 B2
3133 C9	S106 B1
3134 D8	S107 C2
3135 C9	S109 C2
3136 D8	S111 D2
3137 D9	S113 D2
3138 D8	S115 E2
3139 D8	S117 E2
3140 D9	S119 F1
3141 D9	S121 F1
3142 E8	S126 B10
3143 E9	S127 A9
3144 B3	S128 B9
3145 C3	S129 B9
3146 G3	S130 C10
3147 G3	S131 C10
3148 A8	S132 C10
3149 B8	S133 C9
3150 B8	S135 D9
3151 C8	S137 D9
3152 G3	S141 D9
3153 G2	S143 E9
3155 G3	S153 G2
3156 G2	S156 G2
3169 E1	
4101 A2	
5139 F3	

Layout Small Signal Panel (Top Side Overview)


1001	B5	2027	C5	2127	D3	2169	D3	2386	A5	2530	A4	2699	D2	2825	C2	2867	A3	2953	A2	3016	B4	3105	D5	3122	D4	3139	D2	3169	D5	3403	B2	3563	B5	3635	C3	3701	A5	3803	C2	3931	A4	5004	B5	5687	D1	6564	B5	7119	D4	7693	D1
1008	C4	2035	B5	2128	D4	2262	A1	2392	A5	2560	C5	2708	A5	2826	C2	2868	A3	2954	A2	3017	B4	3106	D5	3123	D4	3140	D3	3266	C1	3404	B2	3564	B5	3638	C3	3702	A5	3804	C2	3932	A4	5005	C5	5801	C1	6604	C3	7138	D3	7706	A5
1036	B7	2040	B4	2129	D4	2263	C1	2396	C5	2561	C4	2709	C6	2830	C1	2869	A3	2955	A2	3018	B4	3107	D5	3124	D5	3141	D3	3267	C1	3405	B2	3565	B5	3639	C3	3704	A5	3805	C2	3933	A4	5006	B4	5802	C1	6605	C3	7262	C1	7709	A6
1401	B3	2061	B5	2131	D3	2264	C1	2401	C3	2562	C4	2784	D1	2833	C1	2870	A3	2956	A2	3019	B4	3108	D5	3125	D5	3142	D2	3268	C1	3406	B2	3566	B4	3680	D1	3712	A5	3806	C2	3951	A2	5072	B5	5804	C1	6634	C3	7370	C5	7710	A5
1450	A3	2063	B5	2132	D4	2265	C1	2402	B4	2563	B4	2785	D1	2834	C2	2871	A3	2957	A2	3049	B4	3109	D5	3126	D3	3143	D3	3269	C5	3407	B2	3567	B5	3681	D1	3713	A5	3807	C2	3952	A2	5139	D4	5805	C2	6635	C3	7371	C5	7713	A6
1860	A3	2071	B5	2133	D4	2266	C1	2417	A2	2564	C5	2803	C1	2837	C2	2874	A3	2958	A2	3050	B4	3110	D5	3127	D3	3144	D5	3270	C4	3408	B2	3568	B5	3683	D1	3723	A6	3813	C2	3953	A2	5262	A1	5874	A3	6638	C3	7372	C5	7714	A6
1861	A3	2089	C4	2134	D3	2268	B1	2418	A2	2565	A7	2806	C2	2838	C2	2875	A3	2960	A3	3051	B4	3111	D5	3128	D4	3145	D5	3271	C5	3409	A2	3605	C3	3684	D1	3724	A6	3821	C2	3954	A2	5267	C1	5882	A3	6639	C3	7376	B5	7808	C2
1862	A3	2101	D5	2135	D3	2269	A1	2434	A3	2605	C3	2807	C1	2839	C2	2882	A3	2994	A1	3052	B4	3112	D5	3129	D4	3146	D2	3272	C5	3410	B2	3606	C3	3685	D1	3729	B5	3824	C2	4009	C4	5268	B1	5930	A4	6693	D1	7377	A5	7930	A4
1863	A3	2103	D5	2136	D3	2355	B5	2435	C3	2606	C3	2808	C2	2840	C2	2911	A5	2996	B1	3053	B5	3113	D5	3130	D3	3147	D2	3273	C5	3411	A2	3607	C3	3686	D1	3781	D2	3825	C2	4010	C4	5530	A4	5931	A5	6701	A5	7401	B3	7952	A2
1864	A3	2104	D5	2137	D4	2356	C5	2451	C3	2611	C3	2809	C2	2843	C1	2920	A4	3001	A5	3060	B5	3114	D5	3131	D3	3148	D3	3274	C5	3412	B2	3608	C3	3687	D1	3782	D1	3826	C2	4062	B5	5560	C5	5952	A2	6930	A5	7501	B2		
2002	C4	2105	D5	2138	D2	2357	C5	2465	C3	2625	C4	2810	C1	2860	A3	2921	A4	3002	A5	3085	B5	3115	D5	3132	D4	3149	D4	3275	C5	3413	B2	3609	C3	3689	D2	3783	D1	3830	C2	4101	D5	5605	C3	5953	A1	6951	A1	7530	A3		
2006	B5	2107	D5	2139	D4	2360	B4	2470	C3	2626	C4	2813	C2	2861	A3	2930	A4	3003	A5	3086	B5	3116	D5	3133	D4	3150	D3	3276	C5	3414	B2	3610	C3	3693	D1	3784	D1	3831	C2	4609	C3	5636	C3	5954	A2	7001	A5	7560	B5		
2007	B5	2108	D5	2140	D4	2375	C5	2478	A3	2681	D2	2814	C2	2862	A3	2931	A5	3004	A5	3087	B5	3117	D5	3134	D3	3151	D4	3277	C5	3441	B3	3621	C2	3696	D1	3786	D1	3834	C2	4610	C3	5680	D1	6005	C5	7002	A5	7561	B5		
2008	B5	2109	D5	2152	D2	2376	A5	2482	A3	2686	D1	2818	C1	2863	A3	2932	A4	3007	B5	3101	D5	3118	D5	3135	D3	3152	D2	3278	C5	3442	A2	3622	C2	3697	D1	3787	D1	3835	C1	4611	C3	5683	D1	6121	D4	7003	A5	7562	C5		
2009	B5	2110	D5	2153	D2	2377	B5	2495	C3	2688	D1	2819	C2	2864	A3	2933	A5	3011	B4	3102	D5	3119	D4	3136	D3	3153	D2	3279	C5	3443	B3	3623	C3	3698	D2	3788	D2	3870	A3	4714	A6	5684	D1	6143	D3	7012	B4	7563	B5		
2012	A5	2111	D5	2155	D2	2380	B4	2501	B1	2693	D1	2820	C2	2865	A3	2934	A4	3014	B4	3103	D5	3120	D5	3137	D3	3155	D2	3280	C5	3444	B2	3624	C3	3699	D2	3801	C2	3871	A3	4715	A5	5685	D1	6267	C1	7013	B4	7604	C3		
2024	A5	2112	D5	2157	D2	2382	B5	2502	B1	2698	D2	2824	C1	2866	A3	2935	B5	3015	B4	3104	D5	3121	D4	3138	D3	3156	D2	3281	C5	3445	B2	3625	C3	3700	D2	3802	C2	3930	A4	5003	B5	5686	D2	6563	B5	7014	B4	7605	C3		




Layout Small Signal Panel (Top Side Part 1)



Layout Small Signal Panel (Top Side Part 2)



Layout Small Signal Panel (Top Side Part 4)



Part 4

C

D

4


5

6

7

Layout Small Signal Panel (Bottom Side Overview)

1004 C4	2005 B2	2029 B4	2050 C1	2069 B1	2088 B1	2271 A7	2364 B4	2398 C3	2421 B5	2440 B5	2462 B6	2483 B5	2508 B6	2582 A3	2617 C5	2636 C5	2720 A1	2812 C7	2846 C6	2887 A4	3021 A3	3038 B1	3070 B3	3092 B3	3309 D1	3329 D2	3642 C4	4331 C2	5959 A6
1009 C3	2010 B2	2030 B4	2051 A3	2070 B3	2090 B1	2302 D1	2365 C4	2403 B5	2422 B5	2441 B5	2463 B5	2484 B5	2509 B6	2583 A3	2618 C5	2701 B1	2735 A1	2815 C6	2847 C6	2889 A5	3022 A3	3039 A3	3071 C4	3093 B4	3311 D1	3340 A3	3643 C4	4332 C2	5960 A5
1301 D2	2011 B2	2031 B4	2052 B4	2072 B3	2091 B1	2303 D1	2366 B4	2404 B5	2423 B6	2442 B5	2464 B5	2485 B5	2510 B6	2584 A3	2619 C5	2702 C2	2736 A1	2816 C6	2848 C6	2890 A5	3023 B1	3040 B4	3072 B1	3094 B4	3313 C3	3342 A3	3644 C4	4333 C2	5961 B5
1328 C2	2013 C3	2032 B4	2053 C4	2073 B3	2092 B1	2307 C2	2367 B4	2405 B5	2424 B6	2443 B5	2466 B5	2486 B5	2511 B6	2585 A3	2620 C5	2703 B2	2737 A1	2817 C6	2849 C7	2895 A6	3024 B1	3048 B4	3073 B3	3096 B3	3314 C2	3343 A3	3645 C4	4334 C2	5962 B5
1329 B2	2014 C3	2033 B4	2054 B2	2074 B3	2093 B1	2308 C1	2368 C4	2406 B5	2425 B6	2444 B5	2467 B5	2487 B5	2512 B7	2586 A3	2621 C5	2704 B2	2738 A1	2818 C6	2850 C6	2896 A5	3025 C1	3054 B4	3074 C3	3097 B3	3315 C3	3344 A3	3646 C4	4335 C2	5963 B5
1330 C2	2015 C3	2034 A3	2055 B4	2076 B3	2094 B1	2309 C2	2370 C3	2407 B5	2426 B6	2445 B5	2468 B5	2488 B5	2513 B7	2587 A3	2622 C5	2705 B2	2739 B2	2822 C6	2851 C6	2892 A6	3026 C1	3055 C4	3075 B3	3098 B4	3316 C2	3345 A4	3703 C2	4336 C2	5967 B5
1408 A5	2016 C3	2036 B1	2056 B4	2077 B3	2095 C1	2311 D2	2371 C3	2408 B5	2427 B6	2446 B6	2469 B5	2490 B5	2514 B7	2588 A3	2623 C5	2706 B2	2740 C2	2823 C6	2872 A6	2893 A7	3027 C1	3056 B3	3077 A3	3251 A7	3317 C3	3346 A3	3705 C2	4337 B2	5968 B5
1409 B7	2017 C3	2037 B1	2057 C1	2078 B4	2096 C1	2313 C2	2372 C3	2409 B5	2428 B6	2447 B5	2471 B5	2491 C5	2515 B7	2601 C5	2624 C4	2707 B1	2741 A2	2827 C6	2876 A4	2895 B6	3028 C4	3057 B3	3078 B3	3259 A7	3319 C2	3347 A3	3706 B2	4338 B2	5969 B5
1530 A5	2018 C3	2041 B4	2058 C1	2079 B1	2097 C1	2314 C2	2373 C3	2410 B5	2429 B6	2448 B5	2472 B5	2492 B5	2516 B7	2607 C5	2627 C5	2710 B1	2742 A2	2828 C6	2877 A4	3000 B2	3029 A4	3058 A4	3079 B3	3260 A7	3320 C2	3348 A3	3707 B2	4339 D1	5990 B5
1532 B4	2019 A3	2042 A3	2059 B1	2080 B1	2098 C1	2317 C3	2374 C3	2411 B5	2430 B6	2449 B5	2473 B5	2493 B6	2517 B7	2608 C5	2628 C5	2711 B2	2743 B2	2829 C6	2878 A4	3005 B2	3030 B4	3059 B2	3080 B3	3270 A7	3321 C2	3349 A4	3708 B2	4340 D1	5991 B5
1681 D2	2020 A3	2043 B2	2060 B2	2081 B1	2099 B3	2318 C3	2378 B4	2412 B5	2431 B6	2450 B5	2474 B5	2494 B6	2526 A7	2609 C5	2629 C5	2712 A2	2744 B2	2832 C7	2879 A4	3006 B2	3031 B4	3063 C1	3081 B3	3271 A7	3322 C2	3357 B3	3709 B2	4360 C4	5994 A7
1701 C2	2021 A4	2044 B4	2062 D1	2082 C3	2251 A7	2321 C2	2381 B4	2413 B5	2432 B6	2452 B5	2475 B5	2496 B5	2531 B5	2610 C5	2630 C5	2713 A2	2746 A2	2835 C6	2880 A4	3008 B2	3032 B4	3064 C4	3082 B3	3273 A7	3323 C2	3358 C3	3710 B2	4361 C4	5996 B5
1951 A5	2022 B4	2045 C1	2064 B2	2083 C3	2252 A7	2324 C2	2387 C3	2414 B5	2433 B6	2453 B5	2476 B5	2503 A6	2532 B4	2612 C5	2631 C5	2714 A1	2747 A2	2836 C6	2881 A4	3009 C3	3033 C4	3065 C2	3083 B3	3274 A7	3324 C2	3360 C4	3711 B1	4362 B4	5997 B5
2000 B2	2023 C4	2046 C1	2065 C3	2084 B4	2253 A7	2328 C3	2388 C3	2415 B5	2436 B6	2454 B5	2477 B5	2504 B6	2533 A4	2613 C5	2632 C5	2715 B2	2748 A2	2841 C6	2883 A4	3010 B2	3034 B4	3066 C1	3084 D1	3302 D1	3325 C2	3361 C4	3712 A2	4363 B4	5998 B5
2001 B2	2025 B4	2047 A4	2066 C3	2085 B3	2254 A7	2359 C2	2394 B4	2416 B5	2437 B5	2455 B5	2479 B5	2505 B6	2566 D1	2614 C5	2633 C5	2716 C1	2749 A2	2842 C6	2884 A4	3012 B4	3035 B4	3067 B1	3088 B3	3303 D1	3326 C2	3362 C4	3715 A2	4427 B6	6001 B3
2003 C1	2026 B4	2048 C1	2067 D1	2086 B3	2255 A7	2361 B4	2395 C3	2419 B6	2438 B5	2456 B5	2480 B5	2506 B6	2580 A2	2615 C5	2634 C5	2718 A2	2750 A2	2844 C6	2885 A5	3013 C3	3036 B4	3068 B1	3089 B2	3304 D2	3327 C1	3363 C4	3716 B2	4428 B6	6020 A3
2004 B2	2028 A3	2049 C1	2068 B2	2087 B1	2261 A7	2363 C4	2397 C3	2420 B5	2439 B5	2461 B5	2481 B5	2507 B6	2581 A3	2616 C5	2635 C5	2719 A2	2811 C6	2845 C6	2886 A5	3020 A3	3037 B1	3069 B1	3091 B3	3305 D2	3328 D2	3365 C4	3717 C2	4444 B6	6021 B4




3366 B4	3718 B2	4445 B6	6023 A3
3367 B4	3719 C2	4446 B5	6074 B3
3368 C4	3720 C2	4580 A3	6075 B3
3369 C4	3721 B2	4581 A3	6076 A3
3370 C3	3722 C2	4582 A3	6259 A7
3373 C4	3725 C2	4583 A3	6262 A7
3389 B3	3726 A2	4584 A3	6270 A7
3390 C3	3727 A2	4585 A3	6310 D1
3391 C3	3728 B3	4586 A3	6311 D1
3392 C3	3735 A1	4587 A3	6323 C2
3393 C3	3736 A1	4588 A3	6324 C2
3394 B2	3737 A1	4589 A3	6328 D2
3415 C1	3738 A1	4590 A3	6329 D2
3416 B6	3739 B2	4591 A3	6330 D1
3417 B6	3740 B2	4592 A3	6331 D2
3418 B5	3741 B2	4593 A3	6565 C2
3422 B5	3742 B2	4601 C5	6910 A3
3423 B5	3743 B2	4602 C5	6911 A3
3424 B5	3744 C1	4603 C5	7004 B4
3425 B5	3745 B2	4604 C5	7005 B2
3426 B5	3746 B2	4605 C5	7011 B3
3427 B6	3747 B2	4606 C5	7015 A3
3428 B5	3748 B2	4607 C5	7016 A3
3429 B5	3749 B2	4608 C5	7017 A4
3432 B5	3750 B2	4701 B2	7018 A3
3433 B5	3751 C1	4702 B2	7019 A4
3436 B5	3752 A2	4703 B1	7070 B3
3437 B5	3753 A2	4704 B2	7075 B3
3438 B5	3808 C7	4705 B2	7099 A3
3439 B5	3809 C7	4706 B2	7260 A7
3440 B5	3810 C7	4707 B2	7271 A7
3442 C5	3815 C6	4708 B3	7272 A7
3443 B5	3816 C6	4709 B3	7316 C3
3444 B6	3817 C6	4710 B2	7320 C2
3446 B5	3819 C6	4711 B2	7325 C2
3448 B5	3822 C7	4716 B3	7360 C4
3460 B5	3823 C7	4720 A1	7416 B5
3501 B7	3827 C6	4836 C6	7531 B5
3502 B7	3828 C7	4838 C6	7532 B4
3503 B7	3829 C6	4871 A6	7579 C1
3531 B5	3832 C7	4872 A6	7580 A3
3532 B4	3833 C6	4887 A4	7581 A3
3533 B4	3836 C6	4888 A6	7582 A3
3534 B4	3837 C6	5001 B2	7583 A3
3536 A5	3838 C6	5002 B2	7584 A3
3538 A4	3839 C6	5007 B4	7585 A3
3539 A4	3876 A4	5008 B4	7601 C5
3540 A5	3877 A4	5010 B4	7606 C5
3541 A5	3879 A4	5060 B2	7607 C5
3542 A5	3883 A4	5066 C1	7702 C2
3543 A5	3885 A5	5067 D1	7703 B2
3544 A5	3886 A4	5070 B3	7707 B2
3545 A4	3887 A4	5071 B3	7708 B1
3546 A5	3910 A3	5251 A7	7740 B2
3547 A5	3911 A3	5252 A7	7801 C6
3548 A5	3955 A5	5257 A7	7806 C7
3549 A5	3958 A5	5258 A7	7807 C7
3550 A4	4002 C3	5259 A7	7809 C6
3551 A5	4004 C3	5304 D2	7810 C6
3552 A5	4005 C3	5309 C2	7872 A6
3553 A5	4006 C3	5321 C2	7887 A4
3579 C1	4007 C3	5324 C2	7910 A3
3580 A3	4008 B4	5339 B2	7920 A4
3581 A3	4011 C4	5340 C2	7953 A6
3601 C5	4012 C4	5360 B4	7954 A5
3612 C5	4015 A3	5370 B4	7955 A5
3613 C5	4016 A4	5371 B4	7956 A7
3614 C5	4017 C1	5372 B4	7995 B6
3615 C5	4018 C1	5580 A3	
3616 C5	4019 C1	5601 C5	
3617 C5	4020 C1	5607 C5	
3618 C5	4022 C2	5720 A1	
3619 C5	4023 C3	5721 A2	
3620 C5	4085 B1	5722 A2	
3625 C5	4086 B1	5735 A1	
3626 C5	4251 A7	5736 A1	
3627 C5	4255 A7	5803 C6	
3628 C5	4312 C2	5872 A6	
3629 C5	4313 C3	5910 A4	
3630 C5	4318 C3	5920 A4	
3631 C5	4327 C2	5932 A3	
3632 C5	4328 C2	5955 A5	
3633 C5	4329 C2	5956 A5	
3641 C4	4330 C2	5957 A6	


3139 123 5837.1

E_14710_035.eps
040604


Layout Small Signal Panel (Bottom Side Part 1)




Layout Small Signal Panel (Bottom Side Part 3)



Layout Small Signal Panel (Bottom Side Part 4)



PDP Audio Panel




0045 E5	3761 B8	I717 A5
1701 F2	3762 D7	I718 B5
1702 F2	3763 C8	I719 E2
1735 F1	3764 C8	I720 D2
1736 F1	3765 D8	I721 B2
1739 E4	3766 D8	I722 B2
1M02 A8	3767 C9	I723 E2
2701 F3	3768 D9	I724 D2
2702 B3	3769 A2	I725 E1
2704 B2	3770 A1	I726 C5
2705 A6	3790 B3	I727 A5
2706 B3	3791 B2	I728 F3
2707 B3	3792 B2	I729 C4
2708 A2	3793 B3	I732 B5
2709 C5	3794 B4	I737 C6
2710 C4	3795 B4	I738 B5
2711 E1	3798 C5	I739 B6
2712 D4	3999 F8	I744 D5
2713 A6	5701 E3	I753 A2
2714 D3	5702 E2	I754 E2
2715 E3	5703 A4	I755 C3
2716 D3	5704 F4	I756 C1
2717 F3	5707 C1	I757 C2
2718 E2	5708 D1	I763 C6
2719 E4	5711 C4	I766 B8
2720 B2	5712 C4	I767 C8
2721 B1	6701 C6	I768 C8
2722 C1	6704 A6	I769 C9
2724 D1	6710 C8	I770 D8
2726 D2	6711 D8	I771 D8
2727 E2	7700 B2	I772 D9
2728 D2	7701 B6	I773 D8
2729 F2	7703 B6	I775 D4
2730 D4	7704 A5	I776 D3
2764 A2	7705 B6	I777 C2
2766 A3	7706 B6	I778 D2
2768 D4	7707 B5	I779 D2
2769 D4	7710 C8	I781 A2
2777 D1	7711 C9	I782 B2
2778 B5	7712 D8	I783 B3
2779 D2	7713 D9	I784 D8
2780 D4	7714 B4	I785 B8
2781 D4	9717 A5	I786 C9
2783 C7	9718 D8	I787 A3
2785 C8	9719 F2	I788 B6
2786 A3	9720 F2	I791 A3
2788 D1	9721 E2	I792 B2
2789 D1	9722 F2	I793 B2
2790 D1	F708 F2	I798 D4
2791 B4	F710 F2	I799 D3
2792 A1	F711 A1	
2793 A2	F712 A1	
3701 E5	F713 B2	
3702 A6	F714 B4	
3703 A6	F716 F7	
3704 A5	F717 F8	
3705 B2	F721 F2	
3706 D5	F722 F2	
3707 C5	F732 A9	
3708 D5	F733 A9	
3709 E4	F734 B9	
3710 D3	F735 B9	
3711 C4	F736 B9	
3712 E2	F737 F6	
3713 C6	F738 F2	
3714 B5	F739 F2	
3715 B5	F742 B8	
3716 B6	F743 D7	
3717 F3	F744 F5	
3718 F3	F745 F4	
3721 B1	I700 D5	
3722 C1	I701 D6	
3723 B1	I702 A6	
3724 E1	I703 A6	
3725 D2	I704 A6	
3726 E1	I705 C5	
3727 E4	I706 C4	
3743 E3	I707 C4	
3746 C5	I709 D3	
3747 C6	I710 E4	
3748 B5	I711 B3	
3750 F2	I713 D3	
3756 E3	I714 B4	
3757 F3	I715 C4	
3760 E3	I716 D2	

3104 303 3905.4

E_14720_017.eps
020904


Layout PDP Audio Panel (Top Side)

0045 A1	1735 A4	1M02 A4	2768 A2	2783 A1	2790 A3	3748 A2	5707 A3	5712 A4	9702 A3	9705 A4	9708 A1	9711 A1	9719 A1	9722 A1
1701 A4	1736 A2	2717 A2	2769 A2	2785 A4	3711 A3	5701 A2	5708 A4	7700 A3	9703 A2	9706 A2	9709 A1	9712 A4	9720 A4	
1702 A1	1739 A1	2729 A4	2778 A1	2788 A3	3717 A2	5702 A3	5711 A2	9701 A4	9704 A2	9707 A2	9710 A1	9718 A4	9721 A4	




Layout PDP Audio Panel (Bottom Side)

0045 A4	2701 A4	2709 A4	2716 A3	2724 A3	2766 A4	2781 A4	2791 A4	3705 A3	3712 A4	3721 A3	3743 A2	3760 A4	3767 A2	3793 A4	5703 A5	6704 A5	7705 A5	7714 A4	9707 A4	9718 A2
1701 A2	2702 A4	2710 A4	2717 A4	2726 A3	2768 A4	2783 A5	2792 A5	3706 A3	3713 A5	3722 A3	3746 A5	3761 A2	3768 A2	3794 A4	5704 A4	6710 A2	7706 A5	9701 A2	9708 A5	9719 A5
1702 A5	2704 A3	2711 A3	2718 A4	2727 A3	2769 A4	2785 A2	2793 A5	3707 A3	3714 A5	3723 A3	3747 A5	3762 A2	3769 A5	3795 A4	5707 A3	6711 A2	7707 A5	9702 A3	9709 A5	9720 A2
1735 A2	2705 A5	2712 A4	2719 A4	2728 A3	2777 A3	2786 A4	3701 A5	3708 A4	3715 A5	3724 A3	3748 A4	3763 A2	3770 A5	3798 A5	5708 A2	7700 A4	7710 A2	9703 A4	9710 A5	9721 A2
1736 A4	2706 A3	2713 A5	2720 A3	2729 A2	2778 A5	2788 A3	3702 A5	3709 A4	3716 A5	3725 A3	3750 A5	3764 A2	3790 A4	3999 A1	5711 A4	7701 A5	7711 A2	9704 A4	9711 A5	9722 A5
1739 A5	2707 A3	2714 A4	2721 A3	2730 A4	2779 A3	2789 A3	3703 A5	3710 A3	3717 A4	3726 A3	3756 A2	3765 A2	3791 A3	5701 A4	5712 A2	7703 A5	7712 A1	9705 A2	9712 A2	
1M02 A2	2708 A3	2715 A4	2722 A3	2764 A4	2780 A4	2790 A3	3704 A5	3711 A3	3718 A4	3727 A4	3757 A5	3766 A2	3792 A4	5702 A3	6701 A5	7704 A5	7713 A2	9706 A4	9717 A5	



Side I/O Panel




- 1001-A B1
- 1001-B B1
- 1001-C C1
- 1002 D1
- 1004 B7
- 1101 A3
- 1102 B3
- 1106 C3
- 1108 D3
- 2004 C4
- 2005 C5
- 2006 D4
- 2007 D5
- 3000 A4
- 3004 B4
- 3009 C5
- 3010 C5
- 3012 D5
- 3013 D5
- 6000 A3
- 6001 A3
- 6002 B3
- 6003 C3
- 6004 C3
- 6005 D3
- 6006 D3
- 6007 E3
- 9001 D2
- 9002 D2
- 9007 D7
- I001 A3
- I002 A4
- I003 B6
- I004 B4
- I005 B6
- I006 C6
- I007 C6
- I008 C2
- I009 C4
- I010 D2
- I011 E4
- I012 D7


3104 313 6031.2

E_14720_008.eps
290704

Layout Side I/O Panel (Top Side)




Layout Side I/O Panel (Bottom Side)




Layout Top Control Panel (Top Side)

0345 1701 1702 1703 1704 1705




Layout Top Control Panel (Top Side)

3001 3003 3005 3007 3009 3011 3013 6005 9002 9004 9006
3002 3004 3006 3008 3010 3012 3999 9001 9003 9005



EMC Filter Panel




- 1300 G1
- 1301 G3
- 1320 E1
- 1330 E7
- 1340 B1
- 1345 A7
- 1350 B7
- 1355 A1
- 2300 G4
- 2301 G4
- 2302 G4
- 2303 G4
- 2304 G5
- 2305 G5
- 2306 G5
- 2307 G5
- 2308 B5
- 2309 D4
- 2310 D4
- 2312 D5
- 3300 D4
- 3301 D4
- 3302 E4
- 3303 E4
- 3304 D6
- 3305 D6
- 3306 E6
- 3307 E6
- 3308 C4
- 3309 C4
- 3310 C5
- 3311 C6
- 5300 F4
- 5301 F4
- 5302 F4
- 5303 F4
- 5304 F4
- 5305 F6
- 5306 F6
- 5307 F6
- 5308 F6
- 5309 F6
- 5310 A4
- 5311 A6
- 5312 A4
- 5313 A6
- 5314 D4
- 5315 E4
- 5316 F4
- 5317 D6
- 5318 E6
- 5319 E6
- 5320 F6
- 5321 B4
- 5322 B6
- 5323 E4
- 9300 G2
- 9301 G2
- 9306 G5
- I300 A3
- I301 A3
- I302 A4
- I303 A5
- I304 A6
- I305 B7
- I306 D3
- I307 D4
- I308 D6
- I309 D3
- I310 D4
- I311 D6
- I312 E3
- I313 E4
- I314 E6
- I315 E3
- I316 E4
- I317 E6
- I318 F3
- I319 F5
- I320 F6
- I321 F3
- I322 F5
- I323 F6
- I324 F3
- I325 F5
- I326 F6
- I327 F3
- I328 F5
- I329 F6
- I330 F3
- I331 F5
- I332 F6
- I333 G2
- I334 G3
- I335 B3
- I336 C3
- I337 C3
- I338 B4
- I339 C5
- I340 C5
- I341 B6
- I342 C6
- I343 C6

3104 313 6044.1


E_14720_020.eps
270804

Layout EMC Filter Panel (Top Side)

1320 A2	2301 A1	2308 A2	3303 A1	3310 A2	5305 A1	5312 A2	5319 A1	9306 A2
1330 A1	2302 A1	2309 A1	3304 A1	3311 A2	5306 A1	5313 A2	5320 A1	
1340 A1	2303 A1	2310 A2	3305 A1	5300 A1	5307 A2	5314 A2	5321 A2	
1345 A2	2304 A1	2312 A2	3306 A1	5301 A1	5308 A2	5315 A1	5322 A1	
1350 A1	2305 A2	3300 A1	3307 A1	5302 A1	5309 A2	5316 A1	5323 A1	
1355 A2	2306 A2	3301 A1	3308 A1	5303 A1	5310 A2	5317 A1	9300 A1	
2300 A1	2307 A2	3302 A1	3309 A1	5304 A1	5311 A2	5318 A1	9301 A2	




Layout EMC Filter Panel (Bottom Side)



E_14720_022.eps
270804

LED and Switch Panel




8204 000 6676.1

E_14710_052.eps
210704


- 0222 E2
- 0317 A9
- 0320 B1
- 1101 D3
- 2107 C7
- 2120 E5
- 2126 F6
- 3101 C4
- 3102 B4
- 3103 C5
- 3104 B6
- 3105 C5
- 3106 D6
- 3107 B5
- 3108 B7
- 3109 B7
- 3120 E4
- 3121 F4
- 3122 F3
- 3123 F4
- 3124 F5
- 3125 F5
- 3126 F6
- 3127 F6
- 3128 E8
- 4101 C3
- 4107 B6
- 4108 C8
- 4109 C8
- 4110 C8
- 4111 C8
- 5100 C2
- 6101 C4
- 6103-A D5
- 6103-B D5
- 6105 C6
- 6127 F6
- 7103 B5
- 7105 C5
- 7107 C9
- 7120-A E5
- 7120-B E4
- F101 C2
- F102 C2
- F103 C2
- F104 C2
- F105 C2
- F106 C1
- F107 C1
- F108 C2
- F109 D2
- F110 C5
- F111 C6
- F112 D2
- F115 A9
- F116 A9
- F119 B9
- F120 B9
- F121 E8
- F122 E9
- I102 C4
- I103 C4
- I104 C5
- I105 C5
- I106 C6
- I107 C6
- I109 B7
- I111 C7
- I112 C8
- I113 C8
- I120 F4
- I123 F5
- I125 F5
- I126 F6
- I127 E6

Layout LED and Switch Panel (Top Side)



- 0317 A1
- 0320 A1
- 1101 A1
- 2107 A1
- 2120 A1
- 6103 A1
- 6127 A1
- 7107 A1

Layout LED and Switch Panel (Bottom Side)



- 0317 A1
- 1101 A1
- 2126 A1
- 3101 A1
- 3102 A1
- 3103 A1
- 3104 A1
- 3105 A1
- 3106 A1
- 3107 A1
- 3108 A1
- 3109 A1
- 3120 A1
- 3121 A1
- 3122 A1
- 3123 A1
- 3124 A1
- 3125 A1
- 3126 A1
- 3127 A1
- 3128 A1
- 4101 A1
- 4107 A1
- 4108 A1
- 4109 A1
- 4110 A1
- 4111 A1
- 5100 A1
- 6101 A1
- 6105 A1
- 7103 A1
- 7105 A1
- 7107 A1
- 7120 A1

8. Alignments

Index of this chapter:

- 8.1 General Alignment Conditions
- 8.2 Hardware Alignments
- 8.3 Software Alignments
- 8.4 Option Settings

Note: The Service Default Mode (SDM) and Service Alignment Mode (SAM) are described in chapter 5. Menu navigation is done with the Cursor Up, Down, Left or Right keys of the remote control transmitter.

8.1 General Alignment Conditions

8.1.1 Start Conditions

Perform all electrical adjustments under the following conditions:

- Power supply voltage (depends on region):
 - EU: 230 V_{AC} / 50 Hz (± 10%).
 - US: 120 V_{AC} / 60 Hz (± 10%).
 - AP: 120 V_{AC} or 230 V_{AC} / 50 Hz (± 10%).
- Connect the set to the mains via an isolation transformer with low internal resistance.
- Allow the set to warm up for approximately 15 minutes.
- Measure voltages and waveforms in relation to chassis ground (with the exception of the voltages on the primary side of the power supply).
- **Caution:** never use heatsinks as ground.
- Test probe: R_i > 10 Mohm, C_i < 20 pF.
- Use an isolated trimmer/screwdriver to perform alignments.

8.1.2 Initial Settings

Perform all electrical adjustments with the following initial settings:

1. To avoid the working of the lightsensor, set "Active Control" to "Off" (via the "Active Control" button on the RC).
2. Set "Smart Picture" to "Natural" or "Soft" (via the "Smart Picture" button on the RC).

8.1.3 Alignment Sequence

- First, set the correct options:
 - In SAM, select OPTIONS,
 - Fill in the option settings according to the set sticker (see also paragraph "Option Settings"),
 - Store the OPTIONS by switching the set to STAND-BY.
- Warming up (>15 minutes).
- White-D alignment.

8.2 Hardware Alignments

No hardware alignments necessary.

8.3 Software Alignments

With the software alignments of the Service Alignment Mode (SAM), Options can be set and the WHITE TONE, TUNER (IF) and AUDIO settings can be aligned.

To store the data: Use the RC button MENU to switch to the main menu and then switch to STAND-BY mode.

8.3.1 SAM Menu




Figure 8-1 Overview SAM menu

8.3.2 White Tone

Method 1 (with colour analyser):

Supply a 100% white uniformity test signal to the tuner. Enter SAM menu. Colour features are switched "off" automatically.

Do **NOT** change the SMART PICTURE, ACTIVE CONTROL and CONTRAST+ settings, to prevent activating of Green Enhancement, Blue Stretch, and Black Stretch. Offset values in NVM are used for HD-, HDMI- and VGA mode only the settings in TV mode need to be set. Make the following settings in the normal user menu, when television is in TV Mode:

Table 8-1 Picture settings for white tone alignment

	AUO	LPL	PDP
Contrast	99	99	99
Brightness	42	44	44
Colour	50	50	50

Set the following settings in SAM:

WHITE TONE - NORMAL RED to: Initial value.
 WHITE TONE - NORMAL GREEN to: Initial value.
 WHITE TONE - NORMAL BLUE to: Initial value.

Initial value is: 200 for LCD sets (LPL and AUO) and 180 for PDP sets.

Measure the RGB values with a colour analyser.

Leave the value with the lowest output on the initial value.

Align the normal white points, by lowering the other 2 colours, to the right x-y coordinates (see table "White Tone alignment values").

Note: Only lower the colours to prevent clipping!

Table 8-2 White Tone alignment values

Colour temp. (K)	NORMAL (all regions)
X	0.289
Y	0.299

Note: Measure with a calibrated (phosphor- independent) colour analyser in the centre of the screen. Use a contact less analyser (e.g. Minolta CA-210) to align the LCD TV. The colour analyser may not touch the screen surface. Also, the measurement needs to be done in a dark environment. The colour analyser must be calibrated for the LCD or Plasma panel in question. See the manual of the colour analyser for the procedure on how to perform this calibration.

Only the values for Normal are aligned with X, Y values. The delta values for COLD and WARM are given below.

Table 8-3 Fixed delta values

Screen Type		RED	GREEN	BLUE
PDP	Delta Cool	-6	-10	+5
	Delta Warm	+4	-5	-19
LCD LPL	Delta Cool	-8	-12	+3
	Delta Warm	+2	-10	-21
LCD AUO	Delta Cool	-3	-12	+10
	Delta Warm	+5	-5	-20

After the alignment is finished, switch the set to STANDBY, in order to store the alignments. When disconnecting the power before doing this, the settings will not be stored.

Method 2 (without colour analyser):

If you do not have a colour analyser, you can use the default values. These values are based on the average values in production.

- Set the values for the NORMAL colour temperature. Given in the table "Average statistical values for "NORMAL" from production.
- Set the delta values for the COOL and WARM mode. See table: "Fixed delta values."
- After the alignment is finished, switch the set to STANDBY, in order to store the alignments. When disconnecting the power before doing this, the settings will not be stored.

Table 8-4 Average statistical values for "NORMAL"

Display type	Colour Temp.	RED	GREEN	BLUE
LCD (AUO)	NORMAL	165	182	200
LCD (LPL)	NORMAL	200	195	190
SDI Plasma (37")	NORMAL	174	180	178
SDI Plasma (42")	NORMAL	173	180	172

Note: Values are valid for all regions

8.3.3 Tuner Adjustment

AGC (RF AGC Take Over Point)

Set pattern generator (e.g. PM5580) with colour bar pattern and connect to aerial input with RF signal amplitude - 10mV and set frequency for PAL/SECAM to 475.25 MHz. For France select the L'-signal.

- Activate the SAM-menu. Go to the sub-menu TUNER, select the sub-menu option AFC WINDOW and adjust the value to "100 kHz".
- Select the AGC sub-menu.
- Connect a DC multi-meter to test point F306 or pin1 of the tuner.
- Adjust the AGC until the voltage at pin 1 of the tuner is 3.3 V +0.5 / -1.0.
- The value can be increased or decreased by pressing the RIGHT/LEFT cursor button on the RC.
- Switch the set to STAND-BY to store the data.

8.3.4 Grey Scale Adjustment

SDTV Grey Scale Adjustment

Equipment and setting

- E.g. Fluke 54200 or Philips PM5580.
- 100% "8-step grey scale" pattern.

Alignment Method

- Switch with the RC to TV mode,
- Press the MUTE button on RC,
- Set SMART PICTURE to SOFT mode,
- Activate the auto colour function by pressing key-sequence: "INFO - MUTE - MUTE - MUTE - INFO - MENU - INFO".

Expected Results

- Visual check if the 8 Grey levels are correct.

Analog PC Grey Scale Adjustment

Equipment and setting

- Quantum Data 802B.
- PC input signal, with 64 levels Grey scale pattern, 1024x768 @ 60Hz (Format= 81:DMT1060, Pattern= 123:Grey 64).
- PC input at D-sub VGA connector.

Alignment Method

- Switch with the RC to PC mode.
- Press the MUTE button on RC.
- Set BRIGHTNESS and CONTRAST to nominal "50".
- Activate the auto colour function by pressing key-sequence: "INFO - MUTE - MUTE - MUTE - INFO - MENU - INFO".

Expected Results

- Visual check if the 64 Grey levels are correct.

HD Grey Scale Adjustment

Equipment and setting

- Quantum Data 802B.
- HD input signal, Top half 100% colour bar and bottom half Grey scale pattern, 1920x1080i@60Hz YPbPr (Format= 1080i30, Pattern= HDBar100).
- HD input at D-sub VGA connector.

Alignment Method

- Switch with the RC to HD mode.
- Press the MUTE button on RC.
- Activate the auto colour function by pressing key-sequence:
"INFO - MUTE - MUTE - MUTE - INFO - MENU - INFO".

Expected Results

- Visual check if Colour bar tint and Grey scale is correct.

8.3.5 Sound

No adjustments needed for sound.

8.4 Option Settings

Options are used to control the presence/absence of certain features and hardware.

8.4.1 How to change an Option Byte

An Option Byte represents a number of different options. Changing these bytes directly makes it possible to set all options very fast. All options are controlled via seven option bytes. Select the option byte (OP1.. OP7) with the cursor UP/DOWN keys, and enter the new value.

Leaving the OPTION sub menu saves the changes in the Option Byte settings. Some changes will only take effect after the set has been switched "off" and "on" with the AC power switch (cold start).

Table 8-5 Option codes (general overview for all regions and displays)

Bit (DEC)	Option	Description	/61 (AP)	/69 (AP)	/93 (AP)	/00 (EU)	/37 (US)	Remarks
7 (128)	OP_PHILIPS_TUNER	Philips Tuner available	1	1	1	1	1	
6 (64)	OP_FM_RADIO	FM Radio available	0	0	0	0	0	
5 (32)	OP_LNA	Low Noise Amplifier available	0	0	0	0	0	
4 (16)	OP_ATS	Auto Tuning System	0	0	0	1	0	
3 (8)	OP_ACI	ACI	0	0	0	1	0	
2 (4)	OP_UK_PNP	After virgin = English + Great Britain	0	0	0	0	0	
1 (2)	OP_VIRGIN_MODE	Activate Plug & Play menu at start-up	0	0	0	0	0	
0 (1)	OP_CHINA	AP-PAL tuning algorithm for China	0	0	1	0	0	
OP1:			128	128	129	152	128	
7 (128)	OP_SMART_SOUND	Four smart sound settings	1	1	1	1	1	
6 (64)	OP_UI_GREEN	UI for Magnavox sets (NAFTA)	0	0	0	0	0	
5 (32)	OP_CHANNEL_NAMING	Naming of channel feature available	1	1	1	0	1	
4 (16)	OP_LTI	Histogr. algorithm available (TDA9178)	1	1	1	1	1	
3 (8)	OP_TILT	Picture Rotation available	0	0	0	0	0	
2 (4)	OP_FINE_TUNING	Fine Tuning algorithm available	1	1	1	1	1	
1 (2)	OP_PIP_PHILIPS_TUNER	PIP Philips tuner	0	0	0	0	0	
0 (1)	OP_HUE	Tint for NTSC transmission	1	0	0	0	1	
OP2:			181	180	180	148	181	
7 (128)	OP_EW_FUNCTION	Geometry adj. for Large screen sets	0	0	0	0	0	
6 (64)	OP_2TUNER_PIP	Double Tuner for PIP available	0	0	0	0	0	
5 (32)	OP_PIP_SPLITTER	Not used	0	0	0	0	0	
4 (16)	OP_SPLITTER	Not used	0	0	0	0	0	
3 (8)	OP_VIRTUAL_DOLBY	Virtual Dolby Effect	1	1	1	1	1	
2 (4)	OP_WIDE_SCREEN	16:9 sets	1	1	1	1	1	
1 (2)	OP_WSSB	Wide Screen Signalling Bit detection	0	1	0	1	0	
0 (1)	OP_ECO_SUBWOOFER	Sub woofer available	0	0	0	0	0	
OP3:			12	14	12	14	12	
7 (128)	OP_LIP_SYNC	Lip Synchronisation Circuit available	0	0	0	0	0	Not for LCD
6 (64)	OP_NOTUSED2	Not used	0	0	0	0	0	
5 (32)	OP_ULTRA_BASS	Ultra Bass Boost available	0	0	0	0	0	
4 (16)	OP_DELTA_VOLUME	Delta Volume feature available	0	0	0	1	0	EU only
3 (8)	OP_NOTUSED3	Not used	0	0	0	0	0	
2 (4)	OP_NOTUSED4	Not used	0	0	0	0	0	
1 (2)	OP_STEREO_DBX	Stereo DBX for NTSC available	0	0	0	0	1	NTSC only
0 (1)	OP_STEREO_NICAM_2CS	Stereo NICAM 2CS available	0	1	0	1	0	
OP4:			0	1	0	17	2	
7 (128)	OP_AV1	External Source 1 available	1	1	1	1	1	
6 (64)	OP_AV2	External Source 2 available	1	1	1	1	1	
5 (32)	OP_AV3	External Source 3 (Side AV) available	1	1	1	1	1	
4 (16)	OP_CVI	Component Video In available	1	1	1	0	1	Not for EU
3 (8)	OP_SVHS2	Super Video Home System 2 available	0	0	0	0	0	
2 (4)	OP_SVHS3	Super Video Home System 3 available	0	0	0	0	0	
1 (2)	OP_HOTEL_MODE	LATAM specific simplified Hotel Mode	0	0	0	0	0	
0 (1)	OP_NOTUSED	Not used	0	0	0	0	0	
OP5:			240	240	240	224	240	
7 (128)	OP_PERSONAL_ZAPPING	Zapping of channels feature available	0	0	0	0	0	
6 (64)	OP_SMART_SURF	Surf List available	0	0	0	0	0	
5 (32)	OP_FMTRAP	FM trap available	0	0	0	0	0	
4 (16)	OP_COMBFILTER	comb filter available	1	1	1	1	1	Internal Hercules
3 (8)	OP_ACTIVE_CONTROL	Auto Picture Impr. feature available	1	1	1	1	1	
2 (4)	OP_SMART_LOCK	Toggle Child Lock & Lock Chan. enabled	1	1	1	1	1	
1 (2)	OP_LIGHT_SENSOR	Light Sensor enabled	1	1	1	1	1	
0 (1)	OP_TWIN_TEXT	2 txt pages on screen available	0	1	1	1	0	
OP6:			30	31	31	31	30	
7 (128)	OP_TIME_WIN1	1= 5 s, 0= 2 s (Europe fixed 1.2 s)	1	0	1	0	1	
4 (16)	OP_3DCOMB	3D comb filter available	1	0	0	0	1	NTSC only
AP-PAL								
3 (8)	OP_COLOR_SYSTEM_AP	1: Auto, PAL 4.43, NTSC 4.43, NTSC 3.58, SECAM 0: OFF- Auto, PAL 4.43, NTSC 4.43, NTSC 3.58	0	1	0	0	0	
2 (4)	OP_SOUND_SYSTEM_AP_1	000: BG 001: BG / DK 010: I / DK 011: BG / I / DK 100: BG / I / DK / M	1	1	1	0	0	
1 (2)	OP_SOUND_SYSTEM_AP_2		0	0	0	0	0	
0 (1)	OP_SOUND_SYSTEM_AP_3		0	0	0	0	0	
EUROPE								
3 (8)	OP_DUMMY6	Not used	0	0	0	0	0	
2 (4)	OP_DUMMY7	Not used	0	0	0	0	0	
1 (2)	OP_WEST_EU	West Europe Set (0 - East Europe Set) by default "on"	0	0	0	1	0	
0 (1)	OP_MULTI_STANDARD_EUR	For Europe multi standard set	0	0	0	1	0	
LATAM								
3 (8)	OP_DUMMY6	Not used	0	0	0	0	0	
2 (4)	OP_DUMMY7	Not used	0	0	0	0	0	
1 (2)	OP_SYSTEM_LT_1	00: NTSC-M, 01: NTSC-M, PAL-M, 10: NTSC-M, PAL-M, PAL-N,	0	0	0	0	0	
0 (1)	OP_SYSTEM_LT_2	11: NTSC-M, PAL-M, PAL-N, PAL-BG	0	0	0	0	0	
NAFTA & AP-NTSC								
3 (8)	OP_DUMMY6	Not used	0	0	0	0	0	
2 (4)	OP_DUMMY7	Not used	0	0	0	0	0	
1 (2)	OP_DUMMY8	Not used	0	0	0	0	0	
0 (1)	OP_DUMMY9	Not used	0	0	0	0	0	
OP7:			148	12	132	3	144	

9. Circuit Descriptions, Abbreviation List, and IC Data Sheets

Index of this chapter:

- 9.1 Introduction
- 9.2 Block Diagram
- 9.3 Power Supply (SDI plasma panel)
- 9.4 Input/Output
- 9.5 Tuner and IF
- 9.6 Video: TV Part (diagrams A1, A2, and A3)
- 9.7 Video: Scaler Part (diagram A7 and A13)
- 9.8 Audio Processing
- 9.9 Control
- 9.10 Abbreviation List
- 9.11 IC Data Sheets

Note:

- Only **new** (not recently published) circuits are described here. For the other circuit descriptions, see a.o. the A02, FTL13, and FTL2.1 Service Manuals.
- Figures can deviate slightly from the actual situation, due to different set executions.
- For a good understanding of the following circuit descriptions, please use the wiring, block and circuit diagrams. Where necessary, you will find a separate drawing for clarification.

9.1 Introduction

The LC4.x is a global chassis for the year 2004. Its architecture is based upon the LC03 chassis (LC4.6 is LCD, LC4.7 is PDP). This chassis has the following (new) features:

- **Audio:** The sound processor is part of the UOC processor (called "Hercules").
- **Video:** Enhanced video features, video drivers, Active Control and multiple PIP.

The functions for video/audio processing, microprocessor (uP), and CC/Teletext (TXT) decoder are all combined in one IC (TDA120xx, item 7011), the so-called third generation Ultimate One Chip (UOC-III) or "Hercules". This chip has the following features:

- Control, small signal, mono/stereo, and extensive Audio/Video switching in one IC.
- Upgrade with digital sound & video processing.
- Alignment free IF.
- FM sound, no traps/bandpass filters.
- Full multi-standard colour decoder.
- One Xtal reference for all functions (microprocessor, RCP, TXT/CC, RDS, colour decoder, and stereo sound processor).

9.2 Block Diagram




Figure 9-1 Block Diagram

The PLL tuner delivers the IF-signal, via audio & video SAW-filters, to the Video Signal Processor with FLASH embedded TEXT/Control/Graphics m-Controller (TCG m-Controller) and US Closed Caption decoder. TDA120x1 (item 7011, also called Hercules). This IC has the following functions:

- Analogue Video Processing.
- Sound Demodulation.
- Audio Interfaces and switching.
- Volume and tone control for loudspeakers.
- Reflection and delay for loudspeaker channels.
- Micro Controller.
- Data Capture.
- Display.

The Hercules has one input for the internal CVBS signal and a video switch with 3 external CVBS inputs and a CVBS output. All CVBS inputs can be used as Y-input for Y/C signals. However, only 2 Y/C sources can be selected because the circuit has 2 chroma inputs. It is possible to add an additional CVBS(Y)/C input (CVBS/YX and CX) when the YUV interface and the RGB/YPRPB input are not needed. The I/O is divided over two parts: Rear I/O and Side I/O. The rear has two SCART inputs and a PC (VGA) input. The side has a CVBS and Y/C (SVHS) input. The video part delivers the RGB signals to the Scaler IC.

The Genesis GM1501 Malibu Scaler IC can receive different video input signals: SDTV (from Hercules) or PC (VGA) (from external computer).

After the video processing, the digital data is send via a Low Voltage Differential Signalling bus to the display panel. LVDS is used to improve data speed and to reduce EMI significantly.

There are two I²C lines and two interrupt and communication lines (TV_IRQ and TV_SC_COM) for the Scaler control. The Scaler communicates with the Hercules as a slave device. To avoid buffer overflow at the Scaler side, the TV_SC_COM line provides the necessary hardware flow control. To allow bi-directional communication, the Scaler can initiate a service interrupt-request to the Hercules via the TV_IRQ line.

The Hercules, and EEPROM are supplied with 3.3 V, which is also present during STANDBY.

The EEPROMs, or NVMs (Non Volatile Memory) are used to store the settings.

The sound part is built up around the Hercules. The Source Selection, Decoding and Processing are all done by the Hercules.

Power supply input are several DC voltages coming from a supply panel.

9.3 Power Supply (SDI plasma panel)

See the FTP1.1 manual for a more detailed description.

9.3.1 Start-up sequence




Figure 9-2 Start-up sequence SDI plasma panel

9.4 Input/Output

The I/O is divided over two parts: Rear I/O and Side I/O. The rear has two SCART inputs, a PC (VGA) input, and an Audio input. The side has a CVBS and Y/C (SVHS) input.

EXT1: The input of SCART1 is CVBS + RGB + L/R and the output is the video (+ sound) signal from the tuner (SC1_CVBS_RF_OUT).

EXT2: The input of SCART2 is Y/C + CVBS + L/R. The output signal is CVBS_SC2_MON_OUT (+ sound). SCART2 is meant for VCR and has therefore some additional signals in relation to EXT1 but no RGB: it has the possibility for Y/C_in: Y_in on pin 20 and Chroma_in on pin 15. The selection of the external I/O's is controlled by the Hercules.

PC (VGA) in: This input is directly going to the Scaler IC. See paragraph "Video: Scaler Part".

9.5 Tuner and IF

A Philips UV13xx Tuner is used in the TV board. The SIF signals are decoded by the Hercules. Tuning is done via I²C.

9.5.1 Video IF amplifier

The IF-filter is integrated in a SAW (Surface Acoustic Wave) filter. One for filtering IF-video (1328) and one for IF-audio (1330). The type of these filters is depending of the standard(s) that has to be received.

The output of the tuner is controlled via an IF-amplifier with AGC-control. This is a voltage feedback from pin 31 of the Hercules to pin 1 of the tuner. The AGC-detector operates on top sync and top white level. AGC take-over point is adjusted via the service alignment mode "Tuner" - "AGC". If there is too much noise in the picture, then it could be that the AGC setting is wrong. The AGC-setting could also be mis-aligned if the picture deforms with perfect signal; the IF-amplifier amplifies too much.

9.6 Video: TV Part (diagrams A1, A2, and A3)

The video processing is completely handled by the Hercules

- IF demodulator.
- Chrominance decoder
- Sync separator.
- Horizontal & vertical drive.
- RGB processing.
- CVBS and SVHS source select.

It has also build in features like:

- CTI.
- Black stretch.
- Blue stretch.
- White stretch.
- Slow start up.
- Dynamic skin tone correction etc.

Further, it also incorporates sound IF traps and filters, and requires only one crystal for all systems.

9.6.1 Histogram (YUV picture improvement) IC

The demodulated video-signal can be checked on pins 74, 75, and 76 of IC7011 and is fed to pins 70, 71, and 72. In this path, the Histogram IC TDA9171 is inserted.

This TDA9178 can control various picture improvements:

- Histogram processing.
- Colour transient improvement.
- Luminance transient improvement.
- Black and white stretch.
- Skin tone correction.
- Green enhancement.
- Blue stretch.
- Smart peaking.
- Video dependent coring.
- Colour dependent stretching.

Since the TDA9171 is connected to the Hercules, picture improvement works only for signals that are routed through the Hercules and not for signals directly connected to the Scaler.

9.7 Video: Scaler Part (diagram A7 and A13)

The Genesis GM1501 Scaler is a dual channel graphics and video processing IC for flat monitors and televisions incorporating Picture in Picture, up to SXGA output resolutions. The Scaler controls the display processing in a FTV, e.g. like the deflection circuit in a CRT-based TV. It controls all the view modes (e.g. like "zooming" and "shifting"). Features like PC (VGA) or HD inputs, are also handled by this part.

9.7.1 Features

The Scaler provides several key IC functions:

- Scaling.
- Auto-configuration/ Auto-Detection.
- Various Input Ports:
 - Analog RGB.
 - Video Graphics.
- Integrated LVDS Transmitter.
- On-chip Micro-controller

9.7.2 Inputs

Analog RGB

The RGB input is fed to pins B2, C2 and D2. This input consists of either the Hercules RGB output or the RGB/YpbPr input of the VGA connector. The Scaler can switch between the two signals via the PC_HD_SEL signal and selection IC SM5301.

PC (VGA) input

The VGA input is processed by the VGA block of the Scaler. The Scaler supports pixel frequencies up to 165MHz. YpbPr format is also supported via the VGA interface and covers resolutions of 480p/560p/720p/1080i.

9.7.3 Output

The Display Output Port provides data and control signals that permit the Scaler to connect to a variety of display devices using a TTL or LVDS interface. The output interface is configurable for single or dual wide TTL/LVDS in 18, 24 or 30-bit RGB pixels format. All display data and timing signals are synchronous with the DCLK output clock. The integrated LVDS transmitter is programmable to allow the data and control signals to be mapped into any sequence depending on the specified receiver format.

9.8 Audio Processing




Figure 9-3 Block diagram audio processing

The audio decoding is done entirely via the Hercules. The IF output from the Tuner is fed directly to either the Video-IF or the Sound-IF input depending on the type of concept chosen. There are mainly two types of decoder in the Hercules, an analogue decoder that decodes only Mono, regardless of any standards, and a digital decoder (or DEMDEC) that can decode both Mono and Stereo, again regardless of any standards.

In this chassis, the analogue decoder is used in two cases:

- It is used for AM Sound demodulation in the Europe SECAM LL' transmission.
- It is used for all FM demodulation in AV-Stereo sets.

9.8.1 Diversity

The diversity for the Audio decoding can be broken up into two main concepts:

- The Quasi Split Sound concept used in Europe and some AP sets.
- The Inter Carrier concept, used in NAFTA and LATAM. The UOC-III family makes no difference any more between QSS- and Intercarrier IF, nearly all types are software-switchable between the two SAW-filter constructions.

Simple data settings are required for the set to determine whether it is using the Inter Carrier or the QSS concept. These settings are done via the "QSS" and "FMI" bit found in SAM

mode. Due to the diversity involved, the data for the 2 bits are being placed in the NVM location and it is required to write once during start-up.

On top of that, it can be further broken down into various systems depending on the region. The systems or region chosen, will in turn affect the type of sound standard that is/are allowed to be decoded.

- For Europe, the standard consists of BG/DK/I/LL' for a Multi-System set. There are also versions for Eastern Europe and Western Europe and the standard for decoding will be BG/DK and I/DK respectively.
- For NAFTA and LATAM, there is only one transmission standard, which is the M standard. The diversity then will be based on whether it has a dBx noise reduction or a Non-dBx (no dBx noise reduction).
- For AP, the standard consists of BG/DK/I/M for a Multi-System set. The diversity here will depend on the region. AP China can have a Multi-System and I/DK version. For India, it might only be BG standard.

9.8.2 Functionality

The features available in the Hercules are as follows:

- Treble and Bass Control.
- Surround Sound Effect that includes:
 - Incredible Stereo.
 - Incredible Mono.
 - 3D Sound (not for AV Stereo).
 - TruSurround (not for AV Stereo).
 - Virtual Dolby Surround, VDS422 (not for AV Stereo).
 - Virtual Dolby Surround, VDS423 (not for AV Stereo).
 - Dolby Pro-Logic (not for AV Stereo).
- Bass Feature that includes:
 - Dynamic Ultra-Bass.
 - Dynamic Bass Enhancement.
 - BBE (not for AV Stereo).
- Auto-Volume Leveller.
- 5 Band Equalizer.
- Loudness Control.

All the features stated are available for the Full Stereo versions and limited features for the AV Stereo

9.8.3 Audio Amplifier Panel (diagram C)

Introduction

This panel contains the audio filters and amplifiers necessary for driving the speakers.

The audio inputs come from the SSB (via connector 1739).

The PSU delivers the positive and negative supply voltage of 16 V_{DC}.

After being filtered and amplified, the signals go to the speaker section, where the full range speakers are driven (load impedance is 8 ohm).

Amplifier

The amplifier is an integrated class-D amplifier (TDA7490). It combines a good performance with a high efficiency, resulting in a big reduction in heat generation.

Principle

Audio-power-amplifier systems have traditionally used linear amplifiers, which are well known for being inefficient. In fact, a linear Class AB amplifier is designed to act as a variable resistor network between the power supply and the load. The transistors operate in their linear region, and the voltage that is dropped across the transistors (in their role as variable resistors) is lost as heat, particularly in the output transistors. Class D amplifiers were developed as a way to increase the efficiency of audio-power-amplifier systems.

The Class D amplifier works by varying the duty cycle of a Pulse Width Modulated (PWM) signal.

By comparing the input voltage to a triangle wave, the amplifier increases duty cycle to increase output voltage, and decreases duty cycle to decrease output voltage.

The output transistors of a Class D amplifier switch from 'full off' to 'full on' (saturated) and then back again, spending very little time in the linear region in between. Therefore, very little power is lost to heat. If the transistors have a low 'on' resistance (R_{DS(ON)}), little voltage is dropped across them, further reducing losses.

A Low Pass Filter at the output passes only the average of the output wave, which is an amplified version of the input signal. In order to keep the distortion low, negative feedback is applied (via R3723/3708).

The advantage of Class D is increased efficiency (= less heat dissipation). Class D amplifiers can drive the same output power as a Class AB amplifier using less supply current. The disadvantage is the large output filter that drives up cost and size. The main reason for this filter is that the switching waveform results in maximum current flow. This causes more loss in the load, which causes lower efficiency. An LC filter with a cut-off frequency less than the Class D switching frequency, allows the switching current to flow through the filter instead of the load. The filter is less lossy than the speaker, which causes less power dissipated at high output power and increases efficiency in most cases.

Mute

A mute switch (item 7701) is provided at pin 6. This switch is controlled by the SOUND_ENABLE line from the Hercules (mute during operation).

Protections

Because of the symmetrical supply, a DC-blocking capacitor, between the amplifier and the speaker, is not necessary. However, it is still necessary to protect the speaker for DC voltages. Therefore, the following protections are therefore implemented:

- Via R3765 and R3767, each stabilised supply voltage line is checked on deviations.
- Via R3718 and 3717, each amplifier output is checked for DC-voltage.

9.9 Control

9.9.1 Hercules

The System Board has two main micro-controllers on board. These are:

- On-chip x86 micro-controller (OCM) from Genesis LCD TV/Monitor Controller.
- On-chip 80C51 micro-controller from Philips Semiconductors UOCIII (Hercules) series.

Each micro-controller has its own I2C bus which hosts its own internal devices.

The Hercules is integrated with the Video and Audio Processor. For dynamic data storage, such as SMART PICTURE and SMART SOUND settings, an external NVM IC is being used. Another feature includes an optional Teletext/Closed Caption decoder with the possibility of different page storage depending on the Hercules type number.

The Micro Controller ranges in ROM from 128 kB with no TXT-decoder to 128 kB with a 10 page Teletext or with Closed Caption.

9.9.2 Block Diagram

The block diagram of the Micro Controller application is shown below.




Figure 9-4 Micro Controller block diagram

9.9.3 Basic Specification

The Micro Controller operates at the following supply voltages:

- +3.3 V_{DC} at pins 4, 88, 94, and 109.
- +1.8 V_{DC} at pins 93, 96, and 117.
- I²C pull up supply: +3.3 V_{DC}.

9.9.4 Pin Configuration and Functionality

The ports of the Micro Controller can be configured as follows:

- A normal input port.
- An input ADC port.
- An output Open Drain port.
- An output Push-Pull port.
- An output PWM port.
- Input/Output Port

The following table shows the ports used for the L04 control:

Table 9-1 Micro Controller ports overview

Pin	Name	Description	Configuration
97	INT0/ P0.5	IR	INT0
98	P1.0/ INT1	TV_IRQ	INT2
99	P1.1/ T0	TV_SC_COM	P1.1
102	P0.4/ I2SWS	EXT_MUTE	P0.4
103	P0.3/ I2SCLK	Lip Sync	I2SCLK
104	P0.2/ I2SDO2	NVM_WP	P0.2
105	P0.1/ I2SDO1	Lip Sync	I2SDO1
106	P0.0/ I2SDI/O	Lip Sync	I2SDI/O
107	P1.3/ T1	PC-TV_LED	P1.3
108	P1.6/ SCL	SCL	SCL
109	P1.7/ SDA	SDA	SDA
111	P2.0/ TPWM	SOUND_ENABLE	P2.0
112	P2.1/ PWM0	(for future use)	-
113	P2.2/ PWM1	(for future use)	-
114	P2.3/ PWM2	SEL_IF	P2.3
115	P3.0/ ADC0	Light Sensor - SDM	ADC0
116	P3.1/ ADC1	STATUS_1	ADC1
119	P3.2/ ADC2	STATUS_2	ADC2
120	P3.3/ ADC3	KEYBOARD	ADC3
122	P2.4/ PWM3	STANDBY	P2.4
123	P2.5/ PWM4	(for future use)	-
126	P1.2/ INT2	(for future use)	-
127	P1.4/ RX	HERC_RESET	-
128	P1.5/ TX	POWER_DOWN	P1.5

The description of each functional pin is explained below:

- LED.** This signal is used to drive the LED for Stand-by, Remote, and Error Indication:
 - During protection mode, the LED blinks and the set is in Stand-by mode.
 - During error conditions it blinks at a predefined rate.
 - After receiving a valid RC or local keyboard command it flashes once.
 - For sets with error message indication, the LED blinks when message is active and the set is in Stand-by mode.
- SCL.** This is the clock wire of the two-wire single master bi-directional I²C bus.
- SDA.** This is the data wire of the two-wire single master bi-directional I²C bus.
- STANDBY.** The Hercules generates this signal. This can enable the power supply in normal operation and disable it during Stand-by. It is of logic "high" (3.3 V) under normal operation and "low" (0 V) during Stand-by.
- IR.** This input pin is connected to an RC5 remote control receiver.
- SEL-IF.** This is an output pin to switch the Video SAW filter between M system and other systems.
 - 0: NTSC M (default).
 - 1: PAL B/G, DK, I, L.
- NVM_WP.** The global protection line is used to enable and disable write protection to the NVM. When write to the NVM is required, pin 7 of the NVM must be pulled to logic "0" first (via Write_Protect of the micro-controller pin) before a write is performed. Otherwise pin 7 of NVM must always be at logic "1"
 - 0: Disabled.
 - 1: Enabled (default).
- SOUND_ENABLE.** This pin is use to MUTE the audio amplifier. It is configured as push pull.
- STATUS_1.** This signal is used to read the status of the SCART 1 input (EU only).
- STATUS_2.** This signal is used to read the status of the SCART 2 input (EU only).
- HERC_RESET.** This pin is use to switch the +1.8 V supply.
- POWER_DOWN.** The power supply generates this signal. Logic "high" (3.3 V) under normal operation of the TV and goes "low" (0 V) when the Mains input voltage supply goes below 70 V_{AC}.
- KEYBOARD.** Following are the Keyboard functions and the step values (8 bit) for it.

Table 9-2 Local keyboard values

Function	Voltage (V _{DC})	Step values (8 bit)
P+ / Ch+	0.43	7 - 33
P- / Ch-	0.93	54 - 73
Menu (Vol - and Vol +)	1.19	74 - 96
Vol -	1.49	97 - 121
Vol +	2.12	148 - 169

- TV_IRQ.** This signal is the interrupt from the Scaler IC.
- TV_SC_COM.** This signal is used for the communication with the Scaler IC.
- EXT_MUTE.** This signal is used to reduce the switch "off" pop.

9.10 Abbreviation List


1080i	1080 visible lines, interlaced	FLASH	FLASH memory
1080p	1080 visible lines, progressive scan	FM	Field Memory / Frequency Modulation
2CS	2 Carrier Sound	FMR	FM Radio
2DNR	Spatial (2D) Noise Reduction	FRC	Frame Rate Converter
3DNR	Temporal (3D) Noise Reduction	FRONT-C	Front input chrominance (SVHS)
480i	480 visible lines, interlaced	FRONT-DETECT	Front input detection
480p	480 visible lines, progressive scan	FRONT-Y_CVBS	Front input luminance or CVBS (SVHS)
AARA	Automatic Aspect Ratio Adaptation: algorithm that adapts aspect ratio to remove horizontal black bars; keeping up the original aspect ratio	FTV	Flat TeleVison
ACI	Automatic Channel Installation: algorithm that installs TV channels directly from a cable network by means of a predefined TXT page	G-SC1-IN	Green SCART1 in
ADC	Analogue to Digital Converter	G-SC2-IN	Green SCART2 in
AFC	Automatic Frequency Control: control signal used to tune to the correct frequency	G-TXT	Green teletext
AGC	Automatic Gain Control: algorithm that controls the video input of the feature box	H	H_sync to the module
AM	Amplitude Modulation	HD	High Definition
AP	Asia Pacific	HDMI	High Definition Multimedia Interface, digital audio and video interface
AR	Aspect Ratio: 4 by 3 or 16 by 9	HP	HeadPhone
ASD	Automatic Standard Detection	I	Monochrome TV system. Sound carrier distance is 6.0 MHz
AV	Audio Video	I ² C	Integrated IC bus
B-SC1-IN	Blue SCART1 in	I ² S	Integrated IC Sound bus
B-SC2-IN	Blue SCART2 in	IC	Integrated Circuit
B-TXT	Blue teletext	IF	Intermediate Frequency
B/G	Monochrome TV system. Sound carrier distance is 5.5 MHz	Interlaced	Scan mode where two fields are used to form one frame. Each field contains half the number of the total amount of lines. The fields are written in "pairs", causing line flicker.
BTSC	Broadcast Television System Committee	IR	Infra Red
C-FRONT	Chrominance front input	IRQ	Interrupt ReQuest
CBA	Circuit Board Assembly (or PWB)	Last Status	The settings last chosen by the customer and read and stored in RAM or in the NVM. They are called at start-up of the set to configure it according the customers wishes
CL	Constant Level: audio output to connect with an external amplifier	LATAM	LATin AMERICA
CLUT	Colour Look Up Table	LC04	Philips chassis name for LCD TV 2004 project
ComPair	Computer aided rePair	LCD	Liquid Crystal Display
CSM	Customer Service Mode	LED	Light Emitting Diode
CVBS	Composite Video Blanking and Synchronisation	L/L'	Monochrome TV system. Sound carrier distance is 6.5 MHz. L' is Band I, L is all bands except for Band I
CVBS-EXT	CVBS signal from external source (VCR, VCD, etc.)	LS	LoudSpeaker
CVBS-INT	CVBS signal from Tuner	LVDS	Low Voltage Differential Signalling, data transmission system for high speed and low EMI communication.
CVBS-MON	CVBS monitor signal	M/N	Monochrome TV system. Sound carrier distance is 4.5 MHz
CVBS-TER-OUT	CVBS terrestrial out	MOSFET	Metal Oxide Semiconductor Field Effect Transistor
DAC	Digital to Analogue Converter	MPEG	Motion Pictures Experts Group
DBE	Dynamic Bass Enhancement: extra low frequency amplification	MSP	Multi-standard Sound Processor: ITT sound decoder
DFU	Directions For Use: owner's manual	MUTE	MUTE Line
DNR	Dynamic Noise Reduction	NAFTA	North American Free Trade Association: Trade agreement between Canada, USA and Mexico
DRAM	Dynamic RAM	NC	Not Connected
DSP	Digital Signal Processing	NICAM	Near Instantaneous Compounded Audio Multiplexing. This is a digital sound system, used mainly in Europe.
DST	Dealer Service Tool: special (European) remote control designed for service technicians	NTSC	National Television Standard Committee. Colour system used mainly in North America and Japan. Colour carrier NTSC M/N = 3.579545 MHz, NTSC 4.43 = 4.433619 MHz (this is a VCR norm, it is not transmitted off-air)
DTS	Digital Theatre Sound	NVM	Non Volatile Memory: IC containing TV related data (for example, options)
DVD	Digital Versatile Disc	O/C	Open Circuit
DVI	Digital Visual Interface	ON/OFF LED	On/Off control signal for the LED
DW	Double Window	OSD	On Screen Display
EEPROM	Electrically Erasable and Programmable Read Only Memory		
EU	EUrope		
EXT	EXTERNAL (source), entering the set by SCART or by cinches (jacks)		
FBL	Fast Blanking: DC signal accompanying RGB signals		
FBL-SC1-IN	Fast blanking signal for SCART1 in		
FBL-SC2-IN	Fast blanking signal for SCART2 in		
FBL-TXT	Fast Blanking Teletext		

PAL	Phase Alternating Line. Colour system used mainly in Western Europe (colour carrier = 4.433619 MHz) and South America (colour carrier PAL M = 3.575612 MHz and PAL N = 3.582056 MHz)	WD WYSIWYR	Watch Dog What You See Is What You Record: record selection that follows main picture and sound
PC	Personal Computer	XTAL YPbPr	Quartz crystal Component video (Y= Luminance, Pb/Pr= Colour difference signals B-Y and R-Y, other amplitudes w.r.t. to YUV)
PCB	Printed Circuit Board (or PWB)		
PDP	Plasma Display Panel	Y/C	Video related signals: Y consists of luminance signal, blanking level and sync; C consists of colour signal.
PIG	Picture In Graphic		
PIP	Picture In Picture		
PLL	Phase Locked Loop. Used, for example, in FST tuning systems. The customer can directly provide the desired frequency	Y-OUT YUV	Luminance-signal Baseband component video (Y= Luminance, U/V= Colour difference signals)
Progressive Scan	Scan mode where all scan lines are displayed in one frame at the same time, creating a double vertical resolution.		
PWB	Printed Wiring Board (or PCB)		
RAM	Random Access Memory		
RC	Remote Control transmitter		
RC5 (6)	Remote Control system 5 (6), the signal from the remote control receiver		
RGB	Red, Green, and Blue. The primary colour signals for TV. By mixing levels of R, G, and B, all colours (Y/C) are reproduced.		
RGBHV	Red, Green, Blue, Horizontal sync, and Vertical sync		
ROM	Read Only Memory		
SAM	Service Alignment Mode		
SIF	Sound Intermediate Frequency		
SC	SandCastle: two-level pulse derived from sync signals		
SC1-OUT	SCART output of the MSP audio IC		
SC2-B-IN	SCART2 Blue in		
SC2-C-IN	SCART2 chrominance in		
SC2-OUT	SCART output of the MSP audio IC		
S/C	Short Circuit		
SCL	Clock signal on I ² C bus		
SD	Standard Definition		
SDA	Data signal on I ² C bus		
SDM	Service Default Mode		
SDRAM	Synchronous DRAM		
SECAM	SEquence Couleur Avec Memoire. Colour system used mainly in France and Eastern Europe. Colour carriers = 4.406250 MHz and 4.250000 MHz		
SIF	Sound Intermediate Frequency		
SMPS	Switch Mode Power Supply		
SND	SouND		
SNDL-SC1-IN	Sound left SCART1 in		
SNDL-SC1-OUT	Sound left SCART1 out		
SNDL-SC2-IN	Sound left SCART2 in		
SNDL-SC2-OUT	Sound left SCART2 out		
SNDR-SC1-IN	Sound right SCART1 in		
SNDR-SC1-OUT	Sound right SCART1 out		
SNDR-SC2-IN	Sound right SCART2 in		
SNDR-SC2-OUT	Sound right SCART2 out		
SNDS-VL-OUT	Surround sound left variable level out		
SNDS-VR-OUT	Surround sound right variable level out		
SOPS	Self Oscillating Power Supply		
S/PDIF	Sony Philips Digital InterFace		
SRAM	Static RAM		
STBY	Stand-by		
SVHS	Super Video Home System		
SW	SubWoofer / SoftWare		
THD	Total Harmonic Distortion		
TXT	TeleteXT		
uP	Microprocessor		
VL	Variable Level out: processed audio output toward external amplifier		
VCR	Video Cassette Recorder		
VGA	Video Graphics Array		


9.11 IC Data Sheets

This section shows the internal block diagrams and pin layouts of ICs that are drawn as "black boxes" in the electrical diagrams (with the exception of "memory" and "logic" ICs).

9.11.1 Diagram A2, Type TDA12029H (IC7011)



Pin configuration "stereo" and "AV-stereo" versions with Audio DSP




E_14490_063.epa 160804

Figure 9-5 Internal Block Diagram and Pin Configuration

9.11.2 Diagram A7, Type GM1501 (IC7401)

Block Diagram



Pin Configuration


A	NC	ADC_3.3	ADC_1.8	ADC_1.8	ADC_DGND	RXC+	DVI_GND	RX0+	RX1+	RX2+	DVI_GND	LBADC_N3	D_GND
B	BLUE-	BLUE+	ADC_3.3	ADC_DGND	DVI_GND	RXC-	DVI_GND	RX0-	RX1-	RX2-	REXT	LBADC_N2	D_GND
C	GREEN-	GREEN+	SOG	ADC_AGND	NC	DVI_3.3	DVI_GND	DVI_3.3	DVI_3.3	DVI_3.3	DVI_3.3	LBADC_N1	LBADC_33
D	RED-	RED+	ADC_3.3	ADC_AGND	NC	DVI_1.8	DVI_GND	DVI_1.8	DVI_1.8	DVI_1.8	DVI_GND	LBADC_RETURN	LBADC_PINK
E	ADC_AGND	ADC_AGND	ADC_3.3	ADC_AGND									
F	NC	VDD33_PLL	VSSA33_RPLL	VDDA33_RPLL									
G	VDDA33_FPLL	VSSD33_PLL	TCLK	XTAL									
H	VDD33_SDDS	VSSA33_SDDS	VDDA33_SDDS	VSSA33_FPLL									
J	VDD33_DDSD	VSSA33_DDSD	VDDA33_DDSD	VSSD33_SDDS									
K	RESETn	ACS_RSET_HD	NC	VSSD33_DDSD						CORE_1.8	CORE_1.8	D_GND	D_GND
L	OCM_INT2	OCM_INT1	AVSYNC	AHSYNC						D_GND	CORE_1.8	D_GND	D_GND
M	OCM_UDO	OCM_UDI	IR0	IR1						D_GND	D_GND	D_GND	D_GND
N	VGA_SDA	VGA_SCL	DVI_SDA	DVI_SCL						D_GND	D_GND	D_GND	D_GND
P	OCM_CS1n	OCM_CS2n	MSTR_SDA	MSTR_SCL						D_GND	D_GND	D_GND	D_GND
R	ROM_CSn	OCM_REn	OCM_WEn	EXTCLK						D_GND	D_GND	D_GND	D_GND
T	OCMADDR_17	OCMADDR_18	OCMADDR_19	OCM_CS0n						D_GND	CORE_1.8	D_GND	D_GND
U	OCMADDR_13	OCMADDR_14	OCMADDR_15	OCMADDR_16						CORE_1.8	CORE_1.8	D_GND	D_GND
V	OCMADDR_9	OCMADDR_10	OCMADDR_11	OCMADDR_12									
W	OCMADDR_6	OCMADDR_7	OCMADDR_8	IO_3.3									
Y	OCMADDR_3	OCMADDR_4	OCMADDR_5	IO_3.3									
AA	OCMADDR_0	OCMADDR_1	OCMADDR_2	IO_3.3									
AB	OCMDATA13	OCMDATA14	OCMDATA15	IO_3.3									
AC	OCMDATA10	OCMDATA11	OCMDATA12	IO_3.3	GPIO_G09_B2 (DEGRN0)	IO_3.3	DCLK	IO_3.3	GPIO_G07_B2 (DERED4)	IO_3.3	SHIELD[1] (DEGRN3)	LVDSB_3.3	LVDSB_GND
AD	OCMDATA9	OCMDATA6	OCMDATA3	OCMDATA0	GPIO_G09_B3 (DEGRN1)	GPIO_G08_B0 (DORED0)	DEN	GPIO_G08_B5 (DOBLU1)	GPIO_G07_B3 (DERED5)	GPIO_G07_B6 (DERED8)	SHIELD[2] (DEGRN4)	LVDSB_3.3	LVDSB_3.3
AE	OCMDATA8	OCMDATA5	OCMDATA2	OCMDATA1	GPIO_G09_B0 (DEBLU0)	GPIO_G08_B4 (DORED1)	GPIO_G08_B3 (DOGRN1)	GPIO_G07_B0 (DERED2)	GPIO_G07_B4 (DERED6)	GPIO_G07_B7 (DERED9)	SHIELD[3] (DEGRN5)	BC+ (DEGRN8)	SHIELD[4] (DEBLU2)
AF	OCMDATA7	OCMDATA4	OCMDATA1	OCMDATA0	GPIO_G09_B1 (DERED1)	GPIO_G08_B5 (DOGRN0)	GPIO_G08_B4 (DOBLU0)	GPIO_G07_B1 (DERED3)	GPIO_G07_B5 (DERED7)	SHIELD[0] (DEGRN2)	B3+ (DEGRN6)	B3- (DEGRN7)	BC- (DEGRN9)
	1	2	3	4	5	6	7	8	9	10	11	12	13

E_14490_099.eps
060804

Figure 9-6 Internal Block Diagram and Pin Configuration

9.11.3 Diagram A12, Type SiI9993CT (IC7808)

BLOCK DIAGRAM



PIN CONFIGURATION




Figure 9-7 Internal Block Diagram and Pin Configuration

10. Spare Parts List

Set Level

Various

1104▲	8204 000 77241	PDP S42SD-YDO5
1104▲	8204 000 77261	PDP S37SD-YDO2
8303	3104 311 06691	Cable 10P/340/10P
8303	3104 311 08821	Cable 10P/400/10P
8330	3104 311 06091	Cable 10p/680/10p
8344	3104 311 07211	Cable 3P/560/3P
8346	3104 311 07001	Cable 11P/400/11P
8350	3104 311 08841	Cable 31P/220/31P
8352	3104 311 07381	Cable 9P/220/9P

Small Signal Board [A]

Various

0601	3104 317 07891	Softw. (check Prod.Surv.)
1001	2422 543 01414	Crystal 24M576
1026	3104 328 33151	Side I/O assy
1062	2422 549 00149	Socket 3P m
1101	2422 025 18133	Socket SCART
1102	2422 025 18133	Socket SCART
1105	2422 026 05462	Socket CHINCH 4p f
1301	2422 025 16835	Connector 3p m
1302▲	3139 147 19801	Tuner UV1318S/A IH -3
1328	2422 549 44372	SAW 38.9MHz K3953L
1330	2422 549 44369	SAW 38.9MHz K9656L
1401	2422 543 01133	Xtal 14.32MHz 20pF
1402	2422 025 10768	Connector 3p m
1450	2422 025 18427	Connector 31p f
1681	2422 025 16835	Connector 3p m
1687	2438 031 00416	Connector 15p f
1752	2422 025 10769	Connector 9p m
1860	2422 549 45325	Bead 67Ω at 100MHz
1861	2422 549 45325	Bead 67Ω at 100MHz
1862	2422 549 45325	Bead 67Ω at 100MHz
1863	2422 549 45325	Bead 67Ω at 100MHz
1864	2422 549 45325	Bead 67Ω at 100MHz
8321	3122 358 76331	Tree assy M91-CP91
8336	3104 311 07111	Cable 11P/340/11P

—||—

2000	2022 552 05682	2.2μF 10% 6.3V
2001	2020 552 96718	220nF 10% 6.3V 0402
2002	4822 124 23002	10μF 16V
2003	2238 869 15109	10pF 5% 50V 0402
2004	2020 552 96718	220nF 10% 6.3V 0402
2005	3198 035 71040	100nF 10% 16V 0402
2006	3198 034 06880	6.8pF 1% 50V 0402
2007	3198 034 06880	6.8pF 1% 50V 0402
2008	3198 017 44740	470nF 10V 0603
2009	3198 017 41050	1μF 10V 0603
2010	3198 035 26820	6.8nF 10% 16V 0402
2011	2020 552 96718	220nF 10% 6.3V 0402
2012	4822 124 12095	100μF 20% 16V
2013	3198 035 71040	100nF 10% 16V 0402
2014	3198 035 71040	100nF 10% 16V 0402
2015	3198 035 71040	100nF 10% 16V 0402
2016	3198 035 71040	100nF 10% 16V 0402
2017	3198 035 71040	100nF 10% 16V 0402
2018	3198 035 71040	100nF 10% 16V 0402
2019	4822 124 80151	47μF 16V
2020	2238 869 15101	100pF 5% 50V 0402
2021	2020 552 96628	10nF 10% 16V 0402
2022	3198 035 02210	220pF 5% 50V 0402
2023	3198 035 71040	100nF 10% 16V 0402
2024	4822 124 12095	100μF 20% 16V
2025	3198 035 71040	100nF 10% 16V 0402
2026	3198 035 71040	100nF 10% 16V 0402
2027	3198 035 71040	100nF 10% 16V 0402
2028	2020 552 96628	10nF 10% 16V 0402
2029	3198 035 71040	100nF 10% 16V 0402
2030	3198 035 71040	100nF 10% 16V 0402
2031	3198 035 71040	100nF 10% 16V 0402
2032	3198 035 71040	100nF 10% 16V 0402
2033	2020 552 96718	220nF 10% 6.3V 0402
2034	2020 552 00002	3.3nF 2% 50V 0805
2035	2020 552 96656	10μF 20% 25V 1210
2036	2020 552 96807	1μF 10% 10V 0603
2037	2020 552 96807	1μF 10% 10V 0603
2040	4822 124 23002	10μF 16V
2041	2020 552 96718	220nF 10% 6.3V 0402
2042	2020 552 00002	3.3nF 2% 50V 0805

2043	3198 035 71040	100nF 10% 16V 0402
2044	2020 552 96718	220nF 10% 6.3V 0402
2045	2238 869 15109	10pF 5% 50V 0402
2046	2238 869 15109	10pF 5% 50V 0402
2047	2020 552 96628	10nF 10% 16V 0402
2048	2238 869 15109	10pF 5% 50V 0402
2049	2238 869 15109	10pF 5% 50V 0402
2050	2238 869 15109	10pF 5% 50V 0402
2051	2020 552 00002	3.3nF 2% 50V 0805
2053	2020 552 96618	1nF 10% 50V 0402
2054	2020 552 96632	22nF 10% 16V 0402
2055	4822 126 14519	22pF 5% 50V 0402
2056	3198 035 71040	100nF 10% 16V 0402
2057	2238 869 15109	10pF 5% 50V 0402
2058	2238 869 15109	10pF 5% 50V 0402
2059	2238 869 15109	10pF 5% 50V 0402
2060	3198 035 71040	100nF 10% 16V 0402
2061	4822 124 23002	10μF 16V
2062	2238 869 15109	10pF 5% 50V 0402
2063	3198 017 31540	150nF 10V 0603
2064	3198 017 41050	1μF 10V 0603
2067	2238 869 15109	10pF 5% 50V 0402
2068	2020 552 96718	220nF 10% 6.3V 0402
2069	2238 869 15109	10pF 5% 50V 0402
2070	2020 552 96834	1μF 20% 6.3V 0402
2071	4822 124 12095	100μF 20% 16V
2072	4822 126 14076	220nF +80/-20% 25V
2073	2020 552 96618	1nF 10% 50V 0402
2074	2020 552 96718	220nF 10% 6.3V 0402
2076	2020 552 96718	220nF 10% 6.3V 0402
2077	2020 552 96834	1μF 20% 6.3V 0402
2078	2238 869 15101	100pF 5% 50V 0402
2079	2238 869 15109	10pF 5% 50V 0402
2080	2238 869 15109	10pF 5% 50V 0402
2081	2238 869 15109	10pF 5% 50V 0402
2082	2020 552 96618	1nF 10% 50V 0402
2084	2020 552 96718	220nF 10% 6.3V 0402
2085	2020 552 96618	1nF 10% 50V 0402
2086	2020 552 96618	1nF 10% 50V 0402
2087	2238 869 15109	10pF 5% 50V 0402
2088	2238 869 15109	10pF 5% 50V 0402
2089	2020 552 96618	1nF 10% 50V 0402
2090	2238 869 15109	10pF 5% 50V 0402
2091	2238 869 15109	10pF 5% 50V 0402
2092	2238 869 15109	10pF 5% 50V 0402
2093	2238 869 15109	10pF 5% 50V 0402
2094	2238 869 15109	10pF 5% 50V 0402
2095	2238 869 15109	10pF 5% 50V 0402
2096	2238 869 15109	10pF 5% 50V 0402
2097	2238 869 15109	10pF 5% 50V 0402
2098	2238 869 15109	10pF 5% 50V 0402
2099	2020 552 96618	1nF 10% 50V 0402
2101	4822 126 14241	330pF 0603 50V
2103	4822 126 14241	330pF 0603 50V
2104	2020 552 96807	1μF 10% 10V 0603
2105	4822 126 14241	330pF 0603 50V
2107	4822 126 14241	330pF 0603 50V
2108	2020 552 96807	1μF 10% 10V 0603
2109	4822 126 13881	470pF 5% 50V
2110	4822 126 13881	470pF 5% 50V
2111	4822 126 13881	470pF 5% 50V
2112	4822 126 13881	470pF 5% 50V
2127	4822 126 14241	330pF 0603 50V
2128	2020 552 96807	1μF 10% 10V 0603
2129	4822 126 14241	330pF 0603 50V
2131	4822 126 14241	330pF 0603 50V
2132	2020 552 96807	1μF 10% 10V 0603
2133	4822 126 14241	330pF 0603 50V
2134	4822 126 13881	470pF 5% 50V
2135	4822 126 13881	470pF 5% 50V
2136	4822 126 13881	470pF 5% 50V
2137	4822 126 13881	470pF 5% 50V
2138	3198 017 41050	1μF 10V 0603
2152	4822 126 14241	330pF 0603 50V
2155	4822 126 14241	330pF 0603 50V
2169	4822 124 23002	10μF 16V
2251	2238 869 15109	10pF 5% 50V 0402
2252	2238 869 15109	10pF 5% 50V 0402
2253	4822 124 23002	10μF 16V
2254	4822 124 23002	10μF 16V
2255	2238 869 15109	10pF 5% 50V 0402
2262	4822 124 80151	47μF 16V
2263	2020 552 96656	10μF 20% 25V 1210
2264	2020 552 96656	10μF 20% 25V 1210
2265	3198 035 02210	220pF 5% 50V 0402
2266	2020 552 96632	22nF 10% 16V 0402
2268	2020 012 93795	470μF 20% 16V
2269	2020 012 93795	470μF 20% 16V
2271	2020 552 96628	10nF 10% 16V 0402
2302	4822 122 33761	22pF 5% 50V
2303	4822 122 33761	22pF 5% 50V
2307	3198 024 44730	47nF 50V 0603
2308	3198 030 82280	2.2μF 20% 50V
2309	2020 021 91871	470μF 20% 16V
2311	4822 124 12095	100μF 20% 16V
2321	5322 126 11583	10nF 10% 50V 0603
2324	5322 126 11583	10nF 10% 50V 0603
2355	3198 030 82280	2.2μF 20% 50V
2356	3198 030 82280	2.2μF 20% 50V
2357	3198 035 71040	100nF 10% 16V 0402
2358	2020 552 96625	3.3nF 10% 50V 0402
2359	2020 552 96628	10nF 10% 16V 0402
2370	2020 552 96834	1μF 20% 6.3V 0402
2371	2020 552 96834	1μF 20% 6.3V 0402
2372	2020 552 96618	1nF 10% 50V 0402
2373	2020 552 96618	1nF 10% 50V 0402
2374	3198 035 71040	100nF 10% 16V 0402
2375	4822 124 12082	10μF 20% 50V
2376	3198 017 41050	1μF 10V 0603
2377	3198 017 41050	1μF 10V 0603
2378	2020 552 96718	220nF 10% 6.3V 0402
2380	4822 124 12095	100μF 20% 16V
2381	3198 035 71040	100nF 10% 16V 0402
2382	2020 021 91871	470μF 20% 16V
2386	3198 017 41050	1μF 10V 0603
2387	4822 126 14324	33pF 5% 50V 0402
2388	4822 126 14324	33pF 5% 50V 0402
2392	3198 017 41050	1μF 10V 0603
2394	3198 035 71040	100nF 10% 16V 0402
2395	3198 035 71040	100nF 10% 16V 0402
2396	4822 124 23002	10μF 16V
2397	2020 552 96834	1μF 20% 6.3V 0402
2398	2020 552 96834	1μF 20% 6.3V 0402
2401	4822 124 80151	47μF 16V
2402	4822 124 80151	47μF 16V
2403	3198 035 71040	100nF 10% 16V 0402
2404	3198 035 71040	100nF 10% 16V 0402
2405	3198 035 71040	100nF 10% 16V 0402
2406	3198 035 71040	100nF 10% 16V 0402
2407	3198 035 71040	100nF 10% 16V 0402
2408	3198 035 71040	100nF 10% 16V 0402
2409	3198 035 71040	100nF 10% 16V 0402
2410	3198 035 71	

2456	3198 035 71040	100nF 10% 16V 0402	2632	2020 552 96834	1µF 20% 6.3V 0402	3022	4822 117 13606	10kΩ 5% 0.01W 0402
2461	3198 035 71040	100nF 10% 16V 0402	2633	2020 552 96834	1µF 20% 6.3V 0402	3023	4822 117 13601	22kΩ 5% 0402
2462	3198 035 71040	100nF 10% 16V 0402	2634	2020 552 96834	1µF 20% 6.3V 0402	3024	3198 031 01090	10Ω 5% 0.01W 0402
2463	3198 035 71040	100nF 10% 16V 0402	2635	2020 552 96834	1µF 20% 6.3V 0402	3025	3198 031 01090	10Ω 5% 0.01W 0402
2464	3198 035 71040	100nF 10% 16V 0402	2636	3198 035 71040	100nF 10% 16V 0402	3026	3198 031 06890	68Ω 5% 0402
2465	5322 124 41945	22µF 20% 35V	2681	2020 552 94427	100pF 5% 50V	3027	3198 031 01090	10Ω 5% 0.01W 0402
2466	3198 035 71040	100nF 10% 16V 0402	2686	2020 552 94427	100pF 5% 50V	3028	4822 117 11297	100kΩ 5% 0.1W
2467	3198 035 71040	100nF 10% 16V 0402	2688	2238 586 59812	100nF 20% 50V 0603	3029	4822 117 13548	1kΩ 5% 0402
2468	3198 035 71040	100nF 10% 16V 0402	2693	2238 586 59812	100nF 20% 50V 0603	3030	4822 117 11297	100kΩ 5% 0.1W
2469	3198 035 71040	100nF 10% 16V 0402	2698	2020 552 94427	100pF 5% 50V	3032	3198 031 02240	220kΩ 5% 0.1W 0402
2470	5322 124 41945	22µF 20% 35V	2699	2020 552 94427	100pF 5% 50V	3035	4822 117 13545	100Ω 1% 0402
2471	3198 035 71040	100nF 10% 16V 0402	2702	2020 552 96834	1µF 20% 6.3V 0402	3037	3198 031 04730	47Ω 5% 0402
2472	3198 035 71040	100nF 10% 16V 0402	2707	2020 021 91871	470µF 20% 16V	3038	3198 031 04730	47Ω 5% 0402
2473	3198 035 71040	100nF 10% 16V 0402	2708	2020 552 96834	1µF 20% 6.3V 0402	3040	3198 031 06830	68kΩ 5% 0.01W 0402
2474	3198 035 71040	100nF 10% 16V 0402	2710	3198 035 04710	470pF 50V 0402	3048	4822 117 13606	10kΩ 5% 0.01W 0402
2475	3198 035 71040	100nF 10% 16V 0402	2711	3198 035 04710	470pF 50V 0402	3049	4822 117 13545	100Ω 1% 0402
2476	3198 035 71040	100nF 10% 16V 0402	2713	2238 586 59812	100nF 20% 50V 0603	3050	4822 117 13545	100Ω 1% 0402
2477	3198 035 71040	100nF 10% 16V 0402	2714	2020 021 91871	470µF 20% 16V	3051	4822 117 13545	100Ω 1% 0402
2478	5322 124 41945	22µF 20% 35V	2715	2020 021 91871	470µF 20% 16V	3052	4822 117 13605	Jumper 0402
2479	3198 035 71040	100nF 10% 16V 0402	2719	2238 586 59812	100nF 20% 50V 0603	3056	3198 031 04720	4.7kΩ 5% 0402
2480	3198 035 71040	100nF 10% 16V 0402	2720	2238 869 15109	10pF 5% 50V 0402	3057	4822 117 13545	100Ω 1% 0402
2481	3198 035 71040	100nF 10% 16V 0402	2743	2020 552 96834	1µF 20% 6.3V 0402	3058	4822 117 13543	470Ω 5% 0402
2482	5322 124 41945	22µF 20% 35V	2744	2020 552 96834	1µF 20% 6.3V 0402	3059	4822 117 13548	1kΩ 5% 0402
2483	3198 035 71040	100nF 10% 16V 0402	2747	2238 869 15101	100pF 5% 50V 0402	3060	3198 031 03930	39kΩ 5% 0402
2484	3198 035 71040	100nF 10% 16V 0402	2748	2238 869 15101	100pF 5% 50V 0402	3063	3198 031 06890	68Ω 5% 0402
2485	3198 035 71040	100nF 10% 16V 0402	2749	2238 869 15101	100pF 5% 50V 0402	3065	3198 031 06810	680Ω 5% 0.01W 0402
2486	3198 035 71040	100nF 10% 16V 0402	2750	2238 869 15101	100pF 5% 50V 0402	3066	3198 031 06890	68Ω 5% 0402
2487	4822 126 14519	22pF 5% 50V 0402	2784	4822 126 14241	330pF 0603 50V	3067	3198 031 01090	10Ω 5% 0.01W 0402
2488	4822 126 14519	22pF 5% 50V 0402	2785	4822 126 14241	330pF 0603 50V	3068	3198 031 06890	68Ω 5% 0402
2490	2238 586 59812	100nF 20% 50V 0603	2847	3198 017 41050	1µF 10V 0603	3069	4822 117 13601	22kΩ 5% 0402
2491	2238 586 59812	100nF 20% 50V 0603	2848	3198 017 41050	1µF 10V 0603	3070	4822 117 13545	100Ω 1% 0402
2492	2238 586 59812	100nF 20% 50V 0603	2860	2238 869 15109	10pF 5% 50V 0402	3072	3198 031 06890	68Ω 5% 0402
2495	4822 124 80151	47µF 16V	2861	2238 869 15109	10pF 5% 50V 0402	3073	3198 031 01530	15kΩ 5% 0.01W 0402
2496	3198 035 71040	100nF 10% 16V 0402	2862	2238 869 15109	10pF 5% 50V 0402	3074	4822 117 11297	100kΩ 5% 0.1W
2501	4822 124 80151	47µF 16V	2863	2238 869 15109	10pF 5% 50V 0402	3075	3198 031 04720	4.7kΩ 5% 0402
2502	4822 124 11131	47µF 6.3V	2864	2238 869 15109	10pF 5% 50V 0402	3077	3198 031 04720	4.7kΩ 5% 0402
2503	3198 035 71040	100nF 10% 16V 0402	2865	2238 869 15109	10pF 5% 50V 0402	3078	3198 031 04720	4.7kΩ 5% 0402
2504	3198 035 71040	100nF 10% 16V 0402	2866	2238 869 15109	10pF 5% 50V 0402	3079	3198 031 04720	4.7kΩ 5% 0402
2505	3198 035 71040	100nF 10% 16V 0402	2867	2238 869 15109	10pF 5% 50V 0402	3080	5322 117 13034	1.5kΩ 1% 0.063W 0603
2506	3198 035 71040	100nF 10% 16V 0402	2868	2238 869 15109	10pF 5% 50V 0402	3081	4822 117 13545	100Ω 1% 0402
2507	3198 035 71040	100nF 10% 16V 0402	2869	2238 869 15109	10pF 5% 50V 0402	3082	3198 031 04720	4.7kΩ 5% 0402
2508	3198 035 71040	100nF 10% 16V 0402	2870	2238 869 15109	10pF 5% 50V 0402	3083	3198 031 04720	4.7kΩ 5% 0402
2509	3198 035 71040	100nF 10% 16V 0402	2871	2238 869 15109	10pF 5% 50V 0402	3084	4822 117 13545	100Ω 1% 0402
2510	3198 035 71040	100nF 10% 16V 0402	2872	2238 586 59812	100nF 20% 50V 0603	3085	3198 031 04720	4.7kΩ 5% 0402
2511	3198 035 71040	100nF 10% 16V 0402	2877	2238 869 15109	10pF 5% 50V 0402	3086	4822 117 13602	2.2kΩ 5% 0.01W 0402
2512	3198 035 71040	100nF 10% 16V 0402	2880	2238 869 15109	10pF 5% 50V 0402	3087	4822 117 13606	10kΩ 5% 0.01W 0402
2513	3198 035 71040	100nF 10% 16V 0402	2882	2238 869 15109	10pF 5% 50V 0402	3088	3198 031 03320	3.3kΩ 5% 0402
2514	3198 035 71040	100nF 10% 16V 0402	2883	2238 869 15109	10pF 5% 50V 0402	3089	3198 031 01540	150kΩ 5% 0402
2515	3198 035 71040	100nF 10% 16V 0402	2884	2020 552 96628	10nF 10% 16V 0402	3091	4822 117 13545	100Ω 1% 0402
2516	3198 035 71040	100nF 10% 16V 0402	2885	2238 869 15109	10pF 5% 50V 0402	3092	3198 031 04720	4.7kΩ 5% 0402
2517	3198 035 71040	100nF 10% 16V 0402	2886	4822 124 23002	10µF 16V	3093	3198 031 04720	4.7kΩ 5% 0402
2526	5322 124 41945	22µF 20% 35V	2887	2238 869 15109	10pF 5% 50V 0402	3094	3198 031 01090	10Ω 5% 0.01W 0402
2530	4822 124 23002	10µF 16V	2889	2238 869 15109	10pF 5% 50V 0402	3096	3198 031 03320	3.3kΩ 5% 0402
2531	3198 035 71040	100nF 10% 16V 0402	2910	3198 035 04710	470pF 50V 0402	3097	3198 031 04720	4.7kΩ 5% 0402
2532	3198 035 71040	100nF 10% 16V 0402	2911	3198 030 72290	22µF 20% 35V	3098	4822 117 13545	100Ω 1% 0402
2533	3198 035 71040	100nF 10% 16V 0402	2920	4822 124 80151	47µF 16V	3101	4822 051 30151	150Ω 5% 0.062W
2560	3198 035 71040	100nF 10% 16V 0402	2921	4822 124 80151	47µF 16V	3102	4822 117 12891	220kΩ 1%
2561	4822 124 12095	100µF 20% 16V	2930	2020 021 91871	470µF 20% 16V	3103	4822 051 30223	22kΩ 5% 0.062W
2562	3198 035 71040	100nF 10% 16V 0402	2931	3198 035 04710	470pF 50V 0402	3104	4822 117 12925	47kΩ 1% 0.063W 0603
2563	3198 035 14720	4.7nF 5% 25V 0402	2933	2020 021 91871	470µF 20% 16V	3105	4822 051 30151	150Ω 5% 0.062W
2564	2020 552 96656	10µF 20% 25V 1210	2934	2020 552 96793	4.7nF 10% 50V 0402	3106	4822 117 12891	220kΩ 1%
2580	3198 035 71040	100nF 10% 16V 0402	2935	2020 021 91871	470µF 20% 16V	3107	4822 117 12925	47kΩ 1% 0.063W 0603
2581	3198 035 71040	100nF 10% 16V 0402	2953	2020 021 91871	470µF 20% 16V	3108	4822 051 30223	22kΩ 5% 0.062W
2582	3198 035 71040	100nF 10% 16V 0402	2955	3198 035 14720	4.7nF 5% 25V 0402	3109	4822 051 30759	75Ω 5% 0.062W
2583	3198 035 71040	100nF 10% 16V 0402	2956	3198 035 02210	220pF 5% 50V 0402	3110	4822 051 30331	330Ω 5% 0.062W
2584	3198 035 71040	100nF 10% 16V 0402	2957	2020 021 91871	470µF 20% 16V	3111	4822 051 30273	27kΩ 5% 0.062W
2585	2238 869 75829	82pF 5% 50V 0402	2958	2020 021 91871	470µF 20% 16V	3112	4822 051 30682	6.8Ω 5% 0.062W
2586	2238 869 75829	82pF 5% 50V 0402	2992	3198 035 71040	100nF 10% 16V 0402	3113	4822 051 30759	75Ω 5% 0.062W
2587	3198 035 03310	330pF 5% 50V 0402	2993	2020 552 96618	1nF 10% 50V 0402	3114	4822 051 30331	330Ω 5% 0.062W
2588	3198 035 04710	470pF 50V 0402	2994	2020 021 91871	470µF 20% 16V	3115	4822 051 30759	75Ω 5% 0.062W
2605	3198 035 71040	100nF 10% 16V 0402	2995	3198 035 71040	100nF 10% 16V 0402	3116	4822 051 30331	330Ω 5% 0.062W
2606	3198 035 71040	100nF 10% 16V 0402	2996	4822 124 80151	47µF 16V	3117	4822 051 30331	330Ω 5% 0.062W
2607	3198 035 71040	100nF 10% 16V 0402				3118	4822 051 30759	75Ω 5% 0.062W
2608	3198 035 71040	100nF 10% 16V 0402				3119	4822 051 30689	68Ω 5% 0.063W 0603
2609	3198 035 71040	100nF 10% 16V 0402				3120	4822 051 30008	Jumper 0603
2610	3198 035 71040	100nF 10% 16V 0402				3121	4822 051 30759	75Ω 5% 0.062W
2611	4822 124 11131	47µF 6.3V	3000	3198 031 05620	5.6kΩ 5% 0.01W 0402	3122	4822 051 30331	330Ω 5% 0.062W
2612	2020 552 96628	10nF 10% 16V 0402	3001	2322 702 70398	3.9Ω 5% 0603	3123	4822 051 30102	1kΩ 5% 0.062W
2613	2020 552 96628	10nF 10% 16V 0402	3002	4822 117 13601	22kΩ 5% 0402	3124	4822 051 30151	150Ω 5% 0.062W
2614	2020 552 96628	10nF 10% 16V 0402	3003	2322 702 70398	3.9Ω 5% 0603	3125	4822 051 30151	150Ω 5% 0.062W
2615	2020 552 96628	10nF 10% 16V 0402	3004	4822 117 13601	22kΩ 5% 0402	3126	4822 117 12891	220kΩ 1%
2616	2020 552 96628	10nF 10% 16V 0402	3005	3198 031 05620	5.6kΩ 5% 0.01W 0402	3127	4822 051 30151	150Ω 5% 0.062W
2617	2020 552 96628	10nF 10% 16V 0402	3006	4822 117 13545	100Ω 1% 0402	3128	4822 117 12925	

3140	4822 051 30689	68Ω 5% 0.063W 0603	3437	4822 117 13606	10kΩ 5% 0.01W 0402	3713	4822 117 13606	10kΩ 5% 0.01W 0402
3141	4822 051 30102	1kΩ 5% 0.062W	3438	3198 031 11030	4 x 10kΩ 5% 1206	3716	3198 031 01220	1.2kΩ 5% 0.01W 0402
3142	4822 051 30331	330Ω 5% 0.062W	3439	3198 031 11030	4 x 10kΩ 5% 1206	3718	3198 031 03390	33Ω 1% 0402
3143	4822 051 30759	75Ω 5% 0.062W	3440	3198 031 11030	4 x 10kΩ 5% 1206	3721	3198 031 01220	1.2kΩ 5% 0.01W 0402
3144	4822 051 30151	150Ω 5% 0.062W	3441	3198 031 11030	4 x 10kΩ 5% 1206	3723	4822 117 13548	1kΩ 5% 0402
3145	4822 051 30151	150Ω 5% 0.062W	3442	3198 031 11030	4 x 10kΩ 5% 1206	3724	4822 117 13606	10kΩ 5% 0.01W 0402
3146	4822 051 30151	150Ω 5% 0.062W	3443	4822 117 13606	10kΩ 5% 0.01W 0402	3728	3198 031 05620	5.6kΩ 5% 0.01W 0402
3147	4822 051 30151	150Ω 5% 0.062W	3446	5322 117 13017	100Ω 1% 0.063W 0603	3729	3198 031 03320	3.3kΩ 5% 0402
3148	4822 051 30151	150Ω 5% 0.062W	3447	3198 031 02290	22Ω 5% 0.1W 0402	3730	3198 031 03320	3.3kΩ 5% 0402
3149	4822 051 30223	22kΩ 5% 0.062W	3448	3198 031 01090	10Ω 5% 0.01W 0402	3731	4822 117 13543	470Ω 5% 0402
3150	4822 051 30151	150Ω 5% 0.062W	3501	4822 117 12706	10kΩ 1% 0.063W 0603	3732	4822 117 13548	1kΩ 5% 0402
3151	4822 051 30151	150Ω 5% 0.062W	3502	4822 117 12706	10kΩ 1% 0.063W 0603	3733	4822 117 13543	470Ω 5% 0402
3152	4822 117 12891	220kΩ 1%	3503	2322 704 61501	150Ω 1% 0603	3739	4822 117 13601	22kΩ 5% 0402
3153	4822 051 30151	150Ω 5% 0.062W	3531	4822 117 13606	10kΩ 5% 0.01W 0402	3740	4822 117 13601	22kΩ 5% 0402
3155	4822 117 12891	220kΩ 1%	3532	4822 117 13606	10kΩ 5% 0.01W 0402	3741	4822 117 11297	100kΩ 5% 0.1W
3156	4822 051 30151	150Ω 5% 0.062W	3534	4822 117 13548	1kΩ 5% 0402	3742	4822 117 13601	22kΩ 5% 0402
3169	4822 051 30479	47Ω 5% 0.062W	3536	4822 117 13606	10kΩ 5% 0.01W 0402	3743	4822 117 13601	22kΩ 5% 0402
3251	4822 117 11151	1Ω 5%	3538	3198 031 11030	4 x 10kΩ 5% 1206	3745	4822 117 11297	100kΩ 5% 0.1W
3259	4822 117 13606	10kΩ 5% 0.01W 0402	3539	3198 031 11030	4 x 10kΩ 5% 1206	3752	3198 031 01510	10kΩ 5% 0.01W 0402
3260	3198 031 06820	6.8kΩ 5% 0.01W 0402	3540	3198 031 11030	4 x 10kΩ 5% 1206	3753	3198 031 01510	150Ω 5% 0.01W 0402
3266	3198 031 04720	4.7kΩ 5% 0402	3544	3198 031 11030	4 x 10kΩ 5% 1206	3781	4822 117 12925	47kΩ 1% 0.063W 0603
3267	5322 117 13013	5.6kΩ 1% 0.063W 0603	3545	3198 031 11030	4 x 10kΩ 5% 1206	3782	4822 051 30151	150Ω 5% 0.062W
3268	2322 704 63302	3.3kΩ 1% 0603	3546	3198 031 11030	4 x 10kΩ 5% 1206	3783	4822 051 30103	10kΩ 5% 0.062W
3270	4822 117 13602	2.2kΩ 5% 0.01W 0402	3547	3198 031 11030	4 x 10kΩ 5% 1206	3784	4822 051 30102	1kΩ 5% 0.062W
3271	4822 117 13543	470Ω 5% 0402	3548	4822 117 13606	10kΩ 5% 0.01W 0402	3788	4822 051 30102	1kΩ 5% 0.062W
3273	3198 031 02240	220kΩ 5% 0.1W 0402	3549	4822 051 30102	1kΩ 5% 0.062W	3836	4822 117 13606	10kΩ 5% 0.01W 0402
3274	4822 117 13601	22kΩ 5% 0402	3550	4822 051 30102	1kΩ 5% 0.062W	3838	4822 117 13606	10kΩ 5% 0.01W 0402
3302	4822 051 30101	100Ω 5% 0.062W	3552	4822 051 30102	1kΩ 5% 0.062W	3870	3198 031 06890	68Ω 5% 0402
3303	4822 051 30101	100Ω 5% 0.062W	3553	4822 051 30102	1kΩ 5% 0.062W	3871	3198 031 06890	68Ω 5% 0402
3304	4822 117 13606	10kΩ 5% 0.01W 0402	3560	4822 117 11297	100kΩ 5% 0.1W	3877	3198 031 06890	68Ω 5% 0402
3305	4822 117 13606	10kΩ 5% 0.01W 0402	3561	4822 117 11297	100kΩ 5% 0.1W	3883	3198 031 06890	68Ω 5% 0402
3309	4822 117 13606	10kΩ 5% 0.01W 0402	3562	4822 117 11297	100kΩ 5% 0.1W	3885	3198 031 06890	68Ω 5% 0402
3311	4822 051 30103	10kΩ 5% 0.062W	3563	4822 117 13548	1kΩ 5% 0402	3886	4822 117 13606	10kΩ 5% 0.01W 0402
3319	4822 051 30273	27kΩ 5% 0.062W	3564	3198 031 01220	1.2kΩ 5% 0.01W 0402	3887	4822 117 13606	10kΩ 5% 0.01W 0402
3320	4822 051 30183	18kΩ 5% 0.062W	3565	4822 117 13548	1kΩ 5% 0402	3910	4822 117 13602	2.2kΩ 5% 0.01W 0402
3321	4822 051 30222	2.2kΩ 5% 0.062W	3566	4822 117 13548	1kΩ 5% 0402	3911	4822 117 13548	1kΩ 5% 0402
3322	4822 051 30682	6.8kΩ 5% 0.062W	3567	4822 117 13548	1kΩ 5% 0402	3930	4822 117 12917	1Ω 5% 0.062W
3323	4822 051 30222	2.2kΩ 5% 0.062W	3568	4822 117 13548	1kΩ 5% 0402	3931	4822 117 12917	1Ω 5% 0.062W
3327	4822 117 13548	1kΩ 5% 0402	3579	4822 117 13548	1kΩ 5% 0402	3932	2322 704 61002	1kΩ 1%
3328	4822 117 13545	100Ω 1% 0402	3580	4822 117 13548	470Ω 5% 0402	3933	2322 704 63302	3.3kΩ 1% 0603
3329	4822 117 13545	100Ω 1% 0402	3581	3198 031 04730	47Ω 5% 0402	3951	4822 117 12917	1Ω 5% 0.062W
3340	4822 117 13601	22kΩ 5% 0402	3605	4822 117 13545	100Ω 1% 0402	3952	4822 117 12917	1Ω 5% 0.062W
3342	4822 117 13606	10kΩ 5% 0.01W 0402	3606	4822 117 13545	100Ω 1% 0402	3953	2322 704 61002	1kΩ 1%
3343	3198 031 04720	4.7kΩ 5% 0402	3607	4822 117 13545	100Ω 1% 0402	3954	2322 704 63302	3.3kΩ 1% 0603
3344	4822 117 13548	1kΩ 5% 0402	3608	4822 117 13545	100Ω 1% 0402	4002	4822 117 13605	Jumper 0402
3345	3198 031 04720	4.7kΩ 5% 0402	3609	4822 117 13545	100Ω 1% 0402	4005	4822 117 13605	Jumper 0402
3346	2322 706 75603	56kΩ 1% 0402	3610	4822 117 13601	22kΩ 5% 0402	4007	4822 117 13605	Jumper 0402
3347	3198 031 08210	820Ω 5% 0.5W	3612	4822 117 13543	470Ω 5% 0402	4008	4822 117 13605	Jumper 0402
3348	3198 031 04720	4.7kΩ 5% 0402	3613	3198 031 02290	22Ω 5% 0.1W 0402	4017	4822 117 13605	Jumper 0402
3349	3198 031 01820	1.8kΩ 5% 0.01W 0402	3614	3198 031 02290	22Ω 5% 0.1W 0402	4018	4822 117 13605	Jumper 0402
3357	4822 117 13548	1kΩ 5% 0402	3615	3198 031 02290	22Ω 5% 0.1W 0402	4023	4822 117 13605	Jumper 0402
3358	4822 117 13545	100Ω 1% 0402	3616	3198 031 02290	22Ω 5% 0.1W 0402	4062	4822 117 13605	Jumper 0402
3359	3198 031 03910	390Ω 1% 0402	3617	3198 031 02290	22Ω 5% 0.1W 0402	4255	4822 117 13605	Jumper 0402
3370	3198 031 06810	680Ω 5% 0.01W 0402	3618	3198 031 02290	22Ω 5% 0.1W 0402	4327	4822 051 30008	Jumper 0603
3371	4822 117 13545	100Ω 1% 0402	3619	3198 031 08210	820Ω 5% 0.5W	4331	4822 051 30008	Jumper 0603
3372	4822 117 13545	100Ω 1% 0402	3620	4822 117 13632	100kΩ 1% 0603 0.62W	4333	4822 051 30008	Jumper 0603
3374	5322 117 11726	10Ω 5%	3621	4822 117 13601	22kΩ 5% 0402	4334	4822 051 30008	Jumper 0603
3378	4822 117 13545	100Ω 1% 0402	3622	4822 117 13601	22kΩ 5% 0402	4360	4822 117 13605	Jumper 0402
3380	3198 031 05620	5.6kΩ 5% 0.01W 0402	3623	4822 117 13601	22kΩ 5% 0402	4361	4822 117 13605	Jumper 0402
3381	3198 031 05620	5.6kΩ 5% 0.01W 0402	3624	4822 117 13601	22kΩ 5% 0402	4362	4822 117 13605	Jumper 0402
3382	3198 031 05620	5.6kΩ 5% 0.01W 0402	3625	4822 117 13601	22kΩ 5% 0.01W 0402	4363	4822 117 13605	Jumper 0402
3383	3198 031 05620	5.6kΩ 5% 0.01W 0402	3626	4822 117 13601	22kΩ 5% 0402	4580	4822 117 13605	Jumper 0402
3386	4822 117 13545	100Ω 1% 0402	3633	4822 117 13545	100Ω 1% 0402	4581	4822 117 13605	Jumper 0402
3389	4822 117 13545	100Ω 1% 0402	3634	4822 117 13545	100Ω 1% 0402	4583	4822 117 13605	Jumper 0402
3390	4822 117 13545	100Ω 1% 0402	3635	4822 117 13545	100Ω 1% 0402	4590	4822 117 13605	Jumper 0402
3391	4822 117 13545	100Ω 1% 0402	3638	4822 117 13545	100Ω 1% 0402	4601	4822 117 13605	Jumper 0402
3392	4822 117 13545	100Ω 1% 0402	3639	4822 117 13545	100Ω 1% 0402	4602	4822 117 13605	Jumper 0402
3393	4822 117 13545	100Ω 1% 0402	3641	4822 117 13597	330Ω 5% 0402 0.01W	4603	4822 117 13605	Jumper 0402
3394	3198 031 07590	75Ω 5% 0402	3642	4822 117 13597	330Ω 5% 0402 0.01W	4608	4822 117 13605	Jumper 0402
3401	2350 035 10229	4 x 22Ω 5% 1206	3643	4822 117 13597	330Ω 5% 0402 0.01W	4708	4822 051 30008	Jumper 0603
3402	2350 035 10229	4 x 22Ω 5% 1206	3644	4822 117 13597	330Ω 5% 0402 0.01W	4714	4822 117 13605	Jumper 0402
3403	2350 035 10229	4 x 22Ω 5% 1206	3645	4822 117 13597	330Ω 5% 0402 0.01W	4720	4822 051 30008	Jumper 0603
3404	2350 035 10229	4 x 22Ω 5% 1206	3646	4822 117 13597	330Ω 5% 0402 0.01W	4836	4822 051 30008	Jumper 0603
3405	2350 035 10229	4 x 22Ω 5% 1206	3680	4822 051 30222	2.2kΩ 5% 0.062W	4838	4822 051 30008	Jumper 0603
3406	2350 035 10229	4 x 22Ω 5% 1206	3681	4822 051 30221	220Ω 5% 0.062W	4888	4822 117 13605	Jumper 0402
3407	2350 035 10229	4 x 22Ω 5% 1206	3683	4822 051 30759	75Ω 5% 0.062W			
3408	2350 035 10229	4 x 22Ω 5% 1206	3684	4822 051 30759	75Ω 5% 0.062W			
3409	2350 035 10229	4 x 22Ω 5% 1206	3685	4822 051 30222	2.2kΩ 5% 0.062W			
3410	2350 035 10229	4 x 22Ω 5% 1206	3686	4822 051 30221	220Ω 5% 0.062W			
3411	2350 035 10229	4 x 22Ω 5% 1206	3687	4822 051 30759	75Ω 5% 0.062W			
3412	2350 035 10229	4 x 22Ω 5% 1206	3689	4822 051 30101	100Ω 5% 0.062W	5001	2422 536 00667	1000μF 20% 7032
3413	2350 035 10229	4 x 22Ω 5% 1206	3693	4822 051 30103	10kΩ 5% 0.062W	5002	4822 157 11716	Bead 30Ω at 100MHz
3414	3198 031 02290	22Ω 5% 0.1W 0402	3696	4822 051 30103	10kΩ 5% 0.062W	5003	4822 157 11716	Bead 30Ω at 100MHz
3415	3198 031 01090	10Ω 5% 0.01W 0402	3697	4822 051 30103	10kΩ 5% 0.062W	5004	4822 157 11716	Bead 30Ω at 100MHz
3422	3198 031 02290	22Ω 5% 0.1W 0402	3698	4822 051 30223	22kΩ 5% 0.062W	5005	4822 157 11716	Bead 30Ω at 100MHz
3423	3198 031 03320	3.3kΩ 5% 0402	3699	4822 051 30223	22kΩ 5% 0.062W	5006	4822 157 11716	Bead 30Ω at 100MHz
3424	2322 704 61501	150Ω 1% 0603	370					

5139	4822 051 20008	Jumper 0805
5251	2422 549 45333	Bead 120Ω 100MHz
5252	2422 549 45333	Bead 120Ω 100MHz
5259	2422 549 45333	Bead 120Ω 100MHz
5262	2422 535 94134	10μH 20% 0805
5267	2422 536 00339	33μ 20%
5268	2422 535 94995	10μF 20% 10145
5304	4822 157 11499	Bead 60Ω at 100MHz
5309	3198 018 31290	12μH 10%
5321	3198 018 31970	0.39μF 10% 0805
5324	4822 157 71334	0.68μH 5% 1008
5370	4822 157 11716	Bead 30Ω at 100MHz
5371	4822 157 11716	Bead 30Ω at 100MHz
5372	4822 157 11716	Bead 30Ω at 100MHz
5530	2422 549 45333	Bead 120Ω 100MHz
5560	4822 157 11716	Bead 30Ω at 100MHz
5580	4822 157 71304	1μH 10% 0805
5605	2422 549 45333	Bead 120Ω 100MHz
5607	2422 549 45333	Bead 120Ω 100MHz
5636	2422 549 45333	Bead 120Ω 100MHz
5680	2422 549 45333	Bead 120Ω 100MHz
5683	2422 549 45333	Bead 120Ω 100MHz
5684	2422 549 45333	Bead 120Ω 100MHz
5685	2422 549 45333	Bead 120Ω 100MHz
5686	2422 549 45333	Bead 120Ω 100MHz
5687	2422 549 45333	Bead 120Ω 100MHz
5720	4822 157 11716	Bead 30Ω at 100MHz
5721	4822 157 11716	Bead 30Ω at 100MHz
5722	4822 157 11716	Bead 30Ω at 100MHz
5872	4822 157 11716	Bead 30Ω at 100MHz
5882	3198 018 51080	1μH 10% 0603
5910	2422 536 00667	1000μF 20% 7032
5920	2422 549 45333	Bead 120Ω 100MHz
5930	2422 535 94134	10μH 20% 0805
5931	2422 536 00689	220μF 20%
5932	2422 535 94134	10μH 20% 0805
5952	2422 535 94134	10μH 20% 0805
5953	2422 536 00689	220μF 20%
5954	2422 535 94134	10μH 20% 0805
5984	2422 549 45333	Bead 120Ω 100MHz
5985	2422 549 45333	Bead 120Ω 100MHz
5986	2422 549 45333	Bead 120Ω 100MHz
5987	2422 549 45333	Bead 120Ω 100MHz
5988	2422 549 45333	Bead 120Ω 100MHz
5989	2422 549 45333	Bead 120Ω 100MHz
5990	2422 549 45333	Bead 120Ω 100MHz
5991	2422 549 45333	Bead 120Ω 100MHz
5994	2422 549 45333	Bead 120Ω 100MHz
5996	2422 549 45333	Bead 120Ω 100MHz
5997	2422 549 45333	Bead 120Ω 100MHz
5998	2422 549 45333	Bead 120Ω 100MHz



6001	4822 130 11397	BAS316
6002	4822 130 11397	BAS316
6005	9340 553 52115	BAS321
6020	4822 130 11397	BAS316
6021	4822 130 11397	BAS316
6075	4822 130 80622	BAT54
6076	4822 130 80622	BAT54
6121	4822 130 11416	PDZ6.8B
6143	4822 130 11416	PDZ6.8B
6259	9322 128 70685	SMSS14
6262	3198 010 10720	SS24
6267	3198 010 10730	SS36
6270	4822 130 10837	UDZS8.2B
6310	4822 130 11397	BAS316
6323	4822 130 11525	1SS356
6328	4822 130 11416	PDZ6.8B
6329	4822 130 11416	PDZ6.8B
6330	4822 130 11416	PDZ6.8B
6331	4822 130 11416	PDZ6.8B
6563	9322 102 64685	UDZ2.7B
6564	4822 130 11416	PDZ6.8B
6565	4822 130 10838	UDZ3.3B
6604	4822 130 11397	BAS316
6605	4822 130 11397	BAS316
6634	9322 102 64685	UDZ2.7B
6635	9322 102 64685	UDZ2.7B
6638	9322 102 64685	UDZ2.7B
6639	9322 102 64685	UDZ2.7B
6693	4822 130 11397	BAS316
6701	3198 020 55680	BZX384-C5V6
6910	5322 130 34337	BAV99
6911	9340 548 71115	PDZ33B
6930	9322 128 70685	SMSS14
6951	9322 128 70685	SMSS14



7001 9339 693 90135 BCP69-25

7002	9340 425 20115	BC847BS
7003	9339 693 90135	BCP69-25
7004	3198 010 42310	BC847BW
7005	9340 547 13215	BSH103
7011		For SW see item 0601
7012	3198 010 42310	BC847BW
7013	3198 010 42310	BC847BW
7014	3198 010 42310	BC847BW
7015	9322 208 05668	SM NE555D
7016	9322 208 05668	SM NE555D
7017	9322 208 05668	SM NE555D
7018	5322 130 60159	BC846B
7019	5322 130 60159	BC846B
7051	3104 317 07511	Softw. (check Prod.Surv.)
7052	3104 317 06722	Softw. (check Prod.Surv.)
7053	3104 317 06742	Softw. (check Prod.Surv.)
7054	3104 317 06691	Softw. (check Prod.Surv.)
7075	4822 130 11155	PDTC114ET
7099		For SW see item 7052
7119	5322 130 60159	BC846B
7138	5322 130 60159	BC846B
7260	9322 139 16668	LF33CPT
7262	9322 202 34668	L5973D
7271	3198 010 42310	BC847BW
7272	3198 010 42310	BC847BW
7320	3198 010 42310	BC847BW
7370	9340 550 49115	PUMH7
7371	9340 550 49115	PUMH7
7372	9340 550 49115	PUMH7
7376	9340 425 10115	BC857BS
7377	9340 425 10115	BC857BS
7401	9322 206 86671	GM1501-BD
7501	9322 199 17671	K4D263238M-QC50
7530		For SW see item 7051
7531		For SW see item 7053
7532	9352 691 71115	NE56610-27GW
7560	9352 334 10118	TDA9178T/N1
7561	3198 010 42310	BC847BW
7562	9322 199 24668	L7808CD2T
7563	4822 209 73852	PMBT2369
7579	4822 130 11155	PDTC114ET
7580	9322 199 16668	M74HC590T
7581	9322 199 16668	M74HC590T
7582	9322 201 05671	CY62256LL-70ZC
7583	9351 870 00118	74HC573PW
7584	9351 870 00118	74HC573PW
7585	3198 010 42310	BC847BW
7604	9352 607 39118	74LVC14APW
7605	4822 209 60792	74HC4053D
7606	9322 199 56668	ADG781BCP
7607	9322 199 80668	SM5301BS-G
7693		For SW see item 7054
7706	9351 742 70118	74HC08PW
7708	9340 425 20115	BC847BS
7710	9340 310 50215	PDTA143ET
7713	3198 010 42310	BC847BW
7714	3198 010 42310	BC847BW
7740	9322 183 05668	TS482ID
7872	9352 686 35118	PCA9515DP
7887	3198 010 42310	BC847BW
7910	4822 130 42804	BC817-25
7920	9322 163 24668	L78M08CDT
7930	5322 209 90529	MC34063AD
7952	5322 209 90529	MC34063AD
7992	9322 142 88668	LF25CDT
7995	9322 189 19668	LD1086D2T18

PDP Audio [C]

Various

1735	2422 025 10768	Connector 3p m
1736	2422 025 10768	Connector 3p m
1739	2422 025 10769	Connector 9p m
1M02	2422 025 11244	Connector 7p m
8302	3104 311 07591	Cable 7P/820/7P



2702	5322 126 11578	1nF 10% 50V 0603
2704	5322 126 11578	1nF 10% 50V 0603
2705	2020 552 96684	470nF 10% 25V 0805
2706	2222 580 15649	100nF 10% 50V 0805
2707	4822 126 14585	100nF 10% 0805 50V
2708	2020 552 96326	220nF 10% 16V
2709	4822 126 13881	470pF 5% 50V
2710	4822 126 13881	470pF 5% 50V
2711	5322 126 11578	1nF 10% 50V 0603
2712	2020 552 96684	470nF 10% 25V 0805
2713	2020 552 96684	470nF 10% 25V 0805
2714	4822 126 14549	33nF 16V 0603

2715	5322 126 11578	1nF 10% 50V 0603
2716	4822 126 14241	330pF 0603 50V
2717	5322 121 42498	680nF 5% 63V
2718	4822 122 33761	22pF 5% 50V
2719	5322 126 11578	1nF 10% 50V 0603
2720	2020 552 96326	220nF 10% 16V
2721	4822 126 13881	470pF 5% 50V
2722	4822 126 13881	470pF 5% 50V
2724	2020 552 96684	470nF 10% 25V 0805
2726	4822 126 14549	33nF 16V 0603
2727	5322 126 11578	1nF 10% 50V 0603
2728	4822 126 14241	330pF 0603 50V
2729	5322 121 42498	680nF 5% 63V
2730	2020 552 96684	470nF 10% 25V 0805
2764	4822 126 14491	2.2μF 10V 0805
2766	4822 126 14491	2.2μF 10V 0805
2768	4822 124 40255	100μF 20% 63V
2769	4822 124 40255	100μF 20% 63V
2777	2020 552 96684	220nF 10% 50V
2778	4822 124 40769	4.7μF 20% 100V
2779	2020 552 96683	220nF 10% 50V
2780	2020 552 96683	220nF 10% 50V
2781	2020 552 96683	220nF 10% 50V
2783	4822 124 81151	22μF 50V
2786	2238 586 15641	22nF 10% 50V 0603
2788	4822 124 40255	100μF 20% 63V
2789	2020 552 96684	470nF 10% 25V 0805
2790	4822 124 40255	100μF 20% 63V



3701	4822 051 30103	10kΩ 5% 0.062W
3702	4822 051 30682	6.8Ω 5% 0.062W
3703	4822 051 30333	33kΩ 5% 0.062W
3704	4822 117 10833	10kΩ 1% 0.1W
3705	4822 051 20828	8.2Ω 5% 0.1W
3706	4822 051 30472	4.7Ω 5% 0.062W
3707	4822 051 30683	68kΩ 5% 0.062W
3708	4822 051 30563	56kΩ 5% 0.062W
3709	4822 117 11503	220Ω 1% 0.1W
3710	4822 051 30223	22kΩ 5% 0.062W
3711	4822 050 21204	120kΩ 1% 0.6W
3712	4822 051 30103	10kΩ 5% 0.062W
3713	4822 116 52207	1.2kΩ 5% 0.5W
3714	4822 117 12925	47kΩ 1% 0.063W 0603
3715	4822 117 12925	47kΩ 1% 0.063W 0603
3716	4822 117 12925	47kΩ 1% 0.063W 0603
3717	4822 116 52234	100kΩ 5% 0.5W
3718	4822 117 13632	100kΩ 1% 0603 0.62W
3721	4822 051 30472	4.7Ω 5% 0.062W
3722	4822 051 30683	68kΩ 5% 0.062W
3723	4822 051 30563	56kΩ 5% 0.062W
3724	4822 117 11503	220Ω 1% 0.1W
3725	4822 051 30223	22kΩ 5% 0.062W
3726	4822 117 11503	220Ω 1% 0.1W
3727	4822 117 11503	220Ω 1% 0.1W
3743	4822 117 11449	2.2kΩ 5% 0.1W 0805
3746	4822 051 30223	22kΩ 5% 0.062W
3747	4822 117 12925	47kΩ 1% 0.063W 0603
3748	4822 116 83883	470Ω 5% 0.5W
3750	4822 117 11449	2.2kΩ 5% 0.1W 0805
3756	4822 117 11449	2.2kΩ 5% 0.1W 0805
3757	4822 117 11449	2.2kΩ 5% 0.1W 0805
3760	4822 117 12891	220kΩ 1%
3761	4822 051 20109	10Ω 5% 0.1W
3762	4822 051 20109	10Ω 5% 0.1W
3763	4822 117 13632	100kΩ 1% 0603 0.62W
3764	4822 051 30222	2.2kΩ 5% 0.062W
3765	4822 051 30222	2.2kΩ 5% 0.062W
3766	4822 117 13632	100kΩ 1% 0603 0.62W
3767	4822 117 13632	100kΩ 1% 0603 0.62W
3768	4822 117 13632	100kΩ 1% 0603 0.62W
3790	4822 051 30272	2.7kΩ 5% 0.062W
3791	4822 051 30272	2.7kΩ 5% 0.062W
3792	4822 051 30103	10kΩ 5% 0.062W
3793	4822 051 30103	10kΩ 5% 0.062W
3798	4822 051 30153	15kΩ 5% 0.062W
3999	4822 051 30101	100Ω 5% 0.062W
9717	4822 051 3000	

⇨		
6701	4822 130 11397	BAS316
6710	4822 130 11551	UDZS10B
6711	4822 130 11551	UDZS10B



7700	9322 163 86682	TDA7490L
7701	3198 010 42310	BC847BW
7703	3198 010 42310	BC847BW
7704	3198 010 42310	BC847BW
7705	3198 010 42310	BC847BW
7706	3198 010 42320	BC857BW
7707	3198 010 42310	BC847BW
7710	3198 010 42310	BC847BW
7711	3198 010 42310	BC847BW
7712	3198 010 42310	BC847BW
7713	3198 010 42310	BC847BW

Side I/O [D]

Various

1001	2422 033 00442	Connector 2P f
1002	2422 026 05587	Sock Cinch 2P f RdWh



2004	4822 126 14241	330pF 0603 50V
2005	2020 552 94427	100pF 5% 50V
2006	4822 126 14241	330pF 0603 50V
2007	2020 552 94427	100pF 5% 50V



3000	4822 051 30759	75Ω 5% 0.062W
3004	4822 051 30759	75Ω 5% 0.062W
3009	4822 051 30102	1kΩ 5% 0.062W
3010	4822 051 30333	33kΩ 5% 0.062W
3012	4822 051 30102	1kΩ 5% 0.062W
3013	4822 051 30333	33kΩ 5% 0.062W
9001	4822 051 30008	Jumper 0603
9002	4822 051 30008	Jumper 0603
9004	4822 051 30008	Jumper 0603
9005	4822 051 30008	Jumper 0603
9007	4822 051 30008	Jumper 0603



6000	4822 130 11416	PDZ6.8B
6001	4822 130 11416	PDZ6.8B
6002	4822 130 11416	PDZ6.8B
6003	4822 130 11416	PDZ6.8B
6004	4822 130 11416	PDZ6.8B
6005	4822 130 11416	PDZ6.8B
6006	4822 130 11416	PDZ6.8B
6007	4822 130 11416	PDZ6.8B

Top Control [E]

Various

0345	4822 267 10459	Connector 3p
1701	2422 128 02778	Tact switch
1702	2422 128 02778	Tact switch
1703	2422 128 02778	Tact switch
1704	2422 128 02778	Tact switch
1705	2422 128 02778	Tact switch
8345	3104 311 06551	Cable 3P/1300/3P



3001	4822 051 20391	390Ω 5% 0.1W
3003	4822 117 13528	200Ω 1% 0.125W 0805
3005	4822 117 11951	2kΩ 1% 0.1W
3009	4822 117 11534	1.1kΩ 1% 0.1W
3011	4822 117 10845	620Ω 1% 0.1W
3999	4822 051 20471	470Ω 5% 0.1W
9001	4822 051 20008	Jumper 0805
9003	4822 051 20008	Jumper 0805
9005	4822 051 20008	Jumper 0805
9006	4822 051 20008	Jumper 0805

EMC Filter [EMC]

Various

1320	2422 025 16545	Connector 10p m
1330	2422 025 16545	Connector 10p m
1345	2422 025 16835	Connector 3p m
1355	2422 025 16835	Connector 3p m



2300	5322 126 11583	10nF 10% 50V 0603
2301	5322 126 11583	10nF 10% 50V 0603
2302	3198 016 31020	1nF 25V 0603
2303	5322 126 11583	10nF 10% 50V 0603
2304	5322 126 11583	10nF 10% 50V 0603
2305	5322 126 11583	10nF 10% 50V 0603
2306	5322 126 11583	10nF 10% 50V 0603
2307	5322 126 11583	10nF 10% 50V 0603
2308	5322 126 11583	10nF 10% 50V 0603



3300	4822 051 30101	100Ω 5% 0.062W
3301	4822 051 30101	100Ω 5% 0.062W
3302	4822 051 30101	100Ω 5% 0.062W
3303	4822 051 30101	100Ω 5% 0.062W
3304	4822 051 30101	100Ω 5% 0.062W
3305	4822 051 30101	100Ω 5% 0.062W
3306	4822 051 30101	100Ω 5% 0.062W
3307	4822 051 30101	100Ω 5% 0.062W



5300	2422 549 43062	Bead 600Ω at 100MHz
5301	2422 549 43062	Bead 600Ω at 100MHz
5302	2422 549 43062	Bead 600Ω at 100MHz
5303	2422 549 43062	Bead 600Ω at 100MHz
5304	2422 549 43062	Bead 600Ω at 100MHz
5305	2422 549 43062	Bead 600Ω at 100MHz
5306	2422 549 43062	Bead 600Ω at 100MHz
5307	2422 549 43062	Bead 600Ω at 100MHz
5308	2422 549 43062	Bead 600Ω at 100MHz
5309	2422 549 43062	Bead 600Ω at 100MHz
5310	2422 549 43062	Bead 600Ω at 100MHz
5311	2422 549 43062	Bead 600Ω at 100MHz
5312	2422 549 43062	Bead 600Ω at 100MHz
5313	2422 549 43062	Bead 600Ω at 100MHz

LED + Switch [J]

Various

0320	2422 025 16545	Connector 10p m
1101	2422 128 03123	Switch 2p 2pos 30V



2107	4822 124 12095	100μF 20% 16V
2120	3198 030 71090	10μF 20% 35V
2126	4822 126 14583	470nF 10% 16V 0805



3101	4822 051 30151	150Ω 5% 0.062W
3103	4822 051 30331	330Ω 5% 0.062W
3105	4822 051 30681	680Ω 5% 0.062W
3106	4822 051 30151	150Ω 5% 0.062W
3107	4822 051 30471	47Ω 5% 0.062W
3108	4822 051 30103	10kΩ 5% 0.062W
3109	4822 051 30101	100Ω 5% 0.062W
3120	4822 051 30472	4.7Ω 5% 0.062W
3121	4822 051 30103	10kΩ 5% 0.062W
3122	4822 051 30332	3.3Ω 5% 0.062W
3123	4822 051 30332	3.3Ω 5% 0.062W
3124	4822 051 30102	1kΩ 5% 0.062W
3126	2322 702 60335	3.3MΩ 5% 0603
3127	2322 702 60335	3.3MΩ 5% 0603
3128	4822 051 30472	4.7Ω 5% 0.062W
4101	4822 051 30008	Jumper 0603
4107	4822 051 30008	Jumper 0603
4108	4822 051 30008	Jumper 0603
4111	4822 051 30008	Jumper 0603



5100	2422 549 43769	Bead 30Ω at 100MHz
------	----------------	--------------------



6101	4822 130 11564	UDZ3.9B
6103	4822 130 83915	TLMV3100
6105	4822 130 11564	UDZ3.9B
6127	9322 140 63685	TEMD5000



7103	3198 010 42320	BC857BW
7105	3198 010 42320	BC857BW
7107	9322 206 81667	TSOP34836YA1
7120	5322 209 82941	LM358D

11. Revision List

Manual xxxx xxx xxxx.0

- First release.

Manual xxxx xxx xxxx.1

- Block diagrams and schematics updated.
- Description of white tone alignment added.

Manual xxxx xxx xxxx.2

- Default values of white tone alignment added.
- Small updates in all chapters.

www.s-manuals.com