

## User manual

### Precautions

This manual contains important information regarding safety measures and proper use of the product.

To avoid accident, please be sure to read the manual carefully prior to use the product. Keep the product away from high temperature, moisture or dust.

Do not expose the product to high temperature, especially in a window-closed vehicle during summer.

Avoid drop or strong collision of the product or heavy vibration of the TFT screen, as it may cause damage or abnormal display of the TFT screen.

Please choose appropriate volume. It is not recommended to use earphones in high volume. If ringing occurs in the ear, please lower the volume or stop using the device.

Please charge under the following circumstances:

A. The battery icon indicates no power.

B. The system automatically shuts down, and immediately shuts down again after restart.

C. The operating button does not respond.

D. The red icon is displayed in the lower right corner of the product.

Note: This product cannot be used with any unauthorized charger; otherwise it may burn the product, which is not covered by warranty. For any additional original charger, please contact customer service.

The Li-ion battery cells in the battery pack are not user serviceable.

When battery level is low, Recommendation: use the A/C wall adapter supplied with the product.

Please operate the product properly following the user manual's guidelines.

Do not disassemble the product. Do not use alcohol, thinner or benzene to clean the surface of the product.

Do not operate device where the use of electronic equipment is prohibited, such as on airplanes.

To avoid any accidents, please do not use the product when driving or walking on the street.

USB connection is for data transfer only.


\*As the product may undergo modifications and improvements, product specifications and design are subject to change without prior notice.





**NOTE:** Pictures in this manual are for reference only.

## 1. The Home Screen

### 1.1 Home Screen

After turning on the device, the locked home screen is displayed.



The screen is locked by default. To unlock the screen, drag  towards , or drag  towards  to directly enter the camera application. You can manage application icons from the home screen.

**Add application shortcuts:** Long press an application icon from the application menu and drag the icon to the home screen to add as shortcut.

• **Remove application shortcuts:** Long press an application icon in the home screen as the top of the screen displays an “X”. Drag the application icon towards the “X” until it turns red, and then release the hold to remove the application shortcut.

## 1.2 Wallpapers

Long press the touch screen and the Wallpaper option will appear.

• **Gallery:** Choose a picture saved in your photo gallery or a picture taken by the device camera to use as the background of the home screen.

• **Live Wallpapers:** Choose a moving graphic from Live Wallpapers to use as the background of the home screen.



• **Wallpapers:** Choose a picture from the default system pictures to use as the background of the home screen.


## 1.3 Status Bar

The status bar is located at the bottom the screen.



The icons on the left side are:

- Back:  Tap to return to previous screen.
- Home:  Tap to return to home screen.



- History:  Tap to view the most-recently accessed applications.

The icons on the right side display Wi-Fi signal, Wi-Fi connection status, battery power/battery charging status, current time, USB and SD card connection status. Tap the icons to view the date, and time or another information.


### 1.4 Using the Touch Screen

The tablet is equipped with a 7" touch screen. The following describes the main touch screen area, and tips on how to properly use it.

Whichever interface you are in, you can return to the home screen directly by touching


the Home  icon. You can also touch the History  icon to view recently accessed applications.


In different applications, you can return to the upper layer or previous interface by

touching the Return  icon.

In different applications, you can touch the advanced icon to show relevant options available in the application.

### 1.5 Application Menu

Tap the Application  icon to view the application menu screen.



In the application menu interface, simply touch an application icon to open the application.

In applications with browsing capabilities, such as Explorer, Music, etc., you can drag the scroll bar up and down or flick the screen to scroll the file list.


In Browser or PDF reader, touch and drag the page to scroll up/down.

## 2. Basic Settings

Personalize applications, set system date and time, configure network connection, and change other settings in the **Settings** page. To open the **Settings** page, do one of the following:

Touch the Application  icon, and then tap  Settings.


Tap the notification icons on the right side of the status bar, and then tap



Tap an item on the left panel menu to display more setting options on the right panel.

## 2.1 Wi-Fi and Network

The Wi-Fi menu lets you manage Wi-Fi settings and connect to a wireless network.



Tap the Wi-Fi switch button to turn Wi-Fi on or off.

The Wi-Fi icon displaying  indicates Wi-Fi is turned off.

The Wi-Fi icon displaying  indicates Wi-Fi is turned on.


### Connect to an Access Point

1. Turn on Wi-Fi. The device will search for available networks within range and display the searched Access Point (AP) names on the right panel.
2. Tap the access point name that you wish to connect to. If the selected access point is protected by a password, the device will prompt for the password. (Note: Password entry is only required when connecting to the AP for the first time.)
3. When prompted, enter the password to connect to the AP.

#### 4. Tap **Connect**.

#### **Other Wi-Fi Options**

Tap the Advanced icon on the upper-right corner of the screen to display advanced options and other network information.




When the **Network notification** option is checked, the system automatically scans and displays available networks within range. If it is unchecked, you must tap **SCAN** to manually scan for nearby networks and tap **ADD NETWORK** to manually do so.

\*Note: The tablet recognizes Wi-Fi networks that it has connected to before. Once Wi-Fi is turned on and a known connection is detected, the device automatically connects to that network.

## 2.2 Device

### 2.2.1 Sound


Set the tone and sound notifications.



- **Volumes:** Includes volume adjustments for Music, Video, Games and other medium, notifications and alarm clock. Drag the slider bar to adjust the volume.
- **Default notification:** Set the default notification ringtone.
- **Touch sounds:** Activate sound when you make selection on the screen.

- **Screen lock sound:** Activate sound when you unlock or lock the screen.


## 2.2.2 Display



- **Brightness:** Adjust the brightness of the screen by dragging the slider bar left or right, then click **OK**. You can also select automatic adjustment.
- **Wallpaper:** Change the background of the home screen by three (3) options. Refer back to section **1.2 Wallpapers** for details.
- **Auto-rotate screen:** When you rotate the tablet, the screen changes direction automatically.
- **Sleep:** Adjust idle time before the screen locks.
- **Font size:** Set the size of the system font with four options: Small, Normal, Large, and Huge.

## 2.3 Personal

### 2.3.1 Accounts and Sync



When the device accesses applications, such as the calendar, it needs to log in with an ID to sync data on your account with data on your tablet.


- **Account Synchronization:** Touch the Account Sync switch to enable or disable

account synchronization.

- **ADD ACCOUNT:** Touch this option to add a new E-mail account, if necessary.

### 2.3.2 Location Services

Set your location and allow interactive options with Google.




- **Google's location service:** When checked, applications use data from Wi-Fi or mobile networks to determine your approximate location.

### 2.3.3 Security

The Security menu allows you to set device security options.

- **Screen lock:** Select the method of unlocking the screen.
- **Owner info:** Display the owner information on a locked screen.
- **Encrypt tablet:** Encrypt the device with a PIN or password.
- **Make passwords visible:** Display password characters as you type them on screen.
- **Device administrators:** View or deactivate device administrators.
- **Unknown sources:** Run and install application programs not from Google market.



### CREDENTIAL STORAGE

Ascertain the legality and credibility of the program with some credentials CA.

- **Trusted credentials:** Store trusted credentials used by the system or the user.

- Install from SD card: Import trusted credentials from the SD card.
- Clear credentials: Clear all credentials recorded by the system, generally can't be selected by default.

### 2.3.4 Language and Input Method

This menu allows you to choose the system display language and input method.

- **Language:** Choose the system language, with 60 options.
- **Spelling correction:** Based on the selected language, the system assists to correct spelling errors.
- **Personal dictionary:** Customized words defined by the user, null by default.



### KEYBOARD & INPUT METHODS

Choose to set the system input method.

- **Default:** Select the default input method.
- **Android keyboard:** Tap the Settings icon to configure the Android keyboard settings.
- **Google speech-to-text:** Automatic

### 2.3.5 Backup and Reset

#### PERSONAL DATA


**Factory data reset:** Clear all data in the tablet PC and revert all settings to factory default.

## 2.4 System

### 2.4.1 Date and Time

Set the date, time, time zone and format.






- **Automatic date & time:** Use the time on the network; requires Internet access and system reboot to take effect.
- **Set date:** Access date setting interface and set the date.
- **Set time:** Access time setting interfaces and set the time.
- **Select time zone:** Access time zone setting interface and set time zone.
- **Use 24-hour format:** Set display format of the time.
- **Select date format:** Display the date by selecting different date format.

## 2.4.2 Accessibility


### SYSTEM

- **Large text:** Select the size of the system display font.
- **Auto-rotate screen:** Adjust the screen direction according to the G-sensor.
- **Speak passwords:** Choose to say passwords verbally instead of typing them.
- **Touch & hold delay:** Set the response speed of the touch screen.
- **Install web scripts:** Choose whether or not to install the script from Google for viewing the web conveniently.



### 2.4.3 About the Tablet

- **System updates:** Detect system version and upgrade.
- **Status:** Current status of tablet PC, including battery power, network, uptime, etc.
- **Legal information:** Code development license and Google legal information.
- **Model number:** Device model number.
- **Android version:** Android version number.
- **Kernel version:** Linux core version number.
- **Build number:** The customized version number, used to distinguish the system software.



## Conditions of Guarantee

1. For the guarantee to be carried out, all products must be delivered to IJOY perfectly packed, preferably in its own original packing, with all accessories, user manuals and drivers that the packaging would originally contain. Otherwise, IJOY will not be held responsible for damages that might occur during transportation.
2. To be able to carry out the guarantee it will necessary to have a copy of the proof of purchase, preferably with a copy of the original bill.
3. The repair of the products will be carried out according to the problem reported by the client; therefore it is essential that the client indicates in a clear form and in the most specific way possible where the problem lies, to be able to solve it in the correct manner. In the case that there is not problem with the product a diagnosis and transportation charge can be applied.
4. The client must have carried out a security copy of the data as during the reparation process there exists the possibility that such data may be lost and/or erased. In any case IJOY will not be held responsible for the loss of data contained in hard drives, as well as any other non –original accessory, might there be batteries , memory cards, CD´s DVD´s, etc.
5. In the case that there is no possibility of repair of the product, it can be replaced by another one of similar or superior characteristics, taking into consideration the state in which the product is received, such as usage marks, scratches, etc. In any case the product returned to the customer will have been tested to be functioning correctly.
6. The Guarantee will only cover errors caused by deficiencies in manufacturing, and does not therefore cover damage caused by misuse, modifications or damages caused by accidents of any nature of caused by the client. The guarantee does not cover: Accessories, pieces exposed to normal wear and tea. The Guarantee will not be valid when the product is not used for the purpose for which it was originally conceived.
7. In the case of TFT, there exists what are known as *dead pixels* or *bright dots* (due to the complexity of the manufacturing process), in such cases, there exists a maximum limit permitted by law (ISO 13406/02) that allows this not to be considered defective.
8. The power supplies or chargers and batteries will have a guarantee limited to six months as long as they used within the established operating conditions for the correct usage have not been exposed to power surges.
9. It will be necessary that the equipment has a legible serial number, that the guarantee seal has not been manipulated and in perfect state; that the equipment has all original seals in all components so that the guarantee is valid.
10. The guarantee period starts in the moment of first purchase of the product. The reparation or substitution of the product will not imply an extension of the guarantee period.
11. In the case that the product is not covered by the guarantee, a budget will be drawn up which has to be approved by the client. In the case that the budget is not approved by the client, the client must pay for the cost incurred in the transportation, manipulation and diagnosis of the product.
12. Once the product is repaired after notifying the client, the client will have a period of ten working days to pick up the product. After this period of time, a daily storage charge will be applicable depending on the volume of the product.

### i-Joy

---

C/ Mario Roso de Luna, 31 · P.I. Fin de Semana · 28022-Madrid (Spain)

Tel. +34 902 55 55 60

E-mail: [rma@i-joy.es](mailto:rma@i-joy.es) (Under warranty) | [postventa@i-joy.es](mailto:postventa@i-joy.es) (Technical doubts)

Web: [www.i-joy.es](http://www.i-joy.es)

## FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**FCC RF warning** statement: the device has been evaluated to meet general RF exposure requirement , The device can be used in portable exposure condition without restriction.