



nixplay n
Welcome!

Get to know your frame



- A Motion Sensor**
Senses movement and turns the Cloud Frame ON and OFF
- B Infra-red Sensor**
Receives signals from the remote control


Remote



- C ON / OFF**
Turns Digital Frame on or puts it into standby
- D Playlist**
Display playlists
- E UP / DOWN / LEFT / RIGHT**
Menu navigation / video playback control
- F Play**
Select / Play / Pause
- G Back**
Go back a step
- H Settings**
Go to settings menu

Front

Quick Start Guide




1. Stand Frame using power cable

- ▶ Bend the power cable to stand and support the frame.
- ▶ **IMPORTANT:** Place the frame next to a computer / tablet for the set up process.




2. Plug power cable to adaptor and power source

- ▶ Once plugged in, the frame will automatically start up.
- ▶ When you reach the 'Welcome Screen', please use the **remote** to navigate your frame set up.
- ▶ **IMPORTANT:** The USB cable can only be powered from the supplied power adaptor (5V, 2A). It cannot be plugged into a computer or tablet device.



3. Connect to WiFi network

- ▶ Using the remote, select the WiFi network you wish to connect to and press Play. If required, please enter the WiFi password and select **CONNECT**.
- ▶ **Note:** An automatic software update may take place. Please wait a few minutes and do not switch off or unplug your frame during this process.



4. Add Frame to a Nixplay Cloud Account

- ▶ Once your frame is connected to a WiFi network, please follow the instructions on your frame's display.
- ▶ Please visit www.nixplay.com to create an account and follow the instructions in your browser to complete the set up process (if you are an existing Nixplay user, simply log in to pair your frame).
- ▶ **IMPORTANT:** Please ensure that your computer is using the latest browser version.

Congratulations, you have now successfully activated your frame. Start your Nixplay experience!

For warranty information, please visit our website: www.nixplay.com If you need help, please contact our support team at: <http://support.nixplay.com>

Note: Please find the FCC ID information from "Frame information" under "Setting" menu

Back