
ValveLink[™] Software



Installing ValveLink Software

ValveLink[™] Solo AMS ValveLink[™] SNAP-ON[™] ValveLink[™] DTM ValveLink[™] PLUG-IN for PRM[®]







Comment Form

ValveLink Software Installation Guide

The ValveLink Software Installation Guide is intended to provide the basic information you need to install ValveLink software and associated hardware and software. Detailed information about ValveLink software is provided in the online help.

Please give us your feedback to help us improve this guide.

Did you use this manual to:	Yes	No
Install ValveLink Solo?		
Install AMS ValveLink SNAP-ON?		
Install ValveLink DTM?		
Install ValveLink Plug-In for PRM?		
Install the hardware key or a software license key using the License Wizard?		
Install HART® modem?		
Install HART multiplexer?		
Install FOUNDATION [™] fieldbus hardware and software?		
Setup a Modbus Network?		
Could you easily find the answers to your questions in this manual?		
Could you easily find the answers to your questions In the ValveLink software online help?		
How can we make this manual more useful to yo	ou?	



Identify any areas that you found difficult to unde			
Other comments:			
	Yes	No	
May we contact you about your comments?			
Name			
Company			_
Phone			_
Date			
Thank you for your comments. Fold and mail this form to Fisher Controls International LLC			_
Name			
Company			
Address			

Fisher Controls International LLC

301 S. 1st Avenue

Marshalltown, IA 50158

c/o FIELDVUE Software Product Manager



Table of Contents

Introduction	1-1
What is ValveLink Software?	1-3
About this Guide	1-3
Organization	1-4
Before Installing ValveLink Software	1-5
Technical Support	1-6
Related Documents	1-7
Prerequisites and Requirements	2-1
"Before You Begin" Information	2-2
Installation Tools and Device Documentation	2-3
Personal Computer Requirements	2-4
Compatible Devices	2-7
Installing ValveLink Solo	3-1
ValveLink Solo Installation Overview	3-2
Installing the Software	3-4
Re-installing the Software	
Installing AMS ValveLink SNAP-ON	4-1
AMS ValveLink SNAP-ON Installation Overview	4-2
AMS ValveLink SNAP-ON Installation Overview Installing AMS ValveLink SNAP-ON	
	4-3
Installing AMS ValveLink SNAP-ON	4-3 4-4
Installing AMS ValveLink SNAP-ON	4-3 4-4 5-1
Installing AMS ValveLink SNAP-ON Starting AMS ValveLink SNAP-ON Installing ValveLink DTM ValveLink DTM Installation Overview	4-3 4-4 5-1 5-2
Installing AMS ValveLink SNAP-ON Starting AMS ValveLink SNAP-ON Installing ValveLink DTM ValveLink DTM Installation Overview Installing ValveLink DTM	4-3 4-4 5-1 5-2 5-3
Installing AMS ValveLink SNAP-ON Starting AMS ValveLink SNAP-ON Installing ValveLink DTM ValveLink DTM Installation Overview Installing ValveLink DTM Starting ValveLink DTM	4-3 4-4 5-1 5-2 5-3
Installing AMS ValveLink SNAP-ON Starting AMS ValveLink SNAP-ON Installing ValveLink DTM ValveLink DTM Installation Overview Installing ValveLink DTM	4-3 4-4 5-1 5-2 5-3 5-4
Installing AMS ValveLink SNAP-ON Starting AMS ValveLink SNAP-ON Installing ValveLink DTM ValveLink DTM Installation Overview Installing ValveLink DTM Starting ValveLink DTM Installing ValveLink DTM Installing ValveLink DTM	4-3 4-4 5-1 5-2 5-3 5-4
Installing AMS ValveLink SNAP-ON Starting AMS ValveLink SNAP-ON Installing ValveLink DTM ValveLink DTM Installation Overview Installing ValveLink DTM Starting ValveLink DTM Installing ValveLink DTM Starting ValveLink DTM	4-3 4-4 5-1 5-2 5-3 5-4 6-1 6-2
Installing AMS ValveLink SNAP-ON Starting AMS ValveLink SNAP-ON Installing ValveLink DTM ValveLink DTM Installation Overview Installing ValveLink DTM Starting ValveLink DTM Installing ValveLink DTM ValveLink PLUG-IN for PRM ValveLink PLUG-IN for PRM Installation Overview	4-3 4-4 5-1 5-2 5-3 5-4 6-1 6-2 6-3
Installing AMS ValveLink SNAP-ON Starting AMS ValveLink SNAP-ON Installing ValveLink DTM ValveLink DTM Installation Overview Installing ValveLink DTM Starting ValveLink DTM Installing ValveLink DTM ValveLink PLUG-IN for PRM ValveLink PLUG-IN for PRM Installation Overview Installing ValveLink PLUG-IN for PRM	4-3 4-4 5-1 5-2 5-3 5-4 6-1 6-2 6-3 6-6



Enabling the License of Installed Software	. 7-3
Attaching the Hardware Key	. 7-4
Obtaining a Software License Key for a Fresh Installation	. 7-4
Adding Features to the Installed Software	. 7-8
Obtaining a Software License Key for a StepUp	. 7-9
Removing a License	. 7-11
Transferring a License to Another Computer	. 7-12
Updating a Hardware Key	. 7-13
Enabling a Temporary License	. 7-14
Entering a License Key	. 7-15
HART Modem Installation for ValveLink Solo	8-1
Attaching the HART Modem	. 8-2
Multiplexer Networks for ValveLink	
Solo	9-1
Setting Up a Multiplexer Network	. 9-2
Changing the Multiplexer Tag and Descriptor	. 9-4
Setting Up the Pepperl+Fuchs Multiplexer	. 9-5
Viewing Multiplexers Status	. 9-6
Adding Instruments to a Multiplexer	. 9-8



Installing Software and Hardware for Communication with FOUNDATION fieldbus Instruments for ValveLink
Solo 10-1
NI-FBUS Installation 10-2 Software 10-2 Hardware 10-2
Configuring the PCMCIA-FBUS Card 10-3
Checking for IRQ and Memory Conflicts 10-6
Installing Device Descriptions (DD) 10-7
Connecting to a FOUNDATION Fieldbus Segment 10-9
Connecting to a Single DVC5000f, DVC6000f or DVC6200f Instrument
Modbus Networks for ValveLink Solo 11-1
Setting Up the Modbus Network 11-2
Troubleshooting Installation 12-1
Troubleshooting Communication 13-1
Appendix A Modbus Protocol A-1
Glossary
Index





Section 1 Introduction

This section is an overview of ValveLink software and this guide.

What is ValveLink Software?	1-2
About this Guide	1-3
Organization	1-4
Before Installing ValveLink Software	1-5
Technical Support	1-6
Related Documents	1-7

ValveLink™ Software 1-1



What is ValveLink Software?

ValveLink software is a Windows® software package that communicates with HART and Foundation fieldbus FIELDVUE digital valve controllers. ValveLink software supports access to the information available from DVC2000, DVC6000, DVC6000f, DVC6200, and DVC6200f digital valve controllers, and obsolete DVC5000 and DVC5000f digital valve controllers.

ValveLink Software:

- Communicates with HART instruments (DVC2000, DVC5000, DVC6000 and DVC6200) over the existing 4-20 milliamp (mA) signal wiring via either HART modem or HART multiplexer.
- Communicates with FOUNDATION fieldbus instruments (DVC5000f, DVC6000f, and DVC6200f) over the fieldbus H1 segment via a National Instruments communications card or National Instruments USB fieldbus interface.
 - Integrates data from the HART instruments into a Modbus-compatible host system.
 - Batch Runner or Scheduler automate repetitive actions.
 - Accesses real-time instrument status and diagnostic data.
- Overlays current diagnostic test displays with Signature Series test data collected when the valve was new.
- Monitors control performance during process operations using ValveLink software trending capabilities.
- Maintains a central database and synchronizes other databases using the DataSync tool.
- Supports the automated adjustment of digital valve controller performance using the Performance Tuner.
 - Provides a detailed event log through AuditLog.
- PD Performance Diagnostics provide in-service diagnostics for monitoring the health of the valve assembly without disturbing the process

1-2 ValveLink[™] Software



About This Guide

This installation guide contains easy-to-follow instructions that will guide you through the installation of communications hardware and ValveLink software. Refer to the help system for ValveLink software functions.

Scope

This guide describes:

- Installing ValveLink software. Includes ValveLink Solo, AMS ValveLink SNAP-ON, ValveLink DTM, and ValveLink PLUG-IN for PRM.
- Using License Wizard to enable the license of your ValveLink software, either with a USB hardware key or a software license key.
 - Installing the National Instruments FOUNDATION fieldbus interface software and hardware.
 - Making HART and FOUNDATION fieldbus instrument connections.
 - Setting up multiplexer networks.
 - Setting up Modbus networks.
 - Troubleshooting Installation
 - Troubleshooting Communication

For more detailed information on any of these features, see ValveLink software help.

Customer Feedback Form

Please take a moment to fill out the Customer Feedback Form and return it.

ValveLink™ Software 1-3



Organization

This guide is organized into the following sections:

- Section 1, Introduction, describes ValveLink software and this installation guide for ValveLink Solo, AMS ValveLink SNAP-ON, ValveLink DTM, and ValveLink PLUG-IN for PRM.
- **Section 2**, *Prerequisites and Requirements*, gives "before you begin" information, lists installation tools and device documentation, and charts system requirements.
 - Section 3, Installing ValveLink Solo, explains how to install ValveLink Solo.
- **Section 4,** *Installing AMS ValveLink SNAP-ON*, explains how to install and add AMS ValveLink SNAP-ON to AMS Suite: Intelligent Device Manager.
 - Section 5, Installing ValveLink DTM, explains how to install ValveLink DTM.
- Section 6, *Installing ValveLink PLUG-IN for PRM*, explains how to install and add ValveLink PLUG-IN for PRM to your Plant Resource Manager™ (PRM) application.
- **Section 7**, *License Wizard*, explains the License Wizard program and the use of the hardware key, or the software license key, to enable the ValveLink software license.
- **Section 8,** *Multiplexer Networks for ValveLink Solo,* explains how to set up a multiplexer network and add multiplexers and instruments to a network.
- Section 9, HART Modem Installation for ValveLink Solo, explains how to connect the HART Modem.
- Section 10, Installing Software and Hardware for Communication with FOUNDATION fieldbus instruments for ValveLink Solo, gives installation procedures for the specialized hardware and software required for communication with FOUNDATION fieldbus instruments. Also describes connecting to FOUNDATION fieldbus instruments.
- Section 11, Modbus Networks for ValveLink Solo, explains installation and wiring procedures.
- Section 12, *Troubleshooting Installation*, answers questions you may have about installation.
- Section 13, *Troubleshooting Communication*, answers questions you may have about communication.
 - Appendix A, Modbus Protocol, explains the Modbus data support protocol.

1-4 ValveLink[™] Software



Before Installing ValveLink Software

To successfully install and use ValveLink software, you should:

- Be familiar with the basics of using Microsoft® Windows.
- Be familiar with the installation and function of basic network communications devices and process control instruments.
 - Have experience using AMS Device Manager if installing AMS ValveLink SNAP-ON.
- Have experience using using an FDT frame application if installing ValveLink DTM software.
 - Have experience using PRM if installing ValveLink PLUG-IN for PRM.
- Have knowledge of process control strategies and specific plant operations to be monitored by ValveLink Software.

For more information about ValveLink software installation, contact your Emerson Process Management Local Business Partner.

Find your Local Business Partner online at:

www.fisher.com

Select Sales Contacts.



Note

Neither Emerson, Emerson Process Management, nor any of their affiliated entities assumes responsibility for the selection, use, or maintenance of any product. Responsibility for the selection, use, and maintenance of any product remains with the purchaser and end user.

ValveLink™ Software 1-5



For Technical Support

If you have problems or questions that you cannot resolve while using ValveLink software guides or help, ValveLink software technical assistance is available.

Support Directory

For ValveLink software Technical Support, contact your Local Business Partner.

Find them online at:

www.valvelink.com

and select Contact Sales.

Educational Services

For information on available courses for ValveLink software, as well as a variety of other products contact:

Emerson Process Management Educational Services, Registration P.O. Box 190; 301 S. 1st Ave. Marshalltown, IA 50158–2823 Phone: 800–338–8158 or

Phone: 641–754–3771 FAX: 641–754–3431

e-mail: education@emersonprocess.com

Software updates

For software updates contact your Local Business Partner.

1-6 ValveLink[™] Software



Related Documents

- FIELDVUE DVC2000 Digital Valve Controller Instruction Manual (D103176X012)
- FIELDVUE DVC2000 Digital Valve Controller Quick Start Guide (D103203X012)
- FIELDVUE DVC5000 Series Digital Valve Controller Instruction Manual (D200442X012) (Obsolete product. Contact your Emerson Process Management sales office if a copy of this manual is needed.)
- FIELDVUE DVC5000 Series Digital Valve Controllers Quick Start Guide (D102700X012) (Obsolete product. Contact your Emerson Process Management sales office if a copy of this manual is needed.)
- FIELDVUE DVC5000f Series Digital Valve Controllers for FOUNDATION fieldbus Instruction Manual (D102634X012) (Obsolete product. Contact your Emerson Process Management sales office if a copy of this manual is needed.)
- FIELDVUE DVC5000f Series Digital Valve Controllers Quick Start Guide (D102819X012) (Obsolete product. Contact your Emerson Process Management sales office if a copy of this manual is needed.)
 - FIELDVUE DVC6000 Digital Valve Controllers Instruction Manual (D102794X012)
 - FIELDVUE DVC6000 Digital Valve Controllers Quick Start Guide (D102762X012)
- FIELDVUE DVC6000 SIS Digital Valve Controllers for Safety Instrumented System (SIS) Solutions Instruction Manual (D103230X012)
- FIELDVUE DVC6000 SIS Digital Valve Controller for Safety Instrumented System (SIS) Solutions Quick-Start Guide (D103307X012)
 - FIELDVUE DVC6000f Digital Valve Controllers Instruction Manual (D103189X012)
 - FIELDVUE DVC6000f Digital Valve Controllers Quick Start Guide (D103202X012)
 - FIELDVUE DVC6200 Digital Valve Controller Quick Start Guide (D103410X012)
 - FIELDVUE DVC6200 Digital Valve Controller Instruction Manual (D103409X012)
 - FIELDVUE DVC6200f Digital Valve Controller Quick Start Guide (D103413X012)
 - FIELDVUE DVC6200f Digital Valve Controller Instruction Manual (D103412X012)

The following documentation is available from National Instruments.

- Getting Started with Your PCI-FBUS and the NI-FBUS™ Software
- Getting Started with Your PCMCIA-FBUS and the NI-FBUS Software

ValveLink™ Software 1-7



1-8 ValveLink[™] Software



Section 2 Prerequisites and Requirements

This section is an overview of prerequisites and requirements for installation of ValveLink software.

"Before You Begin" Information	2-2
Installation Tools and Device Documentation	2-3
Personal Computer Requirements	2-4
Supported Operating Systems	2-6
Compatible Devices	2-7
Installation Options for Valvel ink Software	2-8

ValveLink™ Software 2-1



Before You Begin

The complete ValveLink software installation process includes several steps, some of them dependent on the personal computer system that will run ValveLink software and its configuration. In order to successfully install and run ValveLink software, it is important that you follow all of the appropriate steps covered in this installation guide.

Prior to beginning installation, you should:

- Verify that your personal computer system meets the hardware and software requirements specified in this section.
 - Assemble necessary installation tools and documentation.

2-2 ValveLink™ Software



Installation Requirements

Before you begin the installation procedure outlined in this guide, make sure you have the following items available:

- ValveLink software installation media (CD-ROM)
- AMS Suite: Intelligent Device Manager v8.0 or later if installing AMS ValveLink SNAP-ON
 - Frame application supporting FDT 1.2 and addendum if installing ValveLink DTM
 - Yokogawa Plant Resource Manager (PRM) if installing ValveLink PLUG-IN for PRM
- Licensing USB hardware key, if available. If not, you will need to request a software license key for licensing a new installation.
 - Any hand tools (such as a screwdriver) needed for installing communications hardware
- Communications hardware such as the HART modem, and any necessary wires, cables, or other equipment specified in the device documentation for the HART instruments.
- Personal computer with a serial and USB port for connecting to a modem or HART multiplexer network. Additional serial and USB ports are required for communicating on more HART multiplexer networks or to a Modbus network.
- HART multiplexer and RS232-to-RS485 converter, if the ValveLink software has multiplexer capability and you are planning to communicate to the instruments over a HART multiplexer network
 - HART modem, if you are going to communicate with one HART instrument or
 Communications hardware and software for the FOUNDATION fieldbus instruments such as the National Instruments PCI-FBUS board or PCMCIA-FBUS card or USB fieldbus interface and NI-FBUS software.
- Personal computer with a PCI slot for an FBUS board or a PCMCIA-compatible notebook computer for a PCMCIA-FBUS card.
- DVC5000f and DVC6000f Device Descriptions (DD). These DD's are available on the ValveLink software installation CD or from the following Internet address:

www.fieldvue.com

and select Digital Valve Controller, then HART & Fieldbus Device Descriptions.

ValveLink™ Software 2-3



Personal Computer Requirements

ValveLink software, v11.1, has been tested on computers manufactured by Dell, Inc. However, ValveLink software runs on any personal computer or notebook computer equipped with the following software and hardware features.



Note

ValveLink software, v11.1, will not run on a personal computer using the Windows 95 operating system and is not supported on Windows 98, Windows Me, or Windows NT operating systems.

Computer and Processor

- 800 megahertz (MHz) processor (Windows 2000/Windows XP/Windows Server® 2003)
- 1 gigahertz (GHz) processor (Windows Vista® operating system/Windows Server 2008/Windows 7)

Memory

- 256 megabytes (MB) RAM (Windows 2000/Windows XP/Windows Server 2003)
- 1 gigabyte (GB) RAM (Windows Vista/Windows Server 2008/Windows 7)

Hard disk

- No Trending 65 Megabytes of free space
- Trending 125 Megabytes of free space

Drive

CD-ROM Drive

Display

- 1024 X 768 resolution,
- 256 color

1/0

- Product licensing and device step-ups require one of the following: USB Port Parallel Port
- HART communications require at least one of the following interfaces:
 HART Modem Standard RS-232 Port (requires dedicated interrupt)
 HART Multiplexer Standard RS-232 Port (requires RS-485 convertor)
 MACTek VIATOR USB HART Modem USB Port
 MACTek VIATOR Bluetooth HART Interface Windows Bluetooth Serial
 Port Profile (SPP)
 ProComSol Bluetooth HART Interface Windows Bluetooth SPP

2-4 ValveLink™ Software



- Modbus communications require the following Standard RS-232 Port Additional HART Interface (see above)
- FOUNDATION Fieldbus communications require at least one of the following National Instruments Fieldbus H1 interfaces: NI USB-8486

NI USB-8486 PCI-FBUS/2 PCMCIA-FBUS/2 Series 2



Note

Desktop PCs typically require a PCI interface; laptop PCs require a PCMCIA interface.

NI-FBUS Configuration – 2 Port Card

The following settings are applicable for configuration of a NI-FBUS 2 Port Card:

- a) If only one port will be connected to a LIVE segment, the other port must be set to "LAS" (not "Bus Monitor").
- b) If both ports will be connected to LIVE segments, then both ports must be set to "Basic" mode.

NI driver software must be installed BEFORE installing the NI hardware.

Other configurations may result in initialization failure of the Blue Box.

ValveLink™ Software 2-5



Supported Operating Systems

ValveLink Solo

• Windows 2000, Windows XP, Windows Vista, Windows 7 operating systems (32 bit), Windows Server 2003 and Windows Server 2008.

AMS ValveLink SNAP-ON

Operating Systems supported by AMS Suite: Intelligent Device Manager v8.1 and later

ValveLink DTM

• FDT Frame application using Windows 2000, Windows XP, Windows Vista, Windows 7 (32 bit), Windows Server 2003, and Windows Server 2008.

ValveLink PLUG-IN for PRM

- Operating Systems supported by Yokogawa Plant Resource Manager (PRM) v3.02 or newer
 - The DVC5000 digital valve controller is not supported on ValveLink PLUG-IN for PRM.



Note

ValveLink software will not run on a personal computer using the Windows 95 operating system and is not supported on Windows 98, Windows Me, or Windows NT operating systems.

2-6 ValveLink™ Software



Compatible Devices

ValveLink Software communicates with:

- HART-based DVC2000, DVC6000, DVC6200, or obsolete DVC5000 digital valve controllers via a HART modem or HART multiplexers
- FOUNDATION fieldbus DVC6000f or DVC6200f digital valve controllers or obsolete DVC5000f digital valve controllers (with firmware revision 7 or later) over an H1 segment.

After reading this section, continue to page 3-2 for ValveLink Solo installation instructions, page 4-2 for AMS ValveLink SNAP-ON installation instructions, page 5-2 for ValveLink DTM, and page 6-2 for ValveLink PLUG-IN for PRM installation instructions.

ValveLink™ Software 2-7



Installation Options for ValveLink Software

Installation options for ValveLink software include:

- ValveLink Solo
- AMS ValveLink SNAP-ON
- ValveLink DTM
- ValveLink PLUG-IN for PRM



Note

ValveLink Solo, ValveLink DTM, and ValveLink PLUG-IN for PRM cannot be installed on the same PC.

• ValveLink Solo and AMS ValveLink SNAP-ON installed on the same PC.

At the beginning of the installation process, you can specify how you want the software installed. Refer to figure 2-1 for the ValveLink Software Welcome Window.




Figure 2-1. ValveLink Software Installation Welcome Window

2-8 ValveLink™ Software



Section 3 Installing ValveLink Solo

This section describes ValveLink Solo installation.

ValveLink Solo Installation Overview	3-2
Installing the Software	3-4
Re-installing the Software	3-6

ValveLink™ Software 3-1



ValveLink Solo Installation Overview

For further information about ValveLink Solo software and hardware installation:

- For using the License Wizard program, see page 7-2.
- A USB hardware key may be used for the licensing of ValveLink Solo. See page 7-4 for instructions on attaching the USB hardware key.
- If a USB hardware key is not available, a software license key is needed to enable the license of ValveLink Solo. See page 7-4 for instructions on obtaining a software license key.
 - For connecting the HART modem, see page 8-2.
- For installing the HART Interchange multiplexers and connecting field devices to the multiplexers, refer to the appropriate multiplexer instruction manual. For information about installing HART filters, refer to the appropriate HART filter instruction manual.
- For setting up ValveLink software to communicate with a HART multiplexer network, see page 9-2.
 - For installing the NI-FBUS hardware and software, see page 10-2.
 - For connecting to a FOUNDATION fieldbus instrument or H1 segment, see page 10-9.

Fill out the registration form that comes with your software and email or fax the form to Emerson Process Management.

Table 3-1 shows ValveLink Solo capabilities.

3-2 ValveLink™ Software



Table 3-1. ValveLink Solo Capabilities

				Software		
Capability		VL2001 VL2005 VL2010 VL2021 VL2031				
Саравину	,	Database only	Lite Version 5 tags	In-Service only	Modem Version	Multiplexer Version
Initial Database Tags		Unlimited	5	125	125	32 or 125
HART Modem			•	•	•	•
HART Multiplexer				•		•
Foundation fieldbus H1 PC Card			•	•	•	•
FOUNDATION fieldbus National Instrument USB-8	3486 Interface		•	•	•	•
	Valve Signature	•	•	0	•	•
	Dynamic Error Band	•	•	0	•	•
	Drive Signal Test	•	•	0	•	•
Advanced Diagnostics	Step Response	•	•	0	•	•
Note: Advanced Diagnostics can only be run when the instrument is out of service.	Step Response Analysis and Overlay	•	•	0	•	•
when the instrument is out of service.	Performance Step Test	•	•	0	•	•
	Status Monitor	•	•	•	•	•
	Stroke Valve	•	•	0	•	•
	I/P & Relay Integrity	•	•	•	•	•
	Travel Deviation	•	•	•	•	•
	Supply Pressure (DVC6000/DVC6200 only)	•	•	•	•	•
Performance Diagnostics	Relay Adjustment (DVC6000/DVC6200 only)	•	•	•	•	•
Note: Performance Diagnostics are available	Air Mass Flow (DVC6000/DVC6200 only)	•	•	•	•	•
for DVC5000, DVC6000, and DVC2000 digital valve controllers when using	One Button Diagnostic	•	•	•	•	•
ValveLink Solo.	Valve Friction/ Deadband Estimation	•	•	•	•	•
	Valve Friction/ Deadband Trending	•	•	•	•	•
	Profiler	•	•	•	•	•
	Triggered Profile	•	•	•	•	•
SIS Support (includes SIS Partial Stroke) (DVC6000/DVC6200 only)		•	•	•	•	•
Network Scan (HART only)			•	•	•	•
Trending (HART only)		•	•	•	•	•
Event Messenger (HART only)			•	•	•	•
Modbus Interface (HART only)			•	•	•	•
Batch Runner			•	•	•	•
Scheduler			•	•	•	•
DataSync		•	•	•	•	•
Firmware Download (DVC6200, DVC6200f, D	VC6000, DVC6000f, DVC2000 only)		•	•	•	•
Temporary Instrument Level SetUp	•		•	•	•	•
Instrument Level StepUp			•	•	•	•
 indicates capability available indicates Advance Diagnostics can be reviewed be 	out not run	1				

ValveLink™ Software 3-3

Installing ValveLink Solo



Note

You cannot copy the installed program files to another computer or to another directory or hard disk. ValveLink Solo will not work if the installed program files are copied to another computer, directory, or hard disk.

You cannot move installed programs to another computer; doing so will invalidate your ValveLink software license.



Note

To install ValveLink Solo on a personal computer running Windows 2000, Windows XP, Windows 7, Windows Server 2003, or Windows Vista operating system, you must log on as Administrator or as a user with Administrator privileges. If installing on Windows Server 2003 parallel ports are not used, and a soft license is required.



Note

Default user name and password for ValveLink Solo:

User Name: MANAGER Password: FALCON

For full access to ValveLink Solo features you must discontinue use of the default name and password. Create security groups and assign new user names and passwords, then logout and login as a new user. Refer to the ValveLink Software Quick Start Guide (D102813X012) for information on adding a new security group.

Step 1: Close all applications on your desktop.

3-4 ValveLink™ Software



Step 2: Insert the CD into the CD drive of your computer.

If the drive's auto run is enabled, the install wizard will start automatically. Follow the prompts on the screen to start the installation process.

If auto run is disabled, start the install from the run window; Select Start > Run from the taskbar. In the text box, type D:SETUP.EXE (where D is the CD-ROM drive letter). Click OK and follow the prompts.

- Step 3: In the ValveLink software installation Welcome window displays as shown in figure 2-1 select the desired installation(s) and click Next to continue.
- **Step 4:** Follow the prompts on screen to finish the installation.
- Step 5: If you are installing ValveLink Solo for the first time, you will be prompted to run the License Wizard at the end of the installation process, as shown in figure 3-1. Select OK, and follow the prompts on the screen, or select Cancel, and run the License Wizard later. Note that you are not able to run ValveLink Solo without a valid license. See Section 7 for details on running the License Wizard.



Figure 3-1. Run the License Wizard

ValveLink™ Software 3-5



Re-installing the Software

If you are re-installing ValveLink Solo, remember:

- It is not necessary to uninstall a previous version of the program.
- The version you are installing will overwrite an older version of the program and use the existing license.
- Restart your computer before running the ValveLink software installation program so a complete, clean installation is possible.
 - The ValveLink software installation process allows you to save an existing database.

3-6 ValveLink™ Software



Section 4 Installing AMS ValveLink SNAP-ON

This section describes the installation of AMS ValveLink SNAP-ON.

AMS ValveLink SNAP-ON Installation Overview	4-2
nstalling AMS ValveLink SNAP-ON	4-3
Starting AMS ValveLink SNAP-ON	4-4

ValveLink™ Software 4-1



AMS ValveLink SNAP-ON Installation Overview

AMS ValveLink SNAP-ON is a software application that is installed as an integral part of AMS Suite: Intelligent Device Manager to extend its functionality. AMS ValveLink SNAP-ON adds the diagnostic test capabilities of ValveLink software to AMS Device Manager.

• A USB hardware key is not used for installing AMS ValveLink SNAP-ON. However, AMS Device Manager must be licensed for the AMS ValveLink SNAP-ON.

Table 4-1 shows AMS ValveLink SNAP-ON capabilities.

Table 4-1. AMS ValveLink SNAP-ON Capabilities

A 1111		Product Type
Capability		AW7070VLXXXXX
Min Tag Limit		25
Max Tag Limit		2000 (unlimited)
HART Modem		● (1)
HART Multiplexer		● (1)
Foundation Fieldbus Ovation H1		•
Foundation Fieldbus DeltaV H1		•
	Valve Signature Test	•
	Dynamic Error Band	•
Advanced Diagnostics	Drive Signal Test	•
Advanced Diagnostics	Step Response	•
Note: Advanced Diagnostics can only be run when	Step Response Analysis and Overlay	•
the instrument is out of service.	Performance Step Test	•
	Status Monitor	•
	Stroke Valve	•
	I/P & Relay Integrity	•
Performance Diagnostics	Travel Deviation	•
Note: Performance Diagnostics are available for	Supply Pressure (DVC6000/DVC6200 only)	•
DVC5000, DVC6000, and DVC2000 digital valve	Relay Adjustment (DVC6000/DVC6200 only)	•
controllers when using ValveLink Solo and AMS	Air Mass Flow (DVC6000/DVC6200 only)	•
Device Manager, including the HART Multiplexer	One Button Diagnostic	•
Interface. Performance Diagnostics are available for DVC6000 and DVC2000 digital valve controllers	Valve Friction / Deadband Estimation	•
when using the AMS System Interface with Ovation,	Valve Friction / Deadband Trending	•
PROVOX, or DeltaV control systems.	Profiler	•
	Triggered Profile	•
SIS Support (Includes SIS Partial Stroke Test) (DVC6	000/DVC6200 only)	•
Batch Runner		•
Scheduler		•
Firmware Download		•
Temporary Instrument Level StepUp		•
Instrument Level StepUp		•
● indicates capability available	<u> </u>	
1. AMS based capability. AMS ValveLink SNAP-ON does n	ot control or limit this functionality.	

4-2 ValveLink™ Software



Installing AMS ValveLink SNAP-ON

To install AMS ValveLink SNAP-ON, you must first have installed a properly licensed copy of AMS Device Manager. Then, follow the steps below to install AMS ValveLink SNAP-ON.



Note

To install AMS ValveLink SNAP-ON, you must log on to the PC running AMS Device Manager as Administrator or as a user with Administrator privileges.

- **Step 1:** Close all open applications on your desktop.
- Step 2: Insert the CD with AMS ValveLink SNAP-ON into the CD-ROM drive of your computer.

If the drive's auto run is enabled, the install wizard will start automatically. Follow the prompts on the screen to start the installation process.

If auto run is disabled, start the install from the run window; Select Start>Run from the taskbar. In the text box, type D:SETUP.EXE (where D is the CD-ROM drive letter). Click OK and follow the prompts to start the installation process.

- **Step 3:** In the ValveLink software Welcome window shown in figure 2-1, select the desired installation(s) and click Next. See page 2-8 for valid installation combinations.
- **Step 4:** In the next window, confirm the folder where AMS ValveLink SNAP-ON will be installed. Click OK to continue.
- **Step 5:** A progress bar displays as AMS ValveLink SNAP-ON is installed. Follow the prompts on the screen to finish the installation.

ValveLink™ Software 4-3



Starting AMS ValveLink SNAP-ON

Follow these steps to start AMS ValveLink SNAP-ON:

CAUTION

Do not run ValveLink Solo at the same time you are using AMS Device Manager or AMS ValveLink SNAP-ON. Running both simultaneously may cause communication errors.



Note

To successfully use AMS ValveLink SNAP-ON, you must be familiar with using AMS Device Manager. Refer to the AMS online User's Guide and online Help for information.

- **Step 1:** Start AMS Device Manager by selecting Start> Programs > AMS > AMS system from the Windows taskbar.
- **Step 2:** In the AMS User Login window (figure 4-1), enter the correct Username and Password. Click OK to continue.



Figure 4-1. Logon to the AMS System

Continue on with Step 3 to select a HART device. Go to Step 6 if selecting a fieldbus device.

4-4 ValveLink™ Software



HART Device:

- **Step 3:** The AMS Explorer or Device Connection View window (figure 4-2) displays.
- Step 4: AMS displays the communication devices (modem, multiplexer) that are connected to the PC running AMS and the AMS ValveLink SNAP-ON. Right-click the device icon and select Scan All Devices to locate connected HART instruments.




Figure 4-2. AMS Device Manager Device Connection View

Step 5: When a DVC2000, DVC5000, DVC6200 or DVC6000 icon appears, right-click the instrument icon as shown in figure 4-3 and select SNAP-ON/Linked Apps > ValveLink from the context menu.




Figure 4-3. Right-Click Communications Device Icon to Open Menu

ValveLink™ Software 4-5



Fieldbus Device:

Step 6: In the Device View Connection window, right click the instrument icon and select SNAP-ON/Linked Apps > ValveLink from the context menu as shown in figure 4-4.




Figure 4-4. Starting AMS ValveLink SNAP-ON (Fieldbus Device)

4-6 ValveLink™ Software



Section 5 Installing ValveLink DTM

This section describes the installation of ValveLink DTM.

ValveLink DTM Installation Overview	5-2
nstalling ValveLink DTM	5-3
Starting ValveLink DTM	5-4

ValveLink™ Software 5-1



ValveLink DTM Installation Overview

The ValveLink DTM is part of an open solution for field device management that enables configuration, monitoring, calibration, diagnostics and testing of FIELDVUE digital valve controllers.

• A USB hardware key or a software license key is required for enabling the license of ValveLink DTM software.



Note

Frame application supporting FDT 1.2 and addendum is required.

Table 5-1 shows ValveLink DTM capabilities.

Table 5-1. ValveLink DTM Capabilities

O-makilli		Product Type		
Capabili				
Min Tag Limit		Unlimited		
Max Tag Limit		Unlimited		
	Valve Signature Test	•		
	Dynamic Error Band	•		
Advanced Diagnostics	Drive Signal Test	•		
Advanced Diagnostics	Step Response	•		
Note: Advanced Diagnostics can only be run when	Step Response Analysis and Overlay	•		
the instrument is out of service.	Performance Step Test	•		
	Status Monitor	•		
	Stroke Valve	•		
	I/P & Relay Integrity	•		
Performance Diagnostics	Travel Deviation	•		
ŭ	Supply Pressure (DVC6000/DVC6200 only)	•		
Note: Performance Diagnostics are available for DVC5000, DVC6000, and DVC2000 digital valve	Relay Adjustment (DVC6000/DVC6200 only)	•		
controllers when using ValveLink Solo and AMS Device	Air Mass Flow (DVC6000/DVC6200 only)	•		
Manager, including the HART Multiplexer Interface.	One Button Diagnostic	•		
Performance Diagnostics are available for DVC6000 and DVC2000 digital valve controllers when using the	Valve Friction / Deadband Estimation	•		
AMS System Interface with Ovation, PROVOX, or	Valve Friction / Deadband Trending	•		
DeltaV control systems.	Profiler	•		
	Triggered Profile	•		
SIS Support (Includes SIS Partial Stroke Test) (DVC60	00/DVC6200 only)	•		
Batch Runner	•			
Firmware Download		•		
Temporary Instrument Level StepUp		•		
Instrument Level StepUp		•		
indicates capability available				

5-2 ValveLink™ Software



Installing ValveLink DTM

To install ValveLink DTM:



Note

A USB hardware key or a software license key is required for installation of ValveLink DTM software. If available, locate the USB hardware key to use while running the License Wizard. If a USB hardware key is not available, see Section 7 for instructions for obtaining a software license key. For instructions on attaching the USB hardware key see page 7-4 of this Installation Guide.

- **Step 1:** Close all open applications on your desktop.
- Step 2: Insert the CD containing the ValveLink software installation files into the CD drive of your computer. If the drive's auto run is enabled, the install wizard will start automatically. Follow the prompts on the screen to start the installation process.

If auto run is disabled, start the install from the run window; Select Start > Run from the taskbar. In the text box, type D:SETUP.EXE (where D is the CD-ROM drive letter). Click OK and follow the prompts.

- **Step 3:** Click Next to begin the installation process. The ValveLink software installation Welcome window displays as shown in figure 2-1. Select ValveLink DTM.
- **Step 4:** Follow the screen prompts to finish installation.
- Step 5: If you are installing ValveLink DTM software for the first time, you will be prompted to run the License Wizard at the end of the installation process. Select OK and follow the prompts on the screen, or select Cancel to run the License Wizard later. See Section 7 for details on running the License Wizard.
- **Step 6:** Update the DTM catalog in the frame application after installation.

ValveLink™ Software 5-3



Starting ValveLink DTM

Follow these steps to start the ValveLink DTM:



Note

To successfully use the ValveLink DTM, you must be familiar with using the FDT frame application used to launch the ValveLink DTM. This section covers one example. Refer to the users guide for the FDT frame application that the ValveLink DTM is installed with for additional information.

- **Step 1:** Start the FDT frame application.
- Step 2: Select Add Device, as shown in figure 5-1, and click on the appropriate CommDTM. Select OK.




Figure 5-1. Select Add Device to Add the CommDTM

5-4 ValveLink™ Software



Step 3: With the CommDTM highlighted, select Add Device, as shown in figure 5-2, and click on the appropriate Device DTM. Select OK.




Figure 5-2. Select the DeviceDTM

Step 4: Set the appropriate settings for the CommDTM and DeviceDTM (see figure 5-3 and 5-4).




Figure 5-3. Setting the CommDTM

ValveLink™ Software 5-5






Figure 5-4. Setting the DeviceDTM

Step 5: With the DeviceDTM highlighted, select Connect as shown in figure 5-5.




Figure 5-5. Connect the DeviceDTM

5-6 ValveLink™ Software



Step 6: Once connected, select ValveLink DTM as shown in figure 5-6.




Figure 5-6. Select ValveLink DTM

ValveLink™ Software 5-7



Step 7: The ValveLink DTM will launch in a new window. All devices currently connected in the FDT frame application will show in the tree menu to the left of the ValveLink DTM window, as shown in figure 5-7. Double-click the device to open the device tag.




Figure 5-7. ValveLink DTM

5-8 ValveLink™ Software



Section 6 Installing ValveLink PLUG-IN for PRM

This section describes the installation of ValveLink PLUG-IN for PRM.

ValveLink PLUG-IN for PRM	
Installation Overview	6-2
Installing ValveLink PLUG-IN for PRM	6-3
Starting Valvel ink PLUG-IN for PRM	6-6

ValveLink™ Software 6-1



ValveLink PLUG-IN for PRM Installation Overview

ValveLink PLUG-IN for PRM is a software application that is installed as an integral part of Plant Resource Manager (PRM) to enhance system functionality. ValveLink PLUG-IN for PRM adds the diagnostic test capability of ValveLink Software to PRM.

• A USB hardware key or a software license key is required for enabling the license of ValveLink PLUG-IN for PRM.

Table 6-1 shows ValveLink PLUG-IN for PRM capabilities.

Table 6-1. ValveLink PLUG-IN for PRM Capabilities

		Product Type		
Capability Min Tag Limit		VL2021PRM		
		Unlimited		
Max Tax Limit		Unlimited		
Foundation fieldbus PRM/Centum H1		•		
	Valve Signature	•		
	Dynamic Error Band	•		
Advanced Diagnostics	Drive Signal Test	•		
Advanced Diagnostics	Step Response	•		
Note: Advanced Diagnostics can only be run when	Step Response Analysis and Overlay	•		
the instrument is out of service.	Performance Step Test	•		
	Status Monitor	•		
	Stroke Valve	•		
	I/P & Relay Integrity	•		
	Travel Deviation	•		
Performance Diagnostics	Supply Pressure (DVC6000/DVC6200 only)	•		
	Relay Adjustment (DVC6000/DVC6200 only)	•		
	Air Mass Flow (DVC6000/DVC6200 only)	•		
	One Button Diagnostic	•		
	Valve Friction / Deadband Estimation	•		
	Valve Friction / Deadband Trending	•		
	Profiler	•		
	Triggered Profile	•		
SIS Support (includes SIS Partial Stroke) (DVC60	00/DVC6200 only)	•		
Batch Runner		•		
DataSync		•		
Firmware Download		•		
Temporary Instrument Level StepUp		•		
Instrument Level StepUp		•		
indicates capability available				

6-2 ValveLink™ Software



Installing ValveLink PLUG-IN for PRM

To install ValveLink PLUG-IN for PRM:



Note

ValveLink PLUG-IN for PRM requires PRM 2.06 or later.



Note

A USB hardware key or a software license key is required for the installation of ValveLink PLUG-IN for PRM. If available, locate the hardware key to use while running the License Wizard. If a USB hardware key is not available, see Section 7 for instruction for obtaining a software license key. For instructions on attaching the USB hardware key, see page 7-4 in this document.

- **Step 1:** Close all open applications on your desktop.
- **Step 2:** Insert the CD containing the ValveLink software installation files into the CD drive of your computer.

If the drive's auto run is enabled, the install wizard will start automatically. Follow the prompts on the screen to start the installation process.

If auto run is disabled, start the install from the run window; Select Start > Run from the taskbar. In the text box, type D:SETUP.EXE (where D is the CD-ROM drive letter). Click OK and follow the prompts.

- Step 3: Click Next to begin the installation process. The ValveLink software installation Welcome window displays as shown in figure 2-1. Select ValveLink PLUG-IN for PRM from the installation Welcome window.
- **Step 4:** After making your selection, click Next to continue. In the next window, choose the location of the folder that will receive the ValveLink PLUG-IN for PRM installation. Click Next to continue.
- **Step 5:** If you are upgrading ValveLink PLUG-IN for PRM continue with Step 6. If this is a new installation, continue on with Step 8.
- Step 6: Setup will indicate that it has found a licensed version of ValveLink software, and ask if you would like to upgrade/reinstall this copy. Select yes to continue.

ValveLink™ Software 6-3



Step 7: You are given the option to keep the old database or to replace the existing database, as shown in figure 6-1. After making your selection, click Next to continue.




Figure 6-1. Existing Database

Step 8: A progress bar displays as ValveLink PLUG-IN for PRM is installed as shown in figure 6-2.



Figure 6-2. Progress Bar

Step 9: At the end of the installation process, Installation will automatically register ValveLink PLUG-IN for PRM with PRM by running the batch file, as shown in figure 6-3. No user action is required.




Figure 6-3. Batch File

6-4 ValveLink™ Software



Step 10: If you are installing ValveLink PLUG-IN for PRM for the first time, you will be prompted to run the License Wizard at the end of the installation process. Select OK and follow the prompts on the screen, or select Cancel and run the License Wizard later. See Section 7 for details on running the License Wizard.



Figure 6-4. Run License WIzard

ValveLink[™] Software 6-5



Starting ValveLink PLUG-IN for PRM

Follow these steps to start ValveLink PLUG-IN for PRM:



Note

To successfully use ValveLink PLUG-IN for PRM, you must be familiar with using PRM software.

- **Step 1:** Run the PRM application.
- **Step 2:** Select a Fisher fieldbus digital valve controller from the PRM system.
- Step 3: Click on the PLUG-IN tab. Move the mouse cursor to the white list box, as shown in figure 6-5 and right-click. Select the Insert Ctrl+Ins option.




Figure 6-5. PLUG-IN Tab

6-6 ValveLink™ Software



Step 4: Select ValveLink PLUG-IN Launcher from the Tool Name dialog box and click on the OK button.




Figure 6-6. Tool Name Dialog Box

Step 5: Select ValveLink PLUG-IN Launcher and click on execute to start ValveLink PLUG-IN for PRM.




Figure 6-7. Starting ValveLink PLUG-IN Launcher

ValveLink[™] Software 6-7



6-8 ValveLink™ Software



Section 7 ValveLink License Wizard

This section describes the ValveLink License Wizard

ValveLink License Wizard 7-:	2
Enabling the License of Installed Software	4 4
Adding Features to the Installed Software 7-	8
Obtaining a Software License Key for a StepUp 7-	9
Removing a License	11
Transferring a License to another Computer 7-	12
Updating a USB hardware key 7-	13
Enabling a Temporary License 7-	14
Entering a License Key	15

ValveLink™ Software 7-1



ValveLink License Wizard

ValveLink License Wizard is a utility that assists you to enable and administer the license of your ValveLink software.

The License Wizard program is used to:

- Activate the ValveLink software license from an installation USB hardware key or from a software license key.
- Increase the capabilities of the installed ValveLink software. A separate StepUp USB hardware key or a software license key is required to increase the tag limit or add features to the installed software.
- Remove the license from the installed software to restore the license to the original installation USB hardware key.
- Transfer the license from ValveLink software installed on one computer to the ValveLink software installed on another computer.
- Identify the type of USB hardware key and the features available in the USB hardware key.
 - Enable a license temporarily for a maximum period of five (5) days.
- Generate a registration request form that can be e-mailed or faxed to the ValveLink Registration Center to obtain software license keys.

In addition, License Wizard can also be used to save your license information to a file or print your license information.

7-2 ValveLink™ Software



Enabling the License of Installed Software

ValveLink License Wizard can be used to enable the license of installed ValveLink software. A valid installation USB hardware key or a software license key is required to enable the license of installed ValveLink software. See figure 7-1.



Figure 7-1. Installation USB Hardware Key or Software Licensing

ValveLink™ Software 7-3



To enable the license using an installation USB hardware key:

- **Step 1:** Attach your installation USB hardware key to the computer, as shown in figure 7-2.
- **Step 2:** Run License Wizard and click on the New License button.
- Step 3: Select the Generate license using installation hardware key option button (see figure 7-1), and click Next. Follow the License Wizard steps as directed.

To generate a registration form to obtain a software license key for a new license:

- **Step 1:** Unplug any USB hardware keys attached to computer.
- **Step 2:** Run License Wizard and click on the New License button.
- **Step 3:** Select the Generate License using the Software Licensing option button (see figure 7-1). Follow the License Wizard steps as directed.
- Step 4: Attach the .txt file containing the registration form generated by the License Wizard, shown in figure 7-3, to an e-mail and send to the e-mail address shown on the form. If e-mail is not available, fax the form to the number shown on the registration form.




Figure 7-2. Attaching the USB Hardware Key

7-4 ValveLink™ Software





Figure 7-3. ValveLink License Wizard Registration

- **Step 5:** After receiving the license keys, re-run License Wizard, and continue on with Step 6.
- **Step 6:** Click on the Enter License Key button and either import or manually enter the license key received from the ValveLink Registration Center. Follow the License Wizard steps as directed.

ValveLink[™] Software 7-5



Software Features

After running License Wizard, the next screen lists the available software features. After confirming that the appropriate features are enabled in your software, select "Yes. I would like to proceed with the above features.", then click Next.




Figure 7-4. Available Software Features

- HART—When YES, enables communication with a DVC2000, DVC5000, DVC6000, or DVC6200 digital valve controller using a HART modem or over a HART multiplexer network.
- Foundation Fieldbus—When YES, enables communication with a DVC5000f, DVC6000f, or DVC6200f digital valve controller over a FOUNDATION fieldbus H1 segment.
- **Multiplexer**—When YES, allows communicating with FIELDVUE HART instruments over a serial port through HART multiplexers.



Note

ValveLink software that can communicate via HART protocol can communicate through a HART modem or multiplexer.

ValveLink Software can support up to 32 multiplexers per serial port. The software also can support communication on a Modbus network.

• Lite—When YES, you cannot copy tags or create reference tags by creating a tag or modifying an existing tag.

7-6 ValveLink™ Software



- Step Response—When YES, allows running a step response diagnostic test, when the user has the diagnostic privilege. The availability of this level is not dependent upon the availability of the standard diagnostics level.
- Valve Signature—When YES, allows running a valve signature diagnostic test, when the user has the diagnostic privilege and the instrument level is AD. The availability of this level is not dependent upon the availability of the standard diagnostics level.
- Calibration—When YES, allows using ValveLink software to calibrate the instrument, when the user has the calibrate instrument privilege.
- Standard Diagnostics—When YES, enables running any of the diagnostic tests except step response and valve signature. Step response and valve signature tests can be run only if these features are enabled. To run any diagnostic test, the user must be assigned the diagnostic privilege. This level does not affect instrument information. Instrument information is always available.
- Trending—When YES, enables trending parameters such as input current, actuator pressure, travel, and temperature. You can trend live data or review archived data. You can also view a travel histogram to determine where the valve spends the most of its time. Trending requires a HART modem or HART multiplexer network.
- **Batch Runner**—When YES, enables setting up batches to automatically run diagnostic tests, perform instrument calibration, run the performance tuner, upload setup data, or set the instrument clock.
- **Diagnostic Tools**—When YES, enables running a Step Response test with greater than 8 steps, Step Response test analysis and overlay, Performance Step test, and DataSync.
- Event Messenger—When YES, enables e-mail notification of alerts during alert scanning.
 - Share DB—Not available in current configuration. This feature should be set to "No".
 - Select DB—Not available in current configuration. This feature should be set to "No".
- **Performance Diagnostics**—When YES, permits monitoring of critical performance parameters during normal process operations when the user has diagnostic privilege and the instrument level is PD.
- ValveLink DTM—When YES, indicates that ValveLink software can be installed as ValveLink DTM
- **Database only**—(VL2001) This option does not allow ValveLink software to communicate with devices. ValveLink software can only work with datasets stored in the database.
- In Service only—(VL2010) This option prevents the operator from removing the valve from service and restricts the allowed tests to those that can be done while the valve is in service.
- Hardware Key required—When YES, this option will not allow ValveLink software to run without a USB hardware key attached to the computer.
- Tag Count—Indicates the number of instrument tags or reference tags that can be created in the software database.

ValveLink™ Software 7-7



Adding Features to the Installed Software

ValveLink License Wizard can be used to increase the capabilities of the installed ValveLink software. A separate StepUp USB hardware key or a software license key is required to increase the tag limit or add features to the installed software.



Note

The StepUp From Features in the StepUp USB hardware key or software license key must match with the license. If the features do not match, ValveLink License Wizard will display an error message.

To StepUp the installed ValveLink Software:

- **Step 1:** Attach your StepUp USB hardware key to the computer's USB port.
- **Step 2:** Run License Wizard and click on the StepUp button.
- **Step 3:** Select the Upgrade license using StepUp hardware key option button as shown in figure 7-5. Follow the License Wizard steps as directed.



Figure 7-5. Upgrade Using StepUp Hardware Key

- **Step 4:** If the original license was installed with a software license key, skip the following steps.
- **Step 5:** If the original license was installed with an installation USB hardware key, after successfully upgrading the license, the License Wizard will ask you to attach the original installation hardware key.
- **Step 6:** Unplug the StepUp USB hardware key from the computer before attaching the installation USB hardware key.
- **Step 7:** Click on the Confirmation check box to update your installation USB hardware key. Click on Next and follow the License Wizard steps as directed.

7-8 ValveLink™ Software



Obtaining a Software License Key for a ValveLink Feature or Tag StepUp

ValveLink License Wizard can be used to generate a registration form that can be submitted to ValveLink Registration Center to obtain your license keys for StepUp.



Note

A software license key cannot be used for obtaining an Instrument StepUp.

To generate a registration form for StepUp:

- Step 1: Unplug the USB hardware key attached to the computer.
- **Step 2:** Run License Wizard and click on the StepUp button.
- **Step 3:** Select the Upgrade License Using Software Licensing option button as shown in figure 7-6. Follow the License Wizard steps as directed.



Figure 7-6. Upgrade Using Software Licensing

- **Step 4:** Attach the .txt file containing the registration form generated by the License Wizard to an e-mail and send to the e-mail address shown on the form. If e-mail is not available, fax the form to the address shown on the registration form.
- **Step 5:** After receiving the license keys, re-run License Wizard and continue on with Step 6.
- **Step 6:** Click on Enter License Key button, as shown in figure 7-7 on page 7-15, and either import or manually enter the license key received from the ValveLink Registration Center.

ValveLink™ Software 7-9



- **Step 7:** Follow the License Wizard steps as directed.
- **Step 8:** If the original license was installed with a software license key skip the following steps.
- **Step 9:** If the original license was installed with an installation USB hardware key, after successfully upgrading the license, License Wizard will ask you to attach the original installation USB hardware key.
- **Step 10:** Unplug any USB hardware keys from the computer before attaching the installation USB hardware key.
- **Step 11:** Click on the Confirmation check box to update the installation USB hardware key. Click on Next and follow the License Wizard steps as directed.

7-10 ValveLink™ Software



Removing a License

The license from the installed software can be recovered to the original installation USB hardware key. After successfully removing the license, the installation USB hardware key can be used to enable the license of ValveLink Software installed on another computer.



Note

The original installation USB hardware key must be attached to your computer's USB port. The features and the serial number of the original installation USB hardware key must match the license in the installed software.

To remove your License:

- **Step 1:** Attach the original installation USB hardware key to the computer.
- **Step 2:** Make sure the features of the original USB hardware key match the features of the installed software.
- **Step 3:** Make sure there are no licenses left in the USB hardware key.
- **Step 4:** Click on the Remove/ Transfer button and follow the License Wizard steps as directed to remove your license.
- **Step 5:** After successfully removing your license, you can still run ValveLink Software but it requires that a valid installation USB hardware key be attached to your computer.

ValveLink™ Software 7-11



Transferring a License to another Computer

A license from the installed software can be transferred to another computer.



Note

After successfully generating the license keys for the target computer, the license on the source computer will be removed permanently. You will not be able to run ValveLink software on the source computer.

To transfer your license:

- Step 1: Run License Wizard on the target computer to generate the registration request form. Click on the New License button and select the Generate License Using Software Licensing option. Follow the License Wizard steps as directed to generate the registration form.
- **Step 2:** Run License Wizard on the source computer.
- **Step 3:** Click on the Remove/Transfer button.
- Step 4: Import the registration code of ValveLink software installed on the target computer from the registration file you saved in Step 1 above, or enter the registration code manually if you have selected a print option during Step 1.
- **Step 5:** License Wizard will generate the license key for ValveLink software installed on the target computer. You can save the key to a text file or select the print option.
- **Step 6:** Run License Wizard on the target computer. Click on the Enter License Key button. Click on the Import from File button if you have text file saved in Step 5 above. Otherwise, enter the license key manually. Follow the License Wizard steps to enable your license.

7-12 ValveLink™ Software



Updating the USB Hardware Key

ValveLink License Wizard can update your original installation USB hardware key with the new StepUp features. The updated USB hardware key can be used to enable a license on another computer.



Note

The original installation USB hardware key must be attached to your computer's USB port. The features and the serial number of the original installation USB hardware key must match the license. If the original license was obtained with a software license key then the upgrade operation cannot be performed.

If you wish, you can update your USB hardware key at a later time.

To update your USB HardKey:

- **Step 1:** Remove the StepUp USB hardware key from the computer.
- **Step 2:** Attach the original installation USB hardware key to the USB port.
- **Step 3:** Make sure the features of the original USB hardware key match the features of the installed ValveLink Software before upgrade.
- **Step 4:** Make sure there are no licenses left in the USB hardware key.
- **Step 5:** Click on the Update hardware key button to update your USB hardware key.
- **Step 6:** After successfully updating your USB hardware key unplug your installation USB hardware key from the USB port and store it in a safe place.

ValveLink™ Software 7-13



Enabling a Temporary License

ValveLink License Wizard can grant an emergency temporary license for a maximum period of five (5) days.



Note

A temporary license must be used only once per machine for a fresh installation. While the temporary license is active, the system clock should not be set back. If the system clock is set to an earlier date and time the temporary license will be disabled.

To enable a temporary license:

Step 1: Run the License Wizard and click on the Temporary License button.

Step 2: Follow the License Wizard steps as directed.

7-14 ValveLink™ Software



Entering a License Key

After receiving the license key from the ValveLink Registration Center, you must run License Wizard and enable or StepUp the license of the installed ValveLink Software.

To enter your license Key:

Step 1: Run License Wizard and click on the Enter License Key button, as shown in figure 7-7.



Figure 7-7. Enter License Key

- Step 2: Click on the Import from File button to import the file received by e-mail from the ValveLink Registration Center. Otherwise, enter the license key manually from the fax sheet received from the ValveLink Registration Center.
- **Step 3:** Follow the License Wizard steps to enable or StepUp your license.



Note

Store the license key file in a safe place after enabling the license in case you ever need to reinstall ValveLink software on your PC. Note that the license key can only be used on the computer for which it was originally licensed.

ValveLink™ Software 7-15



7-16 ValveLink™ Software



Section 8 HART Modem Installation for ValveLink Solo

This section	ic an	inetallation	ονρινίοω	of the	HART	modem
rnis section	าร สก	installation	overview	or me	DAKI	тноаеть

Attaching the HART Modem 8-2

Refer to ValveLink software help for information on selecting HART modem communication.

ValveLink™ Software 8-1



Attaching the HART Modem

The HART modem attaches to the serial port usually found on the back of the personal computer or the USB port.



Note

HART modem drivers, which are needed for the HART modem to work, are installed during ValveLink software installation.

Step 1: Locate the serial port or USB port.

If ValveLink Solo setup and installation *is complete*, connect the modem to the port specified on the Communication page in the Preferences window.

If ValveLink Solo setup is not complete, make note of the port where you attach the modem so that you can designate the correct port.

Step 2: Attach the HART modem directly to the serial port, the USB port, or to a cable connected to the serial port or USB port.

Use the modem cable assembly to connect the HART modem to the instrument, or to the signal wiring.

- **Step 1:** To communicate with the instrument, locate the signal wires or the terminals of the instrument.
- **Step 2:** Clip the cable assembly to the wires or the terminals.

Refer to the ValveLink software help for more information on using the HART modem.




Figure 8-1. Connecting the HART Modem

8-2 ValveLink™ Software



Section 9 Multiplexer Networks for ValveLink Solo

This section is an overview of multiplexer networks.

Setting Up a Multiplexer Network	9-2
Changing the Multiplexer Tag and Descriptor	9-4
Setting Up the Pepperl+Fuchs Multiplexer	9-5
Viewing Multiplexers Status	9-6
Adding Instruments to a Multiplexer	9-8

ValveLink™ Software 9-1



Setting Up a Multiplexer Network

ValveLink Solo uses an RS485 network to communicate with FIELDVUE DVC2000, DVC5000, DVC6000, and DVC6200 instruments through HART multiplexers. An RS232-to-RS485 converter is required to connect the serial port (RS232 protocol) on the computer to the RS485 network.

Depending upon the multiplexer, ValveLink Solo can support up to 256 individual loop channels per multiplexer. You can connect one instrument to each loop channel. See table 9-1 to determine the number of multiplexers and instruments that may be connected to a network.

Maximum Number Maximum Number **Multiplexer Type** of Multiplexers per of Loops per Network Multiplexer 2530H1 HART Interchange Multiplexer 32 32 ELCON HIS1700 and 2700 Multiplexer 31 32 256⁽¹⁾ MTL4841 Communications Module 31 Pepperl+Fuchs 255 32 1. Each MTL4841 module receives digital data from a maximum of 16 MTL4842 HART Interface Modules. In turn, each MTL4842 module accesses data from a maximum of 16 HART devices.

Table 9-1. Maximum Number of Multiplexers and HART Devices per Network

The following procedure briefly describes how to set up a multiplexer network. The subsections that follow provide more detail about setting preferences. To add a multiplexer network to the computer running ValveLink Solo:

Step 1: Connect physical equipment. Set all multiplexers and the RS232-to-RS485 converter to the same baud rate.

For details about wiring and connecting equipment, refer to the appropriate instruction guide.

- **Step 2:** Apply power to the instruments.
- **Step 3:** Apply power to the multiplexers.
- **Step 4:** Apply power to the RS232-to-RS485 converter.
- Step 5: Start ValveLink Solo. Log on with an account that will allow you to set preferences.
- **Step 6:** Select Customize ValveLink>Preferences.
- **Step 7:** On the Communication page:
 - Click the HART Multiplexer option button.
 - Select the communication port on your personal computer to which the RS232-to-RS485 converter is connected.
 - Select an appropriate baud rate that matches the baud rate of the RS232-to-RS485 converter and multiplexers attached to the communication port.
- **Step 8:** On the Multiplexers page:
 - Verify that the highest multiplexer address to scan for includes the addresses of all multiplexers on the network.
 - Select whether the multiplexers should function as primary or secondary communicating devices for the instruments attached through the network.

9-2 ValveLink™ Software



- Step 9: Click the OK button then exit the program and restart to cause changes to take effect.
- **Step 10:** Refer to figure 9-1. After restarting the program, right click the Communication icon in the left pane of the window.
- **Step 11:** From the drop-down menu select Scan for New. Watch the messages as ValveLink Solo scans the network. You should see the network being scanned. If the software does not recognize and scan the network, check physical connections, baud rates, and communication port, then try again.
- Step 12: Verify that the software recognizes the multiplexers and instruments. You should see a symbol in the left pane of the window for each multiplexer connected to the network. Beneath each multiplexer symbol you should also see a symbol for each instrument connected to the multiplexer. See figure 9-1.



Figure 9-1. Scanning for New Multiplexers and Instruments On a Network

ValveLink™ Software 9-3



Changing the Multiplexer Tag and Descriptor

To change the multiplexer tag or descriptor, click the Tag & Descriptor button on the Multiplexer Information display. Enter an up to 8 character tag and an up to 16 character descriptor.

Valid characters for the tag and descriptor include the letters A through Z, the numbers 0 through 9, and the following special characters: single quotation mark ('), exclamation point (!), at sign (@), number sign (#), dollar sign (\$), percent sign (%), caret (^), ampersand (&), asterisk (*), parenthesis (), hyphen (-), underscore (_), plus (+), equal sign (=), semicolon (;), colon (:), apostrophe ('), quotation marks ("), period (.), slash (/), backslash (\), less than and greater than (<>), brackets ([]), and question mark (?).

9-4 ValveLink™ Software



Setting Up the Pepperl+Fuchs Multiplexer

When adding or removing a submodule from a Pepperl+Fuchs multiplexer you must reconfigure the multiplexer to indicate the changes. Multiplexer configuration changes are made from the Pepperl+Fuchs Module Setup screen, figure 9-2.

To setup a Pepperl+Fuchs multiplexer:

- **Step 1:** On each Pepperl+Fuchs slave module, set the slave address switch to an unused value so that each module has its own individual setting.
- Step 2: On the Pepperl+Fuchs Module Setup screen, check those modules that are installed.




Figure 9-2. Pepperl+Fuchs Module Setup Screen

ValveLink™ Software 9-5



Viewing Multiplexer Status

You can view the status and add a tag and descriptor to each multiplexer on the network. For a Pepperl+Fuchs multiplexer, you can also define which modules are included in the multiplexer.




Figure 9-3. ValveLink Solo Multiplexer Information Window

The following define the fields on the Multiplexer Information window:

- Mux #—The multiplexer address, determined by the address switch settings on the multiplexer or communications module.
- **Unique ID**—The last six digits of a unique ID number assigned to the multiplexer by the manufacturer.
 - Tag—A name assigned to the multiplexer from the Tag & Descriptor screen.
- **Description**—A description assigned to the multiplexer from the Tag & Descriptor screen.
- Manufacturer—The multiplexer manufacturer, Emerson Process Control Systems, MTL, ELCON, or P&F.
- **Device Type**—HART Interchange for a 2530H1 HART Interchange Multiplexer, MTL4841 Communications Module for a MTL4840 HART Maintenance System, KFD HART Multiplexer System for a Pepperl+Fuchs multiplexer, or an ELCON Mux.
 - Univ. Command Rev.—The HART command language revision number, always 5.
- Instr. Command Rev.—The multiplexer or communications module firmware revision number.
- Scanning—Alert scanning. Should always be disabled when not viewing the Network Scan window.
- Scan Cmd—HART command level returned to the multiplexer or communications module by the instrument if an alert occurs. May be a 1 or a 3.
 - Date—The date data was entered.
- **Message**—A message programmed into the multiplexer or communications module software.
- **Gender**—Whether the multiplexer or communications module is a primary master or secondary master.

9-6 ValveLink™ Software



- Loop Search—Currently the multiplexer or communications module only searches for single analog loops, those loops where the instrument polling address is 0.
 - Gateway Device—HART signaling scheme. Always RS485 Bell 202
- **Software Rev.**—Revision number of the software installed in the multiplexer or communications module.
 - Hardware Rev.—Hardware revision level.
- Retry Count—Number of times multiplexer or communications module attempts to send a command to the instrument. Should be 2 after initialization.

ValveLink™ Software 9-7

Adding Instruments to a Multiplexer



Note

ValveLink Solo must be licensed with a Tag Limit sufficient for the number of connected instruments. See page 7-8 for more information.

Depending upon the multiplexer, ValveLink Solo can support up to 256 individual loop channels per multiplexer. You can connect one instrument to each loop channel.

To add a new instrument to a multiplexer:

- **Step 1:** Connect HART signal wiring to the multiplexer.
- **Step 2:** Apply power to the instruments.
- **Step 3:** Apply power to the multiplexers.
- **Step 4:** Right click the multiplexer symbol and select Reset and Rescan the Multiplexer from the drop-down menu.

If the instrument is recognized by the software, a valve symbol appears beneath the multiplexer on the device connection diagram, as shown in figure 9-1. If no symbol appears, then the software does not recognize the instrument. Check physical connections and instrument loop power.



Note

HART Multiplexers can only communicate with FIELDVUE instruments when the polling address is "0". Communication does not occur with a higher polling address.

Step 5: To open the instrument's tag, double click the valve symbol for the instrument.

If a tag does not exist in the ValveLink Solo database, the software creates a database tag that matches the HART tag stored in the instrument. If no HART tag exists, the software creates the following database tags:

- FIELDVUE_0001 for the first instrument,
- FIELDVUE_0002 for the second instrument, etc.

If you have created a tag in the database, ValveLink Solo attempts to match the instrument to the tag.

However, if key data, such as the HART tag, descriptor, valve serial number, and multiplexer address do not match, ValveLink Solo will not use the database tag you created.

Use Query And Match to resolve any discrepancies in key data.

9-8 ValveLink™ Software



Section 10 Installing Software and Hardware for Communication with Foundation fieldbus Instruments for ValveLink Solo

This section is an overview of installing software and hardware from National Instruments Corporation and setting up communication with FOUNDATION fieldbus instruments.

NI-FBUS Installation	
Software	10-2
Hardware	10-2
Configuring the PCMCIA-FBUS Card	10-3
Checking for IRQ and Memory Conflicts	10-6
Installing Device Descriptions (DD)	10-7
Connecting to a FOUNDATION fieldbus Segment	10-9
Connecting to a DVC5000f, DVC6000f, or DVC6200f	
Instrument	10-1

ValveLink[™] Software



NI-FBUS Installation

Before beginning any installation, refer to the Installation Requirements on page 2-3.

Connecting to a FOUNDATION fieldbus instrument requires software and hardware supplied by National Instruments Corporation:

- Fieldbus Interface and Driver (NI-FBUS) software. The installation procedure depends on the operating system installed on your computer.
 - PCMCIA Type II card for a desktop or notebook computer.
 - PCI-FBUS board for a desktop computer

This section is a guide for installing the NI-FBUS software on your computer with Windows 2000, Windows XP, Windows Server 2003, or Windows Vista operating systems.

For a complete installation description and procedures, refer to the documentation supplied with your NI-FBUS interface.

Installing the software

To install the NI-FBUS software, complete the following steps:

Step 1: Insert the first CD of the NI-FBUS Communication Manager software in the CD drive of your computer.

If the drive's auto run is turned on, the install wizard will start automatically.

If auto run is not on, start the install from the run window; Select Start>Run from the taskbar. In the text box, type D:SETUP.EXE (where D is the CD drive letter).

Step 2: Click Next and follow the prompts until the software is installed.

Installing the hardware

To install the PCMCIA-FBUS card, complete the following steps:

- **Step 1:** Shut down your operating system and turn off your computer.
- **Step 2:** Insert the card into a free PC Card (PCMCIA) socket.
- **Step 3:** Connect the PCMCIA-FBUS card to the FOUNDATION fieldbus network using the cable provided with the card.
- **Step 4:** Turn on your computer.

The card has no jumpers or switches to set.

10-2 ValveLink™ Software



To install the PCI-FBUS/2 board, complete the following steps:

Step 1: Shut down your operating system and turn off your computer.

Step 2: Insert the card into any unused PCMCIA socket.

Step 3: Turn on the computer and configure the PCI-FBUS/2 board in accordance with the PCI-FBUS/2

board's documentation.



Note

On a two port fieldbus board, set the second port (PORT1) to LAS NI-FBUS to ensure ValveLink software uses the first port (PORT0). Refer to figure 10-2.

Port0 is associated with Port1 on the cable that connects to the fieldbus segment or instrument. **Port1** is associated with Port2 on the second connecting cable.

Configuring the PCMCIA-FBUS Card



Note

When using ValveLink Solo with a dual-port PCMCIA-FBUS/2 card, only one of the ports (PORT0) is used. ValveLink Solo will use the port configured as NI-FBUS. To prevent ValveLink Solo from attempting to use the second port (PORT1), configure that port as LAS NI-FBUS. Refer to figure 10-2.

ValveLink™ Software 10-3



WARNING

Ensure that the connecting cables in the following steps are connected to the correct ports:

- The cable labeled PORT1 is connected to the software PORT0, and connected to the segment.
- the cable labeled PORT2 is connected to the software PORT1, but NOT used in the segment.

Refer to Step 3 below for PORT0 configuration and Step 6 below for PORT1 configuration.

Incorrect cable configuration and connection could cause loss of communication and control of the segment, resulting in personal injury or property damage.

Follow these steps to configure the PCMCIA-FBUS card to work with ValveLink Solo:

- Step 1: Start the NI-FBUS Configuration utility by selecting Start>Programs>NI-FBUS>Interface Config.
- **Step 2:** In the Interface Config window, select PORT0 and click the EDIT button.
- **Step 3:** Select Basic Device in the Device Type area and NI-FBUS in the Usage area, as shown in figure 10-1.

Port0 here is associated with Port1 on the cable that connects to the fieldbus segment or instrument.




Figure 10-1. Configuring PORT0; Connects Physically to PORT1 on the Cable




Figure 10-2. Configuring PORT1; Connects Physically to PORT2 on the Cable

10-4 ValveLink™ Software



Step 4: Click the OK button.

In the NI-FBUS Interface Configuration Utility dialog box, click the board icon to highlight it; click the Edit button. In the Interface dialog box, click the down arrow on the IRQ list box and select an unused IRQ noted at the start of the NI-FBUS software installation. Then click OK.

Step 5: Select PORT1 in the Interface Config window and click on the EDIT button.

Port1 here is associated with Port2 on the second connecting cable.

- **Step 6:** Select Link Master Device in the Device Type area and NI-FBUS in the Usage area, as shown in figure 10-2.
- Step 7: Click the OK button.

To setup the Windows 2000, Windows XP, Windows Server 2003, and Windows Vista operating systems to automatically reserve resources for NI-FBUS whenever the system starts, repeat steps 1 through 7 plus the following steps:

- **Step 8:** Select Start>Settings>Control Panel>System.
- **Step 9:** Click on the Hardware tab.
- **Step 10:** Click the Device Manager button.
- Step 11: Click on View in the menu bar, and select Resources by Type from the drop down menu.
- Step 12: Expand the Interrupt Request (IRQ) node and double click on the NI-FBUS adapter (nifb).
- **Step 13:** On the Nifb properties box, click the Driver tab and click the Start button. The Nifb device status should change from Stopped to Started. Click the Stop button then click the OK button.
- **Step 14:** Close the Device Manager, System Properties and the Control Panel.

ValveLink™ Software 10-5



Checking for IRQ and Memory Conflicts In Windows 2000, Window XP, Windows Server 2003, and Windows Vista

To make sure that your NI-FBUS software is installed correctly and is working properly, complete the following steps:

- **Step 1:** After you configure your installation, restart Windows. You must restart your computer before you can use the NI-FBUS software.
- **Step 2:** Select Start>Programs>National Instruments FBUS.
- **Step 3:** Double click the NIFB icon (the blue box).

On successful startup, NI-FBUS displays a message saying that the process started successfully, and the title bar of the nifb window changes to NIFB (running).

Once you have determined that NI-FBUS starts and is working properly, shut it down and install ValveLink Solo as described in section 3.

If the NI-FBUS software does not start up successfully, note any error messages that may appear. The base address, the interrupt request (IRQ), or your network address may be incorrect. Restart the computer again and assign new IRQ/Memory locations again.

10-6 ValveLink™ Software



Installing Device Descriptions (DD)

For ValveLink Solo to communicate with DVC5000f, DVC6000f, and DVC6200f instruments, the instrument device descriptions (DDs) must be installed along with the NI-FBUS software on the computer running ValveLink Solo. Use the NI-FBUS configuration utility to setup a location for the DDs. Install the DDs as follows:

Step 1: Create a directory named x:\DD where x is the drive where you want the DDs to be located, preferably on the same drive as the NI-FBUS program and where ValveLink Solo will be located. For example, if you installed the NI-FBUS software in C:\NIFBUS, then create a directory named C:\DD for the device descriptions.

You may load new DD information from the ValveLink installation CD. The CD-ROM contains new device descriptions and the instruction guide for DVC5000f, DVC6000f, and DVC6200f digital valve controllers for FOUNDATION fieldbus. You can also locate this information at the following internet address:

www.fieldvue.com

select Digital Valve Controller, then HART & Fieldbus Device Descriptions.

- **Step 2:** On the CD or from the downloaded internet files, locate the folder called \RELEASE.
- **Step 3:** Open this folder and select the folder named 005100. The number 005100 is the FOUNDATION fieldbus code for Fisher products.
- Step 4: Copy folder 005100 and all its contents, including subfolders, to the directory you created in Step 1. If this is an update (the folders already exist), the system informs you that the folders already exist and asks if they should be replaced. Select OK so the existing folders are properly updated.
- Step 5: Start the NI-FBUS configuration utility by selecting Start>Programs>NI-FBUS>Interface Config.
- **Step 6:** Click the DD Info button.
- Step 7: From the DD Info dialog box, shown in figure 10-3, rename the base directory from C:\Nifbus\Data to the directory you created in the DD Info Dialog Box. (For example, C:\DD)

ValveLink™ Software 10-7






Figure 10-3. NI-FBUS Interface Configuration Utility DD Info Dialog Box




Figure 10-4. Example DD Info Dialog Box with Path to Installed DDs and Standard Dictionary

- Step 8: The standard dictionary provides instructions for NI-FBUS to look up specific instrument parameters. This dictionary is in a file named Standard.dct in the 005100 folder. Therefore, on the DD info dialog box, rename Your standard text dictionary by browsing to the standard.dct file in the directory you created in 10-3. For example, C:\DD\005100\Standard.dct.
- **Step 9:** When you finish, the DD info box should appear similar to figure 10-4.
- **Step 10:** Click the OK button on the Interface configuration Utility screen. The new support files are now installed.

10-8 ValveLink™ Software



Connecting to a FOUNDATION fieldbus Segment

The FOUNDATION fieldbus communication protocol is:

- all digital
- two-way communication
- a protocol that interconnects devices such as digital valve controllers, transmitters, discrete devices, and process controllers.
- a local area network (LAN) for instruments that enables the transfer of basic control and I/O to the field devices.

DVC5000f, DVC6000f, and DVC6200f digital valve controllers use the FOUNDATION fieldbus technology developed and supported by Emerson Process Management and the other members of the independent Fieldbus Foundation.

In order for ValveLink Solo to communicate with a DVC5000f, DVC6000f or DVC6200f digital valve controller an NI-FBUS interface card must be installed in the computer. Cards with a dual-port fieldbus connection are supplied.

WARNING

To avoid personal injury or property damage due to loss of process control, do not connect the computer to an active H1 segment while ValveLink Solo and NI-FBUS software is running. Doing so could interfere with Link Active Scheduler (LAS) operation.

The Link Active Scheduler (LAS) controls traffic on the H1 segment. For an active H1 segment, the LAS function is provided by the host system or another FOUNDATION fieldbus device. When ValveLink Solo is connected (to either an active segment or a single instrument), the NI-FBUS interface card waits to see if the LAS is present. If not, the NI-FBUS interface card provides the LAS function. Therefore, to avoid conflict between the LAS function in the NI-FBUS interface card and LAS on the active segment, do not disconnect ValveLink Solo from a single instrument and connect it to an active segment without first shutting down ValveLink Solo.

ValveLink™ Software 10-9



For a cable with connector:

Step 1: Connect pin 6 of the 9-pin DSUB connector to the segment positive (+) connection.




Figure 10-5. Computer Running ValveLink Solo with Dual-Port NI-FBUS

- **Step 2:** Connect pin 7 to the segment negative (-) connection.
- **Step 3:** Connect the cable shield to the H1 segment shield.

To connect a twisted shielded pair cable:

- Step 1: Connect one wire of the twisted pair to the D+ screw terminal on the PCMCIA-FBUS cable PORT 1.
- Step 2: Connect the other end of this same wire to the H1 segment positive (+) connection.
- Step 3: Connect the second wire to the D- screw terminal on the PCMCIA-FBUS cable PORT 1.
- **Step 4:** Connect the other end of this same wire to the H1 segment negative (-) connection.
- **Step 5:** Connect the cable shield to the H1 segment shield. Connect the shield at one end only.

10-10 ValveLink™ Software



Connecting to a DVC5000f, DVC6000f, or DVC6200f Digital Valve Controller

Connecting to a single instrument requires a fieldbus power hub (Relcom part number FCS-PH-110-PL, or equivalent). The power hub provides a power supply and double terminator. Up to four devices can be connected to the Relcom power hub. The computer with ValveLink Solo and NI-FBUS interface card is considered as one device. This product is used for bench testing. It is not designed for field applications.




Figure 10-6. Typical Connection to a DVC6000f Digital Valve Controller

If using a connection method other than the Relcom power hub, provide power using an approved fieldbus power conditioner in conjunction with a 24 VDC power supply.

For more information on making connections to the digital valve controller, refer to the FIELDVUE DVC5000f Digital Valve Controller for FOUNDATION fieldbus instruction manual (D102634X012) (obsolete product), the DVC6000f Digital Valve Controller instruction manual (D103189X012) or the DVC6200f instruction manual (D103412X012).

Connecting the computer

For a cable with connector:

- **Step 1:** Connect pin 6 of the 9-pin connector to a power hub positive (+) connection.
- **Step 2:** Connect pin 7 to a power hub negative (–) connection.
- **Step 3:** Connect the cable shield to the power hub shield (S) connection.

To connect a twisted shielded pair cable:

- Step 1: Connect one wire of the twisted pair to the D+ screw terminal on the PCMCIA-FBUS cable PORT 1.
- Step 2: Connect the other end of this same wire to the power hub positive (+) connection.
- **Step 3:** Connect the second wire to the D- screw terminal on the PCMCIA-FBUS cable PORT 1.
- **Step 4:** Connect the other end of this same wire to the power hub negative (-) connection.

Use twisted pair shielded cable to connect the instrument to the power hub.

- **Step 5:** Remove the instrument terminal box cover.
- Step 6: Connect the instrument LOOP + terminal to the power hub positive (+) terminal.
- Step 7: Connect the instrument LOOP terminal to the power hub negative (–) terminal.
- **Step 8:** Connect the shield to the power hub shield (S) terminal.

ValveLink™ Software 10-11



10-12 ValveLink™ Software



Section 11 Modbus Networks for ValveLink Solo

This section is an overview of Installing Modbus Networks.

Setting Up the Modbus Network 11-2

ValveLink™ Software 11-1



Setting Up the Modbus Network

ValveLink Solo communicates with a Modbus master over the Modbus interface. The Preferences window provides selections that allow you to:

- Select the Modbus Transmission Mode and Delay. ValveLink Solo supports both ASCII or RTU serial transmission modes. Select the transmission mode and Modbus parameters to match the settings in the Modbus master. You can also specify a delay in milliseconds between the time ValveLink Solo receives a request and the time the software begins to prepare a response.
- Identifies the Communication Port on your personal computer to which the null modem adapter or RS232-to-RS485 converter is attached.
- **Set Modbus Parameters**. Allows you to set up the Modbus parameters to match the settings in the Modbus master. These parameters include: baud rate, data bits, stop bits, and parity.

You must also define the instruments for which ValveLink Solo should communicate information over the Modbus network. The Modbus Setup window allows you to:

• List the ValveLink Solo Database Tags. You define the instruments for which ValveLink Solo should communicate information by listing the database tags in the List of Tags to Scan box on the Network Scan Setup window.




Figure 11-1. Example ValveLink Solo Computer Connections to HART Multiplexer and an RS232 Modbus Network

11-2 ValveLink™ Software




Figure 11-2. Example ValveLink Solo Computer Connections to HART Multiplexer and an RS485 Modbus Network

• Assign Slave Addresses to the Database Tags. ValveLink Solo supports up to 256 slave addresses. You can assign up to 312 tags to each address. As database tags are assigned to the slave addresses, ValveLink Solo automatically calculates the starting coils and registers for that tag.

Refer to the Appendix for information about data support and Modbus function codes. Refer to ValveLink Software help for detailed information.

ValveLink™ Software 11-3



11-4 ValveLink™ Software



Section 12 Troubleshooting Installation

This section contains questions about the installation of ValveLink software. The answers to these questions may help you if you have problems installing the software.

ValveLink™ Software 12-1

Licensing

- Q. What is the License Wizard, and when do I use it?
- **A.** The Licence Wizard is used to activate, step up, restore, remove or transfer the license of your ValveLink software. The License can be enabled by using a hardware key, or from a software license key.
- **Q.** Do I have to have a new USB hardware key with a ValveLink software license to reinstall the software on another computer?
- **A.** If you wish to install a copy of ValveLink software on another computer, you must first remove the license from the installed program and return it to the USB hardware key using the License Wizard. After the license is removed, the installed program will no longer run unless the USB hardware key is installed or until the license is restored. See page 7-2 for information on using the License Wizard.

Alternately, you can also transfer a license from one computer to another computer.

- Q. Can I remove a license from the installed ValveLink software?
- **A.** Yes. Remove License option removes the License from the installed ValveLink software and increments the New License count in the hardware key. After you remove the License, a USB hardware key will be required to run ValveLink software. Consult page 7-11 for more information.
- Q. Can I transfer a license from one computer to another?
- **A.** Yes. The Transfer License option can be used to transfer the license of ValveLink software installed on one computer to ValveLink software installed on another computer. Consult page 7-12 for more information.
- Q. Can I restore a license to the installed ValveLink software?
- **A.** Yes. Restoring a license decrements the License count in the hardware key and restores the License in the installed ValveLink software. After you restore the License, ValveLink software will run without a hardware key attached to the computer. A license can also be restored from a software license key. However, the license key can only be used on a computer on which it was originally installed. Consult Section 7 for more information.
- Q. Can I update my installation hardware key?
- **A.** Once you have stepped up your installed ValveLink software, you can upgrade your original installation USB hardware key to use as a backup. Consult page 7-13 for more information.
- **Q.** License Wizard displayed an error message indicating that the USB hardware key is not attached. However, the USB hardware key is properly attached. What is causing this problem and can I fix it?
- **A.** Try running the License Wizard with a different USB hardware key, or on another computer. When the License wizard program does not recognize any hardware key on a computer, the solution is a change in the BIOS setup. Contact your local technical support staff and request a change in the ECP, EPP, or bi-directional communications configuration in the BIOS of your personal computer.

12-2 ValveLink™ Software

Liaanaina	O. Micromouter does not have a UCD ment I received a UCD trail
Licensing (continued)	Q. My computer does not have a USB port. I received a USB hardware key in the ValveLink software package but I am unable to use the hardware key. How do I activate the license?
	A. You can obtain a software license key to activate the license of your ValveLink software. Please refer to the page 7-4 for information on obtaining a software license key.
	Q. The License Wizard displayed CrypKey error message (CrypKey error –100, –102, or –103). What can I do to fix this error?
	A. There are a number of causes for CrypKey errors during the activation of license. Consult the Readme.txt file on the installation CD. For more information, contact ValveLink software Technical Support. Refer to the Foundation support package that accompanied your ValveLink software for the telephone number.
Installing	Q. Why does my PC operate so slowly when I run ValveLink software?
	A. To operate efficiently, ValveLink software requires an IBM-compatible personal computer or notebook computer equipped with a 800 MHz, or faster, Pentium®-class processor running Windows 2000, Windows XP, Windows Server 2003, or Windows Vista operating system. Consult page 2-4 for more information.
	Q . How can I make sure that my National Instruments FOUNDATION fieldbus software is installed correctly and is working properly?
	A . On successful startup, the NI-FBUS Communications Manager displays a message saying that the process started up successfully, and the title bar of the nifb window changes to NIFB (running). The "blue box" appears on the Windows task bar at the bottom of the screen.
	Q. When I start up my NI Driver in Windows 2000, it doesn't recognize that I installed the necessary software.
	A. You need to install the NI Driver software before you install the PCMCIA-FBUS card, or ValveLink software. After installing the driver software, shutdown your PC, and then put in the PCMCIA card, before turning it back on. After these are both installed properly, then you can install ValveLink software. Consult Section 10.
	Q. I followed the installation procedures, but my ValveLink software won't talk fieldbus.
	A. Check the "blue box". Does it connect by itself? If No, work on setting up NI. Check for the correct DD. Check for the correct IRQ. If Yes, check for power on the bus. Check for a working digital valve controller (try a different one). Check wires for continuity.
	Q. What are ValveLink software's requirements for communication ports?
	A. You need at least one open serial communication port for use by ValveLink Software if you will be using a modem or a multiplexer. With one RS232-to-RS485 converter and one serial port on the PC, VL2031 software can communicate with up to 1024 DVC5000, DVC6000, and DVC6200 instruments via a multiplexer. Each additional serial port and converter permits communicating with an additional 1024 instruments.

ValveLink™ Software 12-3



Installation on a DELL Laptop Computer Running Windows 2000, Communications Error	Q. I have successfully installed ValveLink software on my DELL laptop computer. However, I am experiencing a communications error when I try to use the program. What can I do to fix this error?
	A. In some cases, the Windows Registry requires a patch. Contact ValveLink software Technical Support for instructions. Refer to the Foundation support package that accompanied your ValveLink software for the telephone number.
NI-FBUS Does Not Start	Q. What if the NI-FBUS software does not start up successfully?
	A. Note any error messages that may appear. The base address, the interrupt request (IRQ), or your network address may be incorrect. Start the NI-FBUS Interface Configuration utility by selecting Start>Programs> National Instruments NIFBUS>Interface Config, and make sure that your network address is unique.
Uninstalling	Q. Do I have to uninstall my previous version of ValveLink software to install a new version?
	A. No, it is not necessary to uninstall a previous version. The new version will overwrite the previous version. If you feel a complete uninstall is required for any reason, contact ValveLink software Technical Support. Consult page 1-6 for more information.
Configuring Port	Q. When I am using ValveLink software with a dual-port PCMCIA-FBUS/2 card, ValveLink software tries to use my second port. What am I doing wrong?
	A. When using ValveLink software with a dual-port PCMCIA-FBUS/2 card, only one of the ports is used. ValveLink software will use the port configured as NI-FBUS. To prevent ValveLink software from attempting to use the second port, configure that port as Bus Monitor.

12-4 ValveLink™ Software



Section 13 Troubleshooting Communication

This section contains questions about communications problems. The answers to these questions may help you if you encounter a problem with communication.

ValveLink™ Software 13-1



Serial Ports

Q. ValveLink software does not detect all of my serial ports. How do I enable ValveLink Software to use a port that it doesn't automatically detect?

A. In the VLink.INI file, [COMM] section, change Serial Port Auto Detect = Yes to Serial Port Auto Detect = No. This will cause ValveLink software to bypass auto detection and enable ports 1 through 16 even if all 16 ports are not installed. If you make this change while ValveLink Software is running, you will have to exit and restart the software for this change to take effect.

Some add-on serial ports, such as USB serial ports, may not be detected by ValveLink software and may not be compatible with the HART modem driver used by ValveLink software. Using a serial HART modem on a USB-to-serial port converter may cause significant problems and is not recommended.

The following add-on serial boards have been tested and are approved for use with ValveLink Software.

B & B Electronics Manufacturing Company, Inc. http://www.bb-elec.com

3PCISD2A, PCI 2-Port RS-232/422/485 Serial Card w/SD and 16550A3PCISD4A, PCI 4-Port RS-232/422/485 Serial Card w/SD and 16550A

QUATECH, Inc. http://www.quatech.com

ESC-100D, 8-Port, RS-232 Serial PCI Board with Standard D25 Connector Cable.

COM Port

Q. ValveLink Software isn't seeing the COM port. What could be causing this problem?

A. If you use a PDA (personal digital assistant), and have HotSync Manager® installed on your computer, it may be grabbing the COM port, so ValveLink software can't see it. You need to turn HotSync Manager off, so it can free up the COM port.

Alternatively, other programs, such as Allen Bradley or competitive valve suppliers, etc., may be using the COM port.

Other causes may include:

The power saving is set and has caused the port to use the low power option. You need to set the power saving to none and delete and re-install the COM port.

The COM ports hardware is bad. Replace the PC or the motherboard.

13-2 ValveLink™ Software

Multiplexer	Q. I know I have a certain multiplexer attached to my network, but ValveLink software doesn't see it. What can I do?
	A. One of the first things you should do is verify the settings for the COM port where the multiplexer is attached. In particular, make sure that the baud rate is set properly in ValveLink software and that the baud rate matches what is set in the multiplexer itself and in any converter/repeater devices installed between the personal computer running ValveLink software and the multiplexer.
	Adjust the port acceleration to a lower value, such as Low or <none>.</none>
	Ensure that the address assigned to the multiplexer is not already in use by another multiplexer and that it is selected to be scanned in ValveLink software.
	You can access all of the above ValveLink software specific properties via the Communications page of the ValveLink software Preferences window. If none of the above recommendations solves the problem, you should thoroughly investigate your network hardware to make sure it is properly installed and configured.
Network Rebuild	Q. How can I reduce the time it takes to perform a full network rebuild?
	A. ValveLink Software can scan all ports and all multiplexers virtually simultaneously during a full network rebuild. However, there are some limitations to this when you have more than a handful of multiplexers connected to the same serial port. More evenly distributing your multiplexer network across two or more serial ports can help reduce the time it takes to perform a full network rebuild.
	Also, increasing the port acceleration can help reduce network rebuild time.
Communications Errors, AMS ValveLink	Q. I am getting communications errors when performing operations with ValveLink SNAP-ON. What can I do to fix the errors?
SNAP-ON	A. One cause of communications errors may be that it is taking too long to get message replies from the device. ValveLink SNAP-ON communicates to a device through AMS Device Manager. Depending on the AMS network configuration and activity, it may take a considerable amount of time to get a response back from a device.
	However, ValveLink SNAP-ON will only wait for a specified period for a message reply. This message timeout period is defined in the VLink.ini file and may be modified, as necessary, to a value between 2 and 30 seconds.
	The timeout value is located under the [COMM] section and is initially set to 20000 milliseconds. You may adjust this setting to a value between 2000 (2 seconds) and 30000 (30 seconds). For example, if you want to adjust the timeout value to 10 seconds, you would change the timeout entry to Timeout = 10000 in the VLink.ini file. If you make this change while ValveLink software is running, exit and restart ValveLink software for this change to take effect.

ValveLink[™] Software



13-4 ValveLink™ Software



Appendix A Modbus Protocol

ValveLink Solo acts as a slave on the Modbus network and supports five data block requests from a Modbus master. Table A-1 lists the supported Modbus functions. Either ASCII or RTU Modbus protocols at baud rates from 300 to 19,200 are supported by ValveLink Solo.

The software may be set up to represent one or up to 256 slaves. Each slave can communicate information from up to 312 instruments. Each instrument must have a tag assigned to it in the ValveLink Solo database and must be communicating via a HART multiplexer.

ValveLink™ Software A-1



Code	Meaning	Description
1	Read Coil Status	Status of 30 alerts, 32 bits reserved per tag.
2	Read Input Status	Status of up to 30 alerts. Alerts may be individually selected and packed.
3	Read Holding Registers	Status of up to 30 alerts and 4 analog values. Analog values are single precision IEEE floating point. Alerts and analog values may be packed or unpacked. Unpacked data reserves 32 registers per tag.
4	Read Input Registers	Status of up to 30 alerts and 4 analog values. Analog values are signed integers or scaled zero-based integers. Alerts and analog values may be packed or unpacked. Unpacked data reserves 32 registers per tag.
8	Diagnostics	Subfunction 00 only for loopback testing.

Table A-1. Modbus Function Codes Supported




Figure A-1. ValveLink Solo Response to Modbus Function Code 1, Unpacked Data

Data Support, Modbus Function Code 1

When ValveLink Solo receives a function code 1 from a Modbus master, it responds with alert data according to a predetermined format. The software always allocates 32 coils for each tag although only the first 30 coils are actually used for reporting alert status. The sequence (starting coil to ending coil) in which alerts are provided remains constant. Figure A-1 shows an example response and how the coils are allocated. When an instrument (tag) is added to a slave address, the first (lowest) coil range available is used. If the tag is deleted, the coil range is left open, until another tag is added to the slave address.

The alert statuses are assigned to the coils as shown in figure A-2. The coil contains a "1" when the alert is active and a "0" when the alert is clear. Empty coils all contain "0"s.

A-2 ValveLink™ Software






Figure A-2. Alert Status Assignments to Coil Addresses, Unpacked Data




Figure A-3. Example Alert Status Assignments to Coil Addresses for Packed Data

Data Support, Modbus Function Code 2

If unpacked, the response to a function code 2 is exactly the same as the response to a function code 1. However, in order to optimize communication, the alert data may be compressed (packed) into less than 32 coils per instrument. When packed, ValveLink Solo allocates coils only for selected alerts.

As an example, suppose that only Travel Alert Hi, Travel Alert Lo, Travel Accumulator, and Drive Signal have been selected. Then the response to a function code 2 will appear as shown in figure A-3. The starting coil address for the first instrument is 0. The starting coil address for the second instrument is 4, etc.

Although packing the data maximizes the number of tags (instruments) that can be monitored in a single contiguous block, it also means that changes in the configured alerts or tags will probably require repacking the data and making changes to the master's requests. When tags are added to a slave address, they will be added to the first (lowest) available coil range. If a tag is deleted, the coils for that tag are left unassigned until another tag is added to the slave address or the data is repacked.

If an alert is deselected, the number of coils assigned to a tag does not change until the data is repacked. When an alert is added, any empty coils are filled first. If no empty coils are available, you are requested to repack the data.

ValveLink™ Software A-3






Figure A-4. Register Allocation for One Instrument, Modbus Function Code 3, Unpacked Data

Data Support, Modbus Function Codes 3 and 4

When ValveLink Solo receives a function code 3 or 4 from a Modbus master, the response to either function code may be packed or unpacked. If left unpacked, the software always allocates 32 registers for each tag: 2 registers for alert status and 8 registers for analog data; 22 registers are reserved. The sequence (starting register to ending register) in which data is provided remains constant. For example, the starting register for the first instrument is always register 1. The starting register for the second instrument is always register 33, etc. The starting register for the 312th instrument is register 9953 [Starting register = (N-1)32+1]. Each register contains two bytes (16 bits). Therefore, 32 bits are always used for the alert status. Figure A-4 shows an example unpacked response and how the registers are allocated. The first 30 bits of the starting register are allocated to the alert status in the same order shown in figure A-2, that is, Travel Deviation status is represented by the lowest order bit, Travel Alert Hi is represented by the next bit, etc. Therefore, if the alert status register is displayed as an integer and Travel Alert Hi is the only alert active, the integer 2 will be displayed.

For a function code 3, analog values are reported as IEEE, floating-point numbers. For function code 4, analog values are reported as integers. The integers may be signed or zero-based with user configurable scaling. Zero-based integer values are always positive. Only one register is used for each analog value as shown in figure A-5. Except for temperature, default scaling for signed integer values is 100; i.e., to obtain the actual value for travel, configured pressure, or input current, divide the integer value received by 100. The default scaling for signed integer temperature values is 10.

To optimize communication, the alert data may be packed (compressed) into less than 10 registers per tag. When packed, ValveLink Solo allocates registers only for selected alerts and analog values.

As an example, suppose that only Travel Alert Hi, Travel Alert Lo, Travel Accumulator, and Drive Signal have been selected. In addition, suppose we want to communicate Travel, Input Current, and the Internal Temperature. The response to a function code 3 will appear as shown in figure A-6.

Although packing the data maximizes the number of tags (instruments) that can be monitored in a single contiguous block, it also means that a change in the configured alerts or tags will probably require repacking the data and making changes to the master's requests. When tags are added to a slave address, they will be added to the first (lowest) available register range. If a tag is deleted, the registers for that tag are left unassigned until another tag is added to the slave address or the data is repacked.

If an alert or analog value is deselected, the number of registers assigned to a tag does not change until the data is repacked. When an alert or analog value is added, any empty registers are filled first. If no empty registers are available, you are requested to repack the data.

A-4 ValveLink™ Software






Figure A-5. Register Allocation for One Instrument, Modbus Function Code 4, Unpacked Data




Figure A-6. Register Allocation for Modbus Function Code 3, Packed Data

Data Support, Modbus Function Code 8

ValveLink Solo supports Modbus function code 8, subfunction code 0 for loopback testing. When ValveLink Solo receives a request function code 8, subfunction code 0, it echoes back exactly what was received.

ValveLink™ Software A-5



A-6 ValveLink™ Software

Glossary

abort

Request to discontinue a procedure.

active tag

The open tag as displayed in the title bar. Data for the active tag appears on the status bar. To open an instrument tag, double click the instrument symbol in the explorer view.

address

One or more integers arranged to identify the location of an instrument or multiplexer.

alert point

The values set to trigger an alert.

alphanumeric

Consisting of letters and numbers.

ANSI

American National Standards Institute.

ANSI Class

Valve pressure/temperature rating.

baud rate

Data transmission speed

boot or boot up

The process of initializing software to hardware to bring the software to a known state.

bus

A general term for a group of signal lines to be considered together, as in a data bus or address bus.

byte

A unit of binary digits (bits). A byte consists of eight bits.

configuration (CONFIG)

Giving instructions and supplying operating parameters for a FIELDVUE Instrument.

control signal

The voltage or current provided by ValveLink software to control the valve during testing.

CPU

Central Processing Unit

database

A collection of data stored in a systematic way so that searches and sorts can be rapid and that retrieval of items is simple.

deadband

The range through which an input signal can be varied without initiating observable output response.

device

A piece of electronic hardware that performs one or more prescribed functions.

device id

A unique identifier embedded in the instrument at the factory. ValveLink software uses this identifier to ensure it is communicating with the correct instrument.

download

Sending configuration instructions and calibration information from the ValveLink software database to a FIELDVUE Instrument.

DTM

Device Type Manager

EU

Acronym: Engineering Units

FDT

Field Device Type



firmware revision

The revision number of the instrument firmware. Firmware is a program that is entered into the instrument at the time of manufacture and cannot be changed by the user.

hardware revision

Revision number of the Fisher instrument hardware. The physical components of the instrument are defined as the hardware.

HART

Acronym: Highway Addressable Remote Transducer.

Input current

The current signal from the control system that serves as the analog input to the instrument.

Input signal

The current (or voltage) signal from the control system.

Instrument Society of America (ISA)

A professional organization of designers, manufacturers, and users of process control instrumentation.

Instrument level

Determines the functions available for the FIELDVUE instrument.

ISA

Acronym: Instrument Society of America

Long Address

A unique identifier that includes the manufacturer ID, device type, and device ID embedded in the instrument at the factory. ValveLink software uses this unique identifier to send messages to the instrument.

memory

A computer's storage for programs and data. Most computers and microprocessors have both internal and external memories: use of internal memories is faster, but the capacity of internal memories is more limited.

operating system

The software that controls and supervises all the internal operations of a computer.

parallel

Simultaneous: said of data transmission on two or more channels at the same time.

PCI

Peripheral Component Interconnect – a computer bus standard

primary master

Masters are communicating devices. A primary master is a communicating device typically permanently wired into the instrument in the field. You can establish either a communicating device in the control room or a PC running ValveLink software as the primary master for an instrument. In contrast, a hand-held communicator is a secondary master because it is not permanently wired into the instrument.

RAM

Acronym: Random Access Memory

random access memory (RAM)

A type of semiconductor memory. A user can read from and write to a RAM, electrically, as often as desired.

read-only memory (ROM)

A memory in which information is stored permanently. A user can examine ROM contents as often as desired but cannot change the contents.

ROM

Acronym: Read-Only Memory

Secondary Master

See Primary Master

Glossary-2 ValveLink™ Software



tag

A unique identifying mnemonic or label for a controller or point of a process control system.

temperature sensor

A device within the FIELDVUE instrument that measures the instrument's internal temperature.

travel sensor

A device within the FIELDVUE instrument that senses valve stem or shaft movement.

tuning set

Preset values that identify the gain and rate settings for a FIELDVUE instrument. The tuning set and supply pressure together determine an instruments response to input signal changes

upload

The movement of configuration instructions from a FIELDVUE Instrument to a PC running ValveLink software. An upload lets the current values of parameters be incorporated into the software, eliminating the need for user entry. Uploads also may be used to verify that configuration is correct.

ValveLink™ Software Glossary-3



Glossary-4 ValveLink™ Software

FISHER*

A	HART Modem, 8-2 NI-FBUS
Features, Adding, 7-8	Hardware, 10-2
AMS ValveLink SNAP-ON	Software, 10-2 Overview
Installation, 4-3	AMS ValveLink SNAP-ON, 4-2
Running, 4-4	ValveLink DTM, 5-2
	ValveLink PLUG-IN for PRM, 6-2
С	ValveLink Solo, 3-2 Preparing for, 2-2
•	Requirements
Capability, SNAP-ON for AMS, 4-2	Hardware and Software, 2-3
Communication, Troubleshooting, 13-1	Personal Computer, 2-4
Compatible Devices, 2-7	Troubleshooting, 13-1 ValveLink DTM, 5-3
Companie Bevices, 2 /	ValveLink PLUG-IN for PRM, 6-3
_	ValveLink Solo, 3-4
D	Installation Guide
Detakan Tan	About this Guide, 1-3
Database Tags Limits, Displaying, 7-7	Customer Feedback Form, 1-3
Listing for Modbus Network, 11-2	Organization, 1-4 Related Documents, 1-7
New Instrument, 9-8	Scope, 1-3
Device Descriptions, Installing, 10-7	Installation Options, 2-8
	IRQ and Memory Conflicts
E	Windows 2000, 10-6
E	Windows Server 2003, 10-6
Educational Service, 1-6	Windows Vista, 10-6 Windows XP, 10-6
,	Windows 711, 10 0
F	L
FOUNDATION Fieldbus	License
Connecting	Enabling, 7-3
to H1 segment, 10-9	Using a hardware key, 7-4
to instrument, 10-11 Link Active Scheduler, 10-9	using a software license key, 7-4 Recovering, 7-11
	Removing, 7-11
FOUNDATION fieldbus communication protocol, 10-9	Temporary, Enabling, 7-14 Transferring to another computer, 7-12
Н	License Key
••	Entering, 7-15 For fresh installation, 7-4
Hardware key, Updating, 7-13	For fresh installation, 7-4
HART Modem, Installation, 8-2	License Wizard, 7-1, 7-2 Enabling a license using a software license key, 7-4
ı	using an installation USB hardware key, 7-4
1	Licenses, 7-2
Installation	Enabling, 7-3
AMS ValveLink SNAP-ON, 4-3	License key for a StepUp, 7-9
Device Descriptions, 10-7	Link Active Scheduler, 10-9

ValveLink™ Software Index-1

M R Re-installing, ValveLink Solo, 3-6 Modbus Networks Data Support Related Documents, 1-7 Function Code 1, A-2 RS232-to-RS485 converter, 9-2 Function Code 2, A-3 RS485 network, 9-2 Function Code 3 and 4, A-4 Function Code 8, A-5 Packed Data, A-3 Protocol Support, A-1 Setup, 11-2 Slave Addresses, Modbus Network, 11-3 Multiplexer StepUp, of installed ValveLink Software, 7-8 Pepperl +Fuchs, Setup, 9-5 Tag and Descriptor, 9-4 StepUps Changing, 9-4 Features, 7-8 Valid Characters, 9-4 License Key for SetUp, 7-9 Viewing Status, 9-6 Support, Technical, 1-6 Multiplexer, Information window, 9-6 Supported Operating Systems AMS ValveLink SNAP-ON, 2-6 Multiplexer Network Adding Instruments, 9-8 ValveLink DTM, 2-6 ValveLink PLUG-IN for PRM, 2-6 Setup, 9-2 ValveLink Solo, 2-6 Verifying Connections, 9-3 Т N Technical Support, 1-6 **NI-FBUS** Troubleshooting PCI-FBUS/2 board, Installing, 10-3 Communication **PCMCIA-FBUS Card** COM Port, 13-2 Configuring, 10-3 Communications Errors, AMS ValveLink Installing, 10-2 **SNAP-ON**, 13-3 Multiplexer, 13-3 Network Rebuild, 13-3 P Serial Ports, 13-2 Installation, 12-3 Communications Error, 12-4 PCI-FBUS/2 Board, Installing, 10-3 NI-FBUS Does Not Start, 12-4 **PCMCIA-FBUS Card** Licensing, 12-2, 12-3 Configuring, 10-3, 10-5 PCMCIA-FBUS/2, Port Configuration, 12-4 Installing, 10-2 Uninstalling Software, 12-4 Pepperl+Fuchs Multiplexer, Setting Up, 9-5 Troubleshooting Installation, 12-1

Index-2 ValveLink™ Software





Updates, ValveLink Software, 1-6



ValveLink DTM Installation, 5-3 Starting, 5-4

ValveLink License Wizard, 7-2

ValveLink PLUG-IN for PRM Capability, 6-2 Starting, 6-6

ValveLink Software Features, 7-6 Capability, ValveLink DTM, 5-2 compatible devices, 2-7 Description, 1-2 installation options, 2-8

ValveLink Solo Capability, 3-2 Installation, 3-4 Re-installing, 3-6

ValveLink™ Software Index-3

For information, contact your local Emerson Process Management sales office or local business partner. Visit www.Fisher.com

NORTH AMERICA

Emerson Process Management Marshalltown, Iowa 50158 USA T 1 (641) 754-3011 F 1 (641) 754-2830

LATIN AMERICA

Emerson Process Management Sorocaba, Sao Paulo 18087 Brazil T +(55)(15)238-3788 F +(55)(15)228-3300

EUROPE

Emerson Process Management Chatham, Kent ME4 4QZ England T +44 (0)1634895800 F +44 (0)1634895842

MIDDLE EAST & AFRICA

Emerson FZE Dubai, United Arab Emirates T +971 4 883 5235 F +971 4 883 5312

ASIA PACIFIC

Emerson Process Management Singapore 128461 Singapore T +(65) 6777 8211 F +(65) 6777 0947

Fisher, FIELDVUE, ValveLink, PlantWeb, DeltaV, SNAP-ON, and Baumann are marks owned by one of the companies in the Emerson Process Management business division of Emerson Electric Co. Emerson Process Management, Emerson, and the Emerson logo are trademarks and service marks of Emerson Electric Co. HART is a mark owned by the HART Communication Foundation. Foundation fieldbus is a mark owned the Fieldbus Foundation. All other marks are the property of their respective owners.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available upon request. We reserve the right to modify or improve the designs or specifications of such products at any time without notice. Neither Emerson, Emerson Process Management, nor any of their affiliated entities assumes responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use, and maintenance of any product remains solely with the purchaser and end-user.

