

KAMAI 500 DUAL-BAND WI-FI ADAPTER

Quick Start Guide



What's Included



Kamai 500

Dual-band Wi-Fi Adapter



Quick Start Guide


WARNING: The Kamai 500 Dual-band Wi-Fi Adapter should not be installed in Desktop/Notebook Computer. PC/Laptop will not recognize this device when connected to USB port.

COPYRIGHT ©2013 Entone, Inc. All rights reserved. Entone, Kamai and "connecting the home" are registered trademarks of Entone, Inc. All other trademarks or registered trademarks belong to their respective owners.

P/N: 99-709704-00 - V1.1

Installation

1. Connect the Wi-Fi Adapter to USB port on Kamai 500 Set-Top-Box.




2. Powering up the Kamai.
3. Configure the Kamai to use Wireless Network.*

NOTE: Contact your service provider for more details and instructions about the wireless network configuration.




Added Range and Performance

For added range and performance, you can turn up the antenna for increased Wi-Fi performance.



NOTE: You may adjust the angle of the antenna for the best performance.

Declaration of Conformity

	<p>To ensure proper use of this product, please read this manual carefully and retain it for future reference. Should the unit require maintenance, contact an authorized service location.</p>
	<p>To prevent fire or shock hazard, do not expose this product to rain or moisture. To reduce the risk of electric shock, DO NOT remove the cover or back. No user serviceable parts are inside. For servicing refer to qualified personnel.</p>
	<p>Declaration of Conformity (United States Only) This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Federal Communication Commission (FCC) Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none">• Reorient or relocate the receiving antenna.• Increase the separation between the equipment and the receiver.• Connect the equipment to a different circuit from that to which the receiver is connected.• Consult the dealer or an experienced radio/TV technician for help. <p>FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.</p> <p>This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.</p> <p>Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.</p> <p>For product available in the USA/Canada market, only channel 1~11 can be operated. Selection of other channels is not possible.</p> <p>This device is restricted to indoor use when operated in the 5.15 to 5.25 GHz frequency range.</p> <ul style="list-style-type: none">• FCC requires this product to be used indoors for the frequency range 5.15 to 5.25 GHz to reduce the potential for harmful interference to co-channel Mobile Satellite systems.• This device will not permit operations on channels 116-128 for 11a and 120-128 for 11a which overlap the 5600 -5650MHz band.