

Asset Transponder EV3-AT

This asset transponder enjoys reduced power consumption and allows great flexibility, as member of EV3 family products, which is designed to provide dramatically improved functionality at a much more attractive price point than was attainable by previous conventional Active RFID design approaches. This device operates in a master/slave configuration with an interrogator. In all cases, the interrogator acts as the master unit initiating commands from the transponder. Once, the device has been successfully woken up, it will respond to data transmission from the interrogator by sending packets of data.

This device complies with part 15 of the FCC Rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

WARNING: Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment.



OPERATION OF THE TRANSPONDER

- Remove the battery cap by turning counterclockwise;
- 2. Insert battery to the battery compartment with positive terminal toward inside;
- 3. Replace the battery cap and secure it by turning clockwise;
- 4. The transponder will beep once when it is powered up.
- 5. Now the transponder is ready to be deployed.

MOUNTING OF THE TRANSPONDER

A matching bracket may be provided for the transponder.

- Securely Attach the bracket to a desired location using appropriate methods, such as magnet, Velcro strips, screws or other means;
- 2. Slide the powered transponder into the bracket until it is firmly inserted;
- 3. To remove the transponder from the bracket, push down the tab at the end of the bracket, slide the transponder out of the bracket.

RFID Protocol	ISO 18000-7:2008
Frequency	433.92MHz
Power	A' Size 3.6V primary lithium (Li-SOCI2), user replaceable
Battery Life	>6 years at 2 collections per day
Range	350 feet unobstructed
Dimensions	6.38 L x 2.17 W x 1.42 H
Weight	4.5 oz (127g)
Operating Temperature	-30°C to +70°C
Dust / Moist	IP 64
Beeper	Audible beeper for tag location and status indication
Memory	2 Kbytes
Compliance	FCC, HERO



Data Rich Transponder EV3-DRT

This data rich transponder enjoys many of the characteristics intrinsic to EV3 family products, which is designed to provide dramatically improved functionality at a much more attractive price point than was attainable by previous conventional Active RFID design approaches. Additionally, the increased memory size available locally at the asset site can allow for increased monitoring and visibility. This device operates in a master/slave con guration with an interrogator. In all cases, the interrogator acts as the master unit initiating commands from the transponder. Once, the device has been successfully woken up, it will respond to data transmission from the interrogator by sending packets of data.

This device complies with part 15 of the FCC Rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

WARNING: Changes or modi cations not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment.

OPERATION OF THE TRANSPONDER

- 1. Remove the battery cap by turning counterclockwise:
- 2. Insert battery to the battery compartment with positive terminal toward inside;
- 3. Replace the battery cap and secure it by turning clockwise;
- 4. The transponder will beep once when it is powered up.
- 5. Now the transponder is ready to be deployed.

MOUNTING OF THE TRANSPONDER

A matching bracket may be provided for the transponder.

- Securely Attach the bracket to a desired location using appropriate methods, such as magnet, Velcro strips, screws or other means;
- 2. Slide the powered transponder into the bracket until it is firmly inserted;
- 3. To remove the transponder from the bracket, push down the tab at the end of the bracket, slide the transponder out of the bracket.



RFID Protocol	ISO 18000-7:2008
Frequency	433.92MHz
Power	A' Size 3.6V primary lithium (Li-SOCI2), user replaceable
Battery Life	>5 years at 2 collections per day
Range	350 feet unobstructed
Dimensions	6.5 L x 2.37 W x 1.42 H
Weight	5.6 oz (158.8g)
Operating Temperature	-30°C to +70°C
Dust / Moist	IP 64
Beeper	Audible beeper for tag location and status indication
Memory	256 Kbytes
Compliance	FCC, HERO



License Plate Transponder

EV3-LPT



This license plate transponder is one of the more cost sensitive devices in EV3 family products, which is designed to provide dramatically improved functionality at a much more attractive price point than was attainable by previous conventional Active RFID design approaches. This device operates in a master/slave con guration with an interrogator. In all cases, the interrogator acts as the master unit initiating commands from the transponder. Once, the device has been successfully woken up, it will respond to data transmission from the interrogator by sending packets of data.

This device complies with part 15 of the FCC Rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

WARNING: Changes or modications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment.

OPERATION OF THE TRANSPONDER

- 1. Remove the battery cap by turning counterclockwise;
- 2. Insert battery to the battery compartment with positive terminal toward inside;
- Replace the battery cap and secure it by turning clockwise;
- 4. The transponder will beep once when it is powered up.
- 5. Now the transponder is ready to be deployed.

MOUNTING OF THE TRANSPONDER

A matching bracket may be provided for the transponder.

- Securely Attach the bracket to a desired location using appropriate methods, such as magnet, Velcro strips, screws or other means;
- 2. Slide the powered transponder into the bracket until it is firmly inserted;
- 3. To remove the transponder from the bracket, push down the tab at the end of the bracket, slide the transponder out of the bracket.

RFID Protocol	ISO 18000-7:2008
Frequency	433.92MHz
Power	A' Size 3.6V primary lithium (Li-SOCl2), user replaceable
Battery Life	>6 years at 2 collections per day
Range	350 feet unobstructed
Dimensions	6.38 L x 2.17 W x 1.42 H
Weight	4.5 oz (127g)
Operating Temperature	-30°C to +70°C
Dust / Moist	IP 64
Beeper	Audible beeper for tag location and status indication
Memory	256 bytes
Compliance	FCC, HERO



Sensor Transponder

EV3-ST

This sensor transponder incorporates temperature, humidity, shock and light sensing to our already powerful transponder capabilities of EV3 family products, which is designed to provide dramatically improved functionality at a much more attractive price point 2. Insert battery to the battery compartment than was attainable by previous conventional Active RFID design approaches. Additionally, the increased 3 memory size available locally at the asset site can allow for increased monitoring and visibility. This device operates in a master/slave con guration with an interrogator. In all cases, the interrogator acts as the master unit initiating commands from the transponder. Once, the device has been successfully woken up, it will respond to data transmission from the interrogator by sending packets of data.

This device complies with part 15 of the FCC Rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

WARNING: Changes or modi cations not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment.

OPERATION OF THE TRANSPONDER

- 1. Remove the battery cap by turning counterclockwise:
- with positive terminal toward inside;
- Replace the battery cap and secure it by turning clockwise;
- 4. The transponder will beep once when it is powered up.
- 5. Now the transponder is ready to be deployed.

MOUNTING OF THE TRANSPONDER

A matching bracket may be provided for the transponder.

- 1. Securely Attach the bracket to a desired location using appropriate methods, such as magnet, Velcro strips, screws or other means:
- 2. Slide the powered transponder into the bracket until it is firmly inserted;
- 3. To remove the transponder from the bracket, push down the tab at the end of the bracket, slide the transponder out of the bracket.



RFID Protocol	ISO 18000-7:2008
Frequency	433.92MHz
Power	A' Size 3.6V primary lithium (Li-SOCl2), user replaceable
Battery Life	>4.5 years at 2 collections per day
Range	350 feet unobstructed
Dimensions	6.5 L x 2.37 W x 1.42 H
Weight	5.6 oz (158.8g)
Operating Temperature	-30°C to +70°C
Dust / Moist	IP 64
Beeper	Audible beeper for tag location and status indication
Memory	512 bytes
Compliance	FCC, HERO