

CompuStar ANT2W

By Firstech, Inc

INSTALLATION AND USER'S GUIDE

website: www.compustar.org

FCC/ID Notice – N99J447A

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your Authorized CompuStar dealer.

ANTENNA MODULE

CompuStar ANT2W is an antenna module (hereinafter called Antenna Module) with the FCC ID N99J447A. Antenna Module is installed on the windshield horizontally for the maximum transmitting distance with Remote-Pager.

When Antenna Module receives a radio frequency signal from the hand-held transceiver (hereinafter called “Remote Pager”), the signal is demodulated to digital codes and then send it to Controller, then sends confirmation to Remote Pager. The typical electrical function of this Controller is attached in this manual as a wiring diagram. The Controller is connected to Antenna Module by wires.

If Controller sends digital codes to Antenna Module through the connecting wires, the codes are modulated to radio frequency signal and sent to Remote Pager.

