

Battery Tips

- Do not mix old and new batteries.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Remove the batteries during long periods of non-use. Always remove exhausted batteries from this toy. Battery leakage and corrosion can cause damage. Dispose of batteries safely.
- Do not dispose of batteries in a fire. The batteries may explode or leak.
- Never short circuit the battery terminals.
- Non-rechargeable batteries are not to be recharged.
- Only batteries of the same or equivalent type as recommended in the "Battery Installation" instructions are to be used.
- If removable rechargeable batteries are used, they are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the toy before they are charged.
- If you use a battery charger, it should be examined regularly for damage to the cord, plug, enclosure and other parts. Do not use a damaged battery charger until it has been properly repaired.

Toy ITS
 Ath: Ada
 Fr: Apex
 Polly
 May 15

Consumer Information

Call Fisher-Price® Consumer Relations, toll-free at 1-800-432-KIDS, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052.

Canada: call 1-800-567-7724, or write to: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2.

Great Britain: telephone 01628 500302.

Australia: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

New Zealand: 16-18 William Pickering Drive, Albany 1331, Auckland.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052, U.S.A.
 ©2002 Mattel, Inc. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.

Printed in China

78359pr-0920

Let's Go!

CAUTION


To prevent entanglement, keep hair away from wheels.

Play Safely! Do not operate toys in the street.

- Press the power button on the bottom of the toy to turn it on.
- Press the ↑ button and the toy moves forward!
- Press the ↓ button and the toy moves back and turns!
- Remember to press the power button on the bottom of the toy to turn it off.

Hints:

- The toy will automatically turn off (sleep mode) if it does not receive a signal from the remote within a few minutes. To turn the toy back on, simply press the power button on the bottom of the toy.
- The spider (27MHz) and the scorpion (49MHz) operate on different frequencies and can be used in the same area.



IMPORTANT!

- This toy works best on smooth, hard surfaces. We do not recommend use on grass, loose dirt or wet surfaces.
- For best performance:
 - Hold the remote with antenna upright.
 - Make sure the remote and the toy are in direct line of sight, free of obstacles.
 - Do not operate this toy around other remote control (RC) toys operating on the same frequency.
- If the toy operates erratically or does not respond to the remote, move the toy closer to the remote. If the toy still fails to respond to the remote, it's probably time for an adult to replace the batteries.
- In the unlikely event that use of the remote interferes with normal use of other remote controlled equipment, such as televisions and stereos, or use of other electric or battery powered appliances interfere with operation of the toy, do not use both appliances at the same time.

07695561295

15-MAR-2002 16:26

95%

P.01

001

TAK YUEN

15/03 '02 FRI 16:09 FAX 07695561295

2/2 ~~3/2~~

- To clean, wipe all parts with a damp cloth. Never immerse the remote or toy.
- Keep water, sand and dirt off of this toy.
- Keep this toy away from direct sunlight and excessive heat.
- Do not drop this toy on a hard surface.
- This product contains no consumer replaceable parts. Do not take this toy apart.

FCC Note (United States Only)

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate this equipment.

Spider

Model Number: 78359

Scorpion

Model Number: 78360

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

Consumer Relations Department

636 Girard Avenue

East Aurora, New York 14052



- Meets requirements of Council Directives 89/5/EC, 89/336/EEC, 88/378/EEC
- Suitable for use in all EC member states.