

Quick Start Guide

Congratulations on your purchase of the floorsense occupancy sensor. The following instructions will walk you through the process of turning on your sensor and mapping it to a location on a floorsense controller floorplan.

Prerequisites

In order to operate the floorsense sensor and discover occupancy data you will need to deploy the floorsense controller hardware and have an account setup at floorsense.com.au. The floorsense controller should be deployed prior to attempting to activate sensors. For more information on floorsense controllers please visit <https://support.smartalock.com/support/solutions/articles/5000847692-floorsense-administrator-guide>

Configuration

Turning on your floorsense sensor

1. Unpack your floorsense sensor and identify the installation location
2. Use a paper clip or end of a pen to toggle the on-off switch to ON position
3. The LED light will flash red and then green. After between 30-60 seconds the LED will flash blue once every 60 seconds when it connects to the floorsense controller.
4. Install the floorsense sensor in its final location - for example under a desk. See the hardware installation guide at <http://support.smartalock.com/support/solutions/articles/5000803912-floorsight-and-floorsense-installation-instructions>

Thats it! Navigate to the floorsense controller web portal to map the floorsense sensor to a floorplan location. If The LED does not transition to blue blinking check support.smartalock.com for more information.

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.