





成型尺寸: 75x120mm


128g双铜纸, 印4C, 表面过光油, 正反折

L1 Smart Lightbulb
Quick Start Guide

Product Overview:

L1 Smart Wi-Fi A19 Lightbulb is a tunable white, multi-color LED lightbulb that can be controlled wirelessly via iOS or Android smartphones and tablets, no hub required. You can customize your personal lighting using the VOCOLinc LinkWise App from anywhere with an active internet connection.



What's Included:

- L1 Smart Wi-Fi A19 Lightbulb
- Quick Start Guide

Product Requirements:

- Smartphone or tablet running iOS 10 or higher; Android 4.3.x or higher
- A Wi-Fi connection

Features:

- 16 million colors
- Works with Apple HomeKit
- Works with Amazon Alexa
- Remote Access

Specifications

Input: AC120V, 60Hz
Base type: E26
Rated Power: 9W
LED color range: 16 million colors with cool to warm whites
Color temperature: 2400K – 5300K
Luminous flux: 470 lumens
Beam angle: 220 degrees
Expected LED life: 22.8 years (25000 hours)

-- 2 --

Safety Warnings

-WARNING: RISK OF ELECTRIC SHOCK OR BURNS. Switch OFF the light switch controlling the bulb and WAIT for the bulb to cool down before attempting to change it.

- DO NOT install the Smart Wi-Fi LED Bulb with wet hands or when standing on wet or damp surfaces
- Not suitable for use with standard in-wall dimmers. Dimmable via the app only
- Not suitable for use in operating environment between 0°C and 40°C (32°F and 104°F)
- This device is not intended for use with emergency exit luminaires
- NOT FOR EMERGENCY LIGHTING
- For indoor use only
- DO NOT disassemble
- DO NOT clean with liquid

L1 Smart Lightbulb LED status

Status		L1
Turning on the first time	Searching Wi-Fi	White light at 5% brightness
Pairing		White light at 5% brightness
Device added successfully		White light at 50% brightness
Identifying the lightbulb		White light at 5% brightness quickly flashes 5 times
Firmware update completed		Flashes twice

Quick Start Guide

- Download and open the free VOCOLinc LinkWise app from the App Store (Apple App Store or Google Play).
- Cut the power before you screw L1 into a desired light socket. L1 will light up in white (5% brightness) to indicate it is ready for network setup.
- Make sure your iPhone or iPad (iOS 10.1 or later) is connected to a 2.4GHz Wi-Fi network. Use the router utility software to turn off 5GHz Wi-Fi networks.
- Log in or sign up for a VOCOLinc account (required for Alexa configuration).
- Tap "+" icon located on the top left corner and follow the on-screen directions to complete network setup.

Note: To add more devices (or repeat L1 setup process), tap "+" and you will see the accessory list. Each accessory has an identification code, e.g., VOCOLinc-XXX-XXXXXX. Make sure the last 6 characters of the identification code is consistent with the last 6 characters of MAC on the back of your L1.

-- 3 --

6. When prompted, scan the setup code or manually enter the setup code, and then follow the step to add the device to the Home and Room.

After scanning the setup code, if the app prompts "Couldn't add VOCOLinc-XXX-XXXXXX", please refer to the first FAQ. Please keep the setup code for future use.


7. You can assign a name to your device and use this name when speaking to Siri. For example, you can name your L1 "L1 light", then wake up Siri and speak "Turn on the L1 light".

8. Set up customized scenes to control multiple devices with a single command. For example, if you assign the "I'm going to sleep" command to the scene of turning off all the VOCOLinc lights in the bedroom. When you say "I'm going to sleep" to Siri, The lights will be turned off.

9. The use of a HomeKit-enabled accessory need the follow permissions:
Settings > iCloud > iCloud Drive > Turn On
Settings > iCloud > Keychain > Turn On
Settings > Privacy > HomeKit > LinkWise > Turn On


Enabling Alexa

- Create an account in LinkWise App (username and password are case sensitive) and login to your account.
- Go to LinkWise App > long press the device icon to enter the menu. Look for "Third Party Connection". Tap "Alexa" to complete configuration (iOS app only).




-- 4 --

3.Open Alexa App and enable VOCOLinc Alexa skills using the same account info.



-- 5 --


Download on the App Store



Scan QR Code

VOCOLinc App


ANDROID APP ON Google play



Scan QR Code

Setup code


www.vocolinc.com



Scan QR Code

-- 6 --

4. Discover L1 in the Alexa App, and then follow the steps to complete setup.



Alexa Skills

- "Alexa, turn on (name)"
- "Alexa, turn off (name)"
- "Alexa, set (name) to x percent"
- "Alexa, brighten (name)"
- "Alexa, brighten (name) by x percent"
- "Alexa, dim (name)"
- "Alexa, dim (name) by x percent"
- "Alexa, set (name) to (color)"
- "Alexa, change (name) to (color)"

Factory Resetting

Resetting the smart lightbulb can help you troubleshoot any issues you may have. To reset it to factory defaults:

- Turn the light switch controlling the bulb to the OFF position.
- Flip the light switch on and off 3 times. Time lag between each cycle must not exceed 5 seconds.

The smart lightbulb will flash three times once reset is completed.

-- 7 --

Firmware Update

To gain better experience with L1, we strongly recommend that you update the firmware whenever updates with all the latest improvement and fixes are available:

- Launch LinkWise.
- Long press L1 icon to enter the menu.
- Look for "Firmware update" and tap it, and then tap "Update".

*Only the smart lightbulbs that are currently reachable and have an available update will prompt firmware update notice.

*It is important to leave the LinkWise app running while it finishes updating the smart lightbulbs. Try not to minimize the app, close the app, or interrupt the update to prevent problems.

FAQ

Q1. Why did I fail to add my L1 to the Linkwise App?

- Make sure your accessory is powered on and nearby.
- If you use a dual 2.4G/5G network router, please turn off the 5G network. Connect your phone with 2.4G network and add the device again.
- Make sure that the router setting meets the relevant requirements. The device only supports the mode of WPA/WPA2-PSK.
- Make sure that L1 is in pairing mode. If not, please reset L1 to factory defaults.
- Select the accessory shown on screen, then scan the setup code (XXX-XX-XXX) which can be found on the device, instruction manual or inner packaging.
- If the app prompts "Couldn't add L1-XXXXXX" after you scan the setup code:
 - Close the app
 - Restart the phone
 - Restore L1 to factory settings
 - Add the device again

Q2. How can I recover connection of the device?

- Modification of the router configuration/settings will cause non-resumable disconnection of the device. Delete and add the devices again after factory reset following steps in Q1.
- Unstable network signal could cause disconnection of the device. Wait for about 2 minutes for automatic re-connection. If the connection does not resume after a while, power off L1 and then put it back on. It shall re-connect automatically.
- If the above is not effective, delete and add the devices again after factory reset following steps in Q1.

If you have more questions, please feel free to contact us: support@vocolinc.com.

Q3. The device works normally after restoring factory settings or switching on/off, but it occasionally gets disconnected from the network and can not be recognized.

- Make sure the number of Wi-Fi connected devices is within the wireless network capacity of your router. Otherwise, please replace with another router.
- Reconnect your iOS devices to Wi-Fi and make sure your Wi-Fi signal is strong enough.

-- 8 --

3. Wait until the network is fixed if your router performs poorly in wireless networks that might result from network congestion.

4. Check the router setting and see if there is any limit to the number of simultaneous client connections.

5. Restart your HomeKit accessory or restore your HomeKit accessory to factory settings, and add your HomeKit accessory to the Vocolinc LinkWise app.

6. Update LinkWise App and product firmwares to the latest version.

Q4. Can I control multiple Smart Wi-Fi LED Bulbs at the same time?

Yes. You can manage and save multiple bulbs together as a "scene".

Q5. Can I dim the Smart Wi-Fi LED Bulbs?

The Smart Wi-Fi LED Bulbs are not designed for use with traditional wall-dimmer. It can only be dimmed via the LinkWise app.

Q6. I have set my brightness to 0% before I turn off light switch. Why does it resume to 5% brightness as soon as I turn on the lights switch again?

This is a preset setting to indicate that the smart lightbulb is in good shape.

System Requirement:

- Mobile device running iOS10+ or Android 4.3+
- Existing Wi-Fi network

*Place the Smart Wi-Fi LED Bulb within the range of your Wi-Fi router or access point (approximately 100 feet).

*Avoid physical obstructions and radio interference in the surrounding area.

Legal Information

Apple, iPad, iPad Air, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. HomeKit is a trademark of Apple Inc.

Use of the Works with Apple HomeKit logo means that an electronic accessory has been designed to connect specifically to iPad®, iPhone®, or iPad®, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Controlling this HomeKit-enabled accessory automatically and away from home requires an Apple TV with tvOS 10.1 or later or an iPad with iOS 10.1 or later set up as a home hub.

To control this HomeKit-enabled accessory, iOS 10.1 or later is recommended.

FCC Declaration

Cautions:

This device complies with Part 15 of the FCC Rules / Industry Canada licence-exempt RSS (SIS) standards. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

-- 9 --

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Changes or modifications not expressly approved by the manufacturer for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

MPE Requirements

To satisfy FCC / IC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antennas of this device and persons during device operation.

To ensure compliance, operators at closer than this distance is not recommended. L'antenne installée doit être située de façon à ce que la population ne puisse être exposée à une distance de moins de 20 cm. Installer l'antenne de façon à ce que le personnel ne puisse approcher à 20 cm ou moins de la position centrale de l'antenne. La FCC des états-unis stipule que cet appareil doit être en tout temps éloigné d'au moins 20 cm des personnes pendant son fonctionnement

-- 9 --