

GENERAL DYNAMICS
C4 Systems



ES2440 High-Capacity Infrastructure Mesh Point

Hardware Guide

Fortress ES2440 High-Capacity Infrastructure Mesh Point [rev.4a]

Copyright © 2012 Fortress Technologies, Inc. All rights reserved.

This document contains proprietary information protected by copyright. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, without written permission of Fortress Technologies, 2 Technology Park Drive, Westford, MA 01886-3140, except as specified in the Product Warranty and License Terms.

FORTRESS TECHNOLOGIES MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. FORTRESS TECHNOLOGIES SHALL NOT BE LIABLE FOR ERRORS CONTAINED HEREIN OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, PERFORMANCE OR USE OF THIS MATERIAL. THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE.

The General Dynamics C4 Systems | Fortress Technologies, Fortress Technologies and AirFortress logos and AirFortress and are registered trademarks. Multi-Factor Authentication, Unified Security Model, Wireless Link Layer Security and Three Factor Authentication (TFA) are trademarks of Fortress Technologies, Inc. The technology behind Wireless Link Layer Security™ enjoys U.S. and international patent protection under patent number 5,757,924.

All trademarks mentioned in this document are the property of their respective owners.

LIMITED WARRANTY

Hardware

Fortress warrants the Hardware will be free of defects in material and workmanship under normal use. Fortress further warrants that the Hardware will conform to Specifications in effect on the date of shipment of the product, from Fortress location.

Software

The Limited Warranty as described in the Fortress End User License Agreement (EULA) sets forth Fortress' warranty obligations with respect to Software. This End User License Agreement is included with the product or a copy may be obtained at the following URL: <http://www.gdfortress.com/Support/general-support.html>

This limited warranty extends only to the original purchaser of the Product.

DURATION OF WARRANTY

Hardware and Software is warranted for a period of one (1) year commencing from the ship date to Purchaser [and in the case of resale by a Fortress Solution Provider, commencing not more than (90) days after original shipment by Fortress]. The date of shipment is established per the shipping document (packing list) for the Product that is shipped.

REMEDIES

Purchaser's sole and exclusive remedy (within the warranty period) and the entire liability of Fortress and its suppliers under this limited warranty will be, after return to a Fortress repair facility, the repair and return of Product to Purchaser. At Fortress' option if it is not able to repair the product, we will replace it with a comparable product that is new or refurbished. Purchaser shall pay expenses for return of such Products to Fortress. Fortress shall pay expenses for shipment of returned Products to Purchaser.

WARRANTY EXCLUSIONS

The above Hardware and Software (EULA) limited warranty do not apply if the Hardware Product or Software or any other equipment upon which the Software is authorized by Fortress or its suppliers or licensors to be used (a) has been damaged through abuse or negligence or by accident, (b) has been altered except by an authorized Fortress representative, (c) has been subjected to abnormal physical or electrical stress (i.e., lightning strike) or abnormal environmental conditions, (d) has been lost or damaged in

transit, or (e) has not been installed, operated, repaired or maintained in accordance with instructions provided by Fortress.

Purchaser is responsible for all freight expenses incurred as a result of returning Products that are determined by Fortress to be (1) free from defect or (2) defective as a result of one of the circumstances listed in (a) through (e) above.

Such Products shall be shipped back to Purchaser, and Purchaser shall be responsible for associated freight charges. If Products are returned to Purchaser, title to the Products and risk of loss shall pass to Purchaser at the time Fortress delivers Products to the carrier for shipment.

Limited Warranty shall apply only to those Products that are branded by Fortress with a Fortress trademark ("Fortress Branded"). Fortress does not warrant any third party Products even if included with other Fortress Branded Products. Furthermore, Fortress provides all such third party Products AS IS. However, the original manufacturers or suppliers may provide their own warranties as specified in the documentation accompanying such third party Products.

LIMITED MAINTENANCE & SUPPORT

Fortress provides "Limited Maintenance & Support" on its Products during the Limited Warranty period. Limited Hardware Maintenance & Support consists of (a) repair or replacement of defective components/products and (b) remote technical support. Limited Software Maintenance & Support consists of (a) bug fixes, (b) maintenance releases, and (c) remote technical support.

Limited Maintenance & Support will be provided based on the Urgency & Escalation process in affect at the time of the trouble report.

Issues with products are reported by calling Fortress Technical Support at (978) 923-6400. Note: Please be prepared to provide the product serial number(s), version number(s), and name of the company the product was purchased from (if other than Fortress) to the Fortress Technical Support Engineer; this will assist in determining maintenance & support status.

Technical Support will work to resolve the issue over the phone. If a product needs to be returned to Fortress for repair or replacement; a Returned Materials Authorization (RMA) number will be issued for the return. Note: Fortress Technical Support will e-mail the RMA information which will provide the ship to address, to the person requesting the RMA.

Purchaser ships the product(s) to the address provided for repairs or replacement. Notes: (1) Purchaser pays for shipping to Fortress Technologies service location. (2) Fortress pays for return of repaired or replacement product(s) back to Purchaser location. (3) Fortress evaluates the product and either repairs or replaces it free of charge, other than for Warranty Exclusions.

Services and support provided to diagnose a reported issue with a Fortress Product, which is then determined not to be the root cause of the issue, may at Fortress' option be billed at the standard time and material rates.

Fortress will make all reasonable efforts to repair or replace any returned Product(s) within 10 business days of receipt.

Fortress Technologies Inc. reserves the right to use refurbished parts to complete repairs.

Maintenance & Support Exclusions


Products that are determined by Fortress to be (1) free from defect or (2) defective as a result of one of the circumstances listed in (a) through (e) in Warranty Exclusions above; are not covered under the Service & Support Program. Such repairs with the consent of the Purchaser would be performed on a Time & Materials basis.

WARRANTY DISCLAIMERS

THE WARRANTIES HEREIN ARE SOLE AND EXCLUSIVE, AND NO OTHER WARRANTY, WHETHER WRITTEN OR ORAL, IS EXPRESSED OR IMPLIED. TO THE EXTENT PERMITTED BY LAW, FORTRESS SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE AND NONINFRINGEMENT.

IMPORTANT SAFETY INFORMATION

The ES2440 is an outdoor device. It should be powered by a mid-span PoE (Power over Ethernet) injector obtained from Fortress Technologies over a weatherized Ethernet cable OR by a DC power adapter/supply obtained from Fortress Technologies over a weatherized DC power cable. Either power source, mid-span PoE injector or DC power supply, and the power cord and AC supply it plugs into should remain indoors, protected from the weather. The connection between the ES2440 and its indoor power source/connectors must be made using a weatherized cable (Ethernet or DC power). In this way, power can be safely provided to the outdoor ES2440 while the power source/connectors remain protected indoors, as shown:



IMPORTANT FCC INFORMATION

The Federal Communications Commission has released Office of Engineering and Technology Laboratory Division Knowledge Database (KDB) 44399, which refines the definition of Dynamic Frequency Selection (DFS) support. Since this device has the ability to use frequencies covered by DFS, KDB 44399 must be followed. It is published in full on the FCC web site: <https://apps.fcc.gov/oetcf/kdb/forms/FTSSearchResultPage.cfm?switch=P&id=41732>

In order to support FCC KDB 44399, Fortress has limited the use of certain frequencies within the 5400–5725 MHz range. Specifically, the frequencies defined by the FCC as being of primary interest are those in the 5600–5650 MHz range, which correspond to 802.11a channels 120, 124, and 128. In order to comply with the KDB 44399, these channels have been removed from use, or *notched*. Notched channels are unavailable for use on this device.

KDB 44399 provides additional restrictions on the use of channels within 30 MHz of notched channels when the device is within 35 km of a Terminal Doppler Weather Radar (TDWR) installation. Affected channels 116, 132, and 136 serve as a *guard* of 30 MHz around the critical notched frequencies. Guard frequencies are unavailable for use on this device by default. The FCC allows these channels to be used, however, as long as the device is not within 35 km of a TDWR installation, as described in this excerpt of KDB 44399:

Any installation of either a master or a client device within 35 km of a TDWR location shall be separated by at least 30 MHz (center-to-center) from the TDWR operating frequency.

In some instances it is possible that a device may be within 35 km of multiple TDWRs. In this case the device must ensure that it avoids operation within 30 MHz for each of the



TDWRs. This requirement applies even if the master is outside the 35 km radius but communicates with outdoor clients which may be within the 35 km radius of the TDWRs.

The requirement for ensuring 30 MHz frequency separation is based on the best information available to date. If interference is not eliminated, a distance limitation based on line-of-sight from TDWR will need to be used.

Please refer to the original KDB 443999 as posted on the FCC web site for the complete text.

In order to enable channels 116, 132, and/or 136, please contact Fortress to obtain a special license. This license will be issued after it is confirmed that the installation is not within 30 MHz and 35 km of registered TDWR sites. The following table (provided by the FCC in KDB 443999 published on 10/14/2010) describes the locations of TDWR sites, as well as the frequencies at which these sites operate:

TDWR Location Information				FREQUENCY	TERRAIN ELEVATION (MSL) [ft]	ANTENNA HEIGHT ABOVE TERRAIN [ft]
STATE	CITY	LONGITUDE	LATITUDE			
AZ	PHOENIX	W 112 09 46	N 33 25 14	5610 MHz	1024	64
CO	DENVER	W 104 31 35	N 39 43 39	5615 MHz	5643	64
FL	FT LAUDERDALE	W 080 20 39	N 26 08 36	5645 MHz	7	113
FL	MIAMI	W 080 29 28	N 25 45 27	5605 MHz	10	113
FL	ORLANDO	W 081 19 33	N 28 20 37	5640 MHz	72	97
FL	TAMPA	W 082 31 04	N 27 51 35	5620 MHz	14	80
FL	WEST PALM BEACH	W 080 16 23	N 26 41 17	5615 MHz	20	113
GA	ATLANTA	W 084 15 44	N 33 38 48	5615 MHz	962	113
IL	MCCOOK	W 087 51 31	N 41 47 50	5615 MHz	646	97
IL	CRESTWOOD	W 087 43 47	N 41 39 05	5645 MHz	663	113
IN	INDIANAPOLIS	W 086 26 08	N 39 38 14	5605 MHz	751	97
KS	WICHITA	W 097 26 13	N 37 30 26	5603 MHz	1270	80
KY	COVINGTON CINCINNATI	W 084 34 48	N 38 53 53	5610 MHz	942	97
KY	LOUISVILLE	W 085 36 38	N 38 02 45	5646 MHz	617	113
LA	NEW ORLEANS	W 090 24 11	N 30 01 18	5645 MHz	2	97
MA	BOSTON	W 070 56 01	N 42 09 30	5610 MHz	151	113
MD	BRANDYWINE	W 076 50 42	N 38 41 43	5635 MHz	233	113
MD	BENFIELD	W 076 37 48	N 39 05 23	5645 MHz	184	113
MD	CLINTON	W 076 57 43	N 38 45 32	5615 MHz	249	97
MI	DETROIT	W 083 30 54	N 42 06 40	5615 MHz	656	113
MN	MINNEAPOLIS	W 092 55 58	N 44 52 17	5610 MHz	1040	80
MO	KANSAS CITY	W 094 44 31	N 39 29 55	5605 MHz	1040	64
MO	SAINT LOUIS	W 090 29 21	N 38 48 20	5610 MHz	551	97
MS	DESOTO COUNTY	W 089 59 33	N 34 53 45	5610 MHz	371	113
NC	CHARLOTTE	W 080 53 06	N 35 20 14	5608 MHz	757	113
NC	RALEIGH DURHAM	W 078 41 50	N 36 00 07	5647 MHz	400	113
NJ	WOODBIDGE	W 074 16 13	N 40 35 37	5620 MHz	19	113
NJ	PENNSAUKEN	W 075 04 12	N 39 56 57	5610 MHz	39	113
NV	LAS VEGAS	W 115 00 26	N 36 08 37	5645 MHz	1995	64
NY	FLOYD BENNETT FIELD	W 073 52 49	N 40 35 20	5647 MHz	8	97
OH	DAYTON	W 084 07 23	N 40 01 19	5640 MHz	922	97
OH	CLEVELAND	W 082 00 28	N 41 17 23	5645 MHz	817	113
OH	COLUMBUS	W 082 42 55	N 40 00 20	5605 MHz	1037	113
OK	AERO. CTR TDWR #1	W 097 37 31	N 35 24 19	5610 MHz	1285	80



TDWR Location Information				FREQUENCY	TERRAIN ELEVATION (MSL) [ft]	ANTENNA HEIGHT ABOVE TERRAIN [ft]
STATE	CITY	LONGITUDE	LATITUDE			
OK	AERO. CTR TDWR #2	W 097 37 43	N 35 23 34	5620 MHz	1293	97
OK	TULSA	W 095 49 34	N 36 04 14	5605 MHz	712	113
OK	OKLAHOMA CITY	W 097 30 36	N 35 16 34	5603 MHz	1195	64
PA	HANOVER	W 080 29 10	N 40 30 05	5615 MHz	1266	113
PR	SAN JUAN	W 066 10 46	N 18 28 26	5610 MHz	59	113
TN	NASHVILLE	W 086 39 42	N 35 58 47	5605 MHz	722	97
TX	HOUSTON INTERCONTL	W 095 34 01	N 30 03 54	5605 MHz	154	97

In addition, the FCC recommends that all operators and installers register with the WISPA database used by government agencies to quickly find devices that may be causing interference and notify their owners/operators to shut them down. This registration is not required, but Fortress strongly recommends that all systems be registered, as described in this excerpt of KDB 44399:

A voluntary WISPA sponsored database has been developed that allows operators and installers to register the location information of the UNII devices operating outdoors in the 5470 – 5725 MHz band within 35 km of any TDWR location (see <http://www.spectrumbridge.com/udia/home.aspx>). This database may be used by government agencies in order to expedite resolution of any interference to TDWRs.

KDB 443999 further specifies that the requirements of KDB 594280 must also be met.

KDB 594280 is published in full on the FCC web site:

<https://apps.fcc.gov/oetcf/kdb/forms/FTSSearchResultPage.cfm?switch=P&id=39498>.

This device meets KDB 594280 by not allowing any configuration options to be made such that the device could be taken out of compliance. There is no ability for the user to change country codes or to select power levels that would take the device out of compliance.

For customers such as the U.S. military or others willing to produce evidence that particular devices will be used only outside of the United States, a special license can be obtained from Fortress that will allow those devices the option of selecting a different, non-U.S. country code. Fortress creates such licenses only for those customers who offer proof of non-U.S. device usage, and licenses are specific to particular devices and are not transferrable. Devices having such a license should NOT be considered to be compliant with FCC regulatory requirements. Please contact Fortress with questions about these special licenses.

Only software that has been signed by Fortress using the Fortress private key can be loaded onto a Fortress device, thus insuring that no software other than that which is controlled and signed by Fortress can be loaded onto the device.

**FCC EMISSIONS COMPLIANCE
AND INDUSTRY CANADA STATEMENTS**

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS B DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE IN A RESIDENTIAL INSTALLATION. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTIONS, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS. HOWEVER, THERE IS NO GUARANTEE THAT INTERFERENCE WILL NOT OCCUR IN A PARTICULAR INSTALLATION. IF THIS EQUIPMENT DOES CAUSE

HARMFUL INTERFERENCE TO RADIO OR TELEVISION RECEPTION, WHICH CAN BE DETERMINED BY TURNING THE EQUIPMENT OFF AND ON, THE USER IS ENCOURAGED TO TRY TO CORRECT THE INTERFERENCE BY ONE OR MORE OF THE FOLLOWING MEASURES:

- REORIENT OR RELOCATE THE RECEIVING ANTENNA.
- INCREASE THE SEPARATION BETWEEN THE EQUIPMENT AND THE RECEIVER.
- CONNECT THE EQUIPMENT INTO AN OUTLET ON A CIRCUIT DIFFERENT FROM THAT TO WHICH THE RECEIVER IS CONNECTED.
- CONSULT THE DEALER OR AN EXPERIENCED RADIO/TV TECHNICIAN FOR HELP.

YOU MAY ALSO FIND HELPFUL THE FOLLOWING BOOKLET, PREPARED BY THE FCC: "HOW TO IDENTIFY AND RESOLVE RADIOTV INTERFERENCE PROBLEMS." THIS BOOKLET IS AVAILABLE FROM THE U.S. GOVERNMENT PRINTING OFFICE, WASHINGTON, D.C. 20402

CHANGES AND MODIFICATIONS NOT EXPRESSLY APPROVED BY THE MANUFACTURER OR REGISTRANT OF THIS EQUIPMENT CAN VOID YOUR AUTHORITY TO OPERATE THIS EQUIPMENT UNDER FEDERAL COMMUNICATIONS COMMISSION RULES. IN ORDER TO MAINTAIN COMPLIANCE WITH FCC REGULATIONS, SHIELDED CABLES MUST BE USED WITH THIS EQUIPMENT. OPERATION WITH NON-APPROVED EQUIPMENT OR UNSHIELDED CABLES IS LIKELY TO RESULT IN INTERFERENCE TO RADIO AND TELEVISION RECEPTION.

IN ADDITION, USERS SHOULD ALSO BE CAUTIONED TO TAKE NOTE THAT HIGH POWER RADARS ARE ALLOCATED AS PRIMARY USERS (MEANING THEY HAVE PRIORITY) OF 5250-5350 MHZ AND 5650-5850 MHZ AND THESE RADARS COULD CAUSE INTERFERENCE AND/OR DAMAGE TO LE-LAN DEVICES.

ICES-003 STATEMENT:

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.

OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION OF THE DEVICE.

TO REDUCE POTENTIAL RADIO INTERFERENCE TO OTHER USERS, THE ANTENNA TYPE AND ITS GAIN SHOULD BE SO CHOSEN THAT THE EQUIVALENT ISOTROPICALLY RADIATED POWER (E.I.R.P.) IS NOT MORE THAN THAT PERMITTED FOR SUCCESSFUL COMMUNICATION.


 **CAUTION:** 4.4 GHZ RADIOS ARE OPTIONAL EQUIPMENT IN THE ES2440. THE 4.400 GHZ–4.780 GHZ FREQUENCY RANGE IS REGULATED BY THE UNITED STATES NATIONAL TELECOMMUNICATIONS AND INFORMATION ADMINISTRATION AND ALLOCATED EXCLUSIVELY FOR GOVERNMENT USE. USE OF 4.4 GHZ RADIOS OUTSIDE OF U.S. GOVERNMENT APPLICATIONS AND AUTHORITY IS STRICTLY FORBIDDEN.

Table of Contents

1		
Overview		1
<hr/>		
This Document		1
Related Documents		1
The ES2440		2
Hardware Models		2
Shipped and Optional Parts		3
2		
Installation		4
<hr/>		
Preparation		4
Safety Requirements		4
Powering Options		5
Port and Grounding Stud Locations		6
Front-Panel Connectors		6
Grounding Stud		7
Rear Panel Connectors		7
Connecting the ES2440		8
Connections for Preconfiguration		8
Connections for Deployment		9
Connecting the ES2440-3555 or ES2440-35 for Deployment		9
Connecting the ES2440-3444 or ES2440-34 for Deployment		10
Connecting the ES2440-0 for Deployment		10
Disconnection		10
Mast Mounting the ES2440		11

3		
LEDs and Button Operation		12
<hr/>		
Front-Panel LED Indicators		12
Recessed Button Operation		13
4		
Specifications		14
<hr/>		
Hardware Specifications		14
Physical Specifications		14
Environmental Specifications		15
Compliance and Standards		15
RJ45-to-DB9 Serial Port Adapter		15
2-Pin DC Input Connector		16
Index		I
<hr/>		

Chapter 1


Overview


1.1 This Document

This user guide covers preparing and installing the Fortress ES2440 High-Capacity Infrastructure Mesh Point hardware. It also describes the LED indicators and recessed button operation and provides specifications. Other Fortress hardware devices are covered in separate hardware guides, one for each Mesh Point (or Network Encryptor) model.

Fortress Mesh Point user guidance is intended for professional system and network administrators and assumes that its users have a level of technical expertise consistent with these roles.

Side notes throughout this document are intended to alert you to particular kinds of information, as visually indicated by their icons. Examples appear to the right of this section, in descending order of urgency.

 **WARNING:** can cause physical injury or death and/or severely damage your equipment.

 **CAUTION:** can corrupt your network, your data or an intended result.

1.1.1 Related Documents


Each Fortress hardware series runs the same Fortress software, and differences between ES and FC series software are minor. Fortress software user guidance covers all current Fortress hardware platforms.

Fortress Mesh Point software guides include:

- ◆ *Mesh Point and Network Encryptor Software GUI Guide*
- ◆ *Mesh Point and Network Encryptor Software CLI Guide*
- ◆ *Mesh Point and Network Encryptor Software Auto Configuration Guide*

In addition to this guide, the Fortress hardware guides include:

- ◆ *ES210 Tactical Mesh Point Hardware Guide*
- ◆ *ES440 Infrastructure Mesh Point Hardware Guide*
- ◆ *ES520 Deployable Mesh Point Hardware Guide*
- ◆ *ES820 Vehicle Mesh Point Hardware Guide*
- ◆ *FC-X Inline Network Encryptor Hardware Guide*

 **NOTE:** may assist you in executing the task, e.g. a convenient software feature or notice of something to keep in mind.

1.2 The ES2440

The ES2440 High-Capacity Infrastructure Mesh Point is a full-featured Fortress network device, providing strong data encryption and Multi-factor Authentication™, including native RADIUS authentication, to users and devices on the network it secures.

Two ES2440 models are each equipped with four radios:

- ◆ *Radio 1* is a 400 mW (milliwatt, peak power) dual-band 802.11a/b/g/n radio that can be configured to use either the 802.11b/g band or the 802.11a band, with an option for 802.11n capability in either band. *Radio 1* supports Multiple-Input Multiple-Output (MIMO) operation.
- ◆ Standard equipment *Radio 2*, *Radio 3* and *Radio 4* are 631 mW (peak power) radios fixed on the 802.11a band, also with an option for 802.11n capability and MIMO support. The ES2440 can be optionally equipped with three 800mW (peak power) 802.11a/n 4.4 GHz radios in place of the standard equipment *Radios 2*, *3*, and *4*. The 4.4 GHz radios do not support MIMO.

Any of the ES2440's radios can function as a wireless access point (AP), providing secure WLAN connectivity to wireless devices within range and as a wireless bridge or node in a mesh network.


A third ES2440 model without radios—the High-Capacity Infrastructure Mesh Point for Inline Encryption—is intended exclusively for wired Ethernet operation.


All ES2440 models are equipped with an internal global positioning system (GPS) receiver.

1.2.1 Hardware Models

You can identify by the full model number of the ES2440 whether it is equipped with radios and, if so, how many internal radio are installed and whether they are standard dual band or 5 GHz 802.11a radios or 4.4 GHz radios:

- ◆ ES2440-3555 - four radios:
 - ❖ one dual band 802.11a/b/g/n MIMO-capable radio
 - ❖ three 802.11a/n 5 GHz MIMO-capable radios
- ◆ ES2440-3444 - four radios:
 - ❖ one dual band 802.11a/b/g/n MIMO-capable radio
 - ❖ three 4.4 GHz radios
- ◆ ES2440-35 - two radios:
 - ❖ one dual band 802.11a/b/g/n MIMO-capable radio
 - ❖ one 802.11a/n 5 GHz MIMO-capable radio
- ◆ ES2440-34 - two radios:
 - ❖ one dual band 802.11a/b/g/n MIMO-capable radio
 - ❖ one 4.4 GHz radio
- ◆ ES2440-0 - no radios

 **NOTE:** Although optional 4.4 GHz radios are covered throughout this guide, as of the version 5.4.1 release, they were not yet supported in Mesh Point software. Consult your Fortress representative about future 4.4 GHz radio support on the ES2440.


 **CAUTION:** Use of 4.4 GHz radios outside of U.S. Government applications and authority is strictly forbidden.

The 4.400 GHz–4.780 GHz frequency range is regulated by the NTIA (National Telecommunications and Information Administration), the parent agency of the FCC (Federal Communications Commission). FCC labeling applied to the ES2440-3444 chassis therefore provides an FCC ID for only the 802.11a *Radio 1*.

Each radio-equipped model is furnished with the appropriate rear-panel antenna port configuration for the number and type of radios installed.

Rear-panel radio antenna ports and front-panel radio LED indicators are absent from the ES2440-0, and FCC markings appropriate for network devices incapable of wireless operation are applied to the chassis.

ES2440 chassis are otherwise identical.

 **NOTE:** Radio-related content in this guide, including regulatory information and precautions, does not apply to the ES2440-0.

1.2.2 Shipped and Optional Parts

All ES2440 shipments include (Fortress part numbers in parentheses):

- ◆ one ES2440 Mesh Point
- ◆ one DB9-to-RJ45 serial adapter (*part # 139-00002-01*)
- ◆ three weatherized Ethernet shell connectors (*part # 200-00229-01*)
- ◆ one software CD, including:
 - ❖ ES2440 Mesh Point software package
 - ❖ Fortress and standard SNMP MIBs
 - ❖ RADIUS dictionary file with Fortress Vendor-Specific Attributes for administrative authentication
 - ❖ ES2440 Mesh Point user guides and latest release notes

These additional items are included in shipments of radio-equipped ES2440s:

- ◆ one 18 VDC power adapter/supply (*part # 270-00144-01*)
- ◆ one AC power cord (*part # 620-00016-01*)
- ◆ one mast mounting kit (*part # 381-00004-01*)

This additional item is included in shipments of the ES2440-0:

- ◆ one DC power cable/connector assembly (*part # 620-00070-01*)

Optionally Available from Fortress

- ◆ 60W passive POE+ adapter/injector, gigabit compatible (*part # 270-00139-01*)
- ◆ replacement 18 VDC power adapter/supply (*part # 270-00144-01*)
- ◆ AC power cord for use with either of the above (*part # 620-00016-01*)

Chapter 2

Installation


2.1 Preparation


Before proceeding with installation, review the safety information in Section 2.1.1 below.

2.1.1 Safety Requirements


To prevent damage to the product and ensure your personal safety, operate the Mesh Point only within the operating specifications given in Section 4.1.2, and carefully follow these guidelines:

- ◆ *General:* This equipment must be installed by qualified service personnel according to the applicable installation codes. Do not locate the Mesh Point or antennas near power lines or power circuits. When installing an external antenna, take extreme care not to come into contact with such circuits as they can cause serious injury or death. Avoid metal ladders wherever possible. For proper installation and grounding, refer to national and/or local codes (WSNFPA 70 or, Canadian Electrical Code 54).
- ◆ *Indoor/Outdoor Siting:* All interconnected equipment connected to the Mesh Point must be contained within the same building, including the interconnected equipment's associated LAN connections.
- ◆ *Ambient Temperature:* The temperature of the environment in which the Mesh Point operates should not exceed the maximum (158° F/70° C) or drop below the minimum (-40° F/-40° C) operating temperatures.
- ◆ *Circuit Overloading:* The ES2440 version Mesh Point includes an internal 48V resettable fuse.
- ◆ *Powering:* The Mesh Point can be direct powered by 18 VDC or by 802.3at POE+ (Power over Ethernet Plus).

 **NOTE:** See additional IMPORTANT SAFETY INFORMATION on page iii at the front of this guide.

 **CAUTION:** Use only a DC power adapter or specialized PoE+ injector supplied by Fortress specifically for use with the ES2440.

- ◆ **Grounding:** Ground the ES2440 by connecting a ground wire to the grounding stud located on the left rear corner of the chassis (refer to Figures 2.1 and 2.2, below).
- ◆ **Radio Frequency:** The Mesh Point's internal radios conform to the FCC's safety standard for human exposure to RF electromagnetic energy, provided that you follow these guidelines:
 - ❖ Do not touch or move the antennas while the unit is transmitting or receiving.
 - ❖ To safeguard Mesh Point transmitting circuitry, relocate the Mesh Point and its antennas only when the Mesh Point is powered off.
 - ❖ When the Mesh Point is transmitting, do not hold it so that the antenna is very close to or touching any exposed parts of the body, especially the face or eyes.
 - ❖ Antennas must be installed to provide a separation of at least 25 cm (9.8") from all persons and any co-located antenna or transmitter.
 - ❖ Regarding use in specific environments: · Do not operate near unshielded blasting caps or in an explosive environment. · Limit use in a hazardous location to the constraints imposed by the location's safety director. · Abide by the rules of the Federal Aviation Administration for the use of wireless devices on airplanes. · Restrict the use of wireless devices in hospitals to the limits set forth by each hospital.

 **WARNING:** If the Mesh Point connects to outside-mounted antennas, failure to provide a low resistive earth ground can result in migration of voltage from lightning or line surges onto the premises wiring, which can cause electric shock and/or fire within the building or structure.

2.1.2 Powering Options

The ES2440 can be powered with:

- ◆ the 60W passive 802.3at PoE+ (Power over Ethernet Plus) gigabit compatible adapter/injector via the Ethernet1 port
- ◆ the 18 VDC (volts direct current) power adapter/supply via the **DC Power** inlet
- ◆ external DC power over the DC power cable/connector assembly, via the **DC Power** inlet

In any case, the power adapter (PoE+ or DC) or cable/connector assembly must be one obtained from Fortress specifically for use with the ES2440, or damage to the ES2440 could result.

Whether the mid-span PoE+ injector or a DC power supply is used to power the ES2440, the powering device, its power cord, and the supply it plugs into must remain indoors, protected from the weather. The connection between the ES2440 and its indoor power source/connectors must be made using a weatherized Ethernet or DC power cable.

The external DC power option is not intended to be a redundant back-up supply to PoE (or vice versa). The ES2440

will automatically disconnect PoE if external DC power is applied and will only reconnect PoE when DC power is removed. When either PoE or external DC are removed, the ES2440 will reboot.

Follow one of these procedures to power the ES2440:

with the POE+ adapter

Plug the PoE+ adapter/injector for the ES2440 into a properly rated AC outlet using the power cord provided for the device, and connect the adapter/injector to the ES2440's **Ethernet1/WAN/POE** port (refer to Figure 2.1) with a Cat5 Ethernet cable.

with the DC power adapter

Plug the DC power adapter/supply for the ES2440 into a properly rated AC outlet using the power cord provided for the device, and connect the power adapter/supply to the ES2440's **DC Power** inlet (refer to Figure 2.1).

with external DC power

Connect the DC power connector/cable assembly to a 11–32 VDC power source, and connect the assembly's 2-pin connector to the ES2440's **DC Power** inlet (refer to Figure 2.1).

2.1.3 Port and Grounding Stud Locations

Ethernet and power connectors are located on the ES2440 chassis front panel, and antenna and grounding connectors are located on the rear panel.

2.1.3.1 Front-Panel Connectors

Except for minor differences in LED labeling, the ES2440 front panel is the same for all hardware models.




Figure 2.1. ES2440 Front-Panel Ports, Reset Button, LEDs and Grounding Stud Location

The ES2440 Mesh Point's **Serial** port and three Ethernet ports, **Ethernet1/WAN/POE**, **Ethernet2**, and **Ethernet3** are located on the front panel, along with the **DC Power** inlet and recessed **Reset** button (see Figure 2.1).

All ES2440 front-panel ports are protected by captive covers. Unused ports should remain covered to protect against dust and other debris. Covered or uncovered, all ES2440 ports are waterproof.

The recessed button used to restore the running configuration to factory defaults (Section 3.2) is also located on the front panel, beneath a protective screw cap.

The LEDs located above the ES2440's ports are described in Section 3.1

2.1.3.2 Grounding Stud

On all ES2440 models, the grounding stud is the wing nut located on the left rear corner of the chassis, viewing the ES2440 from the front as shown in Figure 2.1 (refer to also to Figure 2.2).

2.1.3.3 Rear Panel Connectors

The ES2440 rear-panel antenna port configuration depends on the Mesh Point's hardware model.

ES2440-3555

Nine antenna connectors are situated on the ES2440-3555 back panel: eight, corresponding by pair to the ES2440's four internal radios, as shown below, and one for the ES2440 internal GPS.




Figure 2.2. ES2440-3555 Back-Panel Antenna Connectors

Antenna port ring labels identify which radio uses to each pair of ports by color: red, yellow, blue and brown (right-to-left in Figure 2.2), correspond to radios 1, 2, 3, and 4, respectively. Solid ring labels identify the radios' **A** antenna ports; dashed-line labels identify **B** ports. Antenna port labels are printed with the corresponding radio's 802.11 capabilities: **802.11a/b/g/n** or **802.11a/n**.

ES2440-3444

The ES2440-3444 is likewise equipped with the appropriate rear-panel antenna port configuration for the number and type of radios installed: two for *Radio 1*, and one for each 4.4 GHz radio (*Radio 2*, *Radio 3* and *Radio 4*). The GPS antenna port is also present in this model, for a total of six rear-panel antenna ports.

ES2440-35

Five antenna connectors are situated on the ES2440-35 back panel: four corresponding, by pair, to the ES2440's two internal radios, and one for the ES2440 internal GPS.

ES2440-34

The ES2440-34 rear panel is equipped with four antenna ports: two for *Radio 1*, one for the 4.4 GHz *Radio 2*, and the GPS antenna port.

ES2440-0

Only the GPS antenna port is present on the ES2440-0 chassis rear panel.

2.2 Connecting the ES2440

The ES2440 can be connected temporarily to preconfigure the Mesh Point software, and then permanently for deployment.

2.2.1 Connections for Preconfiguration


Mesh Point software should be configured in advance of deployment. This section provides instructions for temporarily connecting the ES2440 Mesh Point for preconfiguration.

- 1 Position the Mesh Point so that it operates only within its safe temperature range.
- 2 Apply power to the ES2440, either through the **Ethernet1/WAN/POE** port to PoE+ or through the **DC Power** inlet to external power. Refer to Section 2.1.2, *Powering Options*, for additional detail.

In either case, you must use a powering device (PoE+ adapter/injector or DC adapter/supply) obtained from Fortress specifically for use with the ES2440.

- 3 Connect a standard Cat5e cable to one of the ES2440's default clear Ethernet ports: **Ethernet2** or **Ethernet3**, and connect the other end to a computer or a switch on the wired LAN.

To complete the configuration, refer to the *Software GUI Guide* or the *Software CLI Guide* for instructions on Logging On, Licensing, and Configuring the Mesh Point software.

 **CAUTION:** Never plug the ES2440 into a PoE adapter/injector or DC power supply other than one obtained from Fortress specifically for use with the ES2440. Using the wrong power adapter can damage the ES2440.


2.2.2 Connections for Deployment


Review the IMPORTANT SAFETY INFORMATION on page iii and Safety Requirements in Section 2.1.1 before installing or operating the ES2440.


2.2.2.1 Connecting the ES2440-3555 or ES2440-35 for Deployment

Antennas used with the ES2440 must be professionally installed and must conform to FCC EIRP (Effective Isotropic Radiated Power) limitations. All antennas must have 50 Ohms impedance.


- 1 Ground the ES2440-3555/35 by connecting a ground wire to the grounding stud located on the left rear corner of the chassis (refer to Figure 2.1).
- 2 If your deployment uses Radio 1, connect a standard 2.4 GHz- or 5 GHz-capable antenna with an N-type male connector to antenna port A for Radio 1 (**Ant1A**).
If the radio will be configured for MIMO (multiple-input and multiple-output) operation, you **must** also connect a second such antenna to the radio's antenna port B (**Ant1B**).
- 3 If your deployment uses Radio 2 (and Radio 3 and Radio 4, if present), connect an antenna cable with a N-type male connector to the antenna port(s) for the radio(s) you will use: **Ant2A** (and **Ant3A** and **Ant4A**, if present). Connect a high-gain omnidirectional or directional antenna to the other end(s) of these cable(s).
If the radio(s) will be configured for MIMO operation, you **must** also connect a second such antenna, for each radio that will be so configured, to the radio's antenna port B: **Ant2B** (and **Ant3B** and **Ant4B**, if present).
- 4 If the Mesh Point's GPS function will be used, connect an SMA GPS antenna to the **GPS** antenna port.
- 5 Apply power to the ES2440-3555/35, either through the **Ethernet1/WAN/POE** port to PoE+ or through the **DC Power** inlet to external power. Refer to Section 2.1.2, *Powering Options*, for additional detail.
In either case, you must use a powering device (PoE+ adapter/injector or DC adapter/supply) obtained from Fortress specifically for use with the ES2440.
- 6 If your deployment includes Ethernet network connections, make them now: using standard Cat5e cable(s) for a through connection to **Ethernet1/WAN/POE** (default encrypted), and/or to connect **Ethernet2** and/or **Ethernet3** (both default clear).

 **WARNING:** To comply with FCC regulations, antennas must be professionally installed and the installer is responsible for ensuring compliance with FCC limits.

 **CAUTION:** The FCC requires co-located radio antennas to be at least 9.8" (25 cm) apart. The Mesh Point's antenna connectors are closer than this. Avoid directly mounting two or more antennas to the Mesh Point's rear-panel connectors.

 **CAUTION:** Outdoor antennas, connectors, and cables must be waterproof.

- 7 Verify that the **Power** LED illuminates, as well as the corresponding LEDs for all connected ports and enabled radio(s).


 **NOTE:** LED indicators are covered in Section 3.1


2.2.2.2 Connecting the ES2440-3444 or ES2440-34 for Deployment

Connection procedures for the ES2440-3444/34 are identical to those provided for the ES2440-3555 above, except that MIMO is not an option for its 4.4 GHz radios (*Radio 2*, and *Radio 3* and *Radio 4*, if present). Only a single antenna port is therefore present for each of these radios, and the second part of Step 3 in Section 2.2.2.1 does not apply.

2.2.2.3 Connecting the ES2440-0 for Deployment

- 1 Ground the ES2440-0 by connecting a ground wire to the ES2440's grounding stud located on the left rear corner of the chassis (refer to Figure 2.1).
- 2 If the Mesh Point's GPS function will be used, connect an SMA GPS antenna to the **GPS** antenna port.
- 3 Connect the front-panel Ethernet port(s), according to the requirements of your deployment, using standard Cat5e cable(s) to **Ethernet1/WAN/POE** (default encrypted), and/or to **Ethernet2** and/or **Ethernet3** (both default clear).
- 4 Connect the DC power connector/cable assembly included with the ES2440-0 to a 11–32 VDC power source, and apply power to the ES2440-0 through the **DC Power** inlet.
- 5 Verify that the **Power** LED illuminates, as well as the corresponding LEDs for all connected Ethernet ports.

 **CAUTION:** Outdoor antennas, connectors, and cables must be waterproof.

 **NOTE:** If you have obtained an alternative powering device from Fortress, refer to Section 2.1.2, *Powering Options*, for detailed instructions.

2.2.3 Disconnection

To disconnect and power down the ES2440, depending on the power source in use by the ES2440:

- ◆ Remove AC power from the PoE+ adapter/injector to which the ES2440 is connected by unplugging the adapter/injector's power cord from the wall.

or

- ◆ Remove DC power from the ES2440 by unplugging the DC power cable connector from the ES2440's **DC Power** inlet.

2.3 Mast Mounting the ES2440

A Mast-Mounting Kit is included with the ES2440-3555 and ES2440-3444. The ES2440-0 ships without it.




Figure 2.3. Mast mounting the ES2440

Mast-mounting hardware accommodates masts from 1.5" to 3" in diameter.

- 1 Fit the two hex bolts through the center mounting holes along the ES2440's sides, top to bottom.
- 2 Fix each bolt to the ES2440 chassis with a split-lock washer followed by a wing nut, tightened securely to the underside of the chassis.
- 3 Position the ES2440 at the desired position on the mast, with the underside of the chassis facing toward the mast and the front panel facing down, as shown in Figure 2.3.
- 4 Sandwiching the mast between the underside of the ES2440 and the mounting bracket, fit the mast into the toothed cut-outs in the mounting bracket and insert the bolt shafts extending from the chassis through the holes in the bracket.
- 5 Place a slip-lock washer and then a wing nut on each of the bolt ends, and tighten the nuts until the washers are flattened against the mounting bracket.

Chapter 3

LEDs and Button Operation

3.1 Front-Panel LED Indicators

The ES2440 Mesh Point features nine LEDs on the front panel (shown in Figure 2.1, on page 6).

Power, Status and Ethernet LEDs are present on all three ES2440 hardware models, and their behaviors have the same meanings across all models.

Power *can exhibit:*

- ◆ *solid green* - Mesh Point is powered on and operating normally.
- ◆ *off* - Mesh Point is powered off.
- ◆ *slow-flash green* - Mesh Point is booting.

Status *can exhibit:*

- ◆ *slow-flash green* - Auto-Config configuration or upgrade distribution is in progress.

Ethernet1, Ethernet2, Ethernet3 *can exhibit:*

- ◆ *solid green* - Link has been established.
- ◆ *intermittent green* - Traffic is passing on the port.

On the ES2440-3555 and ES2440-3444, the four LEDs on the right-hand side of the front panel correspond to the Mesh Point's internal radios.

Radio1, Radio2, (*and Radio3 and Radio4, when present*) *can exhibit:*

- ◆ *solid green* - Radio is on.
- ◆ *intermittent green* - Radio is passing traffic.
- ◆ *off* - Radio is off or Mesh Point's *RF Kill* function is enabled.

On the ES2440-0 the four LEDs on the right side of the front panel are labeled **S1**, **S2**, **S3**, and **S4** and are reserved for future functionality.

Table 3.1. LED Indicators in the ES2440

color	behavior	Power	Status	Ethernet1, Ethernet2, Ethernet3 Link/Act	Radio1, Radio2, Radio3, Radio4 ^a
green	<i>solid</i>	normal operation	-	link established	radio ON
	<i>slow flash</i>	booting	Auto-Config distribution	-	-
	<i>intermittent</i>	-	-	passing traffic	passing traffic
	<i>off</i>	powered OFF	-	-	radio OFF or RF Kill enabled

a. Present only on radio-equipped ES2440s, according to the number of radios installed. Corresponding LEDs **S1**, **S2**, **S3**, and **S4** on ES2440s equipped with fewer or no radios are reserved for future functionality.

3.2 Recessed Button Operation

The single recessed button on the ES2440 front panel (shown in Figure 2.1) returns the ES2440 Mesh Point to the factory default configuration.

The button is covered by a screw cap that you must remove, in order to access the button. ***You must replace the screw cap, in order to maintain the watertight integrity of the ES2440 chassis.***

To restore default settings, depress and hold the button for 10 seconds. All current configuration information on the running boot partition will be lost.

Chapter 4

Specifications

4.1 Hardware Specifications

4.1.1 Physical Specifications

	ES2440-3555/35	ES2440-3444/34	ES2440-0
form factor:	mountable, compact, rugged chassis		
dimensions:	2.75" H x 8.5" W x 10.75" D (6.99 cm x 21.59 cm x 27.3 cm)		
weight:	7.5 lbs (3.4 kg) / 7 lbs (3.18 kg)		6.5 lbs. (2.95 kg)
power supply:	802.3at POE+ or 11–32 VDC		
connections:	three RJ-45 10/100/1000 Mbps Ethernet ports with tethered caps one RJ-45 serial port with tethered cap		
	eight/four N-type radio antenna ports (female)	five/three N-type radio antenna ports (female)	no radio antenna ports
	one SMA antenna port for GPS receiver (female, passive or active) one 11–32 VDC power input port with tethered cap		
radios:	Radio1 ^a : 400 mW (peak power) 802.11a/b/g/n Radio2 ^a (& Radio3 ^a , Radio4 ^a , if present): 631 mW (peak power) 802.11a/n	Radio1 ^a : 400 mW (peak power) 802.11a/b/g/n Radio2 (& Radio3, Radio4, if present): 800mW (peak power) 802.11a/n 4.4GHz	n/a
system & port LED indicators:	Power, Status, Ethernet1 Link/Act, Ethernet2 Link/Act, Ethernet3 Link/Act		
	Radio1, Radio2, Radio3, Radio4		S1, S2, S3, S4 (future)

a. supports MIMO

4.1.2 Environmental Specifications

	ES2440-3555, ES2440-3444	ES2440-35, ES2440-34	ES2440-0
maximum power draw:	40 W	32 W	25 W
maximum heat dissipation:	137 BTUs/hr	110 BTUs/hr	85 BTUs/hr
cooling:	Convection Cooled		
operating temperature:	-40°–158° F (-40°–70° C)		
operating relative humidity:	5%–95% (non-condensing)		
storage temperature:	-40°–158° F (-40°–70° C)		

4.1.3 Compliance and Standards

emissions/immunity:	CE, FCC, IC, ETSI, CB Test, MIL-STD 464A, MIL-STD 461F
vibration:	MIL-STD 810G
weather resistance:	IP67 submersible

The Fortress ES2440-3555 is certified by the Wi-Fi Alliance® for the following standards:

IEEE:	802.11a/b/g/n
security:	WPA™, WPA2™—Personal and Enterprise
EAP types:	EAP-TLS, EAP-TTLS/MSCHAPv2, PEAPv0/EAP-MSCHAPv2, PEAPv1/EAP-GTC, EAP-SIM, EAP-AKA, EAP-FAST

4.2 RJ45-to-DB9 Serial Port Adapter

An RJ45-to-DB9 adapter (included with each Mesh Point) is required in order to connect the Mesh Point’s serial port to a DB9 terminal connection.

Figure 4.1 shows the pin numbers for the two connectors. With the RJ45 connector facing you and oriented with the tab receptacle up, pins are numbered from right to left, as shown. With the DB9 connector facing you and oriented with the wide side up, pins are numbered from right to left, top to bottom.




Figure 4.1. RJ45 and DB9 Pin Numbering

Table 4.1 shows the serial port adapter pin-outs.

Table 4.1. RJ45-to-DB9 Adapter Pin-Outs

RJ45 pin	DB9 pin	standard color
1	8	grey
2	6	brown
3	2	yellow
4	5	green
5	-	red
6	3	black
7	4	orange
8	7	blue

4.3 2-Pin DC Input Connector

The ES2440 Mesh Point uses a 2-pin connector to input DC power.




Figure 4.2. 2-pin Power Connector Pins

Table 4.2 shows DC power connector pin-outs.

Table 4.2. ES2440 DC Power Connector Pin-Outs

pin	signal
A	11–32 VDC
B	Ground



Index

Numerics

4.4 GHz radios vii, 2, 14
802.11a/b/g/n
 see radios

A

antennas
 connecting 9, 10
 connector specifications 14
 precautions 5, 6, 9, 10
 restrictions 9

C

compliance 15
 Canada vi
 FCC v
 standards 15

D

DB9-to-RJ-45 adapter 15–16
DC power input 7, 8, 9, 10, 14
 connector pin-outs 16
dimensions 14

E

earthing 5, 6, 9, 10
emissions v, 15
environmental specifications 14
Ethernet
 connecting 8, 9, 10
 LEDs 12
 port locations 7
 specifications 14
 see *also* PoE

F

FCC
 emissions compliance v
 TDWR information iii–v
fuse 4

G

GPS 2, 7, 8, 9, 10
grounding 5, 6, 9, 10

H

hardware
 mast mounting 3, 11
 models 2
 safety requirements iii, 4–5
 specifications 14–15

I

installation 8–10
 safety requirements 4–5
interference
 see emissions

M

mast mounting 11
MIMO 2, 14
 antenna ports 7
 antennas 9
models 2

O

operating temperature 4, 15

P

pin-outs
 DB9-to-RJ-45 adapter 15–16
 DC power connector 16
PoE 6, 8
 port location 7
 specifications 14
ports
 connecting 8–10
 LEDs 12
 locations 6–7
 specifications 14
powering 4, 5–6, 8, 9
 PoE 7
 supply specifications 14
precautions
 see safety

R

radios 2, 14
 connecting antennas 7, 9
 LEDs 12–13
 precautions vii, 2, 9
 safety requirements 5
 specifications 14
RJ-45-to-DB9 adapter 15–16

S

safety
 precautions iii, 1, 5, 8, 9
 requirements 4–5
 see *also* specifications
serial port
 adapter 15–16
 location 7
specifications 14–15

T

TDWR iii–v
temperature 4, 15

V

VDC input 7, 8, 9, 10, 14
 connector pin-outs 16
vibration 15