

WCT-5W1COILTX User Guide

1 Introduction

This document describes how to use 5W low power wireless charger transmitter WCT-5W1COILTX designed by Freescale.




Figure-1 WCT-5W1COILTX

Contents

1	Introduction	1
2	System Features	2
3	Getting Started	2
4	Cautions	3

2 System Features

The WCT-5W1COILTX reference board has following features:

- Reference design compliant with low power WPC Qi version 1.1 Specification.
- Integrated digital demodulation in chip.
- Support multiple types Rx modulation signals (AC capacitor, AC resistor and DC resistor).
- Support FOD. Support four types of Foreign Object protection.
- Support Qi 1.1 receiver with 5 V DC@1A output power capability.
- Super low standby power by Freescale touch technology.
- Full bridge topology with frequency modulation power control strategy.
- LED for RX and TX alignment indication.
- Input voltage/current, coil current sensing for protection.

3 Getting Started

WCT-5W1COILTX is easy to use, and can convenience to charging the mobile equipment that support the Qi wireless charging, below is the detail step to power up the system and use.

Step 1: power on the Transmitter, plug the 5V adaptor to the AC power line, and plug the adaptor USB port to the transmitter input port, and the LED1 will be blanking.



Figure-2 WCT-5W1COILTX power on

Step 2: Place the wireless charging RX or some equipment that support the Qi wireless charger (such as cell phone, battery and so on) on the WCT-5W1COILTX's coil surface, then the transmitter will charge the equipment, under the normal charging states, LED1 will be turned on all the time, and LED2 will be blanking, and the RX will be powered on the equipment normally.



Figure-3 WCT-5W1COILTX charging the equipments

Others Indicates: when the Transmitter get the end power communication information, it will stop the charging and wait until the RX is removed, under this states LED1 will be turned off, and LED2 will be turned on all the time. When some fault found, the transmitter will turn off LED1, and turn on LED2 until the fault is removed, fault include the FOD fault, OVP, OTP and so on.

4 Cautions

- This device has been tested and found to comply with the limits pursuant to Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
- If this equipment does cause harmful interference to other electronic equipments, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the equipment
 - Increase the separation
 - In order to use the equipment safely 'please don't open the case when powered on 'and don't touch the PCB and components with hand.
 - Don't place some metal things between the TX surface and the RX surface, otherwise the metal things will be heated, it the temperature is too high, the Transmitter will shut down for protection.

This device complies with Part15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

To satisfy FCC RF exposure requirements for mobile and base station transmission devices, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during operation. To ensure compliance, operation at closer than this distance is not recommended. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

How to Reach Us:

Home Page:

www.freescale.com

Web Support:

www.freescale.com/support

Information in this document is provided solely to enable system and software implementers to use Freescale products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. Freescale does not convey any license under its patent rights nor the rights of others. Freescale sells products pursuant to standard terms and conditions of sale, which can be found at the following address: freescale.com/SalesTermsandConditions.

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners.

©2013 Freescale Semiconductor, Inc.