



motorola
H15

Quick Start Guide

Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196

www.hellomoto.com
1-877-MOTOBLU
1-888-390-6456 (TTY/TDD United States for
hearing impaired)

Guide Number: 68000240001-A

Bluetooth QD ID: Bxxxxxx


MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. All other product or service names are the property of their respective owners.

© Motorola, Inc. 2008.

BEFORE YOU BEGIN

Before using this product, read the Important Safety and Legal Information pamphlet and follow its instructions.

Take a moment before you get started to familiarize yourself with your new H15 Bluetooth® Handsfree Headset. Along with your headset, a desktop charger is provided for both charging and storage.



1 CHARGE

Your Headset's Battery

You need to charge your headset using the included travel charger or desktop charger.

Charging with travel charger:

- 1 Remove plastic seal off of ear cushion on speaker.
 - 2 Plug the Motorola charger into the end of the headset.
- The indicator light turns red when the battery is charging. It may take up to 1 minute for the indicator light to turn on. When the headset's battery is fully charged (about 2 hours), the indicator light turns green.
- 3 Disconnect the charger.

Note: Headset is not functional while charging with travel charger.

Charging with desktop charger:

- 1 Plug in the travel charger into the charger port.
 - 2 Plug the headset into the port on the desktop charger as shown.
- The desktop charger light is lit, and the headset indicator light turns red when the battery is charging. It may take up to 1 minute for the headset indicator light to turn on. When the headset's battery is fully charged (about 2 hours), the headset indicator light turns green.
- 3 Remove headset from charger when ready to use.

Note: Headset is functional while charging with desktop charger with the boom open. To operate, remove from charger.

Note: This product uses a lithium ion, rechargeable, non-replaceable battery. Under normal use, the expected life of the rechargeable battery is approximately 400 charges.

2 START BLUETOOTH FEATURE

Your Phone

Your phone's Bluetooth feature is off by default. To use your headset, you must turn on the Bluetooth feature in your phone.

For most Motorola phones (at the main menu):

- 1 Press **[Menu]** > **Settings** > **Connection** > **Bluetooth Link** > **Setup**.
- 2 Scroll to **Power**.
- 3 Select **Change**.
- 4 Scroll to **On**.
- 5 Press **Select** to turn on the Bluetooth feature. The Bluetooth feature remains on until you turn it off.

Note: These steps are for most Motorola phones. For other phones, see your phone's user's guide.

3 PAIR

Your Headset and Phone

Before you can use your headset, you must pair (link) it with your phone.

Step A - ENSURE HEADSET IS IN PAIRING MODE

Open the headset boom to power on the headset and initiate pairing. The indicator light first flashes during power up, then initiates easy pairing. After a few moments, the indicator light will be steadily lit in blue to indicate headset is in pairing mode.



3 PAIR CONTINUED

Your Phone and Headset

Step B - SET YOUR PHONE TO LOOK FOR YOUR HEADSET

For most Motorola phones:

- 1 On your Motorola phone, press **[Menu]** > **Settings** > **Connection** > **Bluetooth Link** > **Handsfree** > **Look for Devices**.
- The phone lists Bluetooth devices it finds.
- 2 Select **Motorola H15**.
 - 3 Select **OK** or **Yes** to pair your headset with your phone.
 - 4 Enter the passkey: **0000**
 - 5 Select **OK**.

When your headset successfully pairs with your phone, the indicator light flashes purple and blue.

Note: These steps are for most Motorola phones. For other phones, see your phone's user's guide.

4 TEST AND USE

Your phone and headset are now paired and ready to make and receive calls. To confirm they are operating properly, make a call:

- 1 Place the headset over your ear. See "Wearing the Headset" on the reverse side of this guide.
- 2 On the phone, dial the number you want to call and press **SEND** key on your phone.
- 3 If your phone and headset are successfully paired, you will hear ringing on the headset.

After you have successfully paired your phone and headset, you don't need to repeat these steps. For daily use, ensure that your headset is turned ON and that your phone's Bluetooth feature is ON.

To conserve power, close the boom to turn your headset off. Re-open the boom to make a call.

USING A SECOND PHONE?

Multipoint technology allows you to make and receive calls from two Bluetooth enabled devices like your personal and business phones.

To pair a second phone to your headset, follow these steps:

- 1 Turn off any phones or devices that are already paired with your headset.
- 2 Turn off your headset by closing the headset boom.
- 3 Perform Step 2 ("Start Bluetooth Feature"), Step 3 ("Pair"), and Step 4 ("Test and Use") to pair your headset with your second phone. Your most recently paired phone is now your primary phone for voice dial functionality.
- 4 To connect to both phones, turn on first phone.
- 5 Close the headset boom and then re-open it. The headset automatically connects to both phones. The last paired phone is now your primary phone for voice dial functionality.

TIPS FOR USING H15 WITH TWO PHONES

Use the following tips when using H15's multipoint technology:

Incoming calls can be answered from both phones:

- When answering a call, the idle phone is disconnected from the headset.
- When the call ends, the idle phone is automatically reconnected to the headset.

Last number redial dials the last outgoing call made from either phone.

Voice dial is accessible from either phone via different key actions:

- For your primary device (last paired phone), tap the Call button until you hear the tone.
- For your secondary device (other paired phone), tap the Call button and either Volume button until you hear the tone.

TROUBLESHOOTING

My headset will not enter pairing mode.
Make sure that any devices previously paired with the headset are turned off. If the indicator light is flashing in blue, first turn off the other device, then close and reopen the headset boom. The indicator light becomes steadily lit in blue indicating the headset is now in pairing mode.

My phone doesn't find my headset.
Make sure the indicator light on your headset is on (lit in blue) and steady when your phone is searching for devices (see step 3).

My headset worked before but now it's not working.
Make sure your phone is on and the Bluetooth feature is turned on in your phone (see step 2). If the Bluetooth feature was turned off or was turned on only temporarily, you may need to restart the Bluetooth feature (see step 2) and pair your phone and headset again (see step 3).

My headset will not pair with my phone.
Open the boom flip. Press and hold both Volume buttons and the Call button for more than 10 seconds. The indicator light flashes blue 3 times and then become steadily lit. The headset is now in pairing mode (see step 3B) to complete the pairing process.

Support.
If you need more help, contact us at **1-877-MOTOBLU** or visit us at www.hellomoto.com/Bluetoothsupport



Features and Functions Guide


IMPORTANT:
Be sure to first follow the **Quick Start Guide** on the reverse side of this guide to complete initial setup of your H15.

TURNING HEADSET ON AND OFF

To turn **ON** your H15, open the headset boom. The indicator light first flashes blue three times, then:

- flashes blue slowly after flashing purple/blue (if paired and connected with a phone), or
- becomes steady blue (if ready to be paired).


To turn **OFF** your H15, close the headset boom. The indicator light will turn off.




EAR CUSHIONS AND YOUR HEADSET

Your H15 headset is supplied with multiple ear cushions. Your headset's performance is greatly dependent upon achieving a good fit on your ear. Therefore, we recommend trying all the supplied ear cushions with your headset.

The ear cushion is fitted onto the end of your headset's earpiece speaker like shown, and placed onto your ear when using your headset.




When fitting an oval-shaped ear cushion on your headset, be sure the cushion is oriented, as shown below (pointing towards the microphone).



WEARING THE HEADSET

To wear your headset, flex the earhook and loop it over your ear, as shown.




Be sure to position the ear cushion into your ear canal for optimal audio performance and comfort.

CHANGING FOR USE ON OTHER EAR

You can wear your H15 headset on your left or right ear. The headset comes ready for the right ear. To change the headset for the left ear:

- 1 Gently lift and pull the top of the earhook up and off speaker stem, as shown.
- 2 Flip the headset over.
- 3 Attach the earhook to the speaker stem, as shown.



QUICK BATTERY CHECK

When not in a call or connected, press and release both Volume buttons.


The indicator light displays charge status until you release the buttons. See below for details on indicator light and available talk time based on charge status.

Headset Indicator	Available Talk Time
Red	Less than 1.5 hours
Yellow	1.5 to 3.5 hours
Green	Up to 5 hours

European Union Directives Conformance Statement

Hereby, Motorola declares that this product is in compliance with:

- The essential requirements and other relevant provisions of Directive 1999/5/EC.
- All other relevant EU Directives.



The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at www.motorola.com/rtte. To find your DoC, enter the product Approval Number from your product's label in the "Search" bar on the web site.

MAKING CALLS

Function	Action
Make a voice dial call (Primary phone)	Tap the Call button and speak the name after the tone
Make a voice dial call (Secondary phone)	Tap the Call button and either Volume button and speak the name after the tone
End a call	Tap the Call button, and hear a high-to-low tone
Answer a call	Open the boom or tap the call button (if boom is ready open), hear a low-to-high tone
Reject a call	Press and hold either Volume button until you hear a tone

Note: Some features are phone/network dependent.

MAKING CALLS CONTINUED

Function	Action
Redial last call	Press and hold the Call button until you hear a tone
Answer a second incoming call	Press and hold the Call button (places first call on hold), and hear a tone
Reject second incoming call	Press and hold either Volume button until you hear a tone
Transfer a call from the headset to the phone	Press both Volume buttons and Call button, and hear a descending tone
Mute or unmute a call	Tap both Volume buttons until you hear a mute tone

Note: Your H15 supports both Handsfree and Headset Profiles. Accessing call functions depends upon which profile your phone supports. See your phone's user's guide for more information.

AUDIOTONES

Audio Tone	Headset Status
Ring tone	Incoming call
Short tone	Phone network not available
High to low tone	End call
Two short tones when pressing Volume button during a call	Volume at minimum or maximum
Ascending tone	Mute enabled
Low tone (repeated every 15 seconds)	Mute reminder
Descending tone	Mute disabled
Low to high tone	Connection confirmation/voice activation
No audio indications; deteriorating quality	Out of range
Two tones repeated every minute	Low battery

INDICATOR LIGHT

With No Charger Plugged In

Headset Indicator	Headset Status
Off	Power off
Three blue flashes	Powering on/off
Steady blue	Pairing mode
Quick blue/purple flashes	Pairing successful
Quick blue flash	Incoming call on primary phone
Quick purple flash	Incoming call on secondary phone
Slow blue pulse	Connected (on a call)
Slow blue flash	Standby (not on a call)

Note: After 20 minutes on a call or of inactivity, the light stops flashing to conserve power; but the headset remains on.

Note: To disable the indicator light, press and hold both Volume buttons while turning headset on.

INDICATOR LIGHT CONTINUED

With No Charger Plugged In

Headset Indicator	Headset Status
Red flash	Idle (not connected to phone)
Slow purple pulse	Connected call muted
Quick red flash	Low battery

Tip: Set your primary and secondary phones to different ring tones to know which phone is ringing when wearing the headset. See "Tips for using H15 with Two Phones" for more information.

INDICATOR LIGHT

With the Charger Plugged In To Travel Charger

Headset Indicator	Headset Status
Red	Battery level less than 50% charge
Yellow	Battery level more than 50% charge
Green	Charging complete

INDICATOR LIGHT

With Headset Plugged In to Desktop Charger

Headset Indicator	Headset Status
Red	Battery level less than 50% charge
Yellow	Battery level more than 50% charge
Green	Charging complete
Quick blue flash	Incoming call on primary phone
Quick purple flash	Incoming call on secondary phone



**Important Safety
and
Legal Information**

Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196

www.hellomoto.com

www.hellomoto.com/bluetooth (click on Support)

1-877-MOTOBLU (Motorola Bluetooth® support)

1-800-331-6456 (United States)

1-888-390-6456 (TTY/TDD United States for hearing impaired)

1-800-461-4575 (Canada)

The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners.

© Motorola, Inc. 2008.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual Number: 6809494A55-D

Contents

Safety Information	5
Driving Safety	9
Industry Canada Notice	12
FCC Notice	12
Warranty	14
Registration	21
Export Law	22
Recycling Information	22

Safety and General Information

IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION. READ THIS INFORMATION BEFORE USING YOUR DEVICE.

Approved Accessories

Use of accessories not approved by Motorola, including but not limited to batteries, antennas, and convertible covers, may cause your mobile device to exceed RF energy exposure guidelines and may void your mobile device's warranty. For a list of approved Motorola accessories, visit our Web site at: www.motorola.com

Electromagnetic Interference/Compatibility

Note: Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed, or otherwise configured for electromagnetic compatibility.

Facilities

Turn off your mobile device in any facility where posted notices instruct you to do so. These facilities may include hospitals or health care facilities that may be using equipment that is sensitive to external RF energy.

Aircraft

When instructed to do so, turn off your mobile device when on board an aircraft. Any use of a mobile device must be in accordance with applicable regulations per airline crew instructions.

Medical Devices

Hearing Aids



Some mobile devices may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer or physician to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

Batteries & Chargers

Your battery, charger, or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.
	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not throw your battery or mobile device in the trash.
	Do not let your battery, charger, or mobile device get wet.
	Listening at full volume to music or voice through a headset may damage your hearing.

Use & Safety for Battery-Powered Accessories

- Do not store or use your battery-powered accessory (such as a Bluetooth® headset or other device) in temperatures below -10°C (14°F) or above 60°C (140°F).
- Do not recharge your accessory in temperatures below 0°C (32°F) or above 45°C (113°F).
- Conditions inside a parked car can exceed this range. Do not store your accessory in a parked car.
- Do not store your accessory in direct sunlight.
- Storing your fully charged accessory in high-temperature conditions may permanently reduce the life of the internal battery.
- Battery life may temporarily shorten in low-temperature conditions.

Smart Practices While Driving

Drive Safe, Call Smart SM

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas. Go to www.motorola.com/callsmart for more information.

Your mobile device lets you communicate by voice and data—almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips:

- **Get to know your Motorola mobile device and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.
- **When available, use a handsfree device.** If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original handsfree accessories available today.



- **Position your mobile device within easy reach.** Be able to access your mobile device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.
- **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- **Do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.
- **Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic.** If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road.
- **Use your mobile device to call for help.** Dial 911 or other local emergency number in the case of fire, traffic accident, or medical emergencies.*

- **Use your mobile device to help others in emergencies.** If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.*
- **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.*

* Wherever wireless phone service is available.

Industry Canada Notice to Users

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device. See RSS-GEN 7.1.5.

FCC Notice to Users

The following statement applies to all products that have received FCC approval. Applicable products bear the FCC logo, and/or an FCC ID in the format FCC-ID:xxxxxx on the product label.

Motorola has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Motorola Limited Warranty for the United States and Canada

What Does This Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

Products and Accessories

Products Covered	Length of Coverage
Products and Accessories as defined above, unless otherwise provided for below.	One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.
Decorative Accessories and Cases. Decorative covers, bezels, PhoneWrap™ covers and cases.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Monaural Headsets. Ear buds and boom headsets that transmit mono sound through a wired connection.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Consumer and Professional Two-way Radio Accessories.	Ninety (90) days from the date of purchase by the first consumer purchaser of the product.

Products Covered	Length of Coverage
Products and Accessories that are Repaired or Replaced.	The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.

Exclusions

Normal wear and tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

Use of non-Motorola Products and Accessories. Defects or damage that result from the use of Non-Motorola branded

or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized service or modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

Communication services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

Software

Products Covered	Length of Coverage
Software. Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	Ninety (90) days from the date of purchase.

Exclusions

Software embodied in physical media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

Software NOT embodied in physical media. Software that is not embodied in physical media (e.g. software that is downloaded from the Internet), is provided "as is" and without warranty.

Who is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information

USA	Phones 1-800-331-6456 Pagers 1-800-548-9954 Two-Way Radios and Messaging Devices 1-800-353-2729
Canada	All Products 1-800-461-4575
TTY	1-888-390-6456
For Accessories and Software , please call the telephone number designated above for the product with which they are used.	

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

Product Registration

Online Product Registration:

**[direct.motorola.com/hellomoto/
Motosupport/source/registration.asp](http://direct.motorola.com/hellomoto/Motosupport/source/registration.asp)**

Product registration is an important step toward enjoying your new Motorola product. Registering helps us facilitate warranty service, and permits us to contact you should your product require an update or other service. Registration is for U.S. residents only and is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Caring for the Environment by Recycling



This symbol on a Motorola product means the product should not be disposed of with household waste.

Disposal of your Mobile Device and Accessories

Please do not dispose of mobile devices or electrical accessories (such as chargers, headsets, or batteries) with your household waste. These items should be disposed of in

accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any Motorola Approved Service Center in your region. Details of Motorola approved national recycling schemes, and further information on Motorola recycling activities can be found at:
www.motorola.com/recycling

Disposal of your Mobile Device Packaging and User's Guide

Product packaging and user's guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

DRAFT