
A-760 SERIES NOTEBOOK OPERATOR'S MANUAL

5/15/01

Prepared By: _____

Reviewed By: _____

Reviewed By: _____

Reviewed By: _____

Reviewed By: _____

Approved By: _____

P/N: 799001122002

R00

A-760 SERIES NOTEBOOK OPERATOR'S MANUAL

P/N: 799001122002

R00

A-320 Notebook Operator's Manual

© Copyright by MTC Corporation 1998. All rights reserved. No part of this publication may be reproduced by any means for any reason without express written approval from MTC Corporation or its authorized representative.

MTC Corporation makes no representations, either express or implied concerning the accuracy of this manual. All the information contained herein is believed to be complete and reliable as of the printing date. MTC Corporation reserves the right to make changes to this manual or product specifications without obligation to notify any person of such changes.

IBM, IBM PC/AT and OS/2 are registered trademarks of International Business Machines Corporation.

Intel Pentium is a registered trademark of Intel Corporation.

MS-DOS, XENEX, Windows 95 and MS-Windows are registered trademarks of Microsoft Corporation.

UNIX is a registered trademark of AT&T Bell Laboratories.

Other brand and product names are trademarks and/or registered trademarks of their respective holders.

Class B Regulations

Federal Communications Commission Radio Frequency Interference Statement

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are design to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Please note:

1. The use of a non-shielded interface cable with this equipment is prohibited.
2. A shielded AC power cord must be used with this equipment.

A-760 Series Notebook Operator's Manual

Products with the CE Marking comply with both the EMC Directive (89/336/EEC) and the Low Voltage Directive (73/23/EEC) issued by the Commission of the European Community.

Compliance with these directives implies conformity to the following European Norms:

- EN55022 (CISR 22)-Radio Frequency Interference
- EN50082-1 (IEC801-2, IEC801-3, IEC801-4)-Electromagnetic immunity
- EN60555-2 (IEC555-2)-Power Line Harmonics
- EN61000-3-3 (IEC1000-3-3)-Voltage Fluctuations and Flicker

Preface

This is the A-760 Series Notebook Operation Guide.

Contents

This manual contains information for personnel using the A-760 Series notebook computer. Readers should have a basic understanding of Windows 95/98 or any other operating system installed on the computer when reading this document. With the exception of the SETUP configuration program, which is part of the system firmware, this manual does not explain any of the software or devices used with the system. Supplemental manuals or text-based documents on the hard disk supply information about any software included with the system.

Audience

All operators using the notebook in or out of the field should read and become familiar with this manual.

Organization

This manual has three chapters.

Chapter 1 introduces the notebook pointing out its major features.

Chapter 2 explains daily operation.

Chapter 3 gives detailed information about configuring the notebook.

Supplemental Reading

For further information about this computer and computing in general, use these references:

- A-760 Series Service Manual for detailed troubleshooting and repair instructions for serious hardware problems associated with the A-760 Series notebook.
- Various software manuals offer detailed instructions about individual programs run on the notebook.

Specifications (reference only)

	Standard	Optional
CPU	Intel Pentium II/III 333, 400 MHz	Intel Pentium II/III 400MHz or more
RAM	128 MB	128 MB or above
Display	<ol style="list-style-type: none"> 12.1-inch color LCD, 64K color TFT,super VGA 13.3-inch color LCD, SVGA TFT/DSTN 	
Input Devices	<ul style="list-style-type: none"> 87-key shower proof and dust-proof rubber keyboard Embedded two-button Track Pad 	Backlight option
		Expansion Unit <ul style="list-style-type: none"> optional easy installed expansion unit (max. 20watts) for two 3/4 size ISA bus cards; or 3/4 size ISA bus card & one CD-ROM (same module as the one in Bay 1)
Communication ports	<ul style="list-style-type: none"> two RS-232C serial port One Centronics parallel port, support EPP/ECP One external monitor port One external PS/2 keyboard port One PS/2 mouse port One external power supply port One infrared port, IrDA compliance One 200-Pin docking port 	
Battery pack	<ul style="list-style-type: none"> removable & rechargeable main Ni-MH battery pack with the functions of on-line charge and hot swap (while Bay 1 or Bay 2 battery coexists), total 64 watts 	<ul style="list-style-type: none"> removable & rechargeable Bay 1 Ni-MH battery pack in Bay 1, total 41watts removable & rechargeable Bay 2 Ni-MH battery pack in Bay 2, total 41 watts
Power adapter	<ul style="list-style-type: none"> AC: 100-240 V, 50-60 Hz , 54 watts Vout 22.5V, -2%~+3%, 2.4A, CV mode Vout 23.5V~10V, 2.1A~3.5A, , CP mode 	<ul style="list-style-type: none"> 12-20 VDC direct input without charging function 20-32 VDC external car adaptor/charger
Operating system		<ul style="list-style-type: none"> W indows 95 Windows NT
Temperature	<ul style="list-style-type: none"> Operating: 0°C to +45°C 	<ul style="list-style-type: none"> Option: -20°C to +50°C (tested)
Storage devices	<ul style="list-style-type: none"> removable shock proof damaged 2.5" IDE HDD, capacity > 2.1GB optional removable 3.5" 1.44MB FDD, to install in Bay 1 internally 	<ul style="list-style-type: none"> removable shock proof damaged 2.5" IDE HDD, capacity > 4.0, 6.4GB (swap with either CD-ROM module or Bay 1 battery pack); connected to parallel port with optional cable externally Optional CD-ROM module to be installed in Bay 1

A-760 Notebook Operator's Manual

Open Size: (With Rubber Bumper)	310mm (31 cm) W 68mm (6.8 cm) H 255mm (25.5 cm) D	
Weight	11.24 lbs (5.1kg)	

Safety Summary

1. Read these instructions before using or working on this computer.
2. Follow all warnings and instructions in this manual or marks on the computer and its components.
3. Avoid submerging the system unit in liquids.
4. avoid stacking papers or other flammable objects on top of, underneath, or next to the system unit.
5. Use only batteries supplied with the system.
6. Make sure any external power source connected to the adapter or system conforms with adaptor or system ratings.
7. The external power adapter has a two-pronged grounding plug. If an adapter is needed to plug the system into a power source, make sure the system is properly grounded.
8. Arrange all cables so that they are out of traffic and unobstructed by personnel or equipment.
9. Avoid using extension cords with this product. If an extension cord is needed, make sure it is rated for at least 10 amperes.
10. Make sure amperage drawn by all items plugged into an outlet with this system does not exceed 15 amperes.
11. Do not put any objects except those designed for use with this system inside the computer.
12. Observe proper electrical safety precautions when performing system maintenance.
13. Replace any cables with identically rated cables as those included with the original equipment.
14. Improper handling of the battery can cause personal injury or fires. Do not attempt to disassemble or replace individual cells in the battery pack. Do not expose the battery to open flames. Do not short the positive and negative ends together even if the battery is fully discharged. Keep the battery away from children.

Table of Contents

Preface

Contents.....	e
Audience	e
Organization	e
Supplemental Reading	e

Specifications

Specifications.....	f
---------------------	---

Safety Summary

Safety Summary.....	h
---------------------	---

Chapter 1 System Overview

1-1	Introduction	1-1
1-2	System Description	1-1
1-3	System Configuration.....	1-1
	1-3.1 Standard Configuration.....	1-1
	1-3.2 Options and Accessories	1-2
	1-3.3 System Identification.....	1-2
1-4	Unpacking	1-2
1-5	Notebook Features.....	1-2
	1-5.1 Cover.....	1-3
	1-5.2 Display	1-3
	1-5.3 Power Switch.....	1-3
	1-5.4 Keyboard.....	1-3
	1-5.5 Pointing Device	1-5
	1-5.6 Volume Control	1-5
	1-5.7 Brightness Control	1-5
	1-5.8 Keyboard Backlight	1-5
	1-5.9 CRT/LCD/Simulscan Toggle.....	1-5

- 1-5.10 Panel On/Off.....1-5
- 1-5.11 Standby Mode1-6
- 1-5.12 Suspend Mode1-6
- 1-5.13 Status Row1-6
- 1-5.14 Battery Pack1-6
- 1-5.15 Low Battery Indication1-7
- 1-5.16 Battery Charger1-7
- 1-5.17 CHARGE LED Indicator Status1-7
- 1-5.18 Diskette Drive and CD-ROM.....1-8
- 1-5.19 PCMCIA Slot and Diskette Drive and CD-ROM Door.....1-8
- 1-5.20 PCMCIA Slot1-8
- 1-5.21 External Power Source Port.....1-8
- 1-5.22 Serial Port1-9
- 1-5.23 Printer Port.....1-9
- 1-5.24 VGA Port1-9
- 1-5.25 IrDA Port.....1-9
- 1-5.26 USB Port1-9
- 1-5.27 Keyboard/Mouse Port1-9
- 1-5.28 External Power Adapter.....1-9

Chapter 2 Operation

- 2-1 Introduction.....2-1
- 2-2 Opening and Closing the Notebook.....2-1
 - 2-2.1 Opening the Cover2-1
 - 2-2.2 Closing the Cover2-1
 - 2-2.3 Opening the PCMCIA/FDD/CD-ROM Door2-2
 - 2-2.4 Shutting the PCMCIA/FDD/CD-ROM Door2-2
- 2-3 Connecting and Installing Devices2-3
 - 2-3.1 Serial and Parallel Port2-3
 - 2-3.2 External Power Adapter.....2-3
 - 2-3.3 Diskettes2-4
 - 2-3.4 Remove the Floppy Diskette Drive and CD-ROM/ Bay 1 Battery2-4
 - 2-3.5 PCMCIA Cards.....2-5
 - 2-3.6 Hard Disk.....2-6
- 2-4 First Time Use2-7
 - 2-4.1 Configuring the System2-7
 - 2-4.2 Installing Software Driver.....2-7
- 2-5 Daily Operation2-23
 - 2-5.1 Starting the Computer.....2-23
 - 2-5.2 Turning Off The Notebook2-24
 - 2-5.3 Using the Notebook in the Car.....2-24
- 2.6 Using External Power Sources.....2-25
 - 2-6.1 Using AC External Adaptor.....2-25
 - 2-6.2 Charging the Batteries.....2-25

2-7	Running On Battery Power	2-25
2-8	Use the External FDD.....	2-26

Chapter 3 The SETUP Program

3-1	Introduction	3-1
3-2	Running SETUP and Moving Around	3-1
3-2.1	Main.....	3-2
3-2.2	Moving Around and making Selections	3-2
3-2.3	Security.....	3-9
3-2.4	Power	3-11
3-2.5	Exit.....	3-14

List of Figures

Figure 1-1 A-320 Notebook, Front View1-2
Figure 1-2 Rubber Keyboard1-3
Figure 1-3 Cursor Control Keys1-4
Figure 1-4 Track Pad Pointing Device1-5
Figure 1-5 A-320 Status Row.....1-7
Figure 1-6 Diskette Drive and CD-ROM1-8
Figure 1-7 Rear Side View.....1-9
Figure 2-1 Opening the Notebook.....2-1
Figure 2-2 Opening a Door2-2
Figure 2-3 Connecting the External Power, Serial & Parallel Ports.....2-3
Figure 2-4 Removing a Diskette2-4
Figure 2-5 Removing a FDD/CD-ROM.....2-5
Figure 2-6 Removing a PCMCIA Cards2-5
Figure 2-7 Removing a Hard Disk2-6
Figure 2-8 Plug Car Power Cable in Notebook2-24
Figure 2-9 Use the External FDD.....2-26

List of Tables

Table 1-1 Standard A-320 Notebook Computer.....1-1