Contents

Contents	1
What is in the box?	2
TomTom RIDER	3
Using your TomTom RIDER	4
Setting up	4
Locating your current position	
Bluetooth headset module	
Taking care of your TomTom RIDER	5
Mounting the TomTom RIDER on your motorcycle	
Where should I mount my TomTom RIDER?	
Mounting your TomTom RIDER	
Handlebar Mount	
Handlebar adaptor	7
Mirror Mount	
Adhesive Mount	8
Placing your TomTom RIDER in the Holder	8
Battery cable	9
Making your first journey	10
Finding alternative routes	10
Driving View	12
Menus	13
Main menu	13
Driving menu	13
Why can't I open the main menu while I am driving?	14
How can I cancel the driving menu?	
What is GPS?	
TomTom PLUS	16

What is in the box?

[boxrider.jpg]	1.	Your TomTom RIDER
[boxSD.jpg]	2.	A memory card (SD card) containing the application and maps
[AllMountsPlusHolder.jpg]	3.	Mounting kit: Holder, Handlebar Mount, Handlebar Adaptor, Mirror Mount, Adhesive Mount and the adhesive
[boxScrews.jpg]		pad
[BoxPlugBike.jpg]	4.	Screws and Allen keys for the mounting kit
[chargeKit.jpg]	5.	Battery cable
[bag.jpg]	6.	Home charger, with international adaptors
	7.	TomTom RIDER case
[boxUSB2.jpg]	8.	USB cable
[boxCD.jpg]	9.	CD for Microsoft Windows® or Apple Macintosh®. The CD contains the full manual as well as a tool for backing up your memory card.
[BTExplainleft.jpg]	10.	Bluetooth™ headset module and headset cable
[BoxHelmHeadset.jpg]	11.	Helmet headset
[boxCarHeadset.jpg]	12.	Standard headset
[cleaner.jpg] [booklet.jpg]	13.	Screen cloth
[LicenseCard.jpg]	14.	Documentation pack
	15.	Your product code card

TomTom RIDER

[NumbersRider1.jpg]

[NumbersRider3.jpg]

[NumberRider2a.jpg]

- 1. Touchscreen
- 2. On/Off button
- 3. Docking connector
- 4. Memory card (SD card) slot
- 5. USB connector
- 6. Charging connector
- 7. Reset button

Using your TomTom RIDER

[FromPoster5.jpg]

- 1. Open the compartment on the bottom of your TomTom RIDER.
- 2. Push the memory card into the memory card slot.
- 3. Press and hold the On/Off button for 2 seconds, or until your TomTom RIDER starts.

The first time you switch on your TomTom RIDER, it may take up to 20 seconds to start. To switch off your TomTom RIDER, press and hold the On/Off button for 2 seconds.

Setting up

First, you have to answer a few questions to set up your device and your Bluetooth headset module. Answer the questions by tapping the screen. You will use the touchscreen for everything you do with your TomTom RIDER.

Follow the instructions to establish a Bluetooth connection between your TomTom RIDER and your Bluetooth headset module. See the Bluetooth headset module section below for more information about your Bluetooth headset module.

Once you have answered the questions, your TomTom RIDER will display the Driving View.

The screen is shown in black and white until your TomTom RIDER locates your current position. Once this is done, the Driving View is shown in full colour.

Locating your current position

Your TomTom RIDER must be outside to be able to locate your current position. The first time you start your TomTom RIDER, it takes up to 5 minutes for the device to find your current position. In future, your position will be found much faster, normally within a few seconds. If your TomTom RIDER takes longer than 5 minutes to locate your current position, make sure that you are in an open place without tall buildings or trees around you.

Your TomTom RIDER does not transmit your location, so others cannot use it to track you while you are driving.

Note: Before driving with your TomTom RIDER, we recommend that you charge it fully using the home charger.

TomTom RIDER uses a GPS receiver to locate your current position. For more information about GPS, see this chapter: What is GPS?

Bluetooth headset module

[NumbersBT1.jpg]	1. Indicators
[NumbersBT2.jpg]	2. Volume controls
	3. On/Off button
	4. Charging connector
	5. Headset connector

Before you can use your Bluetooth headset module with the helmet headset, you must charge the headset module using the home charger.

[HeadsetExplainNoHelm.jpg] [HeadsetExplainUnder.jpg] Connect the headset cable to the Bluetooth headset module and then to the helmet headset or standard headset.

Attach the Velcro pads provided to the inside of your helmet. These hold the helmet headset in place.

To turn your Bluetooth headset module on, press and hold the On/Off button until you see the blue indicator light.

To turn your Bluetooth headset module off, press and hold the On/Off button until you see the red indicator light.

If you did not establish a Bluetooth connection between your Bluetooth headset module and your TomTom RIDER when you first turned your TomTom RIDER on, you can establish the connection at any time. From the main menu, tap Change Preferences. Tap the arrow twice to open the third preferences menu. Tap **Connect to headset** and follow the instructions to establish the connection.

Taking care of your TomTom RIDER

It is important to take care of your TomTom RIDER and to clean it correctly.

- Use the screen cloth provided to wipe the screen of your TomTom RIDER; do not use any liquid cleaners.
- Only open the compartment that contains the memory card slot when you are indoors. Do not open the compartment when your TomTom RIDER is wet.
- When carrying your TomTom RIDER, always use the TomTom RIDER case provided.
- If your TomTom RIDER gets wet, dry it with a soft cloth.
- Do not open the casing of your TomTom RIDER under any circumstances.
- Do not use the memory card (SD card) with any device other than your TomTom RIDER. Other devices may damage the memory card.

Mounting the TomTom RIDER on your motorcycle

Where should I mount my TomTom RIDER?

When you choose where to mount your device, think about the following:

- The mounting options available
- The most comfortable position

Spend some time thinking about where to mount your TomTom RIDER on your motorcycle. Not all mounts are suitable for all bikes. It should be in a position where you can see it easily and where it does not block your vision.

Warning: The Adhesive Mount is very strong and it is very difficult to remove once it has been attached to your motorcycle. Before attaching the Adhesive Mount to your motorcycle, be sure that you have chosen the position where you finally want to mount your TomTom RIDER.

Mounting your TomTom RIDER

There are four different mounts:

- Handlebar Mount
- Handlebar Adaptor
- Mirror Mount
- Adhesive Mount

The sections below describe how to use each mount. Make sure that you screw all parts of the mounts together very tightly, otherwise the mount may move while you are driving.

Handlebar Mount

[handlebarmount.jpg]	The Handlebar Mount is attached directly onto the handlebars. To use this mount, follow these steps:
	1. Unscrew the Handlebar Mount using the Allen key.
[Clampmount5.jpg]	Wrap the piece of rubber provided around the handlebars to make the handlebars thick enough for the Handlebar Mount. Cut the piece of rubber to adjust the thickness.
	Note : The piece of rubber helps prevent vibration and stops the Handlebar Mount from slipping while you are driving.
	3. Place the Handlebar Mount around the handlebars and over the piece of rubber.
	4. Screw the Handlebar mount together tightly using the Allen key provided.
[ScrewHolder.jpg]	5. Screw the Holder to the Handlebar Mount using four of the small screws included with the mounting kit.
[clampmount1.jpg]	If your TomTom RIDER is not in a comfortable position, unscrew the Handlebar Mount slightly and adjust the angle

of the mount and the holder. Then screw the Handlebar Mount together tightly again.

You can now place your TomTom RIDER in the Holder. See this section: **Placing your TomTom RIDER in the Holder**

Handlebar adaptor

	The Handlebar Adaptor is secured by bolts next to the grip, as shown. To use this mount, follow these steps:	
[standardMount6.jpg]	1. Carefully remove the bolts that hold the grip in place. Do not remove the grip from the handlebars.	

2. Place the Handlebar Adaptor over the bolt holes.

[standardMount5.jpg]

3. Use the extra-long bolts provided to attach the Handlebar Adaptor and the grip to the handlebars. Use an Allen key (not provided) to tighten the bolts.

[standardMount4.jpg]

4. Attach the Handlebar Mount to the Handlebar Adapter. Follow steps 2 – 4 in the section **Handlebar Mount** above.

You can now place your TomTom RIDER in the Holder. See this section: **Placing your TomTom RIDER in the Holder**

3. Screw the wing mirror back into place. The wing mirror holds

Mirror Mount

[mirrormount2.jpg]	The Mirror Mount is held in place by the wing mirror. If your motorcycle or scooter has no mirrors but has the bolt holes fo wing mirror, you can still use the Mirror Mount. To use this motollow these steps:	
	1.	Unscrew one of the wing mirrors on your motorcycle.
[mirrormount7.jpg]	2.	Place first the rubber washer, then the Mirror Mount and finally the metal washer over the bolt hole, as shown in the diagram.
		Note : The washers help to prevent the mirror mount from moving or from being damaged. Select the diameter of the washers according to the diameter of the bolt hole.

the Mirror Mount in place. **Note**: If you have only the bolt holes for a wing mirror, use one of the bolts provided to hold the Mirror Mount in place. Select the diameter of the bolt according to the diameter of the bolt hole. 4. Screw the Adhesive Mount to the Mirror Mount, using four of

[mirrormount8.jpg]

the small screws included with the mounting kit.

[mirrormount9.jpg]

5. Screw the Holder to the Adhesive Mount using four of the small screws included with the mounting kit.

You can now place your TomTom RIDER in the Holder. See this section: Placing your TomTom RIDER in the Holder

Adhesive Mount

Use the Adhesive Mount if you are unable to use any of the other mounts, or if you want to place your TomTom RIDER in a position that is not possible using the other mounts. Attach this mount only to a part of your motorcycle that is strong enough to hold the mount, the Holder and your TomTom RIDER. [AdhesiveMount4.jpg] **Note**: It is very difficult to remove the Adhesive Mount. Think carefully about where you want to attach the Adhesive Mount. Clean the position you have chosen thoroughly and make sure that you remove any grease or dirt. To use this mount, follow these steps: 1. Attach the adhesive pad to the Adhesive Mount. 2. Press and hold the Adhesive Mount in the position you have

[Adhesivemount1.jpg]

[AdhesiveMount2.jpg]

3. Screw the Holder to the Adhesive Mount using four of the small screws included with the mounting kit.

You can now place your TomTom RIDER in the Holder. See this section: Placing your TomTom RIDER in the Holder

Placing your TomTom RIDER in the Holder

chosen.

[riderin.jpg]	1.	Open the Holder and place the bottom edge of your TomTom RIDER into the Holder first.
[riderinclose.jpg]		Make sure that the two teeth on the bottom of the Holder meet the two connections on your TomTom RIDER. If your TomTom RIDER is not placed in the Holder correctly, it may fall out while you are driving.
	2.	Push your TomTom RIDER firmly into place.
[RiderInHolder.jpg]	3.	Close the Holder. Make sure that your TomTom RIDER is held firmly in place.

You are now ready to make your first journey with your TomTom RIDER.
--

Battery cable

The battery cable can optionally be used to power and charge your TomTom RIDER from your motorcycle battery.

Note: If you are unsure about setting up the battery cable, consult your local motorcycle garage.

Connect the battery cable connector to the power connector on the holder.

[BatteryCableExplain.jpg]

Connect the red battery cable to the switched positive 12 volt power supply on your motorcycle and the black battery cable to the ground supply on your motorcycle. Make sure that the battery cable is secured safely to your motorcycle. It must not hang from the frame or interfere with the motorcycle in any way. Make sure that it is also not in contact with any areas of the motorcycle that become hot and may melt the cable.

Making your first journey

Planning a route with TomTom RIDER is very simple. To plan your first route, follow the steps below.

1. Tap the screen to bring up the main menu:

[mainmenu.jpg]

- 2. Tap Navigate to...
- 3. Tap **Address**.

[navigateToMenu.jpg]

Now you have to specify where you want to go. This is done by selecting first the town, then the street and then either the house number or the point where two streets meet.

4. Start to type the name of the town where you want to go.

[navigateToTown.jpg]

After you have typed a few letters, the names of towns that match what you have typed are shown. When your destination is shown in the list, tap the name of the town to set the destination.

5. Start to type the name of the street.

[navigateToRoad.jpg]

As with the name of the town, the names of streets that match what you have typed are shown. When your destination is shown in the list, tap the name of the street to set the destination.

- 6. Now do one of the following:
 - Enter the house number of your destination and then tap **Done**.
 - To select a point where two streets meet, tap Crossing and select the name of the street as in step 5.

[navigateToNumber.jpg]

7. The route is calculated by your TomTom RIDER.

[routePlanned.jpg]

8. Tap **Done**. Your TomTom RIDER will immediately start giving you instructions for reaching your destination.

To guide you to your destination, TomTom RIDER will give you spoken instructions and visual instructions on the screen.

You should plan your route before you start driving. It is not possible to plan the route in this much detail once you start moving. While you are driving, only the driving menu is displayed. For more information, see this chapter: **Menus**

Note: Before you can plan a route in this way, your TomTom RIDER must first locate your current position.

Finding alternative routes

If you want a different route from the one that your TomTom RIDER has planned for you, you can ask it to calculate an alternative route for you. Tap the touchscreen and then the button **Find alternative...**. Here are some of the options you can select:

[AvoidPartOfRoute.jpg]	Tap this button to avoid a part of the route, perhaps a junction
Avoid part of route	that is known for traffic problems.
[TravelVia.jpg]	Tap this button to go via a particular location, perhaps to pick
Travel via	up a friend.
[AvoidRoadblock.jpg]	Tap this button to avoid a roadblock that you can see up ahead.
Avoid Roadblock	

For a full description of all the options, see the manual on the CD.

It is not possible to use this functionality while you are driving because then only the driving menu is displayed. You should plan your alternative route before you start driving, or stop driving and then use the main menu to plan an alternative route.

Driving View

[Image with arrows]

- 1. The next instruction.
- 2. The name of the next street to turn onto.
- 3. Information about your journey: remaining journey time, remaining distance, arrival time. You can select which information is displayed in the **Preferences** menu.
- 4. Your current position.
- 5. Buttons to zoom in and zoom out on your position.
- 6. The name of the next major road, if applicable.
- 7. Indicator of the strength of the GPS signal. For more information about GPS, see the chapter: What is GPS?

Menus

Tap the screen at any time when your TomTom RIDER displays the Driving View to open a menu.

Main menu

If you tap the screen when you are stationary, the main menu is shown:

[mainmenu.jpg]

Navigate to...

Tap this button to start planning a route.

Find alternative...

Tap this button to find an alternative route to the one currently planned. You might change your route to avoid roadblocks up ahead, or to incorporate a stop into your route. For more information see the manual on the CD.

TomTom Traffic

Tap this button to enable or disable traffic information. TomTom Traffic is a subscription service provided by TomTom PLUS. For more information, see this chapter: **TomTom PLUS**

Mobile phone

This button opens the mobile phone menu. You can, for example, make calls, write or read messages. For more information, see the manual on the CD.

Change preferences

This button opens the Preferences menu. You can change many things about the way your TomTom RIDER displays information, including the map colours, the volume and the voice used for spoken instructions. For more information see the manual on the CD.

[NextArrow.jpg]

Whenever you see this arrow, it means that there is another screen of buttons. Tap this arrow to open the next screen.

Driving menu

If you tap the screen when you are driving, the driving menu is shown:

[DrivingMenu.jpg]

Navigate to...

Tap this button to select a destination. This button opens another menu with these 4 buttons:

[home.jpg] Home	Tap this button to start navigating to your Home location. You can set your Home location by tapping Change preferences in the main menu, then Change Home location .
[recentDestination.jpg]	Tap this button to start navigating to your most recent destination.
Recent destination	destination.
destination	
[Itineraries.jpg]	Tap this button to start navigating to the next destination
Itinerary planning	on you Itinerary.
[PetrolStation.jpg]	Tap this button to start navigating to the nearest petrol station on your route. If there is no petrol station on your

Petrol	route, your TomTom RIDER will direct you to the nearest
Station	petrol station.

Turn off sound / Turn on sound

Tap this button to turn the spoken instructions on or off.

Clear route

Tap this button to delete the route that is currently planned. Your TomTom RIDER will stop giving you directions. Your position will still be shown in the Driving View. You do not need to clear a route before you plan a new route, or start navigating to a new destination.

Add favourite

Tap this button to add your current location as a favourite. Your TomTom RIDER will use the address of your current location as the name of the favourite. Later, you can go back and change the name of the favourite if you wish.

This button is useful if you see something interesting while you are driving. You can add it as a favourite so that the location is remembered by your TomTom RIDER.

Why can't I open the main menu while I am driving?

- Safety it would be dangerous to operate your TomTom RIDER with all the available menu buttons while driving.
- Gloves when you are wearing gloves, the buttons in the normal menu are too small to use easily. The large buttons in the driving menu can be tapped while driving.

How can I cancel the driving menu?

You cannot cancel the driving menu. The menu will disappear after 10 seconds if you do not tap a button.

What is GPS?

GPS stands for Global Positioning System. GPS uses satellites to locate your current position. There is no charge for using the GPS system.

Note: Your TomTom RIDER does not transmit your location, so others cannot use it to track you while you are driving.

In order to locate your position, your TomTom RIDER must have a clear view of the sky. It will not work if you are inside a building or in a tunnel. It is not affected by the weather conditions and works anywhere in the world. The first time you start your TomTom RIDER, it takes up to 5 minutes for the device to find your current position. If your TomTom RIDER takes longer than 5 minutes to locate your current position, make sure that you are in an open place without tall buildings or trees around you.

If the GPS signal is too weak, your TomTom RIDER will not know your current position. It will try to calculate your position based on the road you are on and the speed and direction you are travelling. When the GPS signal is lost, the Driving View is shown in black and white.

TomTom PLUS

In addition to all the features that are included with TomTom RIDER, TomTom PLUS provides you with a range of additional services. For example:

 Traffic – constantly updated traffic information to warn you about any incidents on your route. Your TomTom RIDER will replan your route accordingly.

Note: TomTom Traffic is not available in all countries or areas. Go to www.tomtom.com/plus for more information.

- Safety Cameras advance warning of Safety Cameras in danger hotspots.
- Weather up-to-date weather information for your journey.

Many more services are available and more are being added all the time. Go to www.tomtom.com/plus for more information.

Note: To use TomTom PLUS, you need a GPRS-ready mobile phone with Bluetooth. If you already read email or browse the Internet with your mobile phone, then it is probably GPRS-ready; if you are not sure, ask your network provider.

Important Safety Notices and Warnings

1. Global Positioning System

The Global Positioning System (GPS) is a satellite-based system that provides location and timing information around the globe. GPS is operated and controlled under the sole responsibility of the Government of the United States of America, who are responsible for its availability and accuracy. Any changes in GPS availability and accuracy, or in environmental conditions, may impact the operation of your TomTom RIDER. TomTom B.V. cannot accept any liability for the availability and accuracy of GPS.

2. Use with Care

Use of TomTom RIDER for navigation still means that you need to drive with due care and attention.

3. Aircraft and Hospitals

Use of devices with an antenna is prohibited on most aircraft, in many hospitals and in many other locations. TomTom RIDER must not be used in these environments.

4. Battery

This product uses a Lithium-Ion battery. Do not use it in a humid, wet and/or corrosive environment. Do not put, store or leave your product in or near a heat source, in a high temperature location, in strong direct sunlight, in a microwave oven or in a pressurized container, and do not expose it to temperatures over 60 C (140 F). Failure to follow these guidelines may cause the Lithium-Ion battery to leak acid, become hot, explode or ignite and cause injury and/or damage. Do not pierce, open or disassemble the battery. If the battery leaks and you come into contact with the leaked fluids, rinse thoroughly with water and seek medical attention immediately. For safety reasons, and to prolong the lifetime of the battery, charging will not occur at low (below 0 C/32 F) or high (over 45 C/110 F) temperatures.

Temperatures: Standard operation: - 10 C to + 55 C; short period storage: - 20 C to + 60 C; long period storage: - 20 C to + 25 C.

5. Mounting TomTom RIDER

Extreme care must be taken when mounting TomTom RIDER on a motorcycle. Read the description in the Quick Start Guide carefully before mounting TomTom RIDER on your motorcycle. TomTom Rider shall be mounted in compliance with the relevant legislation and the vehicle manufacturer's rules. Failure to mount TomTom RIDER correctly could result in damage to your vehicle and serious injury to the vehicle rider and other road users. TomTom RIDER is mounted on your motorcycle at your own risk.

6. Battery cable

The power cable shall be routed to avoid sharp bends, abrasion, overheating, exhaust gases and battery acids and other potential hazards. It must not be strained nor distorted by e.g. excessive tightening of cable ties. Ensure that all connections are mechanically and electrically safe and secure. Keep away from heat sources and vehicle controls. It must not hinder the operation of safety equipment nor interfere with the driver's ability to control the vehicle.



THE LITHIUM-ION BATTERY CONTAINED IN THE PRODUCT MUST BE RECYCLED OR DISPOSED OF PROPERLY. USE TOMTOM RIDER ONLY WITH THE SUPPLIED DC POWER LEAD AND AC ADAPTER FOR BATTERY CHARGING.

To recycle your TomTom RIDER unit, please see your local approved TomTom service centre.

FCC Information for the User

The device used for this transmitter must not be co-located simultaneously operating in conjunction with any other transmitter.

Exposure to Radio Frequency Radiation

To comply with RF exposure requirements please maintain a separation distance of at least 20 cm from any part of the product.

Radio and Television Interference

This equipment radiates radio frequency energy and if not used properly - that is, in strict accordance with the instructions in this manual - may cause interference to radio communications and television reception.

It has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These are designed to provide reasonable protection against harmful interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation distance between the equipment and the receiver.
- If you are using the equipment with a mains adapter, plug it into an outlet which is on a different circuit from that to which the receiver is connected.
- Consult an experienced radio/TV technician for help.

Important

This equipment was tested for FCC compliance under conditions that included the use of shielded cables and connectors between it and the peripherals. It is important that you use shielded cable and connectors to reduce the possibility of causing radio and television interference. Shielded cables, suitable for the product range, can be obtained from an authorised dealer. If the user modifies the equipment or its peripherals in any way, and these modifications are not approved by TomTom, the FCC may withdraw the user's right to operate the equipment. For customers in the USA, the following booklet prepared by the Federal Communications Commission may be of help: "How to Identify and Resolve Radio-TV Interference Problems". This booklet is available from the US Government Printing Office, Washington, DC 20402. Stock No 004-000-00345-4.

FCC Declaration of Conformity

Tested to Comply with FCC Standards for Home or Office Use

TomTom RIDER has been tested to – and complies with – part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.

2. This device must accept any interference received, including interference that may cause undesired operation.

Responsible party in North America

TomTom, Inc., 150 Baker Ave, Concord, MA 01742

Tel: 978 287 9555 option 1

Fax: 978 287 9522

Toll Free: 866 4 TOMTOM (866 4 866 866)

(The Toll Free number does not work outside of the US)

Emissions information for Canada

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.



This equipment complies with the requirements for CE marking when used in a residential, commercial, vehicular or light industrial environment

R&TTE Directive

This equipment complies with the essential requirements of EU Directive 99/5/EC (declaration available at www.tomtom.com).

Diese Ausrüstung erfüllt die wesentlichen Anforderungen der EU-Richtlinie 99/5/EC (Erklärung verfügbar unter <u>www.tomtom.com</u>).

Cet équipement remplit les conditions édictées dans la Directrive EC/99/5 (document disponible sur <u>www.tomtom.com</u>).

Deze apparatuur is conform de eisen van de EU-richtlijnen 99/5/EC (verklaring beschikbaar op www.tomtom.com).

Questa apparecchiatura soddisfa le condizioni essenziali della Direttiva Europeea 99/5/EC (dichiarazione disponibile su www.tomtom.com).

Este equipo cumple con los requisitos esenciales de la Directiva 99/5/EC de la EU (declaración disponible en www.tomtom.com).

Dette udstyr overholder de grundlæggende krav i EU-direktiv 99/5/EC (erklæring herom kan findes på www.tomtom.com).

Denna utrustning rättar sig efter de nödvändiga krav från EU direktiv 99/5/EC (deklaration finns på www.tomtom.com).

TomTom tímto prohlašuje, že RIDER je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1995/5/ES (NV č. 426/2000 Sb.) a Prohlášení o shodě je k dispozici na www.tomtom.com. Toto zařízení lze provozovat v České republice na základě generální licence č. GL - 12/R/2000.

Seadmed vastavad EL direktiivi 99/5/EÜ põhinõuetele (vt www.tomtom.com).

A jelen berendezés megfelel az EU 99/5/EC direktívája meghatározta szükséges előírásoknak (a nyilatkozat a www.tomtom.com honlapon található).

Ši įranga atitinka visus ES direktyvos 99/5/EB reikalavimus (deklaracijos tekstas tinklapyje www.tomtom.com).

Šis produkts atbilst visām ES noteiktajām Direktīvām 99/5/EC (deklarācija ir pieejama www.tomtom.com).

Sprzęt ten jest zgodny z podstawowymi wymaganiami Dyrektywy UE 99/5/EC (deklarację można pobrać ze strony internetowej <u>www.tomtom.com</u>).

TomTom týmto vyhlasuje, že RIDER spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1995/5/ES (NV č.443/2001 Z.z.) a Vyhlásenie o zhode je k dispozícii na www.tomtom.com. Toto zariadenie je možné prevádzkovať v Slovenskej republike na základe Všeobecného povolenia č. VPR-01/2001.

Bu cihaz AB Direktifi 99/5/AT'nin (beyanat www.tomtom.com adresinde mevcuttur) zorunlu gerekliliklerine uygundur.



WEEE Directive ■

In line with EU Directive 2002/96/EC for waste electrical and electronic equipment (WEEE), this electrical product must not be disposed of as unsorted municipal waste. Please dispose of this product by returning it to the point of sale or to your local municipal collection point for recycling. For more information, see www.tomtom.com

languages ...

Ctick [Image]

This product displays the Ctick to show it complies with all relevant Australian and NZ regulations.

This Document

Great care was taken in preparing this manual. Constant product development may mean that some information is not entirely up-to-date. The information in this document is subject to change without notice.

TomTom International B.V. shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the performance or use of this material. This document contains information protected by copyright. No part of this document may be photocopied or reproduced in any form without prior written consent from TomTom International B.V.

Part numbers

TomTom RIDER: 4K00.001 Bluetooth headset: 4K00.002

Copyright information

© 2005 TomTom International B.V., The Netherlands. Patents pending. All rights reserved.

TomTom and the TomTom logo are registered trademarks of TomTom International B.V. The Netherlands. All other trademarks are the property of their respective owners. The use of TomTom products is governed by a license agreement which is included in this package and/or the products. This license contains a limited warranty and limitation of liability. You can review the license conditions at www.tomtom.com

Data Source

Benelux - ©1993-2005 NAVTEQ All Rights Reserved.

France - ©1993-2005 NAVTEQ All Rights Reserved.

Italy - ©1994-2005 NAVTEQ All Rights Reserved.

UK - ©1993-2005 NAVTEQ All Rights Reserved.

Sweden - ©1994-2005 NAVTEQ All Rights Reserved.

Finland - ©2001-2005 NAVTEQ All Rights Reserved.

Norway - ©2001-2005 NAVTEQ All Rights Reserved.

Denmark - ©1997-2005 NAVTEQ All Rights Reserved.

Germany - ©1993-2005 NAVTEQ All Rights Reserved.

Austria - ©1996-2005 NAVTEQ All Rights Reserved.

Switzerland © 1996-2005 NAVTEQ All Rights Reserved.

Portugal - ©1997-2005 NAVTEQ All Rights Reserved.

Spain - ©1997-2005 NAVTEQ All Rights Reserved.

US - ©2005 NAVTEQ All Rights Reserved.

Canada - ©2005 NAVTEQ All Rights Reserved.

Copyright © 2005 AND International Publishers N.V.

All rights reserved