




# NFC MODULE

## Operating Manual



## SETTINGS



Prowise INPUT AUDIO SCREEN DISPLAY SETTINGS

Sleep Timer OFF

LED Logo 0

Auto Updates 0 Manual Update

RS232 0

Language English

NFC Settings


User Menu 2 fingers, 2 sec

Network Settings

Key Lock IR Lock

- Press INPUT button on remote control.
- Press ► button on remote control or directly click with touch pen to enter Settings menu.
- Press ▼ button on remote control or directly click with touch pen to select the “NFC Setting” option.
- Press ENTER button on remote control or directly click with touch pen to setting.

## NFC Settings



NFC Settings

User Name: [ ]


Password: [ ]

Username can't contain these characters: ^|:|=+\*?<>

Note: Username and password need to be exactly the same as set in Windows and/or Android. Please note that passwords are case sensitive. When you experience login issues, please try to update your ID card.

Cancel Apply

- Enter the user name and password, press the APPLY button, then will display the following image.
- Please set an account and a password the same with the unit on your PC after you finish the operation above.



NFC Settings

Present ID Card to Prowise logo below screen

Prowise

00:10 Cancel

- Put the NFC card near to the LED logo in 15 seconds, the card will receive the user name and password.

## **Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **FCC Caution:**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This module shall be installed in the TVs which are similar to the one used for the test.

The device must be installed and used in strict accordance with the manufacturer's instructions as described in the user documentation that comes with the product.

### **IMPORTANT NOTE:**

In the event that these conditions can not be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

### **End Product Labeling**

The final end product must be labeled in a visible area with the following:  
"Contains FCC ID: 2AFG6-KYS".

### **Manual Information to the End User**

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module.