Mobile Disk

User's Guide

HANA Micron Incorporated www.mobiledisk.com Copyright Notice

Copyright Reserved. 2003 HANA Micron hc.

The contents of this User Guide and the Installation CD are copyrighted by HANA Micron Inc.

Reproduction or modification of the contents in part or whole without prior authorization by HANA Micron hc. is strictly prohibited.

This product is subject to change without prior notice for the purposes of performance enhancement. The actual installation and usage of the product may be slightly different from the description in this Guide.

For up-to-date information on Mobile Disk, sit our homepage:

http://www.mobiledisk.com

Trademark

Mobile Disk is the registered trademark of HANA Micron Ic.

Other company and product names are registered trademarks of the corresponding owners.

Table of Contents

1.	Introduction to Mobile Disk4
2.	Product Specifications4
3.	Operation and Usage5
	4.1 Installing Manager Program6
	4.2 Installing and Using Security Features7
	4.3 Boot Up Function14
	4.4 Recovery Disk16
5.	Service Guide
	Precautions for Use19
	U.S. FCC NOTICE

1. Introduction to Mobile Disk

Mobile Disk is a portable data storage device using flash memory, replacing the existing FDD. The capacities vary from 16MB to 1GB, and the physical size of the unit is as small as a little finger. It is an elegant next generation product.

Business people who deal with many private documents and presentation files, designers who have to back up graphic files, and students who must submit reports containing various statistics don't have to wrestle with inconvenient 1.44MB FDDs or CDs. With the Plug & Play feature, you can use it anywhere any time by inserting it into a PC or notebook. You are also able to protect your data with a password.

Very small mobile data storage

- It works on various operating systems without extra driver installation.

Plug & Play

- You can read and write data immediately after inserting it into the USB port of a PC or notebook.

No external power needed

- Batteries or an external power source are unnecessary since it uses USB power.

LED Indicator

- When you insert the Mobile Disk into the computer port, a red LED flashes repeatedly. In standby mode, it flashes once every second. During any reading and writing, it flashes continuously.

2. Product Specifications

Interface	USB Specification 2.0/(1.1 compatible)
Supported OS	Windows98, SE, ME, 2000, XP, Mac OS 9.0 +, LINUX Kernel Version 2.4.0 +
	(Driver CD installation needed for Windows 98,SE)
Capacity	16MB, 32MB, 64MB, 128MB, 256MB, 512MB, 1GB
Term of Data Preservation	10 years
Read/Write Speed	Read: 8MB/sec, Write: 5MB/sec
Power Supply	USB Bus-powered (No separate power source needed)
Components	Main Component, CD, USB Cable, Warrant, Necklace (Except HANA Mobile Disk)
Manufacturer	HANA Micron Inc., Tel: +82-(0)502-111-7272

3. Operation and Usage

General Operations

- Install Mobile Disk to the USB port directly or via an extension cable.
- You can input/output and edit/delete data right after Mobile Disk is connected to the port.

The following operating systems do not need driver installation:

- Windows ME, Windows 2000, Windows XP, Mac OS 9.0 or higher, Linux Kernel Version 2.4.0 or higher.

The following operating systems need driver installation:

- For Windows 98 and Windows 98 Second Edition (SE), driver installation is required since the OS itself does not support a Mass Storage Device. (The Driver Install CD is installed only once.)
- For Windows 98/98SE, install the driver with the Auto Install CD supplied by our company.
- After installation, the Mobile Disk is recognized as a Removable Disk as shown below.

🔄 My Computer	
File Edit Mew Powerces Tools Hold	1
4 tol → 市 谷 ton - 和Fuber (3) to > 昭 昭	X 6 E
-ift-1% 🛄 Yr Longulai	م رقع م
	<u>}</u>
My Computer (%)	NUN Contro Prine C
Selection room to the inter description. (colors the flost and robert of the local biology of	
Secieus Ps Dramerik Pr NetworkPlace secont and USE-ps principali	• •
E ⊕ a::: ¢;	🛃 ko Zrazo 🖉

- [Note1] Be sure to connect the Mobile Disk to the USB port before running the Manager Program. (See Chapter 4 for installation)
- [Note2] For Win98 / Win Me, you must unplug the Mobile Disk after the driver installation and then plug it in for normal operation.

4.1 Installing Manager Program

- 1) Insert the Manager Program CD supplied with the product into the CD ROM drive.
- 2) The main window of the Manager Program automatically appears as shown below.

Image Insertion [Manager Program Selection Window]

3) Select the Manager Program installation menu. The corresponding manager program installation screen appears.

thoose Destination Di	ectory	3
	Setup call instal U-Starage Tools in the following directory	
1	To install to this directory, click Next.	
	To install to a different directory, click Browne and select analyse directory	
	To abort the installation pocess press Cancel	
	Destination Directory	
	C.Vhopen Féel/U-blorage Tools Feel Browne	1
	(Incel	1
Click [N	ext].	



Select a language and click [Next].

4) When the installation is complete, the following message appears. Click OK.



5) "U-Storage" is automatically registered on Programs as shown below.



6) The main window automatically appears as shown below. (Unplug and plug the product for Win98, SE, and ME).



4.2 Installing and Using Secure Feature

1) Changing a Password

To change your password for protection of your private information, proceed as follows:

Right click on the tray icon at the bottom right of the screen.



Right click here.



Select U-Storage.

Select "Change Password." When the following window appears, change the password and click OK.

Henite			
	Carrent Password		
Lauis	New Passand	(married and a second s	the second
	Ganfres Paarvent:		
Louise	Passand Mak	Inc manager	1:00
	1	-	à 1216
Change .	100	and the second	of the local division in

- < Be sure to take note of your new password to not forget it.>
- [Note] If you failed to enter the correct password three times or more, please plug in the device again and try again.

If you can't remember your password, you can use the Hint for help.



2) How to Log in / Log out

Log in to move to the security data area.

Log out to move to the public area.

Logging In

Resize	Welcome to USB Mass Storage Disk
(Lapit)	Password
Legest	C Dan't pap up This velocities and an Minat's savething
Change Passment	

Click "Log In."

Enter Password and click OK to enter the secure area.

The following screen shows when you have successfully logged in.

📾 Removeble Disk (L)			
File Edit View Po-orcos Tools Help			12
i ⇔ent • ⇒ - 🛅 @Sourt @Bains @Hens 🖉 D	S X ∞ E	-	
Portex Percesk Jan (L)			<u> </u>
Removable Disk			
Coolle Karl, Werk			
Capacity: 124 Mo			
■ K (11) ¹⁹			
] 1 at 120 Yz			
toby by:	1.11.55	Etter -	· //

How to Log Out



Click "Log Out."

When the following screen appears, you have successfully logged out.

📾 Kemovable Disk ().)			
File Edit View Fo-orco Took Help			18
i ⇔ente e ⇒ - 🖿 (@Source Beniers: @Herre, 🖄 🔅	XX	I+	
Portex Perceskusk()			• 90-
Removable Disk (E:)			
Coopling Renally WereAL Coopling Renally WereAL Coopling Coopling			
Capacity: 124 Yo			
■ K (110) ²			
□ * ee (2) ¥:			
t objective)	1.11.45	EH.	· //

3) Resizing

With the Resizing feature, you can freely change the sizes of the Security and Public areas.

Public Area: You can read and write in this area without logging in.

Security Area: You must log in to read and write data in this area.

ublic Area + Security Area: The above two areas (Public, Security) can be used simultaneously with 2 drivers.

Ex) When you select Public Area + Security Area, two separate drivers are created.



[Public Area Only]

Function Utili	tv 1
Login	C (Public Area Only (Saugh Enter)
Logent	Patte Acco i Securiti Area Bualtana
Changer Patronici d	

Click "Resize."

Click OK to run Resize.

Take special care since if you resize to "Public Area Only," the security feature disappears.

Even if the partition for the Security Area disappears, the Setup.exe file still exists.

[Security Area]



Move the bar left or right on the screen to resize it, and then click OK.

When the following message appears, click "OK." The resize is applied.

)

[Public Area + Security Area]

Hanipa	Public Annu Elation 15	_ <u>}</u>	Security Areas
Legie	Public forces Dates 2	11	_
Liquid	Bertresset	12.4	Davu
(Danger	Processing that		and the second second

Set the sizes for each driver on the screen and click OK.

The following two drivers are created.



4.3 Boot Up Function

The Boot Up Function enables the device to perform as a boot disk. (The Main Board must provide USB FDD/HDD/ZIP Bootable features).

Read the following before running the program.

- This program runs on Windows 98 SE, ME, or XP. (Windows2000 is not supported.)
- 2) Stop the anti-virus program while the program is running.
- 3) A Window's system must be installed on the C Disk.
- 4) This program applies only to one device. (2 or more devices are not supported simultaneously.)
- 5) The device must be in the Public Area.(When you use this function when logged in, you will be logged out, and all the data in the Public Area will be deleted.)
- [Note] If you wish to create a bootable USB HDD, you cannot use the Security Area of the device. In addition, this option is supported only by Windows 98 SE.

The procedures for Windows 98 SE/Me and XP are different. Please follow the procedures described below. It is not supported by Windows 2000.

4-1 Windows 98 SE / ME

1) As shown in the following picture, click on the Utility button, and then the Boot up button.



2) Select USB HDD or USB ZIP.

USB HDD is supported only for Windows 98 SE.

If you select USB HDD, "C: \ >" appears after booting.

If you select USB ZIP, "A: \ >" appears after booting.

3) Make your selection and click OK. The following warning message appears.



4) When the process is complete, the following message appears.



[Error Messages]

The following message appears when the Windows OS was not installed properly. Create a folder (\WINDOWS\COMMAND\EBD in Windows 98,

 $\ \$ WINDOWS $\ \$ COMMAND $\$ EBD in Windows ME, or $\ \$ XP_Bootable in Windows XP) and copy system files to the folder.



The following message appears when the size of the Public Area is insufficient. Increase the size of the Public Area by using the Resize function.



[Note] When you carry out the above procedure, the booting files are created on the device. Make sure to prevent them from being erased. If they are erased, normal booting is impossible.

4.4 Recovery Disk

This feature is used when you wish to initialize the device because you cannot use it due to problems in the device. If there are any bad blocks in the Flash Memory, you can use Scan Disk to initialize it. However, the capacity of the device decreases for bad blocks.

1) As shown below, select Start Programs U-Storage Recover Disk on your desktop.



harmon Chak	#11
(" Head is selected	
1	Bet
Nugat.	heathens
16.	Taxian'

After running Recover Disk, all the files on the device are deleted.

Since the deleted files cannot be recovered, be sure to back up important files before running Recover Disk.

- 2) When you have checked Read & Write Test, Read/Write tests are performed for each block. It takes approximately 1.5 minutes for 16MB.
- 3) Click Start. The Low Level Format is started.



When the process finishes, the following message appears.



5. Service Guide

Service Guide

Free of Charge Services:

- Services are free for one year after purchase from the Customer Service Center.

However, service is charged for the following cases:

- When product failure results from an error or carelessness on the customer's part (damages due to shock or the entry of foreign substances).
- When product failure results from a repair or product modification by the customer.
- Product damage from natural disasters.

Many products for which service is requested have no faults. Therefore, before calling our Customer Service Center for servicing, carefully read the User Guide and check for any trouble first.

We do not take responsibility for data loss on the mobile storage device.

Customer Service Center

Room 902, First Ssangyong IT Twin Tower,

442-17 Sangdaewon-dong, Jungwon-gu, Seongnam-shi,

Gyeonggi-do, Korea, 462-807

TEL: +82-(0)502-111-7272 FAX: +82-(0)31-608-5534

E-mail: <u>support@hanausb.com</u>

HANA Micron Inc.

Precautions for Use

- Never remove Mobile Disk until the flashing of the LED completely stops. Otherwise, the data may be lost.
- In order to safely remove the drive, select Unplug from "Unplug or Eject Hardware" from the Control Panel before removing it.
- HANA Micron Inc. does not take responsibility for data loss due to any reason except inherent defect of the product.
- When an error message appears while saving data, check the connection of the device, and the Write Protect switch on the side (for corresponding products, except HANA Mobile Disk).
- If the problem is not solved by any above method, format the device completely. To format it, run the U-Storage Manager Program contained on the CD supplied with the product (See 4.2).
- The U-Storage Manager Program supports the format for general Windows as well as complete formats for Flash Memory to enable the safe and efficient use of the product.

U.S. FCC CLASS B NOTICE

Caution : Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy, if it is not installed or used by the instructions, it may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, that could be determined by tuning the equipment on and off, the user is encouraged to try to connect the interference with the following option:

- Re-orient or relocate the reception of antenna.
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected to.
- Consult the dealer or an experienced Radio / Television technician for help.

NOTE: The manufacturer is not responsible for any Radio or TV interference caused by unauthorized modifications to equipment.

Such modifications could void the user's authority to operate the equipment