

- ◇ The item “More” includes “Add bookmark”, “Find on page”, “Select text”, “Page info”, “Share page”, “Downloads”, and “Settings”.

- Get in “Select text”, select the item by **◀ ▶ ▲ ▼**, or select the contents by mouse, then press **OK** to copy.



- Get in “Settings”, and you can revise the browser type in the item “Set browser type” to support more websites. The default browser type is “IPad”. If the websites can not support well, try to revise to “Android” or “Desktop”.



- Adobe Flash player is installed in this unit. Don't uninstall or update with other versions of Flash player.
- Backup “Flash player .apk” in the file “android” of “sdcard_int” to your external equipments.

4.5 Gallery


- Get in “Gallery”, and lists all the files with pictures and show preview window.
- Press **◀ ▶ ▲ ▼** to select and press **OK** to display.
- When displaying, press **◀ ▶** to go to the last or next picture.
You can display them as slides, and also can select the items “Share”, “Delete”, and “More” with mouse.
- Press **SETUP** to show the menu.



4.6 Settings

4.6.1 Wireless & networks

- WIFI setting: Turn on (Tick) / Turn off (No Tick).
- Setting and management of wireless access point.
- Select the wireless hotspot you want to link, and fill the password if needed.
- Press **Setup** or click the sign  on the right top corner with the mouse .Get in “Advanced”, you can set the “Wi-Fi sleep policy” and “Use static IP”.



The Connection speed depends on the signal strength of WIFI. If fail to connect, please strengthen the signal. If no signal of the WIFI, turn off the WIFI of the unit and search again to continue.

4.6.2 Ethernet



- The Ethernet is on when shows “Tick”, and is off when no “Tick”.
- Ethernet settings: “Ethernet Devices”, “Connection type”, “IP address”, “Netmask”, “DNS address”, and “Default router”.



4.6.3 Display

- Output mode:


480I	480P
576I	576P
720P	
1080I	1080P
- Set your TV output mode to 480i or 576i before connect TV with CVBS.




- If display position incorrect, adjust your TV display position by **◀ ▶ ▲ ▼** and **OK**. Press **return** to save and reboot the unit.

4.6.4 Applications

- “Unknown source” (Allow installation of non-Market applications), “Compatibility Mode” (Run older apps in Compatibility mode. This require rebooting.), “Quick launch” (Set keyboard shortcuts to launch applications), “Manage applications” (Manage and remove installed applications), “Running services”, and “Storage use”, “Development” (Set options for application development).
- Tick “Unknown sources” before you install any new application.
- Management applications: “Downloaded”, “All”, and “On SD card”, and “Running” four items are on the menu. There are some relative programs in each item. It shows the occupied capacity and the available capacity on the bottom.
- When get in “Downloaded”, “All”, or “On SD card” and press **SETUP**, you can change the ordering of applications by the capacity or by the name of the applications.



- Select any application and press **OK**, it shows the details of the program, such as name, version, cache. Also can revise the “Setting”, “Force stop”, and “Uninstall”.




◇ **Program uninstall:**

- ① Get in “Setting” -- “Applications” -- “Manage applications” .
- ② Select the program you want to delete from “Downloaded” , “All” , or “On SD card” .
- ③ Select “Uninstall” to finish uninstalling.




4.6.5 Accounts & sync




- “Background data” (synchronize, send or receive the data), “**Auto-sync**” (synchronize the data automatically).
- Manage account (add or remove account).

4.6.6 Privacy




- “Back up my data” & “Factory data reset”
 - ◆ Don’t do the factory data reset unless the system is faulty. When factory data reset, it will erases all applications, including “sdcard_int”. Copy the files and APKs in “sdcard_int” to your external equipments before factory reset.
 - ◆ Don’t erase the SD card!

4.6.7 Storage



4.6.8 Language & keyboard

- Select language & Set Keyboard.



4.6.9 Accessibility

- This function is unavailable.

4.6.10 Date & time

- Tick Automatic, and select time zone. It will update the date and time automatically online.

4.6.11 About device

- “System updates”, “Status”, “Legal information”, “Model number”, “Android version”, “Kernel version”, and “Build number”.

4.7 Android

4.7.1 AppInstaller

Applications install

- ① Copy the application or game application to U disk or other movable disks.

- ② Get in “AppInstaller”, and choose the device.

- ③ Select the applications you want to install.



- ④ Select “Install”--“Application installed”--“Open” or “Done”.

“Do you want to install this application?

Allow this application to:

- ✓ **Storage**
modify/delete SD card contents
- ✓ **Network communication**
create Bluetooth connections, full Internet access
- ✓ **Phone calls**
read device state and identity
- ✓ **System tools**
bluetooth administration, modify global system settings, prevent device from sleeping

Install

Cancel

If the application can not be installed, check the compatibility and APK program corrupted or not. Some APK applications are not compatible with Android 2.3.

4.7.2 Play Store (Android Market)


- In Play Store, a lot of applications are available.
- A Google account is needed to log on.



4.7.3 OOBЕ

- Fast setup:

- ① Language select
- ② Output mode
- ③ Ethernet Configuration
- ④ WIFI Configuration
- ⑤ Finish
- ⑥ Restart



4.7.4 Email

Gmail ID can be used on “E-mail” directly. Other mail ID is needed to configure an Android device as following:

- ① Open your email client.
- ② Enter your full email address and password.
- ③ Choose type of account: POP3, IMAP or Exchange.
- ④ Recommend POP3 or IMAP and use your access domain for the incoming server.
- ⑤ Set SMTP server for the outgoing server settings.
- ⑥ Click next and you're done.



4.7.5 PPPOE

- PPPoE for Android let you establish a PPPoE connection directly from this unit. It's useful for you when haven't got a router and need to login to connect to Internet.
- Connect to your wireless network or Ethernet, then go to preferences, insert username and password and then tap "connect".

5. Troubleshooting

WARNING

Under no circumstances should you try to repair this unit yourself, as this invalidates the warranty.

If a fault occurs, first check the points listed below before taking this unit for repair. If you are unable to remedy a problem by following these hints, consult your dealer.

Problem	Solution
No power.	<ul style="list-style-type: none">- Ensure that the power adapter connect well.- Disconnect the power cord from the adapter, reconnect and try again after a few minutes.
No picture.	<ul style="list-style-type: none">- Refer to your TV's manual for correct Video In source selection. Change the TV source until you see this unit screen.- If you connect TV with CVBS, make sure that your TV output mode is set to 480i or 576i.
No sound	<ul style="list-style-type: none">- Check the audio connections to the connected audio device.- Make sure that the connected audio device is turned on the correct input source.- The audio codec may not be supported by this unit
Failure to get the access to internet	<ul style="list-style-type: none">- Reset network connection.- If Ethernet, select "Settings" — "Ethernet" — "Tick".- If WiFi, select "Settings" — "Wireless & networks" — "Wi-Fi setting" — "Tick".- Make sure the WiFi signal is good.

Problem	Solution
Movable HDD cannot work	<ul style="list-style-type: none"> ▪ Make sure movable HDD is available. ▪ Try to supply power to the movable HDD alone. ▪ “4.6.3 Display” for your reference
TV display position incorrect	<ul style="list-style-type: none"> ▪ Change browser type to “Desktop” or “Android” . ▪ “4.4 website” for your reference
Cannot play the video on the website or not smooth.	<ul style="list-style-type: none"> ▪ Reset the system as below: <ol style="list-style-type: none"> ① Take off the power adapter. ② Connect the TV. ③ Keep pressing the reset button on the unit. ④ Connect the power supply. ⑤ The unit reboot automatically and shows the recovery menu. ⑥ Release the reset button on the unit. ⑦ Select by ▲ ▼ and OK of the remote: “wipe data/factory reset”—“yes—delete all user data” , ⑧ reboot system.



FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For a Class B digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual: Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Statement: This equipment complies with FCC's radiation exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must be installed and operated to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter. Installers must ensure that 20cm separation distance will be maintained between the device (excluding its handset) and users.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.