

barometric pressure calibration. You can calibrate according to the barometric pressure in your local. Press “②” to go up in units, press “⑤” to go down in units. After the adjustment is completed, press and hold “④” again, the date will be saved and it will exit to the calibration mode.


3) Press “⑤” each time, it will circulate among “°C”, “°F”, “RH%”:

°C: Centigrade; °F: Fahrenheit; RH%: Relative Humidity;

7) Press “⑥” each time to select “MAX”, “AVG”, “MIN” of wind speed. Press and hold “⑥” for above 3 seconds, back light will turn on. Press and hold “⑥” for above 3 seconds again, it will turn off.

8) Open the Bluetooth of phone and anemometer power, The anemometer will be automatically connected to the phone. Or you can check the name of Bluetooth on the phone.


Anemometer Instruction Manual Model No.: HoVR 1.0



Above picture and content just for your reference. Please be subject to the actual products if anything different or updated. Please pardon for not informing in advance

1. Function:

- 1) Wind speed measurement
- 2) Barometer indicator
- 3) Temperature/humidity/
- 4) Altitude measurement
- 5) Measure wind speed in: Current/Max/Min/Average
- 6) Low battery warning
- 7) LCD back-light
- 8) Auto / Manual power off (Note: It will not auto power off in the interface of barometer indication)



2. Operation:

- 1) Put battery into battery compartment.
- 2) Recover battery cover, screw down press "①" in 1 second to turn on the unit. LCD will display wind speed, temperature and battery icon. Press again, it will power off.

4) Press "②" to select different wind speed unit: Press "②" each time, it will circulated among "m/s", "Km/h", "Ft/min", "Knots", and "MPH".

Digit symbol:

m/s: meter per second; Km/h: kilometer per hour; Ft/min: feet per minute; Knots: nautical mile per hour; MPH: mile per hour.

5) Press "③" to select different barometric pressure unit: Press "③" each time, it will circulated between "inHg" and "hpa mbar". Press and hold "③" for above 3 seconds, it will enter to the reading of barometric pressure mode. There are total 16 groups data, and record the barometric pressure in 2 hours per time. Now you press it, you can check the 16 groups data. Press and hold "③" again, it will exit to the reading of barometric pressure mode.

Digit symbol:

inHg: inches of mercury

hpa mbar: millibars / hectopascals.

1(inHg)=33.8638816(hpa)

6) Press "④" to select altitude unit, press "④" each time, it will circulated between "M" and "FT".

Note: As the altitude is the conversion from atmospheric pressure, in different periods, the uneven air density which is caused by climate will lead to different altitude.

Digit symbol:

M: meter; FT: feet.

1(m)=3.2808399(ft)

Press and hold "④", it will go into the mode of

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is

no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC Caution.

- English:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1)

This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- French:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radio électrique subi, même si le brouillage est

susceptible d'engendrer le fonctionnement.

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans une condition d'exposition portable sans restriction.