

EN

Augusta H375i


CONGRATULATIONS

Augusta H375i

Get the convenience of push-to-talk calls together with a sleek design in an affordable package.

- **Private Calls:** Stay in touch with your family, friends, and colleagues with the simple touch of a button.
- **My Phone, My Way:** It's your phone - make it that way. Customize your home screen with personal pictures, and change wallpapers and ringtones.

Caution: Before assembling, charging, or using your phone for the first time, please read the important safety, regulatory and legal information provided with your product.

 This product meets the applicable SAR limits of 1.6 W/kg (FCC & IC) and 2.0 W/kg(ICNIRP). The limits and guidelines include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The highest SAR values measured for this device are listed in the regulatory information packaged with your product.

YOUR PHONE

The important keys & connectors



Note: Your phone might look a little different.

Contents

MENU MAP	4
LET'S GO.....	5
BASICS	7
CALLS	11
PUSH-TO-TALK.....	13
SDG CALLS.....	15
WEB	16
TEXT ENTRY	17
CONTACTS	18
MESSAGING.....	19
PERSONALIZE	22
MULTIMEDIA	24
BLUETOOTH™ WIRELESS	27
TOOLS	29
SECURITY	33
SAFETY, REGULATORY & LEGAL	35
LIMITED GLOBAL WARRANTY MOBILE PHONES.....	50

MENU MAP

MAIN MENU



Recent Calls



Contact

- [New Contact]
- [New SDG List]
- [New Msg Group]



Messages

- [Create Message]
- Voice Mail
- Inbox
- Drafts
- Outbox
- Sent Items
- Net Alert



Web

- Net



Multimedia

- Media Center
- My Images
- My Music
- My Video
- Ring Tones
- Voice Record



Push To Talk

- Call Alert
- PT Manager
- Quick PTT
- PTT Options
- PTT Help



Games and Apps

- Buy More
- Alarm Clock Plus
- My Images
- My Music
- My Video
- Java Systems



Tools

- My Info
- Profiles
- Alarm Clock Plus
- Bluetooth
- GPS
- Datebook
- Call Timers
- Memo



Settings

- (See **Settings** menu)

LET'S GO


Let's get you up and running

ASSEMBLE & CHARGE




Caution: Please read “BATTERY USE & SAFETY”

TURN IT ON & OFF

To turn on your phone, press and hold Power/End for  a few seconds or until the display turns on. If prompted, enter your four-digit unlocks code.




Note: If you press Power/End  for more than four seconds, the phone will turn on in **Transmitters Off** mode.

To turn off your phone, press and hold Power/End .

ENABLE SECURITY

You will need to enable security the first time you turn on your phone or within 10 days of using your phone.

- 1 Press **Ok**.
- 2 You are prompted to enable security. Press **Yes** and follow the on-screen instructions.
- 3 Press Power/End  to return to the home screen.





BASICS

ABOUT THIS GUIDE

This guide shows how to locate a menu feature as follows:

Find it: Menu  >  **Settings** > **Phone Calls**

This means that, from the home screen:

- 1 Press the Menu key  to open the main menu.
- 2 Press the navigation keys to scroll to the  **Settings** menu option, and press **OK**  to select it.
- 3 Press the navigation keys to scroll to **Phone Calls**, and press **OK**  to select it.

HOME SCREEN









Your phone shows the home screen when you are not on a call or using the menu.



Note: Your home screen might look different from the one shown, depending on your service provider.

Soft key labels in the home screen show the current soft key functions.

Indicators at the top of your phone's display provide important status information.

Indicators			
	Signal Strength		No Service
	Active Phone Line		New Message
	Speaker On		Packet Data
	Speaker Off		Battery Level
	Ringer Off		Bluetooth™ On
	Vibrate All		New Voicemail

CAROUSEL MENU

Get quick access to your favorite applications, right on your home screen.

OPEN APPLICATIONS

1 Press the Navigation Key left or right until you highlight the desired application.

2 Press **OK**  to launch the Application



Note: Availability of the Carousel is dependent on your service provider.

CHOOSE APPLICATIONS

Customize the Carousel with your most often used applications

Find it: Menu  >  Settings > Personalize > Carousel

AUTO HIDE

To set the Carousel to hide when not in use, press Menu  >  Setting > Personalize > Carousel > Auto Hide

ADJUST VOLUME


Press the volume keys up or down to:

- change the earpiece volume during calls
- change the ringer volume from the home screen
- turn off a call alert before answering the call



Tip: While on the home screen, press and hold the volume key down until your phone vibrates to set your ringer to **vibrate all**.



NAVIGATION KEY

Press the navigation key up, down, left, or right to scroll to items in the display. When you highlight an item, press **OK** to  select it.



TRANSMITTERS

Consult airline staff about the use of the **Transmitters Off** feature during a flight. Turn off your phone whenever instructed to do so by airline staff.

Find it: Menu  >  Settings > Advanced > Transmitters > off

Transmitters Off turns off your phone's calling and Bluetooth features in situations where wireless phone use is prohibited. You can use the phone's other Non-calling features when the transmitters are turned off.


Note: When you select **Transmitters Off**, all wireless services are disabled. Emergency calls can still be made.

CALLS

It's good to talk

MAKE & ANSWER CALLS

Enter a number, then press Talk 

To answer a call, press Talk 

To end a call, press Power/End 



HANDSFREE


Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

During a call:

- To use the speakerphone, press **Speaker**.
- To connect a Bluetooth device, press Menu > **Use Bluetooth**.

RECENT CALLS

Find it: Menu  >  **Recent Calls**

Tip: When you are in the home screen, you can press Talk  to go to **Recent Calls**.

The recent calls list contains information associated with the last 20 calls you have made and received.

To display call details, highlight an entry and press **OK** 



EMERGENCY CALLS

Note: Your service provider programs one or more emergency phone numbers that you can call under any circumstances, even when your phone is locked.

Emergency numbers vary by country. Your pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

1 Enter the emergency number.

2 Press Talk  to call the emergency number.

Note: Emergency calls can't be placed while the keypad is locked, or if the phone is displaying a No Service message. To unlock the keypad, press Menu  > 

Note: Your phone can use location based services (GPS and AGPS) to help emergency services find you. See "LOCATION SERVICES" on page 47.

COOL DOWN

In very limited circumstances, such as where your phone has been exposed to extreme heat, you may see "Cool Down" messages. To avoid possible damage to your battery and phone, you should follow these instructions until the phone is within its recommended temperature range. When your phone is in "Cool Down" mode, only emergency calls can be made.

PUSH-TO-TALK



one or more, talk to them all

PRIVATE CALLS

Private calls are push-to-talk calls between two people.

MAKE AND ANSWER PRIVATE CALLS

To **make** a private call:

- Enter the recipient's PTI number.
- Press Menu  >  **Contacts**, and select a contact that has a PTT number.




To **talk**, press and hold the PTT Button.

To **listen**, release the PTT Button.

To **answer** a private call, press the PTT Button after the caller has stopped talking.

To **end** a private call, press Power/End  or do nothing. The call will end after a few seconds.

SET PUSH-TO-TALK < SPEAKER

You can listen to push-to-talk calls through your phone's speaker or earpiece. Press Speaker  to turn the speaker on or off.



CALL ALERTS

Use call alerts to tell someone you want to speak to them.

To **send** a call alert:

- Enter a Private ID, and press **Alert**. When prompted, press the PTT Button.
- Press **Contacts**, and highlight a contact containing a Private ID. Press **Alert**, and press the PTT Button when prompted.

When you **receive** a call alert, you can:

- **Answer:** Press the PTT Button to begin a private call with the sender.
- **Queue:** Press **Queue** to store the call alert to the call alert queue.
- **Clear:** Press **Clear** to dismiss and delete the call alert.

Note: Call alerts will automatically be moved to the queue after a few minutes of inactivity. You won't be able to make phone calls or private calls until the call alert is moved, or you've chosen one of the options above.

TURN OFF A CALL ALERT

You can press the volume keys to turn off a call alert before answering the call.

SDG CALLS

Need to talk to more than one person at a time? With SDG (Selective Dynamic Group) calls you can talk to up to 20 people at a time.

Note: SDG calls may not be available from your service provider. To store groups on your phone you need a group-call-capable SIM card. Contact your service provider for more information.

CREATE SDG LISTS IN CONTACTS

Find it: Menu  >  **Contacts**

- 1 Select **[New SDG List]**.
- 2 If you want to assign a name to the SDG list, enter the name.

Note: If you do not assign a name, the SDG list is named "SDG" followed by the number of members in the SDG list. For example, "SDG (8)" for an SDG list with eight members.

- 3 Add Private IDs.
- 4 Press **Save**.

MAKE SDG CALLS

- 1 From Contacts or the recent calls list, scroll to or select the SDG list you want.
- 2 Press the PTT button.

WEB


Find it: Menu  >  **Web > Net**

Note: Your service provider may charge you to surf the Web or download data.

GO TO A WEB SITE



- 1 From the home page, select **Go to URL**.
- 2 Press **Edit**.
- 3 Enter the web address and press **Done**.
- 4 Press **Option** and select **accept** to go to the web site.

CREATE A BOOK MARK

- 1 While on a web page, press and hold Menu  > **Bookmark Page**.
- 2 Name the bookmark and select **Save**.

ACCESS A BOOKMARK

From a web page:


- 1 Press and hold Menu  > **View Bookmarks**.
- 2 Highlight a bookmark and press **OK** , or press its number on the keypad.


TEXT ENTRY

Your phone provides convenient ways to enter text.

CHANGE CHARACTER INPUT MODE

While entering text, press Menu , options.

Options	
Alpha	Enter a single letter at a time. Press a key to cycle through the characters. To select a character, press another key or wait a second.
Word	Predicts words as you enter text. Press the Navigation Key right to accept word. If incorrect, press and hold the Navigation Key down for other options. Highlight a word and press OK  to select.
Symbols	Enter symbols.
Numeric	Enter numbers.
Text Input Settings	Select desired entry language and Word Prediction features.
Insert	Select an item to be inserted. Note: Only available with MMS.

Tip: When entering text, press and hold  to change letter capitalization (**Abc** > **ABC** > **abc**).

CONTACTS


STORE A PHONE NUMBER OR PRIVATE ID

Find it: Menu  >  **Contacts > [New Contact]**

- 1 Enter a name for the new contact. Each contact's name can contain up to 20 characters.
- 2 Select a ringtone.
- 3 Select a type for the contact (**Mobile, Private1, Private2, Work1, Work2, Home, Email1, Email2, Fax, Pager, Talkgroup, SDG, Msg Group, IP, or Other**). Choose **Private1 or Private2** to store a Private ID.
- 4 Enter the number for the contact and press **Save**.

CALL A STORED PHONE NUMBER OR PRIVATE ID

Find it: Menu  >  **Contacts**

- 1 Scroll to the contact.
- 2 If the contact contains more than one number, scroll left or right until the type of number you want to call appears (such as **Mobile, Private1, Work1, Work2, Home**).
- 3 If you chose a phone number, press **Talk**  to begin a call. If you chose a Private ID, Talkgroup ID, or SDG list, press and hold the **PTI Button** to start a call.


MESSAGING

Find it: Menu  >  **Messages**

Your phone can use both SMS and Multimedia Messaging Service (MMS) messaging. The type of messaging your phone uses is determined by your service provider.

CREATE & SEND MESSAGES

Find it: Menu  >  **Messages > [Create Message]**


- 1 Enter the phone number of the person you want to send the message to and press **OK** or press **Search** to select a contact or recent call.
- 2 Enter your message in the **Message** field.
- 3 Or add a picture, sound, or quick note:
 - Quick notes are short, pre-written phrases. Press **QNotes** to enter a quick note.
 - To insert pictures, sounds (audio files), or voice recordings into the body of your message, press Menu  > **Insert > Insert Picture, Insert Audio, Insert Video or Record Voice.**

Note: To remove an item from a message, highlight it and press **Delete**.

- To attach a file to the end of your message, select **....MORE.... > Attach > [New Attach] > Browse**

Pictures, Browse Audio, Record, Voice, Browse Video.

Note: You can only attach pictures and audio files if they're not forward locked or DRM-protected.

Tip: To remove an attachment, select **Attach**. Highlight the attachment to remove, and press Menu  **Unattach**.



Note: You can't attach or insert files in SMS messages.

4 When finished, press O K 

5 To send the message, press **Send**.

RECEIVE MESSAGES

- To view the message, press **Read**.
- To dismiss the message notification, press **Exit**.

To read your messages later, press Menu 
 **Messages > Inbox**.

MESSAGE GROUPS

You can create a message group to send messages to a group of up to 20 contacts.

Note: Your service provider may not support this feature.

CREATE MESSAGE GROUPS

Find it: Menu  >  **Contacts** > **[New Msg Group]**

- 1 Select **[Add Member]** and select the contacts you want to add to the group.
- 2 When you're finished press **Done**.
- 3 Enter a name for the group in the **Name** field.

Note: If you don't name the group, it will be named **Msg Group** followed by the number of group members. For example, **Msg Group (3)**.

- 4 Press **Save**.


VOICEMAIL

To receive voicemail, you'll need to contact your service provider to set up a voicemail account.

RECEIVING A MESSAGE

To listen to the message, press **Call**.

To dismiss the notification, press **Back**.

To listen to your messages later, press Menu  > 
Messages > **Voice Mail**.

PERSONALIZE

RINGTONES

Find it: Menu  >  **Multimedia** > **Ring Tones**

- 1 Make sure **Vibrate All** is set to **Off**.
- 2 Scroll through the list of ringtones and select one to assign. **Vibrate** sets your phone to vibrate instead of making a sound. **Silent** sets your phone to neither vibrate nor make a sound.
- 3 Select the features, such as **Messages**, you want to assign the ringtone to.
- 4 When you're finished press **Done**.

Note:  appears if the phone is set to **Silent**.  appears if the phone is set to **Vibrate All**.

SET TO VIBRATE

You can set your phone to vibrate for all calls and alerts.

Find it: Menu  >  **Multimedia** > **Ring Tones** > **Vibrate All**
Set this option **on** or **Locked**

To turn the ringer on when **Vibrate All** is set to **On**, press the volume key up. To turn the ringer on when **Vibrate All** is set to **Locked**, press and hold the volume up key until the phone vibrates, then press the volume key up again.

BACKLIGHT

Set the amount of time the backlight remains on or turn it off to extend battery life

Find it: Menu  >  Settings > Display/Info > Backlight

WALLPAPER

Find it: Menu  >  Settings > Display/Info > Wallpaper

- 1 Select **Wallpaper**.
- 2 Scroll through the list of pictures and press OK to select a picture.

You can set the wallpapers to change automatically by selecting **Auto Cycle**.

MENU LANGUAGE

Find it: Menu  >  Settings > Display/Info > Language

PROFILES

Your phone has different profiles. You can customize ringtones, display settings, call settings, volume, and call filters.

Find it: Menu  >  Tools > Profiles

MULTIMEDIA

MY MUSIC







PLAY MUSIC FILES

Find it: Menu  >  Multimedia > My Music

To play a **Song, Album, Playlist, Genre, or Artist**, highlight it and press **Play**.

To view the contents of an **Album, Playlist, Genre, or Artist**, highlight it and press OK .

MUSIC PLAYER CONTROLS

Options	
Play/Pause	To play a song press OK  To pause a song, press OK  Play/Pause
Next/ Previous Song	Press Fast Forward  (next) or Rewind  (previous).
Fast Forward/ Rewind	Press Fast Forward  (next) or Rewind  (previous).

PLAYLISTS

Find it: Menu  >  Multimedia > My Music > Playlists > [Create New]


To add a song to the Favorites playlist, highlight it and press Menu  > **Add To Favorites**.



PODCASTS


Find it: Menu  >  Multimedia > My Music > Podcasts

PODCAST HIGHLIGHTS

Use highlights to mark parts of a podcast.

To add a highlight, press Menu  > **Add Highlights**. Press **On** to mark the beginning, and **Off** to mark the end. When finished, press **Back**.

Tip: When playing a podcast, press Menu  > **Clear** to delete a highlight, or press Menu  > **Edit Highlights** > **Clear All Highlights** to delete them all.

Press the Navigation Key left or right to move between highlights, or press Menu  > **Highlights Only** to skip everything not marked as a highlight.


FM RADIO

Note: Your service provider may not support FM radio.

Find it: Menu  >  Multimedia > My Music > FM > Radio

Note: A wired 2.5mm PTT headset is required for radio use.

FIND A STATION

Press the navigation key up or down to search for stations, or press Menu  > **Enter Freq.** to use your key pad to enter a station.

STATION PRESETS

Your phone can store up to nine station presets.

To store a station, tune into it and press and hold a number (1-9) on your keypad.


To tune in a station preset, press its number.



MY IMAGES

My Images lets you browse, edit, and view images on your phone.

VIEW IMAGES

Find it: Menu  >  Multimedia > My Images


Press Menu  > **Slideshow** to view a slide show of all the images in the current folder.

Press  and  to switch between images stored on the phone's memory.

MY VIDEOS

Find it: Menu  >  Multimedia > My Videos

VIEW VIDEOS



To view a video, select a folder, highlight the file, and press OK .

Tip: Videos are displayed in portrait by default. To change to landscape, press Menu  > **Full Screen**.

BLUETOOTH™ WIRELESS

lose the wires and go wireless

TURN BLUETOOTH POWER ON OR OFF

Find it: Menu  >  Tools > Bluetooth > Setup > Power





Note: To extend battery life, turn Bluetooth off when not in use.

CONNECT DEVICES

Note: This feature requires an optional accessory.

1 Make sure the Bluetooth device is discoverable.

Note: Refer to the Bluetooth device guide for details.

2 Press Menu  >  Tools > Bluetooth > Audio Devices > **[Look for Devices]** to connect to an audio Bluetooth device. Press Menu  >  Tools > Bluetooth > **Pair to Devices** to connect to any other type of Bluetooth device.

3 Select your Bluetooth device from the list.

4 Press **Yes** when you're prompted to bond.

5 If prompted, enter the Bluetooth PIN, such as **0000**.

6 Press **Ok**.

Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely

RECONNECT DEVICES

To automatically reconnect to a paired device, simply turn it on.

To manually reconnect with a paired device, select the device in the **Audio Devices** list.


DISCONNECT DEVICES

To automatically disconnect from a paired device, simply turn off the device.

To manually disconnect from a paired device, select the device in the **Audio Devices** list. When prompted to disconnect, press **Yes**.

TOOLS

DATEBOOK



Features Menu  >  Tools

Create datebook event

To create a new Datebook event press

Menu  >  Tools > Datebook > [New Event]

See datebook events

To see a datebook event press Menu  >  Tools > Datebook. Press the navigation key left or right to see the day and up or down to see the events.





VOICE RECORD

Features

Create a voice record

Press Menu  >  Multimedia > VoiceRecord > [New VoiceRec]. Press **OK**  to stop recording.

playing voice records

Press Menu  >  Multimedia > VoiceRecord. Highlight a voice record and press **OK**  to play it. To stop the voice record while it's playing, press **OK** .



Note: Recording of calls is subject to varying State and Federal laws regarding privacy and recording of

conversations. Always obey the laws and regulations on the use of this feature.

ACCESSIBILITY

VOICE PLAVBACK

Your navigation and selections, read out loud.

To turn on voice readouts, press Menu  > 
Settings > Voice Playback > Speak Text.






To use voice readouts:

- **Menus:** In menus, highlight an item (it will be read out loud).
- **Dialer & text entry:** As you type, each number or letter is read out loud.

Tip: Navigate through your menus to hear how voice readouts work on your phone.

CALLER ID

When you want to **hear** who's calling:

- **Read out loud:** Have your caller announced-touch Menu  >  Settings > Voice Playback > Speak Caller.
- **Ringtones:** Assign a unique ringtone to a contact - press Menu  >  **Contacts**, highlight a contact, then touch Menu  > Edit > [Ring Tone/Pict] > Ringer, and select a ringtone. When finished, press **Save**.

VOLUME & VIBRATE



Choose volume and vibrate settings that work for you.

- **Volume:** Press the Volume Key up to raise the volume, or press the Volume Key down to lower it.
- **Vibrate:** Press the Volume Key down until the phone vibrates.


HEARING AIDS

To help get a clear sound when using a hearing aid or cochlear implant, your phone may have been rated for use with hearing aids. If your phone's box has "Rated for Hearing Aids" printed on it, then please read the following guidance.



Note: Ratings are not a guarantee of compatibility, see „Hearing Aid Compatibility with Mobile Phones" in your legal and safety information. You may also want to consult your hearing health professional, who should be able to help you get the best results.

- **Settings:** Press Menu  >  **Settings** > **Phone Calls** > **Hearing Aid**. Select **Microphone** to optimize your phone for microphone coupling, or select **Telecoil** to optimize your phone for telecoil coupling.
- **Call volume:** During a call, press the side volume keys to set a call volume that works for you.

- **Position:** During a call, hold the phone to your ear as normal, and then rotate/move it to get the best position for speaking and listening.



TTY

You can use your phone in TTY mode with standard teletype machines. Press Menu  >  Settings > Phone Calls > TTY > On, and select the mode you need:

- **TTY:** Type and read text on your TTY device.
- **HCO:** Hearing-Carry-Over-type text on your TTY device and listen to voice replies on your phone's speaker.
- **VCO:** Voice-Carry-Over-speak into your phone and read text replies on your TTY device.

Note: You'll need a cable/adaptor to connect your TTY device to the headset jack on your phone.


Refer to your TTY device guide for mode and usage information.

SECURITY



PHONE LOCK

Find it: Menu  > **Settings** > **Security** > **Phone Lock** > **Lock Now** or **Auto Lock**

CHANGE UNLOCK CODE


When you receive your phone, your unlock code is **0000**. To change your unlock code, press Menu  > **Settings** > **Security** > **Change Passwords** > **Unlock Code**. Enter the current unlock code and enter the new four digit unlock code. Re-enter the new four digit unlock code to confirm.

KEYPAD LOCK

Find it: Menu  >  **Settings** > **Security** > **Keypad Lock** > **Lock Now** or **Auto Lock**



Shortcut: To lock the keypad, press Menu  > .

LOCK YOUR SIM

To lock your SIM, press Menu  > **Settings** > **Security** > **SIM PIN** > **On**.

Caution: If you enter an incorrect PIN code three times, your phone locks your SIM card and asks for your PIN unlock code.

CHANGE SIM PIN

To change your SIM PIN, press Menu  >  Settings > Security > Change Passwords > SIM PIN.


PUKCODE

To unlock your SIM PIN, you need to enter your PIN unlock code (PUK code) when prompted.

Note: Your PUK code is provided by your service provider.

GPS PIN

When you receive your phone, your GPS PIN is **0000**.

To change your GPS PIN press Menu  > **Settings** > **Security** > **Change Passwords** > **GPS PIN**. Enter the current GPS PIN and enter the new four-to-eight digit GPS PIN. Re-enter the new four- to eight-digit GPS PIN to confirm.

FORGOT YOUR PASSWORD?

If you forget your password, contact your service provider.

Safety, Regulatory & Legal

Battery Use & Safety

The following battery use and safety information applies to all mobile devices. **If your mobile device uses a non-removable main battery** (as stated in your product information **details related to handling and replacing your battery should be disregarded**-the battery should only be replaced by an approved service facility, and **any attempt to remove or replace your battery, unless performed by a service representative, may damage the product and void your warranty.**

Important: Handle and store batteries properly to avoid injury or damage. Most battery safety issues arise from improper handling of batteries, and particularly from the continued use of damaged batteries.

DON'Ts

- **Don't disassemble, crush, puncture, shred, or otherwise attempt to change the form of your battery.**
- **Don't use tools, sharp objects, or excessive force to insert or remove the battery as this can damage the battery.**
- **Don't let the mobile device or battery come in contact with liquids.*** Liquids can get into the mobile device's circuits, leading to corrosion.
- **Don't allow the battery to touch metal objects.** If metal objects, such as jewelry, stay in prolonged contact with the battery contact points, the battery could become very hot.
- **Don't place your mobile device or battery near a heat source.*** High temperatures can cause the battery to swell, leak, or malfunction.
- **Don't dry a wet or damp battery with an appliance or heat source,** such as a hair dryer or microwave oven.

DOs

- **Do avoid leaving your mobile device in your car in high temperatures.***
- **Do avoid dropping the mobile device or battery.*** Dropping these items, especially on a hard surface, can potentially cause damage.*
- **Do contact your service provider if your mobile device or battery has been damaged in any of the ways listed here.**

***Note:** Always make sure that any battery, connector and compartment covers are closed and secure to avoid direct exposure of the battery to any of these conditions, even if your product information states that your **mobile device** can resist damage from these conditions.

Important: The Manufacturer recommends you always use authorised-branded batteries and chargers for quality assurance and safeguards. The warranty does not cover damage to the mobile device caused by non-authorized batteries and/or chargers

Disposal: Promptly dispose of used batteries in accordance with local regulations. Contact your local recycling center or national recycling organizations for more information on how to dispose of batteries.

Warning: Never dispose of batteries in a fire because they may explode.

Battery Charging

Notes for charging your product's battery:

- During charging, keep your battery and charger near room temperature for efficient battery charging.
- New batteries are not fully charged.
- New batteries or batteries stored for a long time may take more time to charge.
- Hi-P batteries and charging systems have circuitry that protects the battery from damage from overcharging.

Third Party Accessories

Use of third party accessories, including but not limited to batteries, chargers, headsets, covers, cases, screen protectors and memory cards, may impact your mobile device's performance. In some circumstances, third party accessories can be dangerous and may void your mobile device's warranty.

Driving Precautions

Responsible and safe driving is your primary responsibility when behind the wheel of a vehicle. Using a mobile device or accessory for a call or other application while driving may cause distraction, and may be prohibited or restricted in certain areas-always obey the laws and regulations on the use of these products.

While driving, NEVER:

- Type, read, enter or review texts, emails, or any other written data.
- Surf the web.
- Input navigation information.
- Perform any other functions that divert your attention from driving.

While driving, ALWAYS:

- Keep your eyes on the road.
- Use a handsfree device if available or required by law in your area.
- Enter destination information into a navigation device **before** driving.
- Use voice activated features (such as voice dial) and speaking features (such as audible directions) if available.
- Obey all local laws and regulations for the use of mobile devices and accessories in the vehicle.
- End your call or other task if you cannot concentrate on driving.

Seizures, Blackouts & Eyestrain

To reduce eyestrain and avoid headaches, it is always a good idea to hold the screen a comfortable distance from your eyes, use in a well-lit area, and take frequent breaks.

Some people may be susceptible to seizures or blackouts (even if they have never had one before) when exposed to flashing lights or light patterns, such as when playing video games, or watching videos with flashing-light effects.

Discontinue use and consult a physician if any of the following symptoms occur: seizures, blackout convulsion, eye or muscle twitching, loss of awareness, or disorientation.

If you or someone in your family has experienced seizures or blackouts, please consult with your physician before using an application that produces flashing-light effects on your mobile device.

Caution About High Volume Usage

Warning: Exposure to loud noise from any source for extended periods of time may affect your hearing. The louder the volume sound level, the less time is required before your hearing could be affected. To protect your hearing:

- Limit the amount of time you use headsets or headphones at high volume.
- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can't hear people speaking near you.

If you experience hearing discomfort, including the sensation of pressure or fullness in your ears, ringing in your ears, or muffled speech, you should stop listening to the device through your headset or headphones and have your hearing checked.



Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. If you continue to have discomfort during or after such use, stop use and see a physician.

Children

Keep your mobile device and its accessories away from small children. These products are not toys and may be hazardous to small children. For example:

- A choking hazard may exist for small, detachable parts.
- Improper use could result in loud sounds, possibly causing hearing injury.
- Improperly handled batteries could overheat and cause a burn.

Supervise access for older children. Similar to a computer, if an older child does use your mobile device, you may want to monitor their access to help prevent

- Exposure to inappropriate apps or content.
- Improper use of apps or content.
- Loss of data.

Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

Operational Warnings

Obey all posted signs when using mobile devices in public areas.








Potentially Explosive Areas


Potentially explosive areas are often, but not always, posted and can include blasting areas, fueling stations, fueling areas (such as below decks on boats), fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders.

When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries, unless it is a radio product type especially qualified for use in such areas and certified as "Intrinsically Safe" (for example, Factory Mutual, CSA, or UL approved). In such areas, sparks can occur and cause an explosion or fire.

Symbol Key

Your battery, charger, or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.
 	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not dispose of your battery or mobile device with your household waste. See "Recycling" for more information.
	Do not use tools.
	For indoor use only.

Symbol	Definition
	<p>Listening at full volume to music or voice through a headset may damage your hearing.</p>

Radio Frequency (RF) Energy

Exposure to RF Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

Your mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

RF Energy Operational Precautions

For optimal mobile device performance, and to be sure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions:

- When placing or receiving a phone call, hold your mobile device just like you would a landline phone.
- If you wear the mobile device on your body, ensure that the device is positioned at least 2.5 cm (1 inch) away from the body, and if you use an accessory case or holder, ensure it is free of any metal.

Two-Way Radio Operation

Your radio product has been designed and tested to comply with national and international standards and guidelines regarding human exposure to RF electromagnetic energy, when operated in the two-way mode (at the face, or at the abdomen when using an audio accessory) at usage factors of up to 50% talk/50% listen.

Transmit no more than the rated duty factor of 50% of the time. To transmit (talk), push the PTT button. To receive calls, release the PTT button. Transmitting 50% of the time or less, is important because this radio generates measurable RF energy only when transmitting (in terms of measuring for standards compliance).

When using your radio product as a traditional two-way radio, **hold the radio product in a vertical position with the microphone 2.5 to 5 cm (1 to 2 inches) away from the lips.**



RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances, your mobile device may cause interference with other devices.

Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do so, such as hospitals or health care facilities.

In an aircraft turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

Medical Devices

If you have a medical device, including an implantable medical device such as a pacemaker or defibrillator, consult your healthcare provider and the device manufacturer's directions before using this mobile device.

Persons with implantable medical devices should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimeters (8 inches) from the implantable medical device when the mobile device is turned ON.
- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the implantable medical device to minimize the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Specific Absorption Rate (FCC & IC)

YOUR MOBILE DEVICE MEETS FCC AND IC LIMITS FOR EXPOSURE TO RADIO WAVES.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) adopted by the Federal Communications Commission (FCC) and Industry Canada (IC). These limits include a

substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 1.6 W/kg.

Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values under the FCC and IC guidelines for your device model are listed below:

Head SAR	iDEN 900, Bluetooth	TBD
Body-worn SAR	iDEN 800, Bluetooth	TBD

During use, the actual SAR values for your device are usually well below the values stated. This is because, for purposes of system efficiency and to minimize interference on the network, the operating power of your mobile device is automatically decreased when full power is not needed for the call. The lower the power output of the device, the lower its SAR value.

If you are interested in further reducing your RF exposure then you can easily do so by limiting your usage or simply using a hands-free kit to keep the device away from the head and body.

FCC Notice to Users

The following statement applies to all products that bear the FCC logo and/or FCC ID on the product label.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. See 47 CFR Sec. 15.105(b). These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(a)(3).

Hi-P has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

For products that support Wi-Fi 802.11a (as defined in product information): In the United States, do not use your device outdoors while connected to an 802.11a Wi-Fi network. The FCC prohibits such outdoor use since frequencies 5.15-5.25 GHz can cause interference with Mobile Satellite Services (MSS). Public Wi-Fi access points in this range are optimized for indoor use.

Industry Canada Notice to Users

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device. See RSS-GEN 7.1.3. This Class B digital apparatus complies with Canadian ICES-003.

Software Notices

Warning against unlocking the bootloader or altering a product's operating system software: The Manufacturer strongly recommends against altering a product's operating system, which includes unlocking the bootloader, rooting a device or running any operating software other than the approved versions. Such alterations may permanently damage your product, cause your product to be unsafe and/or cause your product to malfunction. In such cases, neither the product nor any damage resulting therefrom will be covered by warranty.

Important FCC information: You must not make or enable any changes to the product that will impact its FCC grant of equipment authorization. The FCC grant is based on the product's emission, modulation, and transmission characteristics, including: power levels, operating frequencies and bandwidths, SAR levels, duty-cycle, transmission modes (e.g., CDMA, GSM), and intended method of using the product (e.g., how the product is held or used in proximity to the body). A change to any of these factors will invalidate the FCC grant. It is illegal to operate a transmitting product without a valid grant.

Location Services

Location sources can include GPS, AGPS and Wi-Fi.

Your mobile device can use Global Positioning System (GPS) signals for location-based applications. GPS uses satellites controlled by the U.S. government that are subject to changes implemented in accordance with the Department of Defense policy and the Federal Radio Navigation Plan. These changes may affect the performance of location technology on your mobile device.

Your mobile device can also use Assisted Global Positioning System (AGPS), which obtains information from the cellular network to improve GPS performance. AGPS uses your wireless service provider's network and therefore airtime, data charges, and/or additional charges may apply in accordance with your service plan. Contact your wireless service provider for details.

Your mobile device can also use Wi-Fi signals to determine your approximate location, using information from known and available Wi-Fi networks.

Your Location

Location-based information includes information that can be used to determine the approximate location of a mobile device. Mobile devices which are connected to a wireless network transmit location-based information. Devices enabled with location technology also transmit location-based information. Additionally, if you use applications that require location-based information (e.g. driving directions), such applications transmit location-based information. This location-based information may be shared with third parties, including your wireless service provider, applications providers, and other third parties providing services.

Emergency Calls

When you make an emergency call, the cellular network may activate the AGPS technology in your mobile device to tell the emergency responders your approximate location.

AGPS has limitations and **might not work in your area**. Therefore:

- Always tell the emergency responder your location to the best of your ability; and
- Remain on the phone for as long as the emergency responder instructs you.

Privacy & Data Security

Privacy and data security are important to everyone. Because some features of your mobile device may affect your privacy or data security, please follow these recommendations to enhance protection of your information:

- **Monitor access**-Keep your mobile device with you and do not leave it where others may have unmonitored access. Use your device's security and lock features, where available.
- **Keep software up to date**-If the Manufacturer or a software/application vendor releases a patch or software fix for your mobile device that updates the device's security, install it as soon as possible.
- **Secure Personal Information**-Your mobile device can store personal information in various locations including your SIM card, memory card, and phone memory. Be sure to remove or clear all personal information before you recycle, return, or give away your device. You can also backup your personal data to transfer to a new device.
- **Applications and updates**-Choose your apps and updates carefully, and install from trusted sources only. Some apps can impact your phone's performance and/or have access to private information including account details, call data, location details and network resources.
- **Wireless**-For mobile devices with Wi-Fi features, only connect to trusted Wi-Fi networks. Also, when using your device as a hotspot (where available) use network security. These precautions will help prevent unauthorized access to your device.
- **Location-based information**-Mobile devices enabled with location based technologies such as GPS, AGPS or Wi-Fi, can transmit location-based information. See "Location Services" for more details.
- **Other information your device may transmit**-Your device may also transmit testing and other diagnostic (including location-based) information, and other non-personal information to third-party servers. This information is used to help improve products and services offered.

Use & Care

To care for your Hi-P mobile device, please observe the following:



Liquids

Don't expose your mobile device to water, rain, extreme humidity, sweat, or other liquids.



Drying

Don't try to dry your mobile device using a microwave oven, conventional oven, or dryer, as this may damage the mobile device.



Extreme heat or cold

Don't store or use your mobile device in temperatures below -10°C (14°F) or above 60°C (140°F). Don't recharge your mobile device in temperatures below 0°C (32°F) or above 45°C (113°F).



Dust and dirt

Don't expose your mobile device to dust, dirt, sand, food, or other inappropriate materials.



Cleaning

To clean your mobile device, use only a dry soft cloth. Don't use alcohol or other cleaning solutions.



Shock and vibration

Don't drop your mobile device.



Protection

To help protect your mobile device, always make sure that any battery, connector and compartment covers are closed and secure.

Recycling

Mobile Devices & Accessories

Please do not dispose of mobile devices or electrical accessories (such as Chargers, headsets, or batteries) with your household waste, or in a fire. These items should be disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any Hi-P Approved Service Center in your region.



Packaging & Product Guides

Product packaging and product guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

California Perchlorate Label

Some mobile phones use an internal, permanent backup battery on the printed circuit board that may contain very small amounts of perchlorate. In such cases, California law requires the following label:

Perchlorate Material- special handling may apply when the battery is recycled or disposed of. See www.dtsc.ca.gov/hazardouswaste/perchlorate (in English only).

There is no special handling required by consumers.

Hearing Aid Compatibility with Mobile Phones

Some phones are measured for compatibility with hearing aids. If the box for your particular model has "Rated for Hearing Aids" printed on it the following explanation applies.

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants) users may detect a buzzing, humming, or whining noise. Some hearing devices are

more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box. To maintain the published Hearing Aid Compatibility (HAC) rating for this mobile phone, use only the original equipment battery model.

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Contact your service provider or Hi-P for information on hearing aid compatibility. If you have questions about return or exchange policies, contact your service provider or phone retailer.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

Software Copyright

Products may include copyrighted Hi-P and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Hi-P and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed

by law. Furthermore, the purchase of the products shall not be deemed to grant either directly or by implication, estoppel or otherwise, any license under the copyrights, patents, or patent applications of Hi-P or any third-party software provider, except for the normal non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Content Copyright

The unauthorized copying of copyrighted materials is contrary to the provisions of the Copyright Laws of the United States and other countries. This device is intended solely for copying non-copyrighted materials, materials in which you own the copyright or materials which you are authorized or legally permitted to copy. If you are uncertain about your right to copy any material please contact your legal advisor.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

How to Obtain Service or Other Information

1. Please access and review the online Customer Support section of the service provider's consumer website prior to requesting warranty service.
2. If the Product is still not functioning properly after making use of this resource, please contact the Warrantor listed at the service provider's website or the contact information for the corresponding location.
3. To obtain warranty service, as permitted by applicable law, you are required to include: (a) a copy of your receipt bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) your address and telephone number. In the event the Product is not covered by the Limited Warranty, the Warrantor will inform the consumer of the availability, price and other conditions applicable to the repair of the Product.

Limited Global Warranty Mobile Phones

Statement of Limited Warranty

(The Seller) warrants that for a period of — years from the date of purchase that this product 1) is free from defects in materials and workmanship and 2) conforms to its specifications. If this product does not function as warranted during the warranty period, (The Seller), at its option, will either replace this product with one that is functionally equivalent or will refund your purchase price. These are your exclusive remedies under this warranty. Please call 1-800 (The Seller's toll-free number) for warranty service.

This warranty will be voided by misuse, improper physical environment, accident, or improper maintenance by you. THIS WARRANTY REPLACES ALL OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THESE WARRANTIES GIVE YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF EXPRESS OR IMPLIED WARRANTIES, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU. IN THAT EVENT, SUCH WARRANTIES ARE LIMITED IN DURATION TO THE WARRANTY PERIOD. NO WARRANTIES APPLY AFTER THAT PERIOD.

Circumstances may arise where, because of a default on (The Seller's) part or other liability, you are entitled to recover damages from (The Seller). In each such instance, regardless of the basis on which you are entitled to claim damages from (The Seller) (including fundamental breach, negligence, misrepresentation, or other contract or tort claim), (The Seller) is only liable for:

1. damages for bodily injury (including death) and damage to real property and tangible personal property; and
2. the amount of any other actual direct damages or loss, up to the greater of \$500 or the price paid for this product.

UNDER NO CIRCUMSTANCES IS (The Seller) LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR LOSSES OR DAMAGES (OTHER THAN THOSE UNDER THE FIRST ITEM LISTED ABOVE); (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA: OR (3) SPECIAL, INCIDENTAL OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF (The Seller) IS INFORMED OF THEIR POSSIBILITY. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU.

