

USER GUIDE

HUAWEI U5120




Copyright © Huawei Technologies Co., Ltd. 2012. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

The product described in this manual may include copyrighted software of Huawei Technologies Co., Ltd. and possible licensors. Customers shall not in any manner reproduce, distribute, modify, decompile, disassemble, decrypt, extract, reverse engineer, lease, assign, or sublicense the said software, unless such restrictions are prohibited by applicable laws or such actions are approved by respective copyright holders under licenses.

Trademarks and Permissions



, HUAWEI, and  are trademarks or registered

trademarks of Huawei Technologies Co., Ltd.

Other trademarks, product, service and company names mentioned are the property of their respective owners.

Notice

Some features of the product and its accessories described herein rely on the software installed, capacities and settings of local network, and may not be activated or may be limited by local network operators or network service providers, thus the descriptions herein may not exactly match the product or its accessories you purchase.

Huawei Technologies Co., Ltd. reserves the right to change or modify any information or specifications contained in this manual without prior notice or obligation.

NO WARRANTY

THE CONTENTS OF THIS MANUAL ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAWS, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS MANUAL. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO CASE SHALL HUAWEI TECHNOLOGIES CO., LTD. BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, OR LOST PROFITS, BUSINESS, REVENUE, DATA, GOODWILL OR ANTICIPATED SAVINGS.

Import and Export Regulations

Customers shall comply with all applicable export or import laws and regulations and will obtain all necessary governmental permits and licenses in order to export, re-export or import the product mentioned in this manual including the software and technical data therein.

Safety Precaution

Before using the phone, read safety precautions and inform your children about using the phone correctly and safely. For details, see "[Warnings and Precautions](#)".



Do not crash, throw, or puncture your mobile phone. Avoid the falling, squeezing, and bending of your mobile phone.



Do not use your mobile phone in a moist environment, such as the bathroom. Prevent your mobile phone from being soaked or washed in liquid.



Do not switch on your mobile phone when it is prohibited to use phones or when the phone may cause interference or danger.



Do not use your mobile phone while driving.



Follow any rules or regulations in hospitals and health care facilities. Switch off your mobile phone near medical apparatus.



Switch off your mobile phone in aircraft. The phone may cause interference to control equipment of the aircraft.



Switch off your mobile phone near high-precision electronic devices. The phone may affect the performance of these devices.



Do not attempt to disassemble your mobile phone or its accessories. Only qualified personnel are allowed to service or repair the phone.



Do not place your mobile phone or its accessories in containers with a strong electromagnetic field.



Do not place magnetic storage media near your mobile phone. Radiation from the phone may erase the information stored on them.



Do not put your mobile phone in a high-temperature place or use it in a place with flammable gas such as a gas station.



Keep your mobile phone and its accessories away from children. Do not allow children to use your mobile phone without guidance.



Use only approved batteries and chargers to avoid the risk of explosions.



Observe any laws or regulations on the use of wireless devices. Respect others' privacy and legal rights when using your wireless device.



Strictly follow the relevant instructions of this manual while using the USB cable. Otherwise your mobile phone or PC may be damaged.


1 Getting to Know Your Phone

Note

All the pictures in this guide are provided for your reference only.


SIM/USIM Card and Battery

Before using the phone, install a SIM/USIM card on the phone. Power off the phone before removing the SIM/USIM card or the battery.




microSD Card

The phone supports a microSD card of up to 8 GB.




Charging the Battery


Before using the battery, read the "Battery and Charger" section of "Warnings and Precautions".



Note







- When the icon  is displayed or the charging animation becomes static, the battery is fully charged.
- If the battery has not been used for a long time or if the battery runs out of power, the charging icon may appear several minutes later after you start charging the battery.








Your Phone

















1	Earpiece	2	Screen
3	Navigation keys	4	Left soft key
5	Speaker key	6	Call/Answer key
7	Number keys	8	* key
9	# key	10	End/Power key
11	Clear key	12	Right soft key
13	Charger jack	14	Confirm key
15	Camera	16	Speaker
17	Headset jack	18	microSD card slot


















Keys and Functions

In this guide, the navigation keys of your phone are indicated by , , , ; the left soft key is indicated by , and the right soft key is indicated by .

Press...	To...
	<ul style="list-style-type: none"> Dial a number or answer a call. View call logs in standby mode.
	<ul style="list-style-type: none"> Power the phone on or off (press and hold the key for about 3 seconds). End or reject a call. Return to standby mode.
	Select the option displayed in the lower left corner of the screen.
	Select the option displayed in the lower right corner of the screen.
	Turn on or off the loudspeaker during a call.
	<ul style="list-style-type: none"> In text input mode, delete the character to the left of the cursor. Press and hold the key for about 3 seconds to clear all the characters to the left of the cursor. Return to the previous menu.
	Confirm a selection or display a menu.

Press...	To...
	<ul style="list-style-type: none"> If Standby screen is set to Business mode, press  or  to change the application, select a application, and then press  to access the function. To set the standby screen mode, select Menu > Settings > Display > Standby screen. If the standby screen is set to Shortcut, press  or  to select a shortcut, and then press  to access the function. If the standby screen is set to Concise mode, access the functions assigned to the navigation keys in standby mode. Adjust the volume during a call.
 - 	<ul style="list-style-type: none"> Enter numbers, letters, and symbols. Call voicemail in standby mode (press and hold  for about 3 seconds). Speed-dial phone numbers in standby mode (press and hold the keys  -  for about 3 seconds). To set speed dial, select Menu > Contacts > Options > Settings > Manage contacts > Speed dialing.
	<ul style="list-style-type: none"> Enter *, +, P or W when entering phone numbers. Enable or disable the Meeting profile in standby mode (press and hold the key for about 3 seconds). To set the profile, select Menu > Settings > Phone > Profile.
	<ul style="list-style-type: none"> Enter #. Lock the keypad in standby mode (press and hold the key for about 3 seconds).

Status Icons

Icon	Indicates...
	Signal strength.
	Roaming.
	2G network available.
	The phone is receiving and sending data through 2G network.
	3G network available.
	The phone is receiving and sending data through 3G network.
	Call in progress.
	Missed calls.
	New text messages.
	New multimedia messages.
	The memory for saving the text messages is full.
	The memory for saving the multimedia messages is full.
	New emergency messages.
	New voicemail available.
	Charging.
	Battery level.
	General profile activated.

Icon	Indicates...
	Silent profile activated.
	Meeting profile activated.
	Outdoor profile activated.
	My profile 1 activated.
	My profile 2 activated.
	Alarms enabled.
	Music is being played in the background.
	Bluetooth turned on.
	Bluetooth headset connected.
	Headset connected.
	microSD card installed.

2 Getting Started

Powering On and Off

To power on your phone, press and hold for about 3 seconds. If required, enter the phone password, personal identification number (PIN), or PIN unblocking key (PUK) as prompted.

If **Auto power-on and power-off** is enabled, your phone will automatically power on or off at the preset-time. To set the automatic power-on and power-off time, select **Menu > Settings > Phone > Auto power-on and power-off > Power-on time** or **Power-off time**.

Keypad Lock

To lock the keypad, press and hold for about 3 seconds in standby mode. When the keypad is locked, you can still press to answer a call or make an emergency call.

To unlock the keypad, press (**Unlock**), then (**OK**).

If the **Auto keypad lock** function is enabled, the phone will lock the keypad automatically after being idle in standby mode for a pre-defined period. To set this function, select **Menu > Settings > Phone > Auto keypad lock**.

Phone Lock

The phone lock protects your phone from unauthorized use.

By default, the phone lock is disabled. To enable or disable the phone lock, select **Menu > Settings > Security > Phone lock**.

Once the phone lock is enabled, you must enter a passcode each time you power on the phone.

The preset passcode is **1234**. You can select **Menu > Settings > Security > Change phone lock code** to change the passcode to any numeric string of four to eight digits.

Do remember your passcode. If you forget it, contact the service center.

PIN and PUK

The personal identification number (PIN) protects your SIM/USIM card from unauthorized use. If you incorrectly enter the PIN a specified number of times, the PIN is blocked and the phone prompts you to enter the PIN unblocking key (PUK). If this occurs, enter the PUK to unblock the blocked PIN.

If you incorrectly enter the PUK a specified number of times, the SIM/USIM card will become permanently invalid, and you must contact your service provider for a new SIM/USIM card.





Both the PIN and the PUK are provided with your SIM/USIM card. For details, contact your service provider.

Power Saving Mode

To set the power saving mode, select **Menu > Settings > Phone > Power-saving mode**. If the power-saving mode is enabled, the keypad backlight will be off from 9:00 to 17:00.

3 Call Functions



Making a Call




1. In standby mode, enter the phone number.
 - To make an international call, press  twice to enter the plus sign (+). Then enter the country or region code, area code, and phone number.
 - To call an extension number, enter the phone number, press  three times to enter **P** or four times to enter **W**, and enter the extension number.
2. Press  to dial the number.
3. Press  to end the call or cancel the dialing.

Note

- If you enter **P** between the phone number and the extension number, after the phone number is connected, the phone automatically dials the extension number.
- If you enter **W** between the phone number and the extension number, after the phone number is connected, the phone prompts you to choose whether to dial the extension number.
- You can also make a call from call logs and contacts.


Answering a Call

When there is an incoming call, press  to answer it or  to reject it.



If the **Any key** answer function is enabled, you can press any key except , , or  to answer the call. To enable the any key answer function, select **Menu > Settings > Call > Answer mode > Any key**.

If the **Headset auto-answer** function is enabled and a headset is connected to the phone, the phone will automatically answer incoming calls for a pre-defined period. To enable the headset auto-answer function, select **Menu > Settings > Call > Headset auto-answer**.

4 Text Input

Your phone provides multiple text input modes. In editing mode, the current text input mode is indicated on the screen. To switch between text input modes, press .

Note



- Press  once to delete the character to the left of the cursor, or press and hold  to delete all the characters to the left of the cursor.
- On the message editing screen, select **Options > Text input settings** to configure text input settings, such as the default input language, and whether to enable first letter capitalized and predictive input.



Entering a Word

Multi-tap Input Mode

In multi-tap input mode, press the number key labeled with the desired letter once to enter the first letter on the key, twice to enter the second letter on the key, and so on.

Predictive Input Mode

1. Press each key once according to the spelling sequence of the desired word. The phone displays candidate words that may be spelt by the keystroke sequence.
2. Press  and  to scroll to the desired word.

3. Press  to enter the word, or press  to enter the word followed by a space.








Entering a Number

To enter a number:

- In "123" input mode, press the desired number key.
- In any input mode except "123", press and hold the number key for about 3 seconds to enter the desired digit.

Entering a Symbol

To enter a symbol:



- In any input mode, press  to display the symbol list. Press navigation keys to scroll to the desired symbol. Then press  to enter the symbol.
- In any input mode except "123", press  once to enter a space, twice to enter a line break, or three times to enter **0**.
- In multi-tap input mode, repeatedly press  to switch between the commonly used symbols.
- In predictive input mode, press  to display the commonly used symbol list, and then press  and  to scroll to the desired symbol.

5 Messaging

Note

- Contact your service provider to determine the availability of the Multimedia Messaging Service (MMS) and how to subscribe to the service.
- Open multimedia messages with caution. Objects in multimedia messages may contain viruses and malicious software that can damage your phone.

Creating and Sending a Message

1. Select **Menu > Messages > Create message**.
2. Add recipients by entering the phone numbers, or pressing  and then selecting the recipients from contacts.
3. Edit the message. You can press , and then add pictures, audio clips, video clips and other attachments.
4. Select **Options > Send** to send the message.

Voicemail

Voicemail is a network-dependent service. To subscribe to voicemail, contact your network operator.

Before using voicemail, select **Menu > Messages > Voicemail** to set the voicemail number.

6 Email

Note



- Contact your service provider to determine the availability of the email service and how to subscribe to the service.
- Open emails with caution. Objects in emails may contain viruses and malicious software that can damage your phone.

Creating an Email Account

For the details about the settings of the email account, contact your email service provider.

If your email account has been configured, enter your user name and password to access the email. You can activate mobile access to your account from email server websites using your PC.

1. Select **Menu > Tools > Email > Settings > Account management > Create account** to create an account.
If there is no email account, select **Menu > Tools > Email**. The phone will prompt you to create an account.
2. Select an email server.


3. Configure the relevant settings. After setting an item, press  (**Next**) to proceed to the next item.
4. Press  (**Done**) to save the email account.

Activating an Email Account

1. Select **Menu > Tools > Email > Settings > Account management**.
2. Select your email account.
3. Select **Options > Set as default** to activate the email account. Press to change the email account settings.


Creating and Sending an Email

Before sending or receiving emails, you must create and activate an email account.

1. Select **Menu > Tools > Email**.
2. Select your email account.
3. Press  (**Create**) to create an email.
4. Add recipients. You can enter the email addresses of the recipients, or press and then select the recipients from contacts. You can also select **Options > Add cc/bcc** to add the corresponding recipients.
5. Add the email subject.
6. Add the content of the email. You can type a message, and optionally select **Options > Add attachment** to add pictures, audio clips, video clips and other attachments.
7. Select **Options > Send** to send the email.

7 Contacts

Adding a Contact

1. Select **Menu > Contacts > Create contact**.
2. Edit the contact information.
3. Press  (**Save**) to save the contact.


Searching for a Contact

Select **Menu > Contacts**, and then enter the contact name or or the first several letters of the contact name.

8 Multimedia

Taking a Photo

Select **Menu > Camera**, and press to take a photo.



On the **Camera** screen, press  (**Options**) to configure relevant settings.


To view the photos, select **Options > Go to album**.

To set the default storage, select **Options > Settings > Storage location**.

Recording a Video



Select **Menu > Camera > Options > Shooting mode > Video camera**, and press to record a video clip.

During recording the video clip, press  or to pause or continue, press  to stop recording and save the video clip.


On the **Video camera** screen, press  (**Option**) to configure relevant settings.

Music Player










Creating a Playlist

1. Select **Menu > Multimedia > Music player > Options > Media library > Playlist**.
2. Select **Options > Create** to create a playlist. If there is no playlist, press  (**Create**) to create a playlist.
3. Edit the playlist name.
4. Select the playlist, press to open it.
5. Press  (**Add**) to add audio files to the playlist.

Playing Music



Select a music file, and then press  to play it.

While the music is playing:










- Press  to pause or continue.
- Press  to switch to the next music, or press and hold  to fast-forward through the music currently playing .
- Press  to switch to the previous music, or press and hold  to rewind through the music currently playing.
- Press  and  to adjust the volume.
- Press  (**Minimize**) or  to exit the music player screen and play the music in the background.
- Select **Options** > **Exit** to exit the music player.

Video Player

Select **Menu** > **Multimedia** > **Video player** to start the video player.

Press  (**Options**) and select **All videos** or **Playlist** to select a video file, and press  to play it.


While the video is playing:




- Press  to pause or continue.
- Press  to switch to the next video, or press and hold  to fast-forward through the video currently playing .
- Press  to switch to the previous video, or press and hold  to rewind through the video currently playing.
- Press  and  to adjust the volume.
- Select **Options** > **Full screen** to switch to the full screen mode, and press  to exit the full screen mode.
- Press , to exit the video player.


Recorder



While recording a sound clip, keep the microphone of the phone near the sound source for a better recording effect.

Select **Menu** > **Multimedia** > **Recorder**, and press  to record a sound clip.

During recording the sound clip, press  to pause or continue, press  to stop recording and save the sound clip, press  to cancel the recording.

After stop the recording, press  to play the sound clip.


FM Radio




Before listening to the radio, connect a compatible headset to your phone. The headset cable also functions as the radio's antenna when the radio is switched on. To ensure good radio reception, do not disconnect the headset from the phone or severely bend the headset cable.

Switching On the Radio








Select **Menu** > **FM radio**. The radio will turn on tuned to the last channel listened to.

When you listen to the radio for the first time, press  (**Options**) for the following options:

- **Automatic tuning:** automatically search for available channels and save them to the channel list.
- **Manual tuning:** manually search for available channels and save them to the channel list.
- **Precise tuning:** manually adjust the frequency in increments of 0.1 MHz.
- **Set frequency:** enter a frequency and press  to play the program.

Listening to the Radio

While listening to the radio:

- Press  to enable or disable the loudspeaker.
- Press  and  to change channels.
- Press  and  to adjust the volume.
- Press  (**Minimize**) or  to exit the radio screen and play the radio program in the background.
- Select **Options > Record** to record the program.
- Select **Options > Exit** to switch off the FM radio.

9 Browser

Setting the Connection Profile

Before accessing the Internet using your phone, set up your account first. Generally, the account has been preset on your phone. If you want to use another account, contact your service provider for the account information, and then create the account.


Accessing a Webpage

To access a webpage, open the browser and then do as follows.

- Select **Open homepage** to display the home page.
- Select **Open new page**, and enter a website address.
- Select **Bookmarks**, and select one from the list.
- Select **Saved pages** to view the webpages you have saved.
- Select **History**, and select one from the list.

10 USB

Connect your phone to a PC with the USB cable, double click **My Computer**, find the disk named **Orinoquia** and double click it. The following dialog box will appear on your PC.



Select your desired function in the dialog box:

- **Start Mobile Modem:** use the phone as a USB modem.
- **Start PC Suite:** use the phone through PC Suite on the PC.
- **File Transfer:** use the phone as a USB mass storage device.

Note

- If the PC cannot recognize your phone, restart the PC, and then retry.
- If the dialog box does not appear, open **My Computer** and find the driver for the phone (appears as a CD driver).
- For Windows 7, you need select **My Computer > Orinoquia**, and then double click the file Setup.exe to display the dialog.

Installing PC Suite

PC Suite helps you perform most of the phone operations on a PC. It is supplied with your phone. The PC Suite installation program runs automatically when you use the PC Suite function for the first time. Follow the wizard to complete installation, and restart your PC for the installation to take effect.

Note

- To download the latest PC Suite software, go to <http://www.huaweidevice.com>, and then search for the desired software.
- For the way of using PC Suite, refer to the help of the PC Suite.

USB-based Internet Access

Your phone can be used as a modem after connecting your phone to a PC with the USB cable. The PC can access the Internet through the phone.

The USB modem driver and management program runs automatically when you use the USB modem function for the first time. Follow the wizard to complete installation.

After installation, start the management program, set up a connection, and then access the Internet.



Note

- Only the Windows 2000, Windows XP, 32-bit and 64-bit versions of Windows Vista, and Windows 7 operating systems support the function.
- For details, contact your service provider.

USB disk

Your phone can be used as a USB mass storage device. You can save files to the microSD card.

When you are using the USB disk function, other USB functions are unavailable.



11 Bluetooth

Your phone supports Bluetooth. You can synchronize files between your phone and a PC, transfer data between your phone and other Bluetooth devices, and talk on the phone using a Bluetooth headset.

Select **Menu > Settings > Connectivity > Bluetooth**, and then switch on or off the Bluetooth.

Using a Bluetooth Headset

A Bluetooth headset is not included in the product package and must be purchased separately.

1. Select **Search for devices** to search for the Bluetooth devices.
2. Select your Bluetooth headset from the list.
3. Press  (**Select**).
4. Enter the password of the Bluetooth headset to pair the headset with your phone. When the Bluetooth headset is connected to your phone, the headset icon  is displayed on the standby screen, indicating that you can use the headset.


Transferring Data

Select **Search for devices** to search for available Bluetooth devices, and then connect your phone with the desired device. Then you can transfer data between your phone and the Bluetooth device.

When you pair your phone with the device for the first time, a password is required.

12 Troubleshooting

If you encounter any problem when using your phone, try to solve the problem according to the following table. If the problem still occurs, contact your service provider or vendor.

Problem	Ensure that...
The battery cannot be charged.	The charger is properly connected to your phone and the power socket.
The phone cannot be powered on.	<ul style="list-style-type: none">• The battery power is enough.• The battery is properly installed.• Press and hold .
Cannot make a call except an emergency call.	<ul style="list-style-type: none">• You are in the network service area.• The call restriction function is not enabled.

Problem	Ensure that...
Bad call quality.	<ul style="list-style-type: none"> • The signal strength is strong enough. • If you are indoors, move near a window for better reception.
The signal strength is not strong enough or your phone is often offline.	Move near to a place with strong signal strength.
The phone cannot find other Bluetooth devices or fails to send or receive data via Bluetooth.	<ul style="list-style-type: none"> • The Bluetooth function of both devices is turned on. • The distance between the two Bluetooth devices is less than 10 meters. • There are no obstacles between the two devices. • The other Bluetooth device is set to visible.

13 Warnings and Precautions

This section contains important information pertaining to the operating instructions of your device. It also contains information about how to use the device safely. Read this information carefully before using your device.

Electronic Device

Power off your device if using the device is prohibited. Do not use the device when using the device causes danger or interference with electronic devices.

Medical Device

- Follow rules and regulations set forth by hospitals and health care facilities. Do not use your device when using the device is prohibited.
- Pacemaker manufacturers recommend that a minimum distance of 15 cm be maintained between a device and a pacemaker to prevent potential interference with the pacemaker. If you are using a pacemaker, use the device on the opposite side of the pacemaker and do not carry the device in your front pocket.

Potentially Explosive Atmosphere

Power off your device in any area with a potentially explosive atmosphere, and comply with all signs and instructions. Areas that may have potentially explosive atmospheres include the areas where you would normally be advised to turn off your vehicle engine. Triggering of sparks in such areas could cause an explosion or a fire, resulting in bodily injuries or even deaths. Do not power on your device at refueling points such as service stations. Comply with restrictions on the use of radio equipment in fuel depots, storage, and distribution areas, and chemical plants. In addition, adhere to restrictions in areas where blasting operations are in progress. Before using the device, watch out for areas that have potentially explosive atmospheres that are often, but not always, clearly marked. Such locations include areas below the deck on boats, chemical transfer or storage facilities, and areas where the air contains chemicals or particles such as grain, dust, or metal powders. Ask the manufacturers of vehicles using liquefied petroleum gas (such as propane or butane) whether this device can be safely used in their vicinity.

Traffic Security

Observe local laws and regulations while using the device. In addition, if using the device while driving a vehicle, comply with the

following guidelines:

- Concentrate on driving. Your first responsibility is to drive safely.
- Do not talk on the device while driving. Use hands-free accessories.
- When you have to make or answer a call, park the vehicle at the roadside before using your device.
- RF signals may affect electronic systems of motor vehicles. For more information, consult the vehicle manufacturer.
- In a motor vehicle, do not place the device over the air bag or in the air bag deployment area. Otherwise, the device may hurt you due to the strong force when the air bag inflates.
- Do not use your device while flying in an aircraft. Power off your device before boarding an aircraft. Using wireless devices in an aircraft may cause danger to the operation of the aircraft and disrupt the wireless telephone network. It may also be considered illegal.

Operating Environment

- Do not use or charge the device in dusty, damp, and dirty places or places with magnetic fields. Otherwise, it may result in a malfunction of the circuit.
- The device complies with the RF specifications when the device is used near your ear or at a distance of 1.5 cm from your body. Ensure that the device accessories such as a device case and a device holster are not composed of metal components. Keep your device 1.5 cm away from your body to meet the requirement earlier mentioned.
- On a stormy day with thunder, do not use your device when it is being charged, to prevent any danger caused by lightning.
- While using the device, observe the local laws and regulations, and respect others' privacy and legal rights.
- Keep the ambient temperature between 0°C and 40°C while the device is being charged. Keep the ambient temperature between 0°C to 40°C for using the device powered by a battery.

Prevention of Hearing Damage

Using a headset at high volume can damage your hearing. To reduce the risk of damage to hearing, lower the headset volume to a safe and comfortable level.

Safety of Children

Comply with all precautions with regard to children's safety. Letting the child play with your device or its accessories, which may include parts that can be detached from the device, may be dangerous, as it may present a choking hazard. Ensure that small children are kept away from the device and accessories.

Accessories

Choose only batteries, chargers, and accessories approved for use with this model by the device manufacturer. The use of any other type of battery, charger, or accessory may invalidate any warranty for the device, may be in violation of local rules or laws, and may be dangerous. Please contact your dealer for information about the availability of approved batteries, chargers, and accessories in your area.

Battery and Charger

- Unplug the charger from the electrical plug and the device when not in use.
- The battery can be charged and discharged hundreds of times before it eventually wears out. When the standby time and the talk time are shorter than the normal time, replace the battery.

- Use the AC power supply defined in the specifications of the charger. An improper power voltage may cause a fire or a malfunction of the charger.
- Do not connect two poles of the battery with conductors, such as metal materials, keys, or jewelry. Otherwise, the battery may be short-circuited and may cause injuries and burns on your body.
- Do not disassemble the battery or solder the battery poles. Otherwise, it may lead to electrolyte leakage, overheating, fire, or explosion.
- If battery electrolyte leaks out, ensure that the electrolyte does not touch your skin and eyes. If the electrolyte touches your skin or splashes into your eyes, wash your eyes with clean water immediately and consult a doctor.
- If there is a case of battery deformation, color change, or abnormal heating while you charge or store the battery, remove the battery immediately and stop using it. Otherwise, it may lead to battery leakage, overheating, explosion, or fire.
- If the power cable is damaged (for example, the cord is exposed or broken), or the plug loosens, stop using the cable at once. Otherwise, it may lead to an electric shock, a short circuit of the charger, or a fire.
- Do not dispose of batteries in fire as they may explode. Batteries may also explode if damaged.

Cleaning and Maintenance

- The device, battery, and charger are not water-resistant. Keep them dry. Protect the device, battery, and charger from water or vapor. Do not touch the device or the charger with a wet hand. Otherwise, it may lead to a short circuit, a malfunction of the device, and an electric shock to the user.
- Do not place your device, battery, and charger in places where they can get damaged because of collision. Otherwise, it may lead to battery leakage, device malfunction, overheating, fire, or explosion.
- Do not place magnetic storage media such as magnetic cards and floppy disks near the device. Radiation from the device may erase the information stored on them.
- Do not leave your device, battery, and charger in a place with an extreme high or low temperature. Otherwise, they may not function properly and may lead to a fire or an explosion. When the temperature is lower than 0°C, performance of the battery is affected.
- Do not place sharp metal objects such as pins near the earpiece. The earpiece may attract these objects and hurt you when you are using the device.
- Before you clean or maintain the device, power off the device and disconnect it from the charger.
- Do not use any chemical detergent, powder, or other chemical agents (such as alcohol and benzene) to clean the device and the charger. Otherwise, parts of the device may be damaged or a fire can be caused. You can clean the device and the charger with a piece of damp and soft antistatic cloth.
- Do not dismantle the device or accessories. Otherwise, the warranty on the device and accessories is invalid and the manufacturer is not liable to pay for the damage.

Emergency Call

You can use your device for emergency calls in the service area. The connection, however, cannot be guaranteed in all conditions. You should not rely solely on the device for essential communications.

Certification Information (SAR)

This mobile device meets guidelines for exposure to radio waves. Your device is a low-power radio transmitter and receiver. As recommended by international guidelines, the device is designed not to exceed the limits for exposure to radio waves. These guidelines were developed by the independent scientific organization International Commission on Non-Ionizing Radiation Protection (ICNIRP) and include safety measures designed to ensure safety for all users, regardless of age and health.

The Specific Absorption Rate (SAR) is the unit of measurement for the amount of radio frequency energy absorbed by the body when using a device. The SAR value is determined at the highest certified power level in laboratory conditions, but the actual SAR level of the device when being operated can be well below the value. This is because the device is designed to use the minimum power required to reach the network.

The SAR limit adopted by USA and Canada is 1.6 watts/kilogram (W/kg) averaged over one gram of tissue. The highest SAR value reported to the FCC and IC for this device type when tested for use at the ear is 1.050 W/kg, and when properly worn on the body is 0.973 W/kg.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution

Changes or modifications made to this device not expressly approved by Huawei Technologies Co., Ltd. may void the FCC authorization to operate this device.

Please visit www.huaweidevice.com/worldwide/support/hotline for recently updated hotline and email address in your country or region.