

VHF DIGITAL TRANSCEIVERS IC-F5400D series IC-F5400DP series

UHF DIGITAL TRANSCEIVERS IC-F6400D series IC-F6400DP series

Thank you for choosing this Icom product.
READ ALL INSTRUCTIONS carefully and completely before using this product.

SAVE THESE INSTRUCTIONS — These instructions contain important operating instructions for the following models:
• VHF DIGITAL TRANSCEIVERS
IC-F5400D, IC-F5400DS, IC-F5400DP, IC-F5400DPS
• UHF DIGITAL TRANSCEIVERS
IC-F6400D, IC-F6400DS, IC-F6400DP, IC-F6400DPS

IMPORTANT

This instruction sheet includes some functions that are usable only when they are preset by your dealer. The transceiver may have other functions and operations that are not described in this instruction sheet. Ask your dealer for preset function details.

Icom is not responsible for the destruction or damage to the Icom transceiver, if the malfunction is because of: Force majeure, including, but not limited to, fires, earthquakes, storms, floods, lightning, other natural disasters, disturbances, riots, war, or radioactive contamination.
The use of Icom transceivers with any equipment that is not manufactured or approved by Icom.

Icom, Icom Inc. and the Icom logo are registered trademarks of Icom Incorporated (Japan) in Japan, the United States, the United Kingdom, Germany, France, Spain, Russia, Australia, New Zealand, and/or other countries.
AMBE+2 is a trademark and property of Digital Voice Systems Inc.
All other products or brands are registered trademarks or trademarks of their respective holders.

Icom Inc.

1-1-32 Kamiminami, Hirano-ku, A7312D-1EX-6
Osaka 547-0003, Japan Printed in Japan
Nov. 2021 © 2012–2021 Icom Inc.

EXPLICIT DEFINITIONS

| WORD | DEFINITION |
|-----------------|---|
| WARNING! | Personal injury, fire hazard or electric shock may occur. |
| CAUTION | Equipment damage may occur. |
| NOTE | If disregarded, inconvenience only. No risk of personal injury, fire or electric shock. |


ANTENNA

A key element in the performance of any communication systems is the antenna. Contact your dealer for information regarding antennas and how to install them.

FUSE REPLACEMENT

Fuses are installed in the supplied DC power cable*. If a fuse blows, track down the source of the problem, repair it, and then replace the damaged fuse with a new rated one.
*Depending on version, only 1 fuse holder may be attached.
① Fuse rating: 250 V 10 A (for 1 fuse holder)/
20 A (for 2 fuse holders)

NOTE: Use only specified fuses.



Fuse Coding Explanation

Fuse Coding: FUSE 250 V 10 A
Fuse Voltage Rating: 250 Volts
Fuse Current Rating: 10 Amperes

CLEANING

If the transceiver becomes dusty or dirty, wipe it clean with a soft, dry cloth.

PRECAUTIONS

WARNING! NEVER connect the transceiver to an AC outlet. This may pose a fire hazard or result in an electric shock.

WARNING! NEVER operate the transceiver during a lightning storm. It may result in an electric shock, cause a fire or damage the transceiver. Always disconnect the power source and antenna before a storm.

WARNING! NEVER connect the transceiver to a power source of more than 16 V DC such as a 24 V battery. This could damage the transceiver.

WARNING! NEVER cut the DC power cable between the DC plug and fuse holder. If an incorrect connection is made after cutting, the transceiver might be damaged.

WARNING! NEVER place the transceiver where normal operation of the vehicle may be hindered or where it could cause bodily injury.

CAUTION: DO NOT expose the transceiver to rain, snow or any liquids.

CAUTION: DO NOT use the non-specified microphone only. Other microphones have different pin assignments and may damage the radio.

CAUTION: DO NOT place or leave the transceiver in areas with temperatures below -30°C (-22°F) or above +60°C (+140°F), or in areas subject to direct sunlight, such as the dashboard.

CAUTION: DO NOT operate the transceiver without running the vehicle's engine. The vehicle's battery will quickly run out when the transceiver transmits while the vehicle's engine is OFF.

CAUTION: DO NOT place or leave the transceiver in excessively dusty environments.

CAUTION: DO NOT place the transceiver against walls. Otherwise heat dissipation will be obstructed.

CAUTION: DO NOT use harsh solvents such as Benzine or alcohol when cleaning, as they damage the transceiver's surfaces.

CAUTION: CONFIRM that all connectors and jacks are dry and clean before attachment. Exposing them to dust or water will result in serious damage to the transceiver.

NEVER place the transceiver in an insecure place to avoid inadvertent use by unauthorized persons.

BE CAREFUL! The transceiver will become hot when operating continuously for long periods of time.

BE CAREFUL! DO NOT block the air vent when installing the transceiver. This transceiver has an air vent on the bottom panel of the transceiver to meet the IP55 requirements.



CAUTION: Hot surfaces. **DO NOT** touch the transceiver's surface after continuously transmitting for long periods of time. The transceiver's chassis radiates heat, and it will become hot to protect the power amplifier unit from overheating. Touching it may cause a burn.

ABOUT CE AND DOC

CE Hereby, Icom Inc. declares that the versions of IC-F5400D, IC-F5400DS, IC-F5400DP, IC-F5400DPS, IC-F6400D, IC-F6400DS, IC-F6400DP, and IC-F6400DPS which have the "CE" symbol on the product, comply with the essential requirements of the Radio Equipment Directive, 2014/53/EU, and the restriction of the use of certain hazardous substances in electrical and electronic equipment Directive, 2011/65/EU. The full text of the EU declaration of conformity is available at the following Internet address:
<https://www.icomjapan.com/support/>

About E-marking: Detailed installation notes for Icom mobile transceivers to be fitted into vehicles are available. Please contact your Icom dealer or distributor.

DISPOSAL



The crossed-out wheeled-bin symbol on your product, literature, or packaging reminds you that in the European Union, all electrical and electronic products, batteries, and accumulators (rechargeable batteries) must be taken to designated collection locations at the end of their working life. Do not dispose of these products as unsorted municipal waste. Dispose of them according to the laws in your area.

ABOUT GPS/GLONASS RECEIVER

DO NOT install the GPS antenna near the transceiver or the antenna.

A GPS or GLONASS receiver may not work if the transceiver transmits or receives in the frequency ranges as shown below.

For the IC-F5400D/IC-F5400DP series (Unit: MHz)

| | GPS Receiver | GLONASS Receiver |
|-----------------|-------------------|-------------------|
| Transmit | 142.850 ~ 142.860 | 145.275 ~ 145.945 |
| | 157.135 ~ 157.145 | 159.805 ~ 160.540 |
| Receive | 146.845 ~ 147.110 | 149.745 ~ 150.790 |

For the IC-F6400D/IC-F6400DP series (Unit: MHz)

| | GPS Receiver | GLONASS Receiver |
|-----------------|-------------------|-------------------|
| Transmit | 392.840 ~ 392.865 | 399.515 ~ 401.343 |
| Receive | 443.545 ~ 444.065 | 449.335 ~ 451.425 |

VOICE CODING TECHNOLOGY

The AMBE+2™ voice coding Technology embodied in this product is protected by intellectual property rights including patent rights, copyrights and trade secrets of Digital Voice Systems, Inc. This voice coding Technology is licensed solely for use within this Communications Equipment. The user of this Technology is explicitly prohibited from attempting to extract, remove, decompile, reverse engineer, or disassemble the Object Code, or in any other way convert the Object Code into a human-readable form. U.S. Patent Nos. #8,595,002, #8,359,197, #8,315,860, #8,200,497, #7,970,606, #6,912,495 B2.

SAFETY TRAINING INFORMATION



WARNING Your Icom radio generates RF electromagnetic energy during transmit mode. This radio is designed for and classified as "Occupational Use Only", meaning it must be used only during the course of employment by individuals aware of the hazards, and the ways to minimize such hazards. This radio is NOT intended for use by the "General Population" in an uncontrolled environment.

For compliance with FCC and IC RF Exposure Requirements, the transmitter antenna installation shall comply with the following three conditions:

- The transmitter antenna gain shall not exceed 0 dBi.
- IC-F5400D series:
The antenna is required to be located outside of a vehicle and kept at a distance of 57 centimeters (23 inches) or more between the transmitting antenna of this device and any persons during operation. For small vehicle as worst case, the antenna shall be located on the roof top at any place on the center line along the vehicle in order to achieve 57 centimeters (23 inches) separation distance. In order to ensure this distance is met, the installation of the antenna must be mounted at least 57 centimeters (23 inches) away from the nearest edge of the vehicle in order to protect against exposure to bystanders.
- IC-F6400D series:
The antenna is required to be located outside of a vehicle and kept at a distance of 42 centimeters (17 inches) or more between the transmitting antenna of this device and any persons during operation. For small vehicle as worst case, the antenna shall be located on the roof top at any place on the center line along the vehicle in order to achieve 42 centimeters (17 inches) separation distance. In order to ensure this distance is met, the installation of the antenna must be mounted at least 42 centimeters (17 inches) away from the nearest edge of the vehicle in order to protect against exposure to bystanders.
- IC-F5400D series:
Transmit only when people outside the vehicle are at least the recommended minimum distance of 136 centimeters (54 inches) away from the properly installed antenna. This separation distance will ensure that there is sufficient distance from a properly installed externally-mounted antenna to satisfy the RF exposure requirements in the applicable RF exposure compliance standards.
- IC-F6400D series:
Transmit only when people outside the vehicle are at least the recommended minimum distance of 119 centimeters (47 inches) away from the properly installed antenna. This separation distance will ensure that there is sufficient distance from a properly installed externally-mounted antenna to satisfy the RF exposure requirements in the applicable RF exposure compliance standards.



CAUTION To ensure that your exposure to RF electromagnetic energy is within the FCC and IC allowable limits for occupational use, always adhere to the following guidelines:

- DO NOT** operate the radio without a proper antenna attached, as this may damage the radio and may also cause you to exceed FCC and IC RF exposure limits. A proper antenna is the antenna supplied with this radio by the manufacturer or an antenna specifically authorized by the manufacturer for use with this radio.
- DO NOT** transmit for more than 50% of total radio use time ("50% duty cycle"). Transmitting more than 50% of the time can cause FCC and IC RF exposure compliance requirements to be exceeded. The radio is transmitting when the status indicator lights red. You can cause the radio to transmit by pressing the "PTT" switch.

Electromagnetic Interference/Compatibility

During transmissions, your Icom radio generates RF energy that can possibly cause interference with other devices or systems. To avoid such interference, turn off the radio in areas where signs are posted to do so. DO NOT operate the transmitter in areas that are sensitive to electromagnetic radiation such as hospitals, aircraft, and blasting sites.


FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

CAUTION: Changes or modifications to this transceiver, not expressly approved by Icom Inc., could void your authority to operate this transceiver under FCC regulations.

SUPPLIED ACCESSORIES



NOTE: Some accessories are not supplied, or the shape is different, depending on the transceiver version.


OPTIONS

- RMK-5 SEPARATION KIT + SEPARATION CABLE*1**
Enables you to separately install the transceiver's main unit from the front panel for convenient operation.
 - HM-218 HAND MICROPHONE + SEPARATION CABLE*2**
Command microphone with a built-in speaker
① You need the RMK-5 to connect the HM-218 to the transceiver.
 - RMK-7 DUAL HEAD KIT + SEPARATION CABLE*1**
Enables you to connect two control heads to the transceiver's main unit for dual head operation.
- *1 **OPC-2364, OPC-2365, OPC-2366, or OPC-2367** SEPARATION CABLE is used to connect between the control head and the transceiver's main unit.
• **OPC-2364:** 1.9 m / 6.3 ft
• **OPC-2365:** 3 m / 9.9 ft
• **OPC-2366:** 5 m / 16.4 ft
• **OPC-2367:** 8 m / 26.3 ft
- *2 **OPC-2373 or OPC-2374** SEPARATION CABLE for command microphone is used to connect between the HM-218 and RMK-5.
• **OPC-2373:** 1.9 m / 6.3 ft
• **OPC-2374:** 8 m / 26.3 ft
- SP-30, SP-35, SP-35L EXTERNAL SPEAKERS**
Input impedance: 4 Ω
SP-30: Rated input= 20 W
Maximum input = 30 W
SP-35/SP35L: Rated input= 5 W,
Maximum input = 7 W
 - HM-220, HM-220T, HM-221, HM-221T** HAND MICROPHONES
HM-220: Self-grounding heavy duty microphone
HM-220T: Self-grounding heavy duty DTMF microphone
HM-221: Hand microphone
HM-221T: DTMF microphone
 - SM-29 DESKTOP MICROPHONE**
 - UX-241 GPS ANTENNA**
Enables you to use the GPS function.
 - VS-3 Bluetooth® HEADSET**
The Bluetooth headset with a [PTT] switch.
 - About the third party Bluetooth® headsets:**
Icom has checked the PTT operation with some 3M Peltor headsets such as the WS Headset XP, WS ProTac XP and WS Alert XP. (Compatibility not guaranteed.)


PANEL DESCRIPTION

NOTE: Different functions may have been assigned to the keys by your dealer, except for the Power key.

◇ Segment type



◇ LCD type



◇ About the Status indicator

- Lights red while transmitting.
- Lights green while receiving a signal, or when the squelch is open.


◇ About the Microphone connector

Connect the supplied or optional microphone.


CAUTION: DO NOT connect non-specified microphones. The pin assignments may be different and may damage the transceiver.

FUNCTION DISPLAY (Segment type)

The number that is displayed on the segment type screen is called "Position."
The position number is selected by pushing [Up] or [Down].



FUNCTION DISPLAY (LCD type)



◇ Icon Area

Indicators

- SIGNAL STRENGTH INDICATOR**
Displays the relative received signal strength.
- CLOCK**
Displays the current time.
① "AM" or "PM" is displayed beside the time display when the 12 hour display format is selected.
② "--:--" is displayed instead of the current time when the internal clock is not set.

Icons

* These icons are not displayed, depending on the presetting.

POWER ICON **L1 L2 H**

- "L1" is displayed when the output power is set to low.
- "L2" is displayed when the output power is set to mid.
- "H" is displayed when the output power is set to high.

AUDIBLE ICON

Displayed when the channel is in the Audible (unmuted) mode.

MESSAGE ICON

- Blinks after Messages (Message or Status Message) have been received.
- Stops blinking when the screen is changed, or any key is pushed, but is displayed if unread messages are still in the Message memory.
- Disappears when all messages in the Message memory have been read.

BELL ICON

Displayed when a matching signal is received, depending on the presetting.

SCAN ICON

- Displayed when a scan is paused.
- Blinks while a scanning.

SCAN TARGET CHANNEL

Displayed when the channel is selected as a scan target channel.

SCRAMBLER ICON

In the Analog mode:
Displayed when the Voice Scrambler function is ON.

In the Digital mode:
Displayed when the Voice Encryption function is ON.
Blinks when receiving an encrypted signal.

GPS ICON*

- Displayed when valid position data is received.
- Blinks when searching for satellites or calculating position data.

RECORD ICON*

- Displayed when the Record function is ON.
- Blinks while recording audio.
- ① "Δ" is displayed when there is no microSD card's free space and cannot record audio.

TALK AROUND ICON

Displayed when the Talk Around function is ON.

PHONE ICON

- Displayed when the transceiver is connected to a telephone network on the selected channel.
- Blinks while receiving a phone call.

BROADCAST CALL ICON

Displayed when receiving a Broadcast Call.
① For only the IC-F5400DP and IC-F6400DP series transceivers.

SITE LOCK ICON

Displayed when the Site Lock function is ON.

LONE WORKER ICON

Displayed when the Lone Worker function is ON.

NOISE CANCEL ICON

Displayed when the Noise Cancel function is ON.

SURVEILLANCE ICON

Displayed when the Surveillance function is ON.

VOX ICON

Displayed when the VOX function is ON.

Bluetooth® ICON

- Displayed when Bluetooth is activated.
- Lights Blue when a Bluetooth device is connected.
- Does not light when no Bluetooth® device is connected.

microSD ICON*

Displayed when a microSD card is inserted.
① "Δ" is displayed when the microSD card has not been formatted.

USB ICON

Displayed when a USB device is connected.


◇ Text Area

Displays the selected Zone number, Channel number, and Channel name, if set.

◇ Key Display Area

Displays the assigned function of [P1] and [P2].
① Ask your dealer about the assigned Software key function.

REAR PANEL CONNECTION



1 ANTENNA CONNECTOR

Connect to an antenna. Contact your dealer about antenna selection and placement.

2 GPS ANTENNA CONNECTOR

Connect the UX-241 GPS antenna.

3 EXTERNAL SPEAKER JACK

Connect a 4 ~ 8 Ω external speaker.

4 IGNITION LEAD

Connects to an ignition line.

CAUTION: DO NOT put pressure on this lead. Binding to the DC power cable is recommended.

5 D-Sub 25-pin

Connects to an external unit.

6 USB CABLE

Connects to a PC.

7 MICROPHONE HANGER

For a non-self-grounding type:
Connect the supplied microphone hanger to the vehicle's ground for microphone ON/OFF hook functions.

For a self-grounding type:
The microphone ON/OFF hook functions can be used without the vehicle's ground.

Connect the microphone hanger to the vehicle's ground for microphone ON and OFF hook functions when the HM-220/HM-220T microphone is used.

User supplied

8 Connects to a 12 V DC battery.

Pay attention to polarities.

CAUTION: DO NOT connect to a 24 V battery. This will damage the transceiver.

BASIC OPERATION

◇ Turning power ON

Push [⏻] to turn ON the transceiver.

◇ Receiving and Transmitting

Receiving:

- Push [Up] or [Down] to select a channel.
- When receiving a call, rotate [VOL] to adjust the audio output level to a comfortable listening level.

Transmitting:

- Wait until the channel is clear to avoid interference.
- While holding down [PTT], speak at your normal voice level.
- Release [PTT] to receive.

IMPORTANT:

To maximize the readability of your signal:

- After pushing [PTT], pause briefly before you start speaking.
- Hold the microphone 5 ~ 10 cm (2 ~ 4 inches) from your mouth, then speak at your normal voice level.