



FOR GAMECUBE™

MINI Wireless controller

G5085 G5086

Wireless Controller For Ultimate Gaming!


- ◆ State of the art 2.4 GHz Technology allows up to 16 players
- ◆ Uses 2 AA Batteries (Not Included) for up to 60 hours of play time
- ◆ Ergonomic Analog Sticks & Directional Pad for Superior Control
- ◆ Rubberized Grips For Comfortable Handling
- ◆ Auto-Detect Feature for Simplified Set Up
- ◆ Turbo Function for Rapid Fire



USA & CANADA: www.intelink.com
EUROPE: www.intelinkeurope.com

This Mini Wireless controller uses state of the art technology for a better gaming experience. The technology used in this controller allows up to 16 players to use these controllers in one area. This controller allows you to feel the action of the game when played with "VIBRATION COMPATIBLE" software. You will feel the vibration in the controller grips as a result of the specific game actions. This can be adjusted with the vibration control switch. The Turbo function allows for auto repeat (auto fire) functions. The ergonomically designed grips combine functionality as well as comfort. The use of 2 AA batteries (not included) allows for up to 60 hours of play time depending on the use of the vibration control switch.

In most cases the software used for game play will dictate the functions of the controller buttons. See 'controller setup' in the software game menu. Prior to using the controller, you should move the Analog Sticks in a circular motion.



SET UP:

1. Remove the battery compartment cover on the back of the controller and insert 2 AA batteries. Replace the cover.
 2. Plug the receiver into one of the GAMECUBE® controller ports.
 3. If the LED on the receiver does not automatically begin flashing, press the connect button on the receiver. The LED should now be flashing. This indicates that it is 'searching' for a controller to connect to.
 4. Turn the controller on using the on/off switch in the middle of the controller.
 5. If the LED on the controller is off or flashing, press the connect button on the controller. If it automatically turns on, proceed to next step.
 6. The controller and receiver should be connected now. The LED on the controller should be on, and the LED on the receiver should have stopped flashing and should be on. You are now ready to play.
- Repeat the above procedure for each additional player using an Intec Mini Wireless Controller, one at a time. Plug only one receiver into the GAMECUBE®. Follow the procedure above for connecting that controller. Then plug the second receiver into the GAMECUBE® and follow the procedure above for connecting that controller. Continue connecting them one at a time until all your controllers are connected. You may use up to 16 of these controllers in one area without interfering with each other.

TURBO & CLEAR FUNCTIONS: Use the Turbo function for auto repeat (auto fire). When activated, this will cause the selected button to repeat its function until you release the button (ex: Continuous firing, Continuous kicking, etc.). This function is especially helpful so that you do not have to repeatedly press a button when a continuous action is desired.

TO SET AN ACTION BUTTON TO TURBO:

1. Press and hold the Turbo button.
2. Press and release any action buttons you want to put into turbo mode.
3. Release the Turbo Button.

TO CLEAR THE TURBO FUNCTION FROM AN ACTION BUTTON:

1. Press and hold the Clear button.
2. Press and release any action buttons you want remove the Turbo function from.
3. Release the Clear button. The action buttons you pressed will now return to their original function.

LOW POWER: When battery undercapacity, the power LED is blinking.




VIBRATION CONTROL SWITCH: This switch is used to control the level of vibration feedback in the controller.

-On position is vibration: This setting uses most battery power, but provides vibration feedback.

-Off position is no vibration: This setting uses the least battery power, but provides no vibration feedback.

TROUBLESHOOTING:

If you turn a controller off and on, or unplug a receiver you may lose the connection between that controller and receiver. If you have lost the connection, unplug the receiver and turn off the controller. Plug the receiver in and press connect. Turn the controller on, and if necessary, press the connect button. Whenever you are trying to connect a receiver and controller, unplug the receiver and turn off the controller and follow the steps outlined above in "Setup" for each controller.



TROUBLESHOOTING

Not vibrating	Check software for vibration compatibility. Make sure the vibration control switch is set to on.
Not working	Make sure Power switch on controller is ON. Make sure Receiver is plugged in properly. Make sure new AA Batteries are charged. Check that signal from controller to Receiver is unobstructed. Press an start button to make sure that the controller is not in 'sleep mode'.
Not connecting	See "TroubleShooting" on page 3

WARNING:

Read, follow & understand all warnings & advisory notes in this manual, your video game system instruction manual & video software for safety, health & other information

Do not submerge in water

Do not disassemble any part of controller & receiver

Do not place heavy objects on top of controller & receiver

Do not allow small children to play with controller & receiver unsupervised

Do not use this controller in any other way than its intended use

Do not unplug controller cable while the console is turned on

Keep away from areas where dirt or liquid can get into controller & receiver

Keep away from extreme temperatures

Store in areas away from dust and humidity

Turn off or discontinue use of Vibration function if you have any hand or wrist ailments or if you have any injury's to which the vibration creates discomfort to you in any way

FCC INFORMATION

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. In cases where the manual is provided only in a form other than paper, such as on a computer disk or over the Internet, the information required by this section may be included in the manual in that alternative form, provided the user can reasonably be expected to have the capability to access information in that form.

GameCube® is a registered trademark of Nintendo® of America Inc.

This item is produced by Intec and is not manufactured, sponsored, endorsed or distributed by Nintendo® of America Inc.