

***EXHIBIT D***

***User Manual***



### INTRODUCTION

cordless phone is designed to give you flexibility in use, and high performance. To get the most from your new phone, we suggest that you take a few minutes right now to read through this instruction manual.

### TABLE OF CONTENTS

REGISTRATION AND SETUP	2	THE MEMORY FEATURE	11
COILAR JACK REQUIREMENTS	2	STORING A NUMBER IN MEMORY	11
BASE UNIT INSTALLATION	3	CHANGING A STORED NUMBER	12
WALL MOUNT INSTALLATION	4	DIALING A STORED NUMBER	12
SETUP	5	CHAIN DIALING FROM MEMORY	12
PHONE OPERATION	6	INSERTING A PAUSE IN	13
RECEIVING A CALL	6	THE DIALING SEQUENCE	13
PLACING A CALL	6	REVIEWING AND DELETING	13
FLASH BUTTON	6	STORED NUMBERS	13
DUAL-TONE BUTTON	6	VIP FEATURE	14
EMERGENCY TONE	7	STORING A VIP NUMBER IN MEMORY	14
PLACING THE HANDSET	7	DIALING A VIP NUMBER	14
COILAR SWITCH	7	REMOVING A VIP NUMBER	14
VOLUME SWITCH	7	CHANGING THE BATTERY	15
LINE ID OPERATION	7	BATTERY SAFETY PRECAUTIONS	16
RECHARGING AND STORING CALLS	8	MESSAGE INDICATIONS	17
CALLER ID DISPLAY	8	HANDSET SOUND SIGNALS	18
RECEIVING MESSAGES	9	TROUBLESHOOTING TIPS	18
CALLING RECORDS	10	CAUSES OF POOR RECEPTION	21
DIALING A CALLER ID NUMBER	10	SERVICE	21
CALL WAITING	10	ACCESSORY ORDER FORM	22
		INDEX	23
		WARRANTY	24

**VERY IMPORTANT:** This product requires a subscription to the Caller ID and Call Waiting services from your telephone company.

**WARNING: TO PREVENT FIRE, OR ELECTRICAL SHOCK/HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.**

**CAUTION**  
READ THE INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT. FAILURE TO FOLLOW THE INSTRUCTIONS MAY CAUSE PERSONAL INJURY OR PROPERTY DAMAGE. ALWAYS USE THE PRODUCT AS INTENDED. FOR ADDITIONAL INFORMATION, SEE THE USER MANUAL.


**CAUTION**  
DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

SEE WARNINGS ON THE BACK OF PRODUCT.



## INSTALLATION AND SETUP

Make sure your package includes the items shown here.



## MODULAR JACK REQUIREMENTS

You need an RJ11 type modular jack, which is the most common type of phone jack and might look like the one pictured here. If you don't have a modular jack, call your local phone company to find out how to get one installed.

**INSTALLATION NOTE:** Some cordless telephones operate at frequencies that may cause interference to us by TVs and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR. If such interference continues, move the cordless telephone farther away from the TV or VCR.

**VERY IMPORTANT:** You must call your local phone company and tell the representative that you have a Caller ID/Call Waiting device that integrates the two services. Some phone companies aren't equipped to integrate the two services, which means only the Caller ID part of your unit will work. The phone companies that do have the ability to integrate Call Waiting and Caller ID must program your telephone line so the two services work together. You need to call and ask them to do this.

## FCC REGISTRATION INFORMATION

Your GE telephone equipment is registered with the Federal Communications Commission and is in compliance with parts 15 and 68, FCC Rules and Regulations.

1. **Notification to the Local Telephone Company**  
On the bottom of this equipment is a label indicating, among other information, the FCC Registration number and the Interference Equivalent Number (IEN) for the equipment. You must, upon request, provide this information to your telephone company.  
The IEN is useful in determining the number of devices you may connect to your telephone line and will have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the IENs of all devices connected to one line should not exceed 6. To be certain of the number of devices you may connect to your line as determined by the IEN, you should contact your local telephone company.

### Note

- This equipment may not be used on coin service provided by the telephone company.
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.
- Notice must be given to the telephone company upon permanent disconnection of your telephones from your line.

## 2 Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must, as promptly as possible, notify you of such temporary discontinuance; (1) afford you the opportunity to contact the station and the telephone company to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations; (2) advise you of the nature of the complaint and the steps being taken to correct the problem; and (3) advise you of the steps being taken to correct the problem. If these changes are expected to affect the performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

## INTERFERENCE INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules, which are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Reorient or relocate the equipment (that is, the antenna for radio or television) and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a booklet entitled "How to Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number GSA GEN 50115-4 when ordering copies.

## HEARING AID COMPATIBILITY


This telephone system meets FCC standards for Hearing Aid Compatibility.

FCC NUMBER IS LOCATED ON THE CABINET BOTTOM  
IEN NUMBER IS LOCATED ON THE CABINET BOTTOM

## WALL MOUNT INSTALLATION

1. Remove the base plate from the back by pressing up on the snap tabs located at the bottom, and then sliding the base plate off.
2. Plug the phone line cord into the phone jack on the back of the unit, wrap the extra line cord around the cord wrap in the wall mount base, and then thread it through the slots on top of the base plate.
3. Plug the power supply adapter into the POWER 12V DC jack on the top of the unit.
4. Install the base plate by inserting the two tabs at the top and then snapping the tab at the bottom into place.
5. Slip the mounting holes over the wall plate posts and slide the unit down firmly into place. (Wall plate not included.)
6. Connect the power supply adapter to an AC outlet.
7. Plug the phone line cord into the modular jack.

## DESKTOP INSTALLATION



1. Set the PULSE/TONE switch to TONE for touch-tone service, or PULSE for rotary service. If you don't know which type of service you have, check with the phone company.
2. Plug the telephone line cord into the base and into a modular jack.
3. Plug the power supply cord into the base, into an AC outlet.
4. Raise the base antenna.

**NOTES:** Use only the Thomson 5-2385 power supply that came with this unit. Using other adapters may damage the unit.

**CAUTION:** Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.

## TELEPHONE OPERATION

### RECEIVING A CALL

1. Check the display to see who is calling.
2. Press the PHONE button.

### MAKING A CALL

To make a call, press the PHONE button before you dial and press it again to hang up.

### PHONE LIGHT

You know the phone is on when you see the PHONE light on the handset come on.

### REDIAL

Press the REDIAL button to redial the last number you dialed.

### FLASH BUTTON

Use the FLASH button to activate custom calling services such as call waiting or call transfer, which are available through your local phone company.

The FLASH button is also used to enter a pause in the dialing sequence (see p. 13).

**TIP:** Don't use PHONE button to activate customer calling services such as call waiting, or you'll hang up the phone.


### CHANNEL BUTTON

While talking, you might need to manually change the channel in order to get rid of static. Press and release the CHANNEL button to advance to the next clear channel.

## TELEPHONE SETUP

1. Set the PULSE/TONE switch (on the top of the unit) to TONE for touch-tone service, or PULSE for rotary service. If you don't know which type of service you have, check with the phone company.
2. Place handset in the base to charge for 12 hours. The CHARGE/IN USE light comes on indicating that the battery is charging.
3. Turn on the RINGER switch so the handset rings for incoming calls.

PULSE/TONE switch



## CALLER ID SETUP

**NOTE:** For proper Caller ID operation, you must enter your area code.

1. Make sure the phone is OFF.
2. Press ENTER (the Caller ID display on the handset prompts you to enter your area code).
3. Enter your 3-digit area code by pressing the appropriate number keys. The phone emits 2 beeps to confirm it has accepted the area code entry.
4. To change or enter your area code again, follow steps 1-3 above.

## CALLER ID OPERATION

This Caller ID Cordless Telephone receives and displays information transmitted by your local phone company. This information can include the phone number, date, and time; or the name, phone number, date, and time.


## RECEIVING AND STORING CALLS

When you receive a call, the information is transmitted by the phone company to your Caller ID Telephone between the first and second ring.

- You can monitor the information as it is displayed and decide whether or not to answer the call.
- If you are not at home, the telephone stores the information so that you can see who called while you were out.

**Note:** The Caller ID memory holds 25 names and numbers. When the memory is full, only the most recent calls are stored. The oldest stored numbers in memory is deleted to make room for the newest call, which will be designated as call #25 in the Caller ID display.

## CALLER ID DISPLAY



## TEMPORARY TONE


This feature enables Pulse (rotary) service phone users to access touch-tone services offered by banks, credit card companies, etc., by pressing the TONE button to temporarily make the phone touch-tone compatible. To get information about your bank account, for example, you would:

1. Call the bank's information line.
2. Press the TONE button (Ⓞ) after your call is answered.
3. Follow the voice instructions to complete your transaction.
4. Hang up when finished. The phone returns to Pulse (rotary) service.

## PAGING THE HANDESET

Press the PAGE/FIND button on the base to get the attention of the person using the phone or to locate a misplaced handset.

If you press and hold PAGE/FIND for 3 seconds, the handset beeps for 30 seconds. Or, you can press PHONE on the handset to stop paging the handset.




## RINGER SWITCH

The RINGER switch must be ON for the handset to ring during incoming calls.

## VOLUME SWITCH

Controls the volume of the handset's earpiece.







**CAUTION:** If you make test calls to emergency numbers stored in memory, remain on the line and briefly explain the reason for the call to the dispatcher. Also, it's a good idea to make these calls in off-peak hours, such as early morning or late evening.

### CHANGING A STORED NUMBER

Use the same procedure to change a stored number as you do to store a number—in a sense, you're just reassigning the memory location.

### DIALING A STORED NUMBER

1. Make sure the phone is ON by pressing the PHONE button.
2. Press MEMORY
3. Press the number (0-9) for the desired memory location OR use the arrow buttons to scroll through the numbers stored in memory and press CALL BACK when you reach the desired number.

### CHAIN DIALING FROM MEMORY

Use this feature to make calls which require a sequence of numbers such as using a calling card for a frequently called long distance number. Basically, you dial each part of the sequence from memory. The following example shows how you can use chain dialing to make a call through a long distance service:

The Number For	Memory Location
Long distance access number	7
Authorization code	8
Frequently called long distance number	9

1. Make sure the phone is ON.
2. Press MEMORY and then press 7.
3. When you hear the access tone, press MEMORY and then press 8.
4. At the next access tone, press MEMORY and then 9.

## THE MEMORY FEATURE

Store up to 10 numbers in memory for quick dialing. This memory feature is in addition to the 25 Caller ID records and the 5 VIP records that can be stored in memory.

### STORING A NUMBER IN MEMORY

The phone must be OFF when you store numbers.

1. Press the MEMORY button.
2. Press ENTER.
3. Use the keypad to store a name. More than one letter is stored in each of the number keys. For example, to enter Joe Smith, press 5 for J; press 6 three times for O; press 3 two times for E; press 1 to enter a space before you start entering the last name; press 7 four times for S; press 6 for M; press 4 three times for I; press 8 for T; and 4 two times for H. If you're using two letters consecutively that are stored in the same number key, you must press ENTER between the letters. For example, if you enter Barb, press 2 two times for B; press ENTER; press 2 for A; 7 three times for R; and 2 two times for B. You need to press enter between the B and the A since they are stored within the same number key.
4. Press MEMORY.
5. Use the keypad to enter the number you want to store (up to 24 digits).

6. Press MEMORY and then press a number key (0-9) to store the dialed number in that memory location.
7. Record whose number is stored in the location on the memory directory card on the back of the handset. You will also be able to view the name and number in the phone's display.

NOTE: If you don't want to enter the name, skip step 3.





## VERY IMPORTANT PERSON (VIP) FEATURE

You can designate 5 Caller ID records as VIP. Each time someone on the VIP list calls, you will hear a distinct ring.

### STORING A VIP NUMBER IN MEMORY

1. Use the arrow buttons to scroll through the Caller ID records for desired number.
2. Press VIP.
3. Press ENTER (The phone emits 2 beeps to confirm it has transferred the number from Caller ID memory into VIP memory.)

### CALLING A VIP NUMBER

1. Press the VIP button.
2. Use the arrow buttons to scroll through the VIP list.
3. When you see the desired name/number in the display, press CALL BACK for local calls. If the VIP number is long distance, just press #. (If automatically enters the "1" needed to complete a long distance call.)

Note: If name information is not in the caller ID record, the name will not be stored in the memory location.

09:15 AM 10/22 MON 11:23  
1-234-555-6709  
JOE SMITH

### REMOVING A VIP NUMBER

1. Press VIP.
2. Use the arrow buttons to scroll through the VIP list.
3. When you see the desired name/number in the display, press DELETE.
4. ERASE CALLER ID? appears in the display. Press DELETE again.

### ERASING ALL VIP NUMBERS

1. Press VIP and the arrow keys.
2. Press and hold the DELETE button.
3. ERASE ALL VIP? appears in the display.
4. Press DELETE again.

TIP: Wait for the access tones before pressing the next memory button, or your call might not go through.

### INSERTING A PAUSE IN THE DIALING SEQUENCE

Press the FLASH button to insert a delay in the dialing sequence of a stored telephone number when a pause is needed to wait for a dial tone (for example after you dial 9 for an outside line, or to wait for a computer access tone). Each pause counts as 1 digit in the dialing sequence.

### REVIEWING AND DELETING STORED NUMBERS

1. Press MEMORY, then press the arrow keys to view the entry.
2. While the entry is displayed, press the DELETE key to delete the entry. The display asks you to confirm that you want to delete the entry.
3. Press DELETE a second time to delete the entry.

To exit the memory review mode, press the memory location button again.

### BATTERY SAFETY PRECAUTIONS

Don't disassemble, mutilate, puncture, wet, or dispose of battery in fire. Like other batteries of this type, if it is burned or punctured, it could release toxic materials which can cause injury.

- Keep batteries out of the reach of children.



**NOTE:** The RMC seal on the battery used in your Thomson Consumer Electronics product indicates that we are participating in a program to collect and recycle Nickel Cadmium batteries throughout the United States of America. Please call 1-800-84-BATTERY for information or contact your local recycling center.

### GENERAL PRODUCT CARE

To keep your telephone working and looking good, follow these guidelines:


- Avoid putting the phone near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping the handset, as well as other rough treatment to the phone.
- Clean the phone with a soft cloth.
- Never use a strong cleaning agent or abrasive powder because this will damage the finish.
- Retain the original packaging in case you need to ship the phone at a later date.
- Periodically clean the charge contacts on the handset and base with a soft cloth.

### CHANGING THE BATTERY


The handset runs on a consumer-replaceable nickel cadmium battery pack. If you experience any of the following problems, you may need to replace the battery pack:

- Short talk time
  - Limited range
  - Poor sound quality
  - CHARGE/IN USE light fails to light
- Make sure phone is OFF before you replace battery.



1. Slide open the battery compartment door.
2. Unhook the strap holding the battery in place.
3. Pull out the battery plug.
4. Remove the battery pack.




Battery Holding Strap




Plug




5. Replace and plug in the new battery pack. (use GE DT-12 replacement battery.)




6. Reconnect the strap to secure the battery.



7. Replace the battery compartment door.



8. Charge the battery for 12 hours before use.



## MESSAGE INDICATORS

The following indicators show the status of a message or the unit.

<b>CALLER ID ERROR</b>	Caller information has been interrupted during transmission or the phone is excessively noisy.
<b>ENTER AREA CODE</b>	Prompt telling you to enter your area code.
<b>ENTER NAME</b>	Prompt telling you to enter name into VIP memory or one of the 10 memory locations.
<b>ERASE ALL?</b>	Prompt asking you if you want to erase all Caller ID records.
<b>ERASE ALL VIP?</b>	Prompt asking you if you want to erase all 5 VIP records.
<b>ERASE CALL ID?</b>	Prompt asking you if you want to erase the current Caller ID record or VIP record that is shown on the display.
<b>ERASE MEMO?</b>	Prompt asking you if you want to erase one of the 10 numbers stored in the phone's outgoing memory.
<b>MESSAGE WAITING</b>	Someone left a voice mail message. Note that voice mail is a subscription service; check with your local telephone company for availability.
<b>NEW</b>	Number of new calls for you to review.
<b>OUT OF AREA</b>	The incoming call is from an area not serviced by Caller ID or the information was not sent.
<b>PAGING YOU</b>	Someone is pressing the PAGE button.
<b>PRIVATE</b>	The person is calling from a number that has been blocked from transmission.
<b>REPT</b>	Repeat call message. Indicates that a new call from the same number was received more than once.
<b>NO CID</b>	There is incoming call, but you did not order Caller ID Service from your phone company.

2-9772 US 10 E 0

17

2-9772 US 10 E 0

17

## HANDSET SOUND SIGNALS

Signal	Meaning
Three long beeps	Page signal
A long warbling tone (with ringer on)	Signals an incoming call
Four short beeps	Out of range warning

## TROUBLESHOOTING TIPS

Caller ID	Solution
<b>Problem</b> No Display	<ul style="list-style-type: none"> <li>If you are using battery power, try replacing the battery.</li> <li>If you are using AC power, make sure that the unit is connected to a non-switched electrical outlet. Disconnect the unit from the plug and plug it in again.</li> <li>Did you order Caller ID service from your local telephone company? The display won't work unless you order Caller ID service from your phone company.</li> </ul>
<b>Data Error Message</b>	<ul style="list-style-type: none"> <li>The unit displays this message if it detects anything other than valid Caller ID information during the silent period after the first ring. This message indicates either the presence of noises on the line, or that an invalid message has been sent from the telephone company.</li> </ul>
<b>CALL WAITING</b>	
<b>Problem</b> You hear call waiting tone, but number doesn't appear in display	<b>Solution</b> <ul style="list-style-type: none"> <li>You must subscribe to Call Waiting for this feature to work.</li> <li>Even if you have subscribed to both Call Waiting and Caller ID, you must call your phone company and tell them to integrate your Call Waiting and Caller ID services.</li> </ul>

18

2-9772 US 10 E 0

18

2-9772 US 10 E 0

## TROUBLESHOOTING TIPS

### FLIPPHONE

Problem	Solution
No dial tone	<ul style="list-style-type: none"> <li>• Check installation:                             <ul style="list-style-type: none"> <li>— Is the base power cord connected to a working outlet?</li> <li>— Is the PHONE light on?</li> <li>— Is the telephone line cord connected to the base unit and the wall jack?</li> </ul> </li> <li>• Disconnect the base from the wall jack and connect another phone to the same jack. If there is no dial tone in the second phone, the problem might be your wiring or local service.</li> <li>• Is the handset out of range of the base?</li> <li>• Make sure the battery is properly charged (12 hours).</li> <li>• Is the battery pack installed correctly? See p. 15.</li> <li>• Did the handset beep when you pressed the PHONE button? Did the Phone-In-Use light come on? The battery may need to be charged.</li> </ul>
Dial tone is OK, but can't dial out	<ul style="list-style-type: none"> <li>• Make sure the TONE/PULSE switch on the base is correctly set (see p. 3).</li> </ul>
Handset does not ring	<ul style="list-style-type: none"> <li>• Make sure the RINGER switch on the handset is turned to OFF.</li> <li>• You may have too many extension phones on your line. Try unplugging some phones.</li> <li>• See solutions for "No dial tone."</li> </ul>

## TROUBLESHOOTING TIPS

Problem	Solution
You experience static, noise, or fading in and out	<ul style="list-style-type: none"> <li>• Change channels</li> <li>• Is handset out of range? Move closer to the base.</li> <li>• Does the base need to be relocated?</li> <li>• Charge battery.</li> <li>• Make sure base is not plugged into an outlet with another household appliance.</li> </ul>
Unit beeps	<ul style="list-style-type: none"> <li>• Place handset in base for 20 seconds to reset the security code. If that doesn't work, charge battery for 12 hours.</li> <li>• Clean charging contacts on handset and base with a soft cloth, or an eraser.</li> <li>• See solutions for "No dial tone."</li> <li>• Replace battery.</li> </ul>
Memory Dialing	<ul style="list-style-type: none"> <li>• Did you program the memory location keys correctly? See p. 11.</li> <li>• Did you follow proper dialing sequence? See p. 12.</li> <li>• Make sure TONE/PULSE switch is correctly set. See p. 3.</li> <li>• Did you reprogram numbers into memory after power outage or replacing battery?</li> </ul>