


# User's Guide

(Bluetooth Phone Adaptor)



## **Operating method:**


**Turn On :** Press **【PAIRING】** till the LED flash, then release.

**Pairing :** Press **【PAIRING】** till red/green blinking light, then release. Meanwhile, switch your Bluetooth headset into pairing mode.

**Two devices should connect themselves and green LED flashing shows connected.**

LED	MODE	REMARKS
RED/GREEN BLINKING	PAIRING	
GREEN FLASH	NORMAL	
RED FLASH	LOW-BATTERY	
RED LIGHT ON	RE-CHARGING	GREEN INDICATES BATTERY FULL.

# Bluetooth Headset



## Operation:

### Turning on the headset

Switch on the headset by pressing “Function key” max. 3 seconds and a beep tone with LED flashing indicates the headset is on.

### Putting HS in Pairing Mode

Press and hold the “Function key” for 6 seconds, blinking of red and green LEDs alternately indicates the headset is in Pairing Mode.

\* The default Passkey required for pairing is **0000**. If the headset is not successfully paired within the Pairing Timeout (120 seconds) period, it shuts off automatically.

Your headset needs to pair with Bluetooth Phone before you use, please refer to your phone manual for user instruction.

### Answer incoming calls

Pressing the “Function key” to answer the call when there is an incoming call present. The green LED will continue to flash fast while the call is in session.

### Transferring calls

Calls can be transferred from phone to the headset OR from the headset to phone.

Note: It varies from phone to phone; please refer to your mobile phone user’s manual.

## Disconnecting calls

While a call is in session on the headset, press the **“Function key”** to disconnect the call. After the call is disconnected, the green LED will flash normally.

## Putting HS in Standby Mode

The headset can be put into Standby Mode in different ways:

- Turning on the headset but not going into Pairing Mode
- After successfully pairing the headset
- Disconnecting from a call

Note: The headset can receive incoming calls in Standby Mode.

## Locally changing the volume on HS

Press the **Right button** upward to increase the listening volume on the headset.

Press the **Left button** downward to decrease the listening volume on the headset.

## Remotely changing the volume on HS

The headset listening volume can be remotely changed by the blue tooth mobile phone. Please refer to your blue tooth mobile phone manual for volume adjusting.

## Low-battery indication

The headset LED will flash red instead of green and a short beep every 30 seconds when the battery is low.

## Battery recharging

Allow approximately 1 hour to fully recharge an empty battery.

Li-ion Charger LED indicators:

Green: ready for charging/battery is full.

Red: charging in progress

## Turning off the headset

Switch off the power by pressing the “Function key” max. 3 seconds, a beep tone and LED off indicate the headset is off.

## Recommend bluetooth phone

Nokia 6310, Nokia 6310i, Nokia 8910,

Ericsson T39, Sony Ericsson T68, Sony Ericsson T68i,

## Recommend Non-Bluetooth cellular Phone( with our Bluetooth Phone Adaptor)

Cable-M01: Motorola 3688, Motorola 8088, Motorola V66, Motorola T289, Motorola T720,

Motorola 7689, Motorola L2000, Panasonic GD85, NEC 250I, OKWAP 166

Cable-N01: Nokia 3310, Nokia 8210, Nokia 8310, Nokia 8850, Palmax XG5D

## FCC Safety Statements

The device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

The radiated output power is far below the FCC radio frequency exposure limits. Nevertheless, this device should be used in such a manner that the potential for human contact during normal operation is minimized.

**IMPORTANT NOTE:** To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

The equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no grantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The user should not modify or change this equipment without written approval from the manufacture. Modification could void the FCC authorization to use this equipment.

## Battery Information

1. For the first time use, plug the adaptor plug into the headset's power jack and charge it at least 4 hours until the charging LED turns off.
2. Only qualified service centers are authorized to remove or replace the battery.
3. The battery can only be charged in a temperature range of  $-10 \sim 45$  .
4. Use the headset in room temperature for maximal battery capacity.
5. Leaving the headset in an environment above  $45$  for a long period of time may damage the battery. Although it is not harmful to human, it reduces the life span of the battery.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two

conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.