

TROUBLESHOOTING

If ...	TRY THIS ...
My smartphone or wireless device cannot find the camera during setup.	Make sure the camera's green LED is blinking in a 3-flash/pause pattern. If it isn't, reset the camera by pressing and holding the Reset button on the cord until the LEDs begin to flash.
The app cannot find the camera	<ul style="list-style-type: none"> - Make sure your network supports DHCP protocol. - Make sure that the DHCP option is turned on. - Make sure the camera and your mobile device connect to the same WiFi router. - Make sure the WiFi router is activated. - Make sure the camera is properly powered on. - Make sure the WiFi router has enabled SSID broadcasting.
The camera does not find the router to connect to	<ul style="list-style-type: none"> - Make sure you selected the correct router in the <i>Manage WiFi Network</i> box. - Make sure you entered the correct password for the router you selected in the <i>Manage WiFi Network</i> box.

APPCAM 26PT QUICK START GUIDE



Use this Quick Start Guide to connect the camera on the network. If you want to set up more cameras later, refer to the online user manual for instructions.

IN THE BOX


Camera (1)	Antenna (1)	Mounting Bracket (1)	AC Power Adapter (1)
Quick Start Guide (1)	Ethernet Cable (1)	Screw Pack (1)	

SET UP CAMERA AND SMARTPHONE/TABLET



This Quick Start Guide only shows images for Android devices. Images for iOS devices are very similar.

PREREQUISITES




- Your router must support WEP/WPA/WPA2 security and it must be turned on.
- You must have an available WiFi-enabled mobile device (Android or iOS smartphone/tablet).
- The AppCam and your mobile device must connect to the same Wi-Fi router for setup.

1. Download the Uniden® AppCam™ app from the Apple iTunes store (iOS) or Google Play (Android) onto your device.	
2. Connect the antenna to the camera.	
3. Connect the camera to power. After about 45 seconds, the green LED begins to flash (3-flash/pause pattern).	

CONNECT CAMERA AND MOBILE DEVICE

1. From your device's Settings, go to <i>WiFi</i> . Select the AppCam 26PT to connect your device to it. The camera listing will be HD-XXXXXX where XXXXXX are the last 6 digits on the camera label. Enter the default password, 12345678.	
2. When the device is connected to the camera, launch the app and tap the Add New System icon.	
3. The <i>System Information</i> screen displays. Name the camera and tap <i>Search..</i>	
4. The <i>Search in LAN</i> results box displays. The camera's DID should display. Tap the DID number.	
5. The <i>System Information</i> screen displays again. This time, enter the security code (123456); tap <i>Save</i> . Tap <i>YES</i> , then <i>NO</i> at the next prompts.	
6. The <i>Globe</i> screen displays. Tap the Globe to access the AppCam 26PT video.	

CONNECT CAMERA TO WIFI ROUTER

1. Tap the Back icon, the System icon, and then the System Settings icon. The System Information screen displays	
2. Tap <i>Advanced</i> . Enter the Admin password (123456).	
3. Scroll to WiFi on the Advanced Settings list. Tap <i>Manage WiFi Network</i> . Select your router from the drop-down list and enter your router's password. Tap <i>Connect</i> . Your camera will reboot and reconnect to the router. Wait until the camera's LEDs return to the steady on state to continue.	
4. The Camera screen indicates that it is disconnected. Tap the System icon and then the Refresh icon. The camera refreshes and reconnects to the router you chose. The LEDs should be both on steady and app displays a photo of the video image.	

Attach the AppCam 26PT Mounting Plate and Camera

1. Hold the mounting plate where you want to mount it and mark the location of the screw holes.
2. Use the included screws and anchors to attach the mounting plate to the wall.
3. Use the enclosed screws to screw the camera to the bracket.



SET TIME ZONE/DAYLIGHT SAVINGS TIME

It is important to set the correct time zone and daylight savings time indication on your camera to ensure correct date/time stamp on the video files.

1. Access the *Advanced Settings* list (see Connect Camera to Internet, described previously).
2. From the *Advanced Settings* list, scroll to *Time Zone*.
3. Select your time zone. The most commonly used time zones are:
 - GMT-05:00 - Eastern Standard
 - GMT-06:00 - Central Standard
 - GMT-07:00 - Mountain Standard
 - GMT-08:00 - Pacific Standard
 - GMT-09:00 - Yukon Standard
 - GMT-10:00 - Alaska-Hawaii Standard
4. Set the Daylight Savings Time indicator.
5. Tap *Back*, and exit the *Advanced Settings* list.

For complete operation instructions, refer to the online user manual at www.uniden.com

FCC Compliance Statement: This device complies with Part 15 of the FCC rules. Operation is subjected to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The distance between user and products should be no less than 20cm
La distance entre l'utilisateur et de produits ne devrait pas être inférieure à 20cm

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.