

AGE 8+

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
8. Only use attachments/accessories specified by the manufacturer.
9. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ❖ Reorient or relocate the receiving antenna.
- ❖ Increase the separation between the equipment and receiver.
- ❖ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ❖ Consult the dealer or an experienced radio / TV technician for help.

Shielded cables must be used with this unit to ensure compliance with the Class B FCC limits.

SEIZURE WARNING: A small percentage of individuals may experience epileptic seizures when exposed to certain light patterns or flashing lights. Exposure to certain patterns or backgrounds on a television screen or while playing video games, including games played on the TV Games unit, may induce an epileptic seizure in these individuals. Certain conditions may induce previously undetected epileptic seizure or symptoms in these individuals or in persons who have no history of prior seizures or epilepsy. If you or anyone in your family has an

epileptic condition, consult your physician prior to playing. If you or anyone in your family experience any of the following symptoms while playing a video game — dizziness, altered vision, eye or muscle twitches, loss of awareness, disorientation, any involuntary movement or convulsions — IMMEDIATELY discontinue use and consult your physician before resuming play.

-To reduce the likelihood of a seizure while playing video games:

1. Sit or stand as far from the screen as possible.
2. Play video games in a well-lit room and on the smallest available screen.
3. Do not play if you are tired.
4. Take a 10 to 15 minute break every hour.

REPETITIVE STRAIN WARNING: Playing video games continuously can make your muscles, joints or skin hurt after a few hours. To avoid problems such as Tendonitis, Carpel Tunnel Syndrome or skin irritation:

1. Take a 10 to 15 minute break every hour, even if you don't think you need it.
2. If your hands, wrists or arms become tired or sore while playing, stop and rest them for several hours before playing again.
3. If you continue to have sore hands, wrists or arms during or after play, stop playing and see a doctor.

BATTERY SAFETY INFORMATION:

⚠ WARNING: Battery acid leakage can cause personal injury and cause damage to the product and surrounding property. If battery leakage occurs, thoroughly wash any affected skin, making sure to keep battery acid away from eyes, ears, nose and mouth. Immediately wash any clothing or other surface that comes in contact with leaked battery acid. Leaking batteries may make "popping" sounds. Dispose according to Local, State or Federal Battery Laws.

NEVER mix old and new batteries or different brands of batteries.

NEVER mix alkaline, standard (carbon-zinc), rechargeable (nickel-cadmium) batteries with this product.

NEVER dispose of batteries in fire, as they may leak and explode.

NEVER use rechargeable batteries.

NEVER attempt to charge non-rechargeable batteries.

ALWAYS remove exhausted batteries from toy.

ALWAYS have an adult install batteries consistent with installation instructions.

ONLY use batteries specified by manufacturer.

Batteries are to be inserted with the correct Polarity.

The supply terminals are not to be short-circuited.

WARRANTY > For warranty information, visit www.jakks.com/warranty

TROUBLESHOOTING > If you cannot get the product to work with your audio/video devices, please contact the device manufacturer.

This device complies with Industry Canada Licence-exempt RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.




VIDEO GAME

FOR SET-UP:


(ADULT INSTALLATION REQUIRED)

1. **Battery installation:** Locate the battery compartment on the bottom side of the portal. Using a Phillips Head screwdriver, remove the screw and the battery door. Install fresh batteries, matching polarity icons with those on the unit. Replace the battery compartment and the screw.
2. **Unit Connection:** Connect unit to TV, VCR or DVD player and select the appropriate "line in" source. Consult the audio/video device's manual for details.

Before replacing batteries, turn power off and disconnect the AV cable from the TV.



Requires 4 "AA" alkaline batteries (not included)



If you experience screen problems such as horizontal lines, distorted graphics, ghosting or fading, batteries may need to be changed.

If you experience further difficulties, reset the PORTAL by turning it OFF and ON again or consult the audio/video device's manual to troubleshoot.

GAME PLAY: 6 STAGES, 18 MISSIONS
Flap, glide and blast! Find the Hero gates and unlock sub-levels for 6 different types of play. Battle through waves of enemy dragons, collect dragon eggs and challenge yourself to reach 100% completion.

DreamWorks Dragons © 2014 DreamWorks Animation L.L.C.

TM & © 2014 MANUFACTURED BY JAKKS PACIFIC, INC., 22619 PCH, MALIBU, CA, 90265 U.S.A.

All other symbols, marks, logos, and designs (collectively "Trademarks") are Trademarks of and proprietary to their respective owners and used under license.

MADE IN CHINA.

Contents may vary in style, color, shape and decoration from images shown on package or in advertising.

Questions or comments? www.jakks.com, consumers@jakks.com, or 1-877-875-2557 in North America.

Developed by HotGen Ltd London.

The ratings icon is a trademark of the Entertainment Software Association.

ATTENTION! Remove and discard packaging ties and fasteners before giving toy to child.




Hero Portal™ DreamWorks Dragons Figures only work with the Hero Portal™ DreamWorks Dragons Game System.



SET UP


1

Plug the A/V CONNECTORS into a TV, VCR or DVD player and select the appropriate "line in" source. Consult the audio/video device's manual for details.




2

Move the POWER SWITCH, located on the bottom of the PORTAL, to the ON position.




3

Select a FIGURE and place it on the PORTAL. This will be the character that you will control in the game.




4

Place FIGURE 2 on the PORTAL to select support character. Support characters can be summoned to perform special attacks in the game!



CONTROLS



ADVANCED CONTROLS

EVADE BACK ◀ + ▶

DASH FORWARD ▶ + ▶

EVADE UP ▲ + ▲

EVADE DOWN ▼ + ▼

FIRE (A)

HEAVY SHOT (A) (HOLD)

ACTIVATE SHIELD (B)

SPECIAL ATTACK (C)

SUPPORT ATTACK (C) (HOLD)

GAME SCREEN



1 SCORE

2 PLAYER HERO

3 SHIELD METER

4 SPECIAL ATTACK METER

5 HEALTH METER

6 CO-OP HERO

7 CO-OP SPECIAL ATTACK METER

8 COLLECTIBLE / COLLECTED:

A) Dragon Coins; B) Dragon Eggs

C) Dragon Blade

TIP: Achieve 100% to unlock Ultimate Hero Mode.

TROUBLESHOOTING TIPS

1 NO PICTURE – TV/MONITOR Screen is black with no picture:

- Make sure batteries have been installed properly. (ADULT INSTALLATION REQUIRED)
- Make sure the Hero Portal™ power switch is in the ON position.
- Make sure the AV cables are properly connected to your TV or Monitor.
- Make sure the TV or Monitor input setting is correct.

2 FIGURE NOT RECOGNIZED – Error message appears, "Incorrect figure on the Portal. Please remove it to continue."

- ONLY Hero Portal™ DreamWorks Dragons figures will work with the Hero Portal™ DreamWorks Dragons Video game.
- If you are using a non Hero Portal™ DreamWorks Dragons figure it will not work with this product.
- If you are using an Official Hero Portal™ DreamWorks Dragons figure please make sure it is laying flat on the top of the PORTAL surface.
- Please remove all other figures from proximity of the PORTAL and replace the figures you would like to use one at a time.
- Note only two figures may be placed on the PORTAL surface at one time.
- Restart the game by powering the Hero Portal™ OFF, wait 15 seconds, and power back ON.
- Power the Hero Portal™ OFF, replace batteries, and power back ON. (ADULT INSTALLATION REQUIRED)

3 GAME FREEZES – Game screen is stuck or screen has gone black:

- Power the Hero Portal™ OFF, wait 15 seconds, and power back ON.
- Replace batteries then turn the PORTAL unit ON and try again. (ADULT INSTALLATION REQUIRED)

4 MISSION ACCESS – Hero cannot gain access to areas in game:

- Please check to see if you are currently using any one of the required characters to access the mission
- Replace current figure with any one of the characters shown in the on-screen prompt.

5 GAME AUTOMATICALLY RESETS –

- Game reloads unintentionally:
- Power the Hero Portal™ OFF, wait 15 seconds, and power back ON.
 - Power the Hero Portal™ OFF, replace batteries, and power back ON. (ADULT INSTALLATION REQUIRED)

6 GAME IS IN BLACK AND WHITE –

- No color on your TV or Monitor:
- Make sure you have connected the A/V CONNECTORS properly and have selected the appropriate "input" setting. (ADULT INSTALLATION REQUIRED)
 - Consult the Manufacturer's manual for your TV/MONITOR for additional information.