

NASCAR

1:64 R/C CONTROL INSTRUCTIONS

QUICK START

STEP 1: BATTERY INSTALLATION

-Radio Control Handset

1. Switch the power to "OFF".
2. Unscrew the battery compartment cover located on the back of the handset with a Phillips screwdriver and remove. (see Fig. 1)
3. Insert 9V Alkaline batteries (not included) in the proper direction as indicated inside the battery compartment. (see Fig. 1)
4. Replace the battery cover & tighten screw securely.
5. Switch the power to "ON".




Figure 1




Figure 2

-External Charger

1. Unscrew the battery compartment cover with a Phillips screwdriver & remove. (see Fig. 2)
2. Insert 3 AAA (1.5V) Alkaline batteries (not included) in the proper direction as indicated inside the battery compartment. (see Fig. 2)
3. Replace the battery cover & tighten screw securely.

STEP 2: CHARGING CAR BATTERY

1. Place the car on the charging base inside of the helmet controller.

NOTE: line up the holes on the bottom of the car with the pegs of the charger. Once on the charging base, the car will fully charge in approximately 45 seconds. Repeat when the car's charge is fully drained.

2. To provide maximum speed and duration fully charge the vehicle. **DO NOT PLACE A FULLY CHARGED CAR BACK ON THE CHARGING BASE, THIS MAY DAMAGE THE PRODUCT!**

NOTE: The Charging Indicator on the Charger will light up only when the racer is charging.

3. Remove your CAR from the Helmet Charger and place it on the ground for racing.




Figure 3

STEP 3: RACING YOUR CAR

1. Switch the Remote Control Handset to "ON".
2. Extend the Antenna. (see Fig. 4).
3. Push the FORWARD, BACKWARD, LEFT and RIGHT buttons to race your CAR in any direction! (see Fig. 5, 6)
4. After approximately 2 minutes, your CAR will begin to lose its power. Simply follow the steps outlined in the 'Charging Your CAR' section to recharge your CAR and race again!

Race the 27 MHz Nascar Against the 49 MHz racers for awesome competitive racing action!




Figure 4




Figure 5




Figure 6

THE NASCAR TUNE-UP: STEERING ADJUSTMENT

1. Adjust your CAR's steering by rotating the Steering Knob by bit. (see Fig. 7)
2. After you have made an adjustment, place your CAR on the ground and take it for a spin!
3. Simply repeat these simple steps until you get the best steering action for your CAR.




Figure 7

TROUBLE SHOOTING

IF THERE IS NO FUNCTION BETWEEN THE REMOTE CONTROL HANDSET AND THE RACER:

- Make sure you have turned ON the Remote Control.
- Make sure your CAR racer is fully charged.
- Check that the batteries are inserted properly.
- Replace the old batteries with new alkaline batteries.
- Move the remote control handset closer to your CAR to determine the best communication between the Remote Handset and the Racer. (The operating range is approximately 6 to 8 feet.)

IF YOUR CAR RACER FAILS TO CHARGE:

- Make sure the batteries have been inserted properly.
- Make sure the batteries are fresh; if not, replace with new, alkaline batteries.
- Make sure you have connected your CAR onto the External Charging Unit's Charging Connector securely and so that the contact on the bottom of your racer are connected to the contacts on the top of the Charger.

HELPFUL HINTS

- Do not operate during thunderstorms.
- Avoid water when racing your CAR. In addition, do not submerge your Racer, Charging Unit or Handset in water.
- When your vehicle starts to lose power, it may experience loss of performance ability. If this happens, simply recharge your CAR again.
- Your CAR is operated by radio waves. It is possible the unit may not perform properly due to interference from nearby devices such as a cordless phone, hair dryer, radio, walkie-talkie or other radio-controlled toys.
- Avoid sand and snow when operating your vehicle.
- Always select a safe place to play. Never drive your vehicle on populated streets.
- Keep fingers, hair and loose clothing away from the tires, wheel hubs and motors while the vehicle is switched on.

SAFE BATTERY PRECAUTIONS

- Do not dispose the batteries in fire; batteries may leak or explode.
- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- The supply terminals are not to be short-circuited.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are only to be charged under adult supervision.
- When not in use for an extended time, remove batteries to prevent possible leakage.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- Batteries should be replaced by adult.

IMPORTANT:

- EMISSIONS OR INTERFERENCE OF SURROUNDING ELECTRONIC EQUIPMENT MAY AFFECT OPERATING PERFORMANCE.

CAUTION:

- Do not use rechargeable batteries for the Remote Control Handset and/or the External Charger.
- Not suitable for children under 3 years.
- May contain small parts.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

PLEASE KEEP THIS INSTRUCTION SHEET SINCE IT CONTAINS IMPORTANT INFORMATION.

Printed in China

NOTES:

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

For 27 MHz

Field Strength : 64.1 dB μ V/m at 3 m

For 49 MHz

Field Strength : 71.1 dB μ V/m at 3 m