


naxa[®]

Wi-Fi&Bluetooth Speaker with Amazon Alexa Voice Control



MODEL:NAS-5000


PLEASE READ CAREFULLY BEFORE OPERATING THIS EQUIPMENT
KEEP IT IN A SAFE PLACE FOR FUTURE REFERENCE

FCC WARNING:


To assure continued operation, follow the attached installation instructions and use only shield cables when connecting to other devices. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

PRODUCT OVERVIEW

TOP VIEW



REAR VIEW



1. LED Light Ring
2. Play/Pause,WPS Button
3. Previous/Volume Down Button
4. Next/Volume Up Button
5. MODE Button
6. Voice Control Button

7. Mode Indicator
8. Built-in Microphone
9. Charge Indicator
10. ON/OFF Switch
11. DC IN Jack
12. AUX IN Jack

POWER SOURCE:

There is a built in Li-ion rechargeable battery, recharge it if the battery is low.

1. Connect the Micro USB Plug from the supplied USB Connection Cable to the Micro USB Port on the rear of unit.
2. Connect the full sized USB Plug from the supplied USB Connection Cable to the USB Port on the USB Charger (During charging, the charge indicator on the top of unit will turn RED, When finished, it will turn off).

NOTES:

Your battery will last longer if you're following these simple guidelines for charging and storing:

- A. Before first time use, charge it approximately 4 hours until the unit is fully charged.
- B. Recharge and store the unit within the temperature range of 5°C~35°C (40°F~95°F).
- C. Do not charge longer than 24 hours. Excessive charging or running the unit until battery fully drains will damage battery. Battery life will be extended if you keep the battery fully charged.
- D. Battery life naturally shortens slowly over time.
- E. The rechargeable battery incorporated in this product is not user replaceable.

AUX IN:

To listen from an external Audio Player such as a MP3 Player, Discman ...etc.

1. Connect one end of the Audio Connection Cable to the AUX Out/Line Out/Phone Jack on the external Audio Player.
2. Connect the other end of the cable to the AUX IN Jack on the rear of the unit. Switch on the unit, wait the mode indicator blinks green only, press the MODE button repeatedly until the Mode Indicator will turn INDIGO.
3. Play the music on the connected Player as usual.

BLUETOOTH OPERATION:

1. Switch on the unit, wait the mode indicator blinks green, then press the MODE button repeatedly until the Mode Indicator will turn BLUE and blinks.
2. Activate the bluetooth menu on the device you wish to connect to the speaker, try to search the speaker, the pairing name "NAXA NAS-5000" will appear on bluetooth device list, select it and make connection.
3. After successful connection, the unit will send a tone and the indicator stays lit.
4. Play a track on your paired audio player or phone as normal.

During playing:

Press the **⏮** Button to switch between playing and pause.

Press the **⏪** or **⏩** to skip to the desired track.

Press and hold the **+** or **-** button to adjust volume.

NOTE:

- After first time pairing, the unit will be automatically paired with the device connected before when the bluetooth of the device and speaker are activated and in range.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

FCC ID: OKUCAW37051

SETUP

APP DOWNLOAD AND INSTALLATION

- Download the MUZO Player from Apple App store for iOS devices.
- Download MUZO Player from Google Play store for Android devices.
- The App icon will appear as the figure on right after successful installation.




MUZO Player

NOTE:

- The following operation base on iOS system. The operation of Android is similar.

CONNECTION


1. Switch on the unit, the mode indicator will blink blue and green for a few seconds, wait until it blinks green only, now it is WiFi mode.
2. Turn on the WiFi on your iOS or Android device(smart phone or tablet with WiFi function), Connect your iOS or Android device to the desired WiFi network (router).





3. Click the MUZO Player icon on your iOS or Android device.

It will start to scan and search the available speaker automatically.

Read the screen instructions and press the **Wi-Fi Setup Wizard** to continue.




4. Inputing the WiFi password to make the speaker to connect to WiFi network(router),
Press the  to continue.




5. **Press and hold the WPS button** on top of the speaker.

Press the  button on your MUZO Player to continue.



6. There will be voice instructing like " searching for WiFi connection", " waiting for WiFi connection" during the connecting process.




7. When the speaker is connected to the Wi-Fi (router) successfully, and the voice sounds "Wi-Fi connected", the Indicator on top of the speaker will stay lit. If connection fails, please try again and repeat the above connecting steps.




HOME PAGE INTERFACE

Click the " MUZO " on screen to enter homepage, operate as below instructions and the screen instructions. Some platforms may need registration.



SPOTIFY OPERATION

Before use, you have to create an spotify premium account for log in.

1. Tap "Spotify" on MUZO homepage.
2. Input your account and password to log in.
3. Open the Spotify on your phone, tablet or PC, and play any song.
4. Tap the connect icon  .
5. Pick your device from the list.

Licenses

The Spotify Software is subject to third party licenses found here:
www.spotify.com/connect/third-party-licenses.

IHEARTRADIO OPERATION

Before use, you have to create an iHeartradio account for log in.

1. Tap "iHeartradio" on MUZO homepage.
2. Input your account and password to log in.
3. Select the desired song and play.


TIDAL OPERATION



Before use, you have to create a TIDAL account for log in.


1. Tap "TIDAL" on MUZO homepage.
2. Input your account and password to log in.
3. Select the desired song and play.

AMAZON LINKPLAY ALEXA VOICE CONTROL





Before using Amazon linkplay Alexa voice control function, you must get an Amazon prime account, create an account on Amazon website.

1. Touch  Amazon on homepage, the log in window will pop up, input your account and password to log in.
2. If you have logged in before, the figures below will appear and operate as the tips.



3. Press the  button on top of the speaker, then you can speak to it, the speaker will respond to your question or requirement (command).

For example:

- Press the  button then ask the speaker, what's the weather like today?
The speaker will reply: the weather is not so cold.
 - Press the  button then ask the speaker again, what's the time now?
The speaker will reply: it is 8 o'clock now.
 - Press the  button then tell the speaker, play music.
The speaker will reply: here is the station we found. the music will be played.
4. Before asking or requiring the speaker, press the  button first. Except the examples stated above, you may ask the speaker to do more things desired.

TROUBLESHOOTING

Check the following before requesting service:

SYMPTOM	POSSIBLE CAUSE	POSSIBLE SOLUTION
Can't power on	Built in battery drained	Recharge the battery
No sound or sound weak	Volume level of paired/connected device is in low level	Rise the volume level of the paired/connected device
Sound distortion	Volume level of the connected/paired device too high	Reduce the volume level of the connected/paired device
BT not functioning	The external BT device had NOT paired to the unit	Pair the external BT device to the unit
	The external BT device too far from the unit	Place the external BT device close to the unit

SPECIFICATIONS

Power source: Built-in DC --- 3.7V, 2200mAh (7.4WH) rechargeable Li-ion Battery,
Recharge by DC --- 5V through Micro USB Port

BT Version: 4.1
BT Operation Distance: about 32 Feet in open area
Wifi Operation Distance: about 96 Feet in open area

PACKAGE INCLUDES

- 1 x User's Manual
- 1 x USB Connection Cable (For Charging Only)
- 1 x Audio Connection Cables with 3.5mm Plugs

**SPECIFICATIONS AND ACCESSORIES ARE SUBJECT TO CHANGE
WITHOUT NOTICE**



LIMITED WARRANTY

NAXA LIMITED WARRANTY (“Warranty”) — For Product Categories Listed in Chart Below (as applicable, “Product”).

Before returning your Product for service under this Warranty, please read the instruction manual carefully and visit our website at www.naxa.com for product updates and extended support documentation (e.g., Frequently Asked Questions, Common Troubleshooting Guides, etc ...). If you are still having trouble with your Product, please contact Naxa Customer Support.

Warning: *Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children.*

Subject to the terms and conditions herein, Naxa Electronics, Inc. (herein after called “Naxa”) warrants to the original purchaser of the Product (“Customer”) that the Product will be free from defects in material or workmanship under normal, non-commercial use (“Defects”) for the applicable Warranty Period listed below.

Warranty Period encompasses separate “Coverage Periods” for Parts and Labor as listed in the table below. Each Coverage Period begins from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Coverage Period, Naxa will, at its option: (1) repair the Product (or any component thereof) or; (2) replace the Product (or any component thereof) with a new or refurbished Product (or any component thereof), in either case free of charge to Customer for Parts and/or Labor during the specified Coverage Period only, and excluding the applicable shipping charges noted below for which the Customer is responsible. The foregoing states the Customer’s exclusive remedy and Naxa’s sole liability for breach of the limited warranty contained herein.

This warranty specifically excludes any product that has been subject to or has defects resulting from:(a)any neglect or misuse by a Customer; (b) an accident, improper application, violation of operating instructions for the Product, or any other Customer-induced damage; (c) the alteration or removal of any Product serial number; (d) any modification or repair to Product (or any component thereof) by any party other than Naxa or a party authorized in writing by Naxa; (e) any damage to Product due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (f) cosmetic damage to the Product caused by normal wear and tear; (g) shipping damage that occurs while the Product is in transit; (h) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions; or (i) any acts of God. Refurbished products are not covered by this Warranty.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where there is a risk that any data stored on Product will be breached or otherwise compromised, or the data stored on Product is relied upon for medical or lifesaving applications. Naxa disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify Naxa for any damages claimed for such uses.

EXCEPT FOR THE EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, ALL PRODUCTS ARE PROVIDED “AS IS”, AND NAXA DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY OF (I) MERCHANTABILITY; (II) FITNESS FOR A PARTICULAR PURPOSE, OR; (III) NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL NAXA BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA, OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF NAXA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, NAXA’S AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction.

All warranty returns must have an RMA number provided by Naxa Customer Support. An RMA number can be obtained by contacting Naxa Customer Support by phone, email, or online by using the RMA ticketing system at www.naxa.com.

Naxa Electronics, Inc.
RMA Processing / Customer Support
2320 E. 49th St., Vernon, CA 90058

Email: support@naxa.com
Phone: (866) 411-6292
Web: www.naxa.com

Hours of Operation:
Monday – Friday
10:00 AM to 5:00 PM PST