





规格: 30*18mm

ACORN SPEAKER

INSTRUCTIONS



KIKKERLAND®



Design by / par MOTZ

FCC ID: 2ACMZ-US66L
NB: C0890

Includes:

1 x Speaker
1 x USB charging cable
1 x 3.5mm audio cable

Specs:

Max output power: 3W
Impedance: 4 ohm
Battery Capacity: 400MAH
Charging: 5V, 500MA
Frequency: 100HZ to 20 KHZ

Charging:

Charge using the USB charging cable. Indicator light will turn red while charging and turn off when product is fully charged. The acorn speaker needs approximately 90 minutes to become fully charged. Battery lasts approximately 4 hours during wireless play, and 5 hours during wired play.

Power:

To power on and off, press and hold the button for approximately 3 seconds until you hear the tone. The indicator light will be turned blue while the speaker is on, even while it is charging.

Wireless Play:

While in your device's bluetooth settings, turn the Acorn Speaker on. Choose to connect with or select "Acorn Speaker" from the menu. You will hear a tone once the speaker has been successfully paired with your device. Once they are connected, use the the button to play and pause your audio. Use your device's volume controls to control the speaker's volume. Max wireless distance is 33ft (10m).

Wired Play:

Use the included audio cable to instantly connect your device to the speaker.

Product name: Acorn Speaker
model: US66L
manufacturer: WEN ZHOU TANY LIGHT INDUSTRY ELECTRONIC CO., LTD

⚠️ WARNING:

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.