INSTRUCTION MANUAL

NX-200/300 TK-5220/5320

THANK YOU!

We are grateful you chose **KENWOOD** for your land mobile radio applications. We believe this easy-to-use transceiver will provide dependable communications to keep personnel operating at peak efficiency.

KENWOOD transceivers incorporate the latest in advanced technology. As a result, we feel strongly that you will be pleased with the quality and features of this product.

NOTICES TO THE USER

WARNING:

- GOVERNMENT LAW PROHIBITS THE OPERATION OF UNLICENSED RADIO TRANSMITTERS WITHIN THE TERRITORIES UNDER GOVERNMENT CONTROL.
- ILLEGAL OPERATION IS PUNISHABLE BY FINE OR IMPRISONMENT OR BOTH.
- REFER SERVICE TO QUALIFIED TECHNICIANS ONLY.
- DO NOT OPERATE YOUR TRANSCEIVER IN EXPLOSIVE ATMOSPHERES (GASES, DUST, FUMES, ETC.).
- TURN OFF YOUR TRANSCEIVER WHILE TAKING ON FUEL, OR WHILE PARKED IN GASOLINE SERVICE STATIONS.

SAFETY:

It is important that the operator is aware of and understands hazards common to the operation of any transceiver.

WARNING:

EXPLOSIVE ATMOSPHERES (GASES, DUST, FUMES, etc.)

Turn off your transceiver while taking on fuel, or while parked in gasoline service stations.

One or more of the following statements may be applicable:

FCC WARNING

This equipment generates or uses radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

INFORMATION TO THE DIGITAL DEVICE USER REQUIRED BY THE FCC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can generate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- · Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer for technical assistance.



ATTENTION (U.S.A. Only):

The RBRC Recycle seal found on **KENWOOD** nickel-cadmium (Ni-Cd) battery packs indicates **KENWOOD**'s voluntary participation in an industry program to collect and recycle Ni-Cd batteries after their operating life has expired. The RBRC program is an alternative to disposing Ni-Cd batteries with your regular refuse or in municipal waste streams, which is illegal in some areas.

For information on Ni-Cd battery recycling in your area, call (toll free) 1-800-8-BATTERY (1-800-822-8837). **KENWOOD**'s involvement in this program is part of our commitment to preserve our environment and conserve our natural resources.

UNPACKING AND CHECKING EQUIPMENT

Note:

The following unpacking instructions are for use by your

KENWOOD dealer, an authorized **KENWOOD** service facility, or the factory.

Carefully unpack the transceiver. We recommend that you identify the items listed in the following table before discarding the packing material. If any items are missing or have been damaged during shipment, file a claim with the carrier immediately.

§ Accessories


| Item | Part Number | Quantity K |
|-----------|-----------------|---------------|
| Belt Clip | J29 - 0730 -*5 | 1 |
| Screw | N30 - 3008 - 60 | 2 |
| Сар | B09 - 0717 - *3 | 1 |
| Screw | N08 - 0564 - *4 | 1 |

Installing/ Removing the Optional Battery Pack

The battery pack is not charged at the factory; charge it before use.

CAUTION:

- DO NOT RECHARGE THE BATTERY PACK IF IT IS ALREADY FULLY CHARGED. DOING SO MAY CAUSE HE LIFE OF THE BATTERY PACK TO SHORTEN OR THE BATTERY PACK MAY BE DAMAGED.
- AFTER RECHARGING THE BATTERY PACK, DISCONNECT IT FROM THE CHARGER. IF THE CHARGER POWER IS RESET (TURNED ON AFTER BEING TURNED OFF), RECHARGING WILL START AGAIN AND THE BATTERY PACK WILL BECOME OVERCHARGED.
- DO NOT SHORT THE BATTERY TERMINALS OR DISPOSE OF THE BATTERY BY FIRE.
- NEVER ATTEMPT TO REMOVE THE CASING FROM THE BATTERY PACK.
- 1 Match the guides of the battery pack with the corresponding grooves on the upper rear of the transceiver, then firmly press the battery pack t
- 2 Flip the safety catch into place to prevent accidentally pressing the release latch and removing the battery.
- **3** To remove the battery pack, lift the safety catch, press the release latch, then pull the battery pack away from the transceiver.



Installing the Antenna


Screw the antenna into the connector on the top of the transceiver by holding the antenna at its base and turning it clockwise until secure.



Installing the Belt Clip


If necessary, attach the belt clip using the two supplied 3 x 6 mm screws.

Notes: If the belt clip is not installed, its mounting location may get hot during continuous transmission or when left sitting in a hot environment.




Installing the Cap over the Speaker/Microphone Jacks

If you are not using an optional KMC-25 speaker/ microphone, install the cover over the univeral connector using the supplied 4×6 mm screw.



Installing the Optional Speaker/ Microphone


- 1 Insert the guide of the speaker/microphone connector into the groove of the universalconnector.
- 2 Secure the connecter in place using the attached screw.



GETTING ACQUAINTED

Knob

| NO. | Name | Lock/ Non Lock | Description | |
|-----|---------------------------------|-------------------|--|--|
| 1 | Power switch/ Volume control | Lock/ Non Lock | Power SW (CCW:Power OFF) Audio Volume adjuster | |
| 2 | Selector Knob | Lock | Programmable default : CH/GID Select | |



Х

Fig. 1 Left Side

Fig.2 Front

<Top Side>

| NO. | Name | Lock/ Non Lock | | Description |
|-----|-------------|-------------------|--------------|----------------------|
| 1 | AUX(Orange) | Non Lock | Programmable | default: No Function |

<Left side>

| NO. | Name | Lock/ Non Lock | Description | |
|-----|--------|-------------------|--------------|--------------------------------|
| 1 | PTT | Non Lock | TX ON/OFF | |
| 2 | Side 1 | Non Lock | Programmable | default: Squelch off momentary |
| 3 | Side 2 | Non Lock | Programmable | default: Backlight |

<Front Side>

| NO. | Name | | Description |
|-----|------|--------------|------------------------|
| 1 | U1 | Programmable | default: Zone Up |
| 2 | D1 | Programmable | default: NoneZone Down |
| 3 | P1 | Programmable | default: None |
| 4 | P2 | Programmable | default: CH/GID Up |
| 5 | P3 | Programmable | default: None |
| 6 | P4 | Programmable | default: None |

LED

| NO. | Name | Description |
|-----|------|--|
| 1 | LED | The LED is three colors. Lights green while receiving at user mode. Light red while transmitting, flashes red when the battery power is low .Lights orange when individual called. |

TERMINAL

Universal connector

Universal connector covering for blindfold mode of resin is possible.

| NO. | Name | Description | I/O |
|-----|-------|-----------------------------------|-----|
| 1 | SSW | Ext/Int Speaker Switch Input | [|
| 2 | SP+ | BTL Output + for External Speaker | 0 |
| 3 | SP- | BTL Output - for External Speaker | 0 |
| 4 | MSW | Ext/Int MIC Switch Input | I |
| 5 | EMC | External MIC Input | I |
| 6 | ME | External MIC GND | - |
| 7 | PTT | External PTT Input | I |
| 8 | PF | Programable Function Key Input | I |
| 9 | OPT | Aux I/O port | I/O |
| 10 | E | GND | - |
| 11 | 5U | 5V | 0 |
| 12 | TXD | Serial Data Output | 0 |
| 13 | RXD | Serial Data Input | I |
| 14 | NC(E) | Not use | - |

Battery Terminal

It's type of spring plate. The minus terminal connect to chassis ground It's mounted rear side of radio and mounting instruction is slide method.

OTHER

Rear


A rail and a hook for battery installation. Space which affixes name plate. Model name plate Screw hole for belt hook installation.

NX-200-K, NX-200-K2, TK-5220-K, TK-5220-K2 FCC ID: ALH378400

IC: 282D-378400

Bottom Battery release lever

Appearance



Appearance with KNB-47L

OPERATING BASICS

§ Switching Power ON/OFF

Turn the **Power** switch/ **Volume** control clockwise to switch the transceiver ON.

Turn the **Power** switch/ **Volume** control counterclockwise to switch the transceiver OFF.

§ Adjusting the Volume

Rotate the **Power** switch/ **Volume** control to adjust the volume.

§ Selecting a Channel

Pressing [<B], [C>] to select a channel.

Pressing [C>] increases the channel number and pressing [<B] decreases it.

§ Making a Call

- 1 Select the desired channel.
- 2 Press the **Side1** key (Programmed function Squelch off) to determine whether or not the current channel is being used.
- If the channel is busy, wait until it becomes free.
- 3 Press and hold the PTT switch, then speak into the microphone in your normal voice.
- For best results, hold the microphone approximately 3 to 4 cm (1 1/2 inches) from your lips.
- 4 Release the PTT switch to receive.

AUXILIARY FEATURES

§ Time-out Timer (TOT)

The TOT is used to automatically inhibit transmission after a specified time elapse. If the PTT switch is held down for longer than specified time, the transceiver will stop transmitting and a tone will sound. Release the PTT switch, then press it again to continue transmitting.

RADIO FREQUENCY ENERGY SAFETY INFORMATION

This **KENWOOD** transceiver has been evaluated and complies with the standards listed below, in regards to Radio Frequency (RF) energy and electromagnetic energy (EME) generated by the transceiver.

- FCC RF exposure limits for Occupational Use Only: RF Exposure limits adopted by the FCC are generally based on recommendations from the National Council on Radiation Protection and Measurements, & the American National Standards Institute.
- FCC OET Bulletin 65 Edition 97-01 Supplement C
- American National Standards Institute (C95.1 1992)
- American National Standards Institute (C95.3 1992)

- WARNING

This KENWOOD transceiver generates RF EME while transmitting. RF EME (Radio Frequency Electric & Magnetic Energy) has the potential to cause slight thermal, or heating effects to any part of your body less than the recommended distance from this radio transmitter's antenna. RF energy exposure is determined primarily by the distance to and the power of the transmitting device. In general, RF exposure is minimized when the lowest possible power is used or transmission time is kept to the minimum required for consistent communications, and the greatest distance possible from the antenna to the body is maintained. The transceiver has been designed for and is classified for *Cocupational Use Only**. Occupational Oontrolled exposure limits are applicable to situations in which persons are exposed to RF energy as a consequence of their employment, and such persons have been made aware of the potential for exposure and can exercise control over their exposure. This means you can use the transceiver only if you are aware of the potential hazards of operating a transceiver and are familiar in ways to minimize these hazards. This transceiver is not intended for use by the general public in uncontrolled environment exposure limits are applicable to situations in which the general public may be exposed to RF energy, or in which the persons who are exposed as a consequence of their employment may not be fully aware of the potential for exposure or cannot exercise control over their exposure.

The following list provides you with the information required to ensure that you are aware of RF exposure and of how to operate this transceiver so that the FCC RF exposure limitations are not exceeded.

- While transmitting (holding the PTT switch or speaking with VOX enabled), always keep the antenna and the radio at least 3 cm (1 3/16 inches) from your body or face, as well as from any bystanders. A LED on the top of the radio shows red when the transmitter is operating in both PTT and VOX modes.
- Do not transmit for more than 50% of the total transceiver use time; transmitting over 50% of the total use time
 may exceed the limits in accordance to the FCC RF exposure requirements. Nominal transceiver operation is
 5% transmission time, 5% reception time, and 90% stand-by time.
- Use only the specified antenna for this transceiver; this may be either the antenna provided with the transceiver or another antenna authorized by KENWOOD.

Use only **KENWOOD** authorized accessories (antennas, battery packs, belt clips, Speaker/ Mics or headsets etc.): When worn on the body, always place the radio in a **KENWOOD** recommended clip or carrying case meant for this product. The use of other than recommended or approved body- worn accessories may result in RF exposure levels which exceed the FCC's occupational/ controlled environment RF exposure limits.



To ensure that your exposure to RF EME is within the FCC limits for occupational use, you must observe and adhere to the above points.

Electromagnetic Interference Compatibility

accordance with airline regulations and/or crew instructions.

Electronic devices are susceptible to electromagnetic interference (EMI) if they are not adequately shielded or designed for electromagnetic compatibility. Because this transceiver generates RF energy, it can cause interference to such equipment.

- Turn OFF your transceiver where signs are posted to do so. Hospitals and health care facilities use
 equipment that is sensitive to electromagnetic radiation.
- equipment that is sensitive to electromagnetic radiation.
 Turn OFF your transceiver while on board an aircraft when so instructed. Use of the transceiver must be in